TECHNICAL MANUAL

OPERATOR'S ORGANIZATIONAL, DIRECT SUPPORT, GENERAL SUPPORT, AND REPORT MAINTENANCE MANUAL (INCLUDING REPAIR PARTS INFORMATION AND SUPPLEMENTAL MAINTENANCE INSTRUCTIONS FOR

CRANE, TRUCK MOUNTED
HYDRAULIC, 25 TON (CCE)
HARNISCHFEGER MODEL MT-250,
NON-WINTERIZED
NSN 3810-00-018-2021
HARNISCHFEGER MODEL MT-250,
WINTERIZED NSN 3810-00-018-2007

HEADQUARTERS. DEPARTMENT OF THE ARMY
6 JUNE 1980

This copy is a reprint which includes current pages from Changes 1 through 3.

Changes in Force 1,2, and 3

CHANGE
NO. 3

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C., *26 June 1992*

Operator's Organizational, Direct Support, and General Support, Maintenance Manual for CRANE, TRUCK MOUNTED, HYDRAULIC, 25-TON (CCE), HARNISCHFEGER MODEL MT-250, NON-WINTERIZED (NSN 3810-00-018-2021) HANISHCHFEGER MODEL MT-250, WINTERIZED (NSN 3810-00-018-2007)

TM 5-3810-293-14&P-3, 6 June 1980, is changed as follows:

1. The title of the manual is changed to read as shown above.
2. Remove old pages and insert new pages.
3. New or changed material is indicated by a vertical bar in the margin of the page.

Remove Pages	Insert Pages
i and ii	i /(ii blank)
Page 53 and Page 54	Page 53 and 54

4. File this change sheet in front of the publication for reference purposes.

Approved for public release; distribution is unlimited.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:

MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army
01963

Distribution:

To be distributed in accordance with DA Form 12-25-E, Block 0571), Operator, Unit, Direct Support and General Support maintenance requirements for TM 5-3810-293-14

Changes in force: C 1 and C 2

CHANGE

NO. 2

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C., *12 July 1991*

OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE MANUAL (INCLUDING REPAIR PARTS INFORMATION AND SUPPLEMENTAL MAINTENANCE INSTRUCTIONS) FOR CRANE, TRUCK MOUNTED, HYDRAULIC, 25 TON (CCE) HARNISCHFEGER MODEL MT-250, NON-WINTERIZED NSN 3810-00-018-2021 HARNISCHFEGER MODEL MT-250, WINTERIZED NSN 3810-00-018-2007

TM 5-3810-293-14&P-3, 6 June 1980, is changed as follows:

Page 5. The following paragraph is added at the beginning of the page below "GENERAL DESCRIPTION":

A decal has been developed that warns of NBC exposure. It is to be positioned in a noticeable place on or near the air cleaner or air filter housing. You may order the decal using part number 12296626, CAGEC 19207. Refer to TB 43-0219 for further information. Add the decal to the air cleaner tray (Figure 9 and Figure 10), the United Specialties Dry Type Air Cleaner body (Figure 11), and the Farr Dry Type Air Cleaner housing (Figure 12).


WARNING
IF NBC EXPOSURE IS SUSPECTED ALL AIR FILTER MEDIA WILL BE HANDLED BY PERSONNEL WEARING FULL NBC PROTECTIVE EQUIPMENT. SEE OPERATOR/MAINTENANCE MANUAL.
7690-01-114-3702

Figure 1.1 - NBC Warning Decal

Add the NBC exposure WARNING on each of the following pages:

On *page 17*, preceding the paragraph "Air Cleaners"; on *page 114* below "Air Inlet Restriction"; on *page 117* in the section entitled "TEMPORARY STORAGE (30 days of less)", preceding paragraph 4; on *page 118*, preceding paragraph 14; on *page 119*, preceding paragraph 11; in that portion of the book entitled "SERIES 53, SERVICE MANUAL, DETROIT DIESEL ENGINES", in Section 3, at *Sec. 3.1, page 1*, under "AIR CLEANER"; at *Sec. 15.1,page 5,* in Item 10; at *Sec 15.2, page 9*, preceding paragraph 8; at *Sec. 15.3, page 1,* under "TEMPORARY STORAGE (30 days or less)", preceding paragraph 4; and at *Sec. 15.3, page 3*, under "PROCEDURE FOR RESTORING AN ENGINE TO SERVICE WHICH HAS BEEN IN EXTENDED STORAGE", preceding paragraph 11:

WARNING

If NBC exposure is suspected, all air filter media should be handled by personnel wearing protective equipment. Consult your unit NBC Officer or NBC NCO for appropriate handling or disposal Instructions.

By Order of the Secretary of the Army:

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:
PATRICIA P. HICKERSON
Brigadier General, United States Army
The Adjutant General

Distribution:
To be distributed IAW DA Form 12-25-E (Block No. 0571) Operator, Unit, Direct Support and General Support maintenance requirements for TM 5-3810-293-14&P-3.

CHANGE
NO.1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., *10 October, 1986*

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT,
GENERAL SUPPORT, AND DEPOT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS INFORMATION AND SUPPLEMENTAL
MAINTENANCE INSTRUCTIONS)
FOR
CRANE, TRUCK MOUNTED, HYDRAULIC, 25 TON (CCE)
HARNISCHFEGER MODEL MT-250, NON-WINTERIZED
NSN 3810-00-018-2021**

**HARNISCHFEGER MODEL MT-250, WINTERIZED
NSN 3810-00-018-2007**

TM 5-3810-293-14&P-3, 6 June 1980, is changed as follows:

1. Part Three-Engine Parts Catalog in this manual is replaced by TM5-3810-293-20P, ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS, and TM5-3810-293-34P, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS.

File this change sheet in front of the publication for reference purposes.

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR
General, United States Army
Chief of Staff

Official:

R.L. DILWORTH
Brigadier General, United States Army
The Adjutant General

Distribution:
To be distributed in accordance with DA Form 12-25A-R, Operator, Organizational, Direct Support and General Support Maintenance requirements for Cranes, Truck Mounted, Hydraulic, 25-T, Model MT-250.

TECHNICAL MANUAL
No. 5-3810-293-14&P-3

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C., *6 June 1980*

Operator Organizational, Direct Support, General Support, and Depot Maintenance Manual for CRANE, TRUCK MOUNTED, HYDRAULIC, 25-TON (CCE), HARNISCHFEGER MODEL MT-250, NON-WINTERIZED (NSN 3810-00-018-2021) (NSN 3810-00-018-2007) HANISHCHFEGER MODEL MT-250, WINTERIZED

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual, direct to: Commander, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MB, Warren, MI 48397-5000. A reply will be furnished to you.

Part One. ENGINE OPERATOR'S MANUAL.....

Part Two ENGINE SERVICE MANUAL

NOTE: Part Three, ENGINE PARTS CATALOG, has been replaced by TM 5-381 0-293-20P and TM 5-3810-293-34P.

NOTE: Part Three, ENGINE PARTS CATALOG, has been replaced by TM 5-3810-293-20P and TM 5-3810-293-34P.

NOTE: Refer to TM 5-3810-293-14&P-1 for Crane Operator's Manual, Weighload Automatic Safe Load Indicator.

NOTE: Refer to TM 5-3810-293-14&P-2 for Crane Shop Manual, Front Axle, Transmissions, and Winches.

This technical manual is an authentication of the manufacturers' commercial literature and does not conform with the format and content specified on AR 310-3, Military Publications. This technical manual does, however, contain available Information that is essential to the operation and maintenance of the equipment.

Approved for public release; distribution is unlimited.

PART ONE

ENGINE OPERATOR'S MANUAL

6SE337 (Rev. 9/74)

Operators Manual

Series 53 Engines

Detroit Diesel Allison
Division of General Motors Corporation
Detroit, Michigan 48228

Printed in U.S.A.

© 1974 General Motors Corp.

TO THE OPERATOR

This manual contains instructions on the operation and preventive maintenance of your Detroit Diesel engine. Sufficient descriptive material, together with numerous illustrations, is included to enable the operator to understand the basic construction of the engine and the principles by which it functions. This manual does not cover engine repair or overhaul.

Whenever possible, it will pay to rely on an authorized *Detroit Diesel Allison Service* Outlet for all your service needs from maintenance to major parts replacement. There are over 1500 authorized service outlets in the U.S. and Canada. They stock factory original parts and have the specialized equipment and personnel with technical knowledge to provide skilled and efficient workmanship.

The operator should familiarize himself thoroughly with the contents of the manual before running an engine, making adjustments, or carrying out maintenance procedures.

The information, specifications and illustrations in this publication are based on the information in effect at the time of approval for printing. Generally, this publication is reprinted annually. It is recommended that users contact an authorized Detroit Diesel Allison Service Outlet for information on the latest revision. The right is reserved to make changes at any time without obligation.

WARRANTY

The applicable engine warranty is contained in the form entitled POLICY ON OWNER SERVICE, available from authorized Detroit Diesel Allison Service Outlets.

TABLE OF CONTENTS

SUBJECT PAGE

DESCRIPTION
Principles of Operation ... 4
General Description ... 5
Model Description ... 6
General Specifications ... 8
Engine Model and Serial Number Designation ... 9
Built-In Parts Book ... 9
Cross Section Views of Engine ... 10

ENGINE SYSTEMS
Fuel System ... 13
Air System ... 17
Lubricating System ... 22
Cooling System ... 25

ENGINE EQUIPMENT
Instrument Panel, Instruments and Controls ... 31
Engine Protective Systems ... 33
Electrical Starting System ... 37
Hydraulic Starting System ... 38
Cold Weather Starting Aids ... 41
Governors ... 44
Transmissions ... 44

OPERATING INSTRUCTIONS
Engine Operating Instructions ... 47
A.C. Power Generator Set Operating Instructions ... 51

LUBRICATION AND PREVENTIVE MAINTENANCE
Lubrication and Preventive Maintenance ... 55
Fuel, Lubricants and Coolants ... 66

ENGINE TUNE-UP PROCEDURES
Engine Tune-Up Procedures ... 73
Exhaust Valve Clearance Adjustment ... 74
Timing Fuel Injector ... 76
Limiting Speed Mechanical Governor (In-Line Engines) ... 77
Limiting Speed Mechanical Governor (6V-53 Engine) ... 82
Variable Speed Mechanical Governor (In-Line Open Linkage) ... 87
Variable Speed Mechanical Governor (In-Line Enclosed Linkage) ... 91
Variable Speed Mechanical Governor (6V-53 Engine) ... 96
Supplementary Governing Device Adjustment ... 101
Hydraulic Governor (In-Line Engine) ... 106
Hydraulic Governor (6V-53 Engine) ... 109

TROUBLE SHOOTING ... 111

STORAGE ... 117

BUILT-IN PARTS BOOK ... 121

ALPHABETICAL INDEX ... 145

DESCRIPTION

PRINCIPLES OF OPERATION

The diesel engine is an internal combustion power unit, in which the heat of fuel is converted into work in the cylinder of the engine.

In the diesel engine, air alone is compressed in the cylinder; then, after the air has been compressed, a charge of fuel is sprayed into the cylinder and ignition is accomplished by the heat of compression.

The Two-Cycle Principle

In the two-cycle engine, intake and exhaust take place during part of the compression and power strokes respectively, as shown in Fig. 1. In contrast, a four-cycle engine requires four piston strokes to complete an operating cycle; thus, during one half of its operation, the four-cycle engine functions merely as an air pump.

A blower is provided to force air into the cylinders for expelling the exhaust gases and to supply the cylinders with fresh air for combustion. The cylinder wall contains a row of ports which are above the piston when it is at the bottom of its stroke. These ports admit the air from the blower into the cylinder as soon as the rim of the piston uncovers the ports as shown in Fig. 1 (scavenging).

The unidirectional flow of air toward the exhaust valves produces a scavenging effect, leaving the cylinders full of clean air when the piston again covers the inlet ports.

As the piston continues on the upward stroke, the exhaust valves close and the charge of fresh air is subjected to compression as shown in Fig. 1 (compression).

Shortly before the piston reaches its highest position, the required amount of fuel is sprayed into the combustion chamber by the unit fuel injector as shown in Fig. 1 (power). The intense heat generated during the high compression of the air ignites the fine fuel spray immediately. The combustion continues until the injected fuel has been burned.

The resulting pressure forces the piston downward on its power stroke. The exhaust valves are again opened when the piston is about halfway down, allowing the burned gases to escape into the exhaust manifold as shown in Fig. 1 (exhaust). Shortly thereafter, the downward moving piston uncovers the inlet ports and the cylinder is again swept with clean scavenging air. This entire combustion cycle is completed in each cylinder for each revolution of the crankshaft, or, in other words, in two strokes; hence, it is a "two-stroke cycle".



Fig. 1 - The Two-Stroke Cycle

GENERAL DESCRIPTION

The two-cycle diesel engines covered in this manual have the same bore and stroke and many of the major working parts such as injectors, pistons, connecting rods, cylinder liners and other parts are interchangeable.

The In-line engines, including the inclined marine models, include standard accessories such as the blower, water pump, governor and fuel pump, which, on some models, may be located of either side of the engine regardless of the direction the crankshaft rotates. Further flexibility in meeting installation requirements is achieved with the cylinder head which can be installed to accommodate the exhaust manifold on either side of the engine.

The V-type engine uses many In-line engine parts, including the 3-53 cylinder head. The blower is mounted on top of the engine between the two banks of cylinders and is driven by the gear train. The governor is mounted on the rear end of the 6V-53 blower, The meaning-f each digit in the model numbering system is shown i Figs. 2 and 3. The letter L or R indicates left or right-hand engine rotation as viewed from the front of the engine. The letter A,B,C or D designates the blower and exhaust manifold location on the In-line engines as viewed from the rear of the engine while the letter A or C designates the location of the oil cool-t and starter on the 6V-53 engine.

Each engine is equipped with an oil cooler, replaceable element type lubricating oil filter, fuel oil strainer, fuel oil filter, an air cleaner or air silencer, a governor, a heat exchanger and raw water pump or a fan and radiator, and a starting motor.

Full pressure lubrication is supplied to all main bearings, connecting rod bearings, and camshaft bearings, and to other moving parts.

Oil is drawn by suction from the oil pan through the intake screen and pipe to the oil pump where it is pressurized and delivered to the oil filter and the oil cooler. From the oil cooler, the oil enters oil galleries in the cylinder block and cylinder head for distribution to the main bearings, connecting rod bearings, camshaft bearings, rocker arm mechanism and other functional parts.

The cooling system has a centrifugal water pump which circulates the engine coolant through the oil cooler and water jackets. The engine temperature is regulated by a thermostat(s).

Fuel is drawn from the supply tank through the fuel strainer and enters a gear type fuel pump at the inlet side. Upon leaving the pump under pressure, the fuel is forced through the fuel filter into the inlet manifold where it passes through fuel pipes into the inlet side of the fuel injectors. The fuel is filtered through elements in the injectors and then atomized through small spray tip orifices into the combustion chamber. Excess fuel is returned to the fuel tank through the fuel outlet galleries and connecting lines.

Air for scavenging and combustion is supplied by a blower which pumps air into the engine cylinders via the air box and cylinder liner ports. All air entering the blower first passes through an air cleaner or air silencer.

The engine may be started by either a hydraulic or an electric starting system.

The engine speed is regulated by a mechanical or hydraulic type engine governor, depending upon the engine application.



Fig. 2 - In-Line Engine Model Description, Rotation and Accessory Arrangement



Fig. 3 - 6V Engine Model Description, Rotation and Accessory Arrangement

GENERAL SPECIFICATIONS

	3-53	4-53	6V-53
Number of Cylinders	3	4	6
Bore	3.875 in	3.875 in	3.875 in.
Stroke	4.5 in	4.5 in	4.5 in.
Compression Ratio (Nominal)(Standard Engines)	17 to 1	17 to 1	17 to 1
Compression Ratio (Nominal)("N" Engines)	21 to 1	21 to 1	21 to 1
Total Displacement - Cubic Inches	159	212	318
Number of Main Bearings	4	5	4



Fig. 4 - Series 53 Cylinder Arrangement

ENGINE MODEL AND SERIAL NUMBER DESIGNATION



Fig. 5 Typical Model and Serial Numbers as Stamped on Cylinder Block (In-Line Engine)



Fig. 6 Typical Model and Serial Numbers as Stamped on Cylinder Block (6V Engine)

On the In-line engines, the model number and serial number are stamped on the right-hand side of the cylinder block in the upper rear corner (Fig. 5). The model number and serial number on the V-type engine is located on the top right-hand front corner of the cylinder block, as viewed from the rear of the engine (Fig. 6).

An option plate, attached to the valve rocker cover, is also stamped with the engine serial number and model number and, in addition, lists any optional equipment used on the engine (Fig. 7).

With any order for parts, the engine model number and serial number must be given. In addition, if a type number is shown on the option plate covering the equipment required, this number should also be included on the parts order.

Power take-off assemblies, torque converters, hydraulic marine gears, etc. may also carry name plates pertaining to the particular assembly to which they are attached. The information on these name plates is useful when ordering Darts for these assemblies.



Fig. 7 - Option Plate

BUILT - IN PARTS BOOK

The *Built-In Parts Book* is an anodized aluminum plate (Option Plate) that fits into a retainer on the engine valve rocker cover and contains the necessary information required when ordering parts. It is recommended that the engine user read the section or the *Built-In Parts Book* in order to take full advantage of the information provided on the engine option plate.

Numerous exploded view type illustrations are included to assist the user in identifying and ordering service parts.



Cross Section Views of a Typical In-Line Engine



Cross Section Views of a Typical 6V-53 Engine

ENGINE SYSTEMS

The Series 53 Detroit Diesel engines incorporate four basic systems which direct the flow of fuel, air, lubricating oil, and engine coolant. A brief description of each of these systems and their components, and the necessary maintenance and adjustment procedures are given in this manual.

FUEL SYSTEM

The fuel system (Figs. 1 and 2) consists of the fuel injectors, fuel pipes, fuel manifolds (integral with the cylinder head), fuel pump, fuel strainer, fuel filter and the necessary connecting fuel lines.

On In-line engines, a restricted fitting is located in the cylinder head fuel return manifold outlet to maintain pressure within the fuel system. On V-type engines, this restricted fitting is located in the left-bank cylinder head.

Fuel is drawn from the supply tank through the fuel strainer and enters the fuel pump at the inlet side.

Upon leaving the pump under pressure, the fuel is forced through the fuel filter and into the fuel inlet manifold where it passes through fuel pipes into the inlet side of each fuel injector. The fuel is filtered through elements in the injectors and atomized through small spray tip orifices into the combustion chamber. Surplus fuel, returning from the injectors, passes through the fuel return manifold and connecting fuel lines back to the fuel tank.

The continuous flow of fuel through the injectors helps to cool the injectors and remove air from the fuel system.



Fig. 1 - Schematic Diagram of Typical Fuel System - In-Line Engine

A check valve may be installed between the fuel strainer and the source of supply as optional equipment to prevent fuel drain back when the engine is not running.

Fuel Injector

The fuel injector combines in a single unit all of the parts necessary to provide complete and independent fuel injection at each cylinder. The injector creates the high pressure necessary for fuel injection, meters the proper amount of fuel, atomizes the fuel and times the injection into the combustion chamber.

Since the injector is one of the most important and carefully constructed parts of the engine, it is recommended that the engine operator replace the injector as an assembly if it is not operating properly. Authorized Detroit Diesel Allison Service Outlets are properly equipped to service injectors.



Fig 2 - Schematic Diagram of Typical Fuel System - V-type Engine



Fig. 3 - Removing Injector from Cylinder Head

Remove Injector

An injector may be removed in the following manner:

1. Clean and remove the valve rocker cover.

2. Disconnect the fuel pipes from both the injector and the fuel connectors.

3. Immediately after removing the fuel pipes, cover the injector inlet and outlet fittings with shipping caps to prevent dirt from entering.

4. Turn the crankshaft manually in the direction of engine rotation or crank the engine with the starting motor, if necessary, until the rocker arms for the particular cylinder are aligned in a horizontal plane.

> **CAUTION: If a wrench is used on the crankshaft bolt at the front of the engine, do not turn the crankshaft in a left-hand direction of rotation as the bolt will be loosened. Remove the starting motor and use a pry bar against the teeth of the flywheel ring gear to turn the crankshaft.**

5. Remove the two rocker shaft bracket bolts and swing the rocker arm assembly away from the injector and valves.

6. Remove the injector clamp bolt, washer and clamp.

7. Loosen the inner and outer adjusting screws on the injector rack control lever and slide the lever away from the injector.

8. Free the injector from its seat as shown in Fig. 3 and lift it from the cylinder head.

9. Cover the injector hole in the cylinder head to keep foreign particles out of the cylinder.

Install Injector

Before installing an injector, be sure the beveled seat of the injector tube is free from dirt particles and carbon deposits.

A new or reconditioned injector may be installed by reversing the sequence of operations given above for removal.

Be sure the injector is filled with fuel oil. If necessary, add clean fuel oil at the inlet filter until it runs out the outlet filter.

> **CAUTION: On four valve cylinder heads, there is a possibility of damaging the exhaust valves if the exhaust valve bridge is not resting on the ends of the exhaust valves when tightening the rocker shaft bracket bolts. Therefore, note the position of the exhaust valve bridge before, during and after tightening the rocker shaft bracket bolts.**

Do not tighten the injector clamp bolt to more than 20-25 lb.-ft torque, as this may cause the moving parts of the injector Jo bind. Tighten the rocker shaft bolts to 50-55 lb.-ft torque.

Align the fuel pipes and connect them to the injector and the fuel connectors. Us socket J 8932-01 and a torque wrench to tighten the fuel pipe nuts to 12-15 lb. ft torque.

> **CAUTION: o not bend the fuel pipes and do not exceed the specified torque. Excessive tightening will twist or fracture the flared ends of the fuel pipes and result in leaks. Lubricating oil diluted by fuel oil can cause serious damage to the engine bearings.**

Time the injector, position the injector rack control lever and adjust the exhaust valve clearance (cold setting) as outlined in the engine tune-up procedure. If all of the injectors have been replaced, perform a complete tune-up on the engine

Fuel Pump

A positive displacement gear-type fuel pump is attached to the governor or blower on the In-line engines and to the flywheel housing on the V-type engines.

A spring-loaded relief valve. incorporated in the pump body, normally remains In the closed position, operating only when the pressure on the outlet side (to the fuel filter) becomes excessive due to a plugged filter or fuel line.

The fuel pump incorporates two oil seals. Two tapped holes are provided in the underside of the pump body, between the oil seals, to permit a drain tube to be attached. If fuel leakage exceeds one drop per minute, the seals must be replaced. An authorized Detroit Diesel Allison Service Outlet is properly equipped to replace the seals.

Fuel pumps are furnished in either left or right-hand rotation, according to the engine model, and are stamped RH or LH. These pumps are not interchangeable and cannot be rebuilt to operate in an opposite rotation.

Fuel Strainer and Fuel Filter

A replaceable-element type fuel strainer and fuel filter (Fig. 4) are used in the fuel system to remove impurities from the fuel. The strainer removes the larger particles and the filter removes the small foreign particles.

The fuel strainer and fuel filter are basically identical in construction, both consisting of a cover, shell and replaceable element. Since the fuel strainer is placed between the fuel supply tank and the fuel pump, it functions under suction; the fuel filter, which is installed between the fuel pump and the fuel inlet manifold in the cylinder head, operates under pressure.

Replace the elements as follows:

1. With the engine shut down, place a suitable container under the fuel strainer or filter and open the drain cock. The fuel will drain more freely if the cover nut is loosened slightly.

2. Support the shell, unscrew the cover nut and remove the shell and element.



Fig. 4 - Typical Fuel Strainer and Filter Mounting

3. Remove and discard the element and gasket. Clean the shell with fuel oil and dry it with a cloth or compressed air.

4. Place a new element, which has been thoroughly soaked in clean fuel oil, over the stud and push it down on the seat. Close the drain cock and fill the shell approximately two-thirds full with clean fuel oil.

5. Affix a new shell gasket, place the shell and element into position under the cover and start the cover nut on the shell stud.

6. Tighten the cover nut only enough to prevent fuel leakage.

7. Remove the plug in the strainer or filter cover and fill the shell with fuel. Fuel system primer J 5956 may be used to prime the fuel system.

8. Start and operate the engine and check the fuel system for leaks.

Spin-On Type Fuel Filter

A spin-on fuel strainer and fuel filter is used on certain engines. The spin-on filter cartridge consists of a shell, element and gasket combined into a unitized replacement assembly. No separate springs or seats are required to support the filters.

The filter covers incorporate a threaded sleeve to accept the spin-on filter cartridges. The word "Primary" is cast on the fuel strainer cover and the word "Secondary" is cast on the fuel filter cover for identification.

No drain cocks are provided on the spin-on filters. Where water is a problem, it is recommended that a water separator be installed. Otherwise, residue may be drained by removing and inverting the filter. Refill the filter with clean fuel oil before reinstalling it.

A 1 "diameter twelve-point nut on the bottom of the filter is provided to facilitate removal and installation.

Replace the filter as follows:
1. Unscrew the filter (or strainer) and discard it.

2. Fill a new filter replacement cartridge about two thirds full with clean fuel oil. Coat the seal gasket lightly with clean fuel oil.

3. Install the new filter assembly and tighten it to two thirds of a turn beyond gasket contact.

4. Start the engine and check for leaks.

Fuel Tank

Refill the fuel tank at the end of each day's operation to prevent condensation from contaminating the fuel.

> **CAUTION:A galvanized steel tank should never be used for fuel storage because the fuel oil reacts chemically with the zinc coating to form powdery flakes which quickly clog the fuel strainer and filter and damage the fuel pump and the fuel injectors.**

AIR SYSTEM

In the scavenging system used in two-cycle engines, illustrated in Figs. 5 and 6, a charge of air is forced into the cylinders by the blower and thoroughly sweeps out all of the burned gases through the exhaust valve ports. This air also helps to cool the internal engine parts, particularly the exhaust valves. At the beginning of the compression stroke, each cylinder is filled with fresh, clean air which provides for efficient combustion.

The air, entering the blower from the air silencer or air cleaner, is picked up by the blower rotor lobes and carried to the discharge side of the blower. The continuous discharge of fresh air from the blower enters the air chamber of the cylinder block and sweeps through the intake ports of the cylinder liners.

The angle of the ports in the cylinder liner creates a uniform swirling motion to the intake air as it enters the cylinder. This motion persists throughout the compression stroke and facilitates scavenging and combustion.

Air Cleaners

Several types of air cleaners are available for use with industrial engines. The light-duty oil bath air cleaner is used on most models. However, a heavy-duty oil bath type or a dry type air cleaner may be installed where the engine is operating in heavy dust concentrations.



Fig. 5 - Air Intake System Through Blower and Engine (In-line Engine)

The air cleaners are designed for fast, easy disassembly to facilitate efficient servicing. Maximum protection of the engine against dust and other forms of air contamination is possible if the air cleaner is serviced at regular intervals.

The light-duty oil bath type air cleaner (Fig. 7) consists of a metal wool cleaning element supported inside of a housing which contains an oil reservoir. A chamber beneath, the oil reservoir serves as a silencer for the incoming air to the blower. Air is drawn into the cleaner by the blower and passes over the top of the oil bath, where a major portion of the dirt is trapped, then up through the metal wool, where the finer particles are removed, and then down the central duct to the blower.

The heavy-duty oil bath type air cleaner (Fig. 8) consists of the body and fixed filter assembly which filters the air and condenses the oil from the air stream so that only dry air enters the engine. The condensed oil is returned to the cup where the dirt settles out of the oil and the oil is recirculated. A removable element assembly removes a major part of the dust from the air stream thereby decreasing the dust load to the fixed element. An inner cup, which can be removed from the outer (oil cup), acts as a baffle in directing the oil-laden air to the element and also controls the amount of oil in circulation and meters the oil to the element. The oil cup supports the inner cup and is a reservoir for oil and a settling chamber for dirt.

Service the light-duty oil bath air cleaner as follows



Fig. 6 · Air Intake System Through Blower and Engine (6V-53 Engine)



Fig. 7 Light-Duty Oil Bath Air Cleaner

1. Loosen the wing bolt and remove the air cleaner assembly from the air inlet housing. The cleaner may then be separated into two sections; the upper section or body assembly contains the filter element, the lower section consists of the oil cup, removable inner cup or baffle and the center tube.

2. Soak the body assembly and element in fuel oil to loosen the dirt, then flush the element with clean fuel oil and allow it to drain thoroughly.

3. Pour out the oil, separate the inner cup or baffle from the oil cup. remove the sludge and wipe the baffle and outer cup clean.

4. Push a lint-free cloth through the center tube to remove dirt or oil.

5 Clean and check all of the gaskets and sealing surfaces to ensure air tight seals.

6. Refill the oil cup to the oil level mark only, install the baffle, and reassemble the air cleaner.

7. Check the air inlet housing before installing the air cleaner assembly on the engine. The inlet will be dirty if air cleaner servicing has been neglected or if dust-laden air has been leaking past the air cleaner or air inlet housing seals.

8. Make sure that the air cleaner is seated properly on the inlet housing and the seal is installed correctly.

Tighten the wing bolt until the air cleaner is securely mounted.

Service the heavy-duty oil bath air cleaner as follows:

1. Loosen the wing nuts and detach the lower portion of the air cleaner assembly.

2. Remove the detachable screen by loosening the wing nuts and rotating the screen one-quarter turn.

One of the most important steps in properly cleaning the tray type oil bath air cleaner is a step that is most overlooked. Unless the filter tray is thoroughly cleaned, satisfactory performance of the engine cannot be realized. The presence of fibrous material found in the air is often underestimated and is the main cause of the malfunctioning of heavy-duty air cleaners. This material comes from plants and trees during their budding season and later from airborne seed from the same sources. Figure 9 illustrates the severity of plugging in a tray that is 50% plugged. The solid black areas in the mesh are accumulations of this fibrous material. When a tray is plugged in this manner, washing in a solvent or similar washing solution will not clean it satisfactorily. It must be blown out with high pressure air or steam to remove the material that accumulates between the layers of screening. When a clean tray is held up to the light, an even pattern of light should be visible.



Fig. 8 - Heavy-Duty Oil Bath Air Cleaner

It may be necessary, only as a last resort, to burn off the lint. Extreme care must be taken to prevent melting the galvanized coating in the tray screens. Some trays have equally spaced holes in the retaining baffle. Check to make sure that they are clean and open. Figure 10 illustrates a thoroughly cleaned tray. The dark spots in the mesh indicate the close overlapping of the mesh and emphasize the need for using compressed air or steam. It is suggested that users of heavy-duty air cleaners have a spare tray on hand to replace the tray that requires cleaning. Having an extra tray available makes for better service and the dirty tray can be cleaned thoroughly as recommended. Spare trays are well worth their investment.

3. Pour out the oil, separate the inner cup or baffle from the oil or outer cup, remove the sludge and wipe the baffle and outer cup clean.

4. Clean and inspect the gaskets and sealing surfaces to ensure an air tight seal.

5. Reinstall the baffle in the oil cup and refill to the proper oil level with the same grade of oil being used in the engine.

6. Remove the hood and clean by brushing, or by blowing out with compressed air. Push a lint-free cloth through the center tube to remove dirt or oil from the walls.

7. Inspect the lower portion of the air cleaner body and center tube each time the oil cup is serviced. If there are any indications of plugging, the body assembly should be removed from the engine and cleaned by soaking and then flushing with clean fuel oil. Allow the unit to drain thoroughly.



Fig. 9. Air Cleaner Tray (Plugged) Engine Systems



Fig. 10. Air Cleaner Tray (Clean)

8. Place the removable element in the body assembly.

Install the body if it was removed from the engine for servicing.

9. Install the outer cup and baffle assembly. Be sure the cup is tightly secured to the body assembly.

All oil bath air cleaners should be serviced as operating conditions warrant. At no time should more than 1/2"of "sludge" be allowed to form in the oil cup or the area used for sludge deposit, nor should the oil cup be filled above the oil level mark.

The *United Specialties dry-type air cleaner* shown in Fig. 11 consists of a body, dust unloader and element clamped to a base.

Air is drawn through the cleaner intake pipe and is automatically set into a circular motion. This positive spinning of the dirty air "throws out" the heavier particles of dust and dirt where they are collected in the dust port and then expelled through the dust unloader. The circular action continues even during low air intake at engine idle speeds.

The *United Specialties dry-type air cleaner* should be serviced, as operating conditions warrant as follows:



Fig. 11 - United Specialties Dry Type Air Cleaner

1. Loosen the clamp screw and check the dust unloader for obstruction or damage.

2. Unlock the spring clamps that hold the cleaner body to the cleaner base which is bolted to the air inlet housing. Remove the body and then remove the element from the cleaner base.

3. The paper pleated air cleaner element can be cleaned as follows:

a. For a temporary expedient in the field, tap the side or end of the element carefully against the palm of your hand.

CAUTION: Do not tap the element against a hard surface. This could damage the element.

b. Compressed air can be used when the major contaminant is dust. The compressed air (not to exceed 100 psi) should be blown through the element in a direction opposite to the normal air flow. Insert the air nozzle inside of the element and gently tap and blow out the dust with air. When cleaning the dust from the outside of the element, hold the nozzle at least 6" from the element.

c. Wash the element if compressed air is not available, or when the contaminant is carbon, soot, oily vapor or dirt which cannot be removed with compressed air.

d. Agitate the element in warm water containing a non-sudsing detergent.

CAUTION: Do not use water hotter than your hand can stand, solvents, oil, fuel oil or gasoline.

Preceding the washing, it helps to direct air (not exceeding 100 psi) through the element in a direction opposite the normal air flow to dislodge as much dust as possible. Reverse flush with a stream of water (not exceeding 40 psi) until the water runs clean to rinse all

 loosened foreign material from the element. Shake out excess water from the element and allow it to dry thoroughly.

CAUTION: Do not attempt to remove excess water by using compressed air.

4. Inspect the cleaned element with a light bulb after each cleaning for damage or rupture. The slightest break in t(e element will admit sufficient airborne dirt to cause rapid failure of piston rings. If necessary, replace the element.

5. Inspect the gasket on the end of the element. If the gasket is damaged or missing, replace the element.

6. Install the element on the base with the gasket side of the element down against the base. Place the body over the element and base and tighten the spring clamps by hand.

7. Replace the element after 10 washings or I year of service, whichever comes first, or any time damage is noted.

8. Install the dust unloader and tighten the clamp.

The *Farr dry-type air cleaner* (Fig. 12) is designed to provide highly efficient air filtration under all operating conditions and is not affected by engine speed. The cleaner assembly consists of a cleaner panel with a replaceable impregnated paper filter element.

The cleaner panel and replaceable filter element are held together in a steel housing with fasteners.



Fig. 12 - Farr Dry Type Air Cleaner

The deflector vanes impart a swirling motion to the air entering the air cleaner and centrifuge the dust particles against the walls of the tubes. The dust particles are then carried to the dust bin at the bottom of the cleaner by approximately 10% bleed-off air and are finally discharged into the atmosphere. The cleaner panel is fully effective at either high or low velocities.

The remainder of the air in the cleaner reverses direction and spirals back along the discharge tubes again centrifuging the air. The filtered air then reverses direction again and enters the replaceable filter element through the center portion of the discharge tubes. The air is filtered once more as it passes through the pleats of the impregnated paper element before leaving the outlet port of the cleaner housing.

The cleaner panel tends to be self-cleaning. However, it should be inspected and any accumulated foreign material removed during the periodic replacement of the impregnated paper filter element. Overloading of the paper element will not cause dirt particles to bypass the filter and enter the engine, but will result in starving the engine for air.

The filter element should be replaced, as operating conditions warrant, as follows:

1. Loosen the wing nuts on the fasteners and swing the retaining bolts away from the cleaner panel.

2. Lift the cleaner panel away from the housing and inspect it. Clean out any accumulated foreign material.

3. Withdraw the paper filter element and discard it.

4. Install a new filter element.

5. Install the cleaner panel and secure it in place with the fasteners.

Air Silencer

The air silencer, used on some marine engines, is bolted to the intake side of the blower housing. The silencer has a perforated steel partition welded in place parallel with the outside faces, enclosing flameproof, felted cotton waste which serves as a silencer for air entering the blower.

While no servicing is required on the air silencer proper, it may be removed when necessary to replace the air inlet screen. This screen is used to filter out any Engine Systems large foreign particles which might seriously damage the blower assembly.

Air Box Drains

During normal engine operation, water vapor from the air charge, as well as a slight amount of fuel and lubricating oil fumes, condenses and settles on the bottom of the air box. This condensation is removed by the air box pressure through air box drain tubes mounted on the side of the cylinder block.

The air box drains must be open at all times. With the engine running, a periodic check is recommended for air flow from the air box drain tubes. Liquid accumulation on the bottom of the air box indicates a drain tube may be plugged. Such accumulations can be seen by removing the cylinder block air box cover(s) and should be wiped out with rags or blown out with compressed air. Then remove the drain tubes and connectors from the cylinder block and clean them thoroughly.

Some engines are equipped with an air box drain check valve. Refer to the Lubrication and Preventive Maintenance section of this manual for service instructions.

Crankcase Ventilation

Harmful vapors which may form within the engine are removed from the crankcase, gear train and valve compartment by a continuous, pressurized ventilation system.

A slight pressure is maintained within the engine crankcase by the seepage of a small amount of air from the airbox past the piston rings. This air sweeps up through the engine and is drawn off through a crankcase breather.

In-line engines are equipped with a breather assembly which is mounted on the rocker cover or the flywheel housing. The 6V engines incorporate a breather assembly mounted inside of the upper engine front cover.

The wire mesh pad (element) in the breather assemblies should be cleaned if excessive crankcase pressure is observed. If it is necessary to clean the element, remove the breather housing from the flywheel housing (In-line engines) and the upper engine front cover (6V engines). Wash the element in fuel oil and dry it with compressed air. Reinstall the element and the breather assembly.

LUBRICATING SYSTEM

The Series 53 engine lubricating system, illustrated in Figs. 15 and 16, includes an oil intake screen and tube assembly, an oil pump, a pressure regulator, a full-flow oil filter or by-pass filter with by-pass valve; and an oil cooler with a by-pass valve.

Lubricating oil from the pump passes from the lower front cover through short oil galleries in the cylinder block. From the block, the oil flows to the full-flow oil filter, then through the oil cooler (if used) and back into the front engine cover and cylinder block oil galleries for distribution to the various engine bearings. The drains from the cylinder head(s) and other engine parts lead back to the oil pan.

Oil pressure is regulated by a pressure relief valve mounted in the engine front cover. Oil cooler and oil filter by-pass valves prevent the stoppage of oil flow if these items become plugged.

Oil Filters

Each engine is equipped with a full-flow type lubricating oil filter (Figs. 13 and 14). If additional filtering is required, a by-pass type oil filter may also be installed.

All of the oil supplied to the engine passes through the full-flow filter that removes the larger foreign particles without restricting the normal flow of oil.



Fig 13. Typical In-Line Engine Oil Filter Mounting

The by-pass filter assembly, when used, continually filters a portion of the lubricating oil that is being bled off the oil gallery when the engine is running. Eventually all of the oil passes through the filter, filtering out minute foreign particles that may be present.

The lubricating oil filter elements should be replaced, each time the engine oil is changed, as follows:

1. Remove the drain plug and drain the oil.

2. The filter shell, element and stud may be detached as an assembly, after removing the center stud from the base. Discard the gasket.

3. Clean the filter base.

4. Discard the used element, wipe out the filter shell and install a new element on the center stud.

5. Place a new gasket in the filter base, position the shell and element assembly on the gasket and tighten the center stud carefully to prevent damaging the gasket or center stud.

6. Install the drain plug and, after the engine is started, check for oil leaks.



Fig. 14. Typical V-Type Engine Oil Filter Mounting



Fig. 15. Schematic Diagram of Typical In-Line Engine Lubricating System



Fig. 16. Schematic Diagram of Typical 6V Engine Lubricating System

COOLING SYSTEM

One of three different types of cooling systems is used on a Series 53 engine: radiator and fan, heat exchanger and raw water pump, or keel cooling. A centrifugal type water pump is used to circulate the engine coolant in each system. Each system incorporates thermostats to maintain a normal operating temperature of 160°-185° F. Typical engine cooling systems are shown in Figs. 17 and 18.

Radiator Cooling System

The engine coolant is drawn from the bottom of the radiator core by the water pump and is forced through the oil cooler and into the cylinder block. The coolant circulates up through the cylinder block into the cylinder head, then to the water manifold and thermostat housing. From the thermostat housing, the coolant returns to the radiator where it passes down a series of tubes and is cooled by the air stream created by the fan.

When starting a cold engine or when the coolant is below operating temperature, the coolant is restricted at the thermostat housing(s) and a by-pass provides water circulation within the engine during the warm-up period.

Heat Exchanger Cooling System

In the heat exchanger cooling system, the coolant is drawn by the circulating pump from the bottom of the expansion tank through the engine oil cooler, then through the engine the same as in the radiator and fan system. Upon leaving the thermostat housing, the coolant either passes through the heat exchanger core



Fig. 17. Typical Cooling System for In-Line Engine

or by-passes the heat exchanger and flows directly to the water pump, depending on the coolant temperature.

While passing through the core of the heat exchanger, the coolant temperature is lowered by raw water, which is drawn by the raw water pump from an outside supply. The raw water enters the heat exchanger at one side and is discharged at the opposite side.

To protect the heat exchanger element from electrolytic action, a zinc electrode is located in both the heat exchanger inlet elbow and the raw water pump inlet elbow and extends into the raw water passage.
The length of time a heat exchanger will function satisfactorily before cleaning will be governed by the AS kind of coolant used in the engine and the kind of raw water used. Soft water plus a rust inhibitor or a high boiling point type antifreeze should be used as the engine coolant.

When foreign deposits accumulate in the heat exchanger to the extent that cooling efficiency is impaired, such deposits can, in most instances, be removed by circulating a flushing compound through the fresh water circulating system without removing the heat exchanger. If this treatment does not restore the engine's normal cooling characteristics, contact an authorized *Detroit Diesel Allison Service Outlet.*



Fig. 18. Typical Cooling System for V-Type Engine

Keel Cooling System

The keel cooling system is similar to the heat exchanger system, except that the coolant temperature is reduced in the keel cooler. In this system, the coolant is drawn by the circulating pump from the bottom of the expansion tank through the engine oil cooler. From the cooler the flow is the same as in the other systems. Upon leaving the thermostat housing, the coolant is by-passed directly to the bottom of the expansion tank until the engine operating temperature, controlled by the thermostat, is reached. As the engine temperature increases, the coolant is directed to the keel cooler, where the temperature of the coolant is reduced before flowing back to the expansion tank.

ENGINE COOLING SYSTEM MAINTENANCE

Engine Coolant

The function of the engine coolant is to absorb the heat, developed as a result of the combustion process in the cylinders, from the component parts such as exhaust valves, cylinder liners and pistons which are surrounded by water jackets. In addition, the heat absorbed by the oil is also removed by the engine coolant in the oil-to-water oil cooler.

For the recommended coolant, refer to Engine Coolant.

Cooling System Capacity

The capacity of the basic engine cooling system (cylinder block, head, thermostat housing and oil cooler housing) is shown in Table 1.

To obtain the complete amount of coolant in the cooling system of an engine, the additional capacity of the radiator, hoses, etc. must be added to the capacity of the basic engine. The capacity of radiators and related equipment should be obtained from the equipment supplier.

Fill Cooling System

Before starting an engine, close all of the drain cocks and fill the cooling system completely. If the unit has a raw water pump, it should be primed, since operation without water may cause impeller failure.

COOLING SYSTEM CAPACITY CHART (BASIC ENGINE)	
ENGINE	CAPACITY (Quarts)
3-53	8
4-53	9
6V-53	14

TABLE 1

Start the engine and, after normal operating temperature has been reached, allowing the coolant to expand to its maximum, check the coolant level. The coolant level should be within 2"of the top of the filler neck.

Should a daily loss of coolant be observed, and there are no apparent leaks, there is a possibility of gases leaking past the cylinder head water seal rings into the cooling system. The presence of air or gases in the cooling system may be detected by connecting a rubber tube from the overflow pipe to a water container. Bubbles in the water in the container during engine operation will indicate this leakage. Another method for observing air in the cooling system is by inserting a transparent tube in the water outlet line.

Drain Cooling System

The engine coolant is drained by opening the cylinder block and radiator (heat exchanger) drain cocks and removing the cooling system filler cap. Removal of the filler cap permits air to enter the cooling passages and the coolant to drain completely from the system.

Drain cocks or plugs are located on each side of the 4-53 and 6V cylinder blocks. The 3-53 cylinder block has a drain cock or plug located on the side of the block opposite the oil cooler.

> **IMPORTANT**: Drain cocks or plugs on both sides of the engine must be opened to drain the engine completely.

In addition to the drains on the cylinder blocks, the Inline engines have a drain cock located on the bottom of the oil cooler housing. The V-type engines have two drain cocks that must be opened when draining the system. Radiators, etc., that do not have a drain cock, are drained through the oil cooler housing drain.

To insure that all of the coolant is drained completely from an engine, all cooling system drains should be opened. Should any entrapped water in the cylinder block or radiator freeze, it will expand and may cause damage. When freezing weather is expected, drain all engines not adequately protected by antifreeze.

Leave all of the drain cocks open until refilling the cooling system.

The exhaust manifolds of marine engines are cooled by the same coolant used in the engine. Whenever the engine cooling system is drained, each exhaust manifold drain cock, located on the bottom near the exhaust outlet, must be opened.

Raw water pumps are drained by loosening the cover attaching screws. It may be necessary to tap the raw water pump cover gently to loosen it. After the water has been removed, tighten the screws.

Flushing

The cooling system should be flushed each spring and fall. The flushing operation cleans the system of antifreeze solution in the spring and removes the summer rust inhibitor in the fall, preparing the cooling system for a new solution. The flushing operation should be performed as follows:

1. Drain the previous season's solution from the engine.
2. Refill the cooling system with soft clean water. If the engine is hot, fill slowly to prevent rapid cooling and distortion of the engine castings.
3. Start the engine and operate it for 15 minutes to circulate the water thoroughly.
4. Drain the cooling system completely.
5. Refill the system with the solution required for the coming season.

Cooling System Cleaners

If the engine overheats and the fan belt tension and water level are satisfactory, clean and flush the entire cooling system. Remove scale formation by using a quality de-scaling solvent. Immediately after using the solvent, neutralize the system with the neutralizer. It is important that the directions printed on the container of the de-scaling solvent be thoroughly read and followed.

After the solvent and neutralizer have been used, completely drain the engine and radiator and reverse-flush before filling the cooling system.

Reverse-Flushing

After the engine and radiator have been thoroughly cleaned, they should be reverse-flushed. The water pump should be removed and the radiator and engine reverse-flushed separately to prevent dirt and scale deposits clogging the radiator tubes or being forced through the pump. Reverse-flushing is accomplished by hot water, under air pressure, being forced through the cooling system in a direction opposite to the normal flow of coolant, loosening and forcing scale deposits out.

The radiator is reverse-flushed as follows:

1. Remove the radiator inlet and outlet hoses and replace the radiator cap.
2. Attach a hose at the top of the radiator to lead water away from the engine.
3. Attach a hose to the bottom of the radiator and insert a flushing gun in the hose.
4. Connect the water hose of the gun to the water outlet and the air hose to the compressed air outlet.
5. Turn on the water and, when the radiator is full, turn on the air in short blasts, allowing the radiator to fill between air blasts.

> **CAUTION: Apply air gradually. Do not exert more than 30 psi air pressure. Too great a pressure may rupture a radiator tube.**

6. Continue flushing until only clean water is expelled from the radiator.

The cylinder block and cylinder head water passages are reverse-flushed as follows:

1. Remove the thermostat and the water pump.
2. Attach a hose to the water inlet of the cylinder block to drain the water away from the engine.
3. Attach a hose to the water outlet at the top of the cylinder block and insert the flushing gun in the hose.
4. Turn on the water and, when the water jackets are filled, turn on the air in short blasts, allowing the engine to fill with water between air blasts.
5. Continue flushing until the water from the engine runs clean.

If scale deposits in the radiator cannot be removed by chemical cleaners or reverse-flushing as outlined above, it may be necessary to remove the upper tank and rod out the individual radiator tubes with flat steel rods. Circulate water through the radiator core from the bottom to the top during this operation.

Miscellaneous Cooling System Checks

In addition to the above cleaning procedures, the other components of the cooling system should be checked periodically to keep the engine operating at peak efficiency. The thermostat and the radiator pressure cap should be checked and replaced, if found defective. The cooling system hoses should be inspected and any hose that feels abnormally hard or soft should be replaced immediately.

Also, check the hose clamps to make sure they are tight. All external leaks should be corrected as soon as detected. The fan belt must be adjusted to provide the proper tension, and the fan shroud must be tight against the radiator core to prevent recirculation of air which may lower cooling efficiency.

Fresh Water Pump

A centrifugal-type fresh water pump is mounted on top of the engine oil cooler housing, either on the right-hand or left-hand side of the engine, depending upon the, engine model and rotation. It circulates the coolant through the cooling system.

The pump is belt driven, by either the camshaft or balance shaft (In-line engines) or by one of the camshafts (V-type engines).

An impeller is pressed onto one end of the water pump shaft, and a water pump drive pulley is pressed onto the opposite end. The pump shaft is supported on a sealed double-row combination radial and thrust ball bearing. Coolant is prevented from creeping along the shaft toward the bearing by a seal. The shaft and bearing constitute an assembly and are serviced as such, since the shaft serves as the inner race of the ball bearing.

The sealed water pump shaft ball bearing is filled with lubricant when assembled. No further lubrication is required.

Contact an *authorized Detroit Diesel Allison Service Outlet* if more information is needed.

Raw Water Pump

The raw water pump (Figs. 19 and 20) is a positive displacement pump, used for circulating raw water through the heat exchanger to lower the temperature of the engine coolant. It is driven by a coupling from the end of the camshaft.

Seal failure is readily noticed by a flow of water visible at the openings in the raw water pump housing, located between the pump mounting flange and the inlet and outlet ports. These openings must remain open at all times.



Fig. 19. Raw Water Pump Used on In-Line Engine

The impeller, cam and wear plate assembly, and water seal assembly may be serviced without removing the pump from the engine as outlined below.

1. Remove the cover and gasket.
2. Note the position of the impeller blades to aid in the reassembly. Then grasp a blade on each side of the impeller with pliers and pull the impeller off of the shaft.
3. The neoprene spline seal(s) can be removed from the impeller by pushing a screw driver through the impeller from the open end.



Fig. 20. Raw Water Pump Used on V-Type Engine

CAUTION: If the impeller is reusable, exercise care to prevent damage to the splined surfaces.

4. Remove the cam retaining screw and withdraw the cam and wear plate assembly.

5. Remove the seal assembly from the pump used on a V-type engine by inserting two wires with hooked ends between the pump housing and seal with the hooks over the edge of the carbon seal. Remove the seal seat and gasket in the same way.

6. The seal may be removed from the pump used on the In-line engine by drilling two holes in the seal case and placing metal screws in the holes so that they may be grasped and pulled with pliers. Then remove the rubber seal ring.

7. Clean and inspect the impeller, cam and wear plate assembly and water seal. The impeller must have a good bond between the neoprene and the metal. If the impeller blades are damaged, worn or have taken a permanent set, replace the impeller. Reverse the wear plate if it is worn excessively and remove any burrs. Replace the seal, if necessary.

8. Install the seal assembly in the pump used on a V-type engine as follows:

a. If the seal seat and gasket were removed, place the gasket and seal seat over the shaft and press them into position in the seal cavity.

b. Place the seal ring securely in the ferrule, and with the carbon seal and washer correctly positioned against the ferrule, slide the ferrule over the shaft and against the seal seat. Use care to ensure that the seal ring is contained within the ferrule so that it grips the shaft.

c. Install the flat washer and then the marcel washer.

A new seal may be installed in the pump used on the In-Line engine by placing the rubber seal ring in its groove, starting the seal (with the lip facing the impeller cavity) over the shaft and tapping it into place against the seal spacer.

9. Install the cam and wear plate assembly.

NOTE: The wear plate is round and is doweled to the cam. The wear plate must be installed with the cam in the pump housing as an assembly.

10. Apply a non-hardening sealant to the cam retaining screw-and the hole in the pump body to prevent any leakage. Then hold the cam with the tapped hole aligned and secure it with the screw.

11. Compress the impeller blades to clear the off-set cam and press the impeller on the splined shaft. The blades must be correctly positioned to follow the direction of rotation.

12. Install the neoprene splined seal(s) in the bore of the impeller.

13. Turn the impeller several revolutions in the normal direction of rotation to position the blades.

14. Affix a new gasket and install the pump cover.

The Jabsco raw water pump is equipped with a synthetic rubber impeller. Since synthetic rubber loses its elasticity at low temperatures, impeller made of natural rubber should be installed when it is necessary to pump raw water that has a temperature below 40°F.

The natural rubber impeller can be identified by a stripe of green paint between two of the impeller blades

ENGINE EQUIPMENT

INSTRUMENT PANEL, INSTRUMENTS AND CONTROLS

The instruments (Fig. 1) generally required in the operation of a diesel engine consist of an oil pressure gage, a water temperature gage, an ammeter and a mechanical tachometer. Also, closely related and usually installed in the general vicinity of these instruments are certain controls consisting of an engine starter switch, an engine stop knob, an emergency stop knob and, on certain applications, the engine hand throttle.

Torqmatic converters are equipped with an oil pressure gage and, in some instances, an oil temperature gage. These instruments are mounted on a separate panel.

Oil Pressure Gage

The oil pressure gage registers the pressure of the lubricating oil in the engine. As soon as the engine is started, the oil pressure gage should start to register. If the oil pressure gage does not register at least the minimum pressure listed under Running in the Engine Operating Instructions, the engine should be stopped and the cause of low oil pressure determined and corrected before the engine is started again.

Water Temperature Gage

The engine coolant temperature is registered on the water temperature gage.



Fig. 1. Typical Instrument Panel

Ammeter

An ammeter is incorporated into the electrical circuit to show the current flow to and from the battery. After starting the engine, the ammeter should register a high charge rate at rated engine speed. This is the rate of charge received by the battery to replenish the current used to start the engine. As the engine continues to operate, the ammeter should show a decline in charge rate to the battery. The ammeter will not show zero charge rate since the regulator voltage is set higher than the battery voltage. The small current registered prevents rapid brush wear in the battery-charging alternator. If lights or other electrical equipment are connected into the circuit, the ammeter will show discharge when these items are operating or the engine speed is reduced.

Tachometer

The tachometer is driven by the engine and registers the speed of the engine in revolutions per minute (rpm).

Engine Starting Motor Switch

The starting switch is mounted on the instrument panel with the contact button extending through the front face of the panel. The switch is used to energize the starting motor. As soon as the engine starts, release the switch.

Stop Knob

A stop knob is used on most applications to shut the engine down. When stopping an engine, the speed should be reduced to idle and the engine allowed to operate at idle for a few minutes to permit the coolant to reduce the temperature of the engine's moving parts. Then the stop knob should be pulled and held until the engine stops. Pulling on the stop knob manually places the injector racks in the "no-fuel" position. The stop knob should be returned to its original position after the engine stops.

Emergency Stop Knob

In an emergency or if after pulling the stop knob, the engine continues to operate, the emergency stop knob

may be pulled to stop the engine. The emergency stop knob, when pulled, will trip the air shut-off valve located between the air inlet housing and the blower and shut off the air supply to the engine. Lack of air will prevent further combustion of the fuel and stop the engine.

The emergency stop knob must be pushed back in after the engine stops so the air shut-off valve can be opened for restarting after the malfunction has been corrected.

Throttle Control

The engine throttle is connected to the governor speed control shaft through linkage. Movement of the speed control shaft changes the speed setting of the governor and thus the engine speed.

ENGINE PROTECTIVE SYSTEMS

MANUAL SHUT-DOWN SYSTEM

The manually operated emergency engine shut-down device, mounted in the air inlet housing, is used to stop the engine in the event an abnormal condition should arise. If the engine continues to run after the engine throttle is placed in the no-fuel position, or if combustible liquids or gases are accidentally introduced into the combustion chamber causing overspeeding of the engine, the shut-down device will prevent damage to the engine by cutting off the air supply and thus stopping the engine.

The shut-down device consists of an air shut-off valve mounted in the air inlet housing which is retained in the open position by a latch. A cable assembly is used to remotely trip the latch. Pulling the emergency shutdown knob all the way out will stop the engine. After the engine stops, the emergency shut-down knob must be pushed all the way in and the air shut-off valve manually reset before the engine can be started again.

AUTOMATIC MECHANICAL SHUT-DOWN SYSTEM

The automatic mechanical shut-down system illustrated in Fig. 2 is designed to stop the engine if there is a loss of oil pressure, loss of engine coolant, overheating of the engine coolant, or over-speeding of the engine. Engine oil pressure is utilized to activate the components of the system.

A coolant temperature-sensing valve and an adaptor and copper plug assembly are mounted on the exhaust manifold outlet. The power element of the temperature-sensing valve is placed against one end of the copper plug, and the other end of the plug extends into the exhaust manifold. Engine coolant is directed through the adaptor and passes over the power element of the valve. Engine oil, under pressure, is directed through a restricted fitting to the temperature-sensing valve and to an oil pressure actuated bellows located on the air inlet housing.



Fig. 2.· Mechanical Shut-Down System Schematically Illustrated

The pressure of the oil entering the bellows overcomes the tension of the bellows spring and permits the latch to retain the air shut-off valve in the open position. If the oil pressure drops below a predetermined value, the spring in the bellows will release the latch and permit the air shut-off valve to close and thus stop the engine.

The overspeed governor, used on certain applications, consists of a valve actuated by a set of spring-loaded weights. Engine oil is supplied to the valve through a connection in the oil line between the bellows and the temperature-sensing valve. An outlet in the governor valve is connected to the engine oil sump. Whenever the engine speed exceeds the overspeed governor setting, the valve (actuated by the governor weights) is moved from its seat and permits the oil to flow to the engine sump. This decreases the oil pressure to the bellows, thus actuating the shut-down mechanism and stopping the engine.

A restricted fitting, which will permit a drop in oil pressure great enough to actuate the shut-down mechanism, is required in the oil line between the cylinder block oil gallery and the shut-down sensing devices.

To be sure the protective system will function properly if an abnormal engine condition occurs, have the system checked periodically by your local *Detroit Diesel Allison Service Outlet.*

Also make sure the air shut-off valves close each time the engine is shut down.

Operation

To start an engine equipped with a mechanical shutdown system, first manually open the air shut-off valve and then press the engine starting switch. As soon as the engine starts, the starting switch may be released, but the air shut-off valve must be held in the open position until the engine oil pressure increases sufficiently to permit the bellows to retain the latch in the open position.

During operation, if the engine oil pressure drops below the setting of the pressure sensitive bellows, the spring within the bellows will release the latch and permit the air shut-off valve to close, thus stopping the engine.

If the engine coolant overheats, the temperature-sensing valve will open and permit the oil in the protective system to flow to the engine crankcase. The resulting decrease in oil pressure will actuate the shutdown mechanism and stop the engine. Also if the engine loses its coolant, the copper plug will be heated up by the hot exhaust gases passing over it and cause the temperature-sensing valve to open and actuate the shut-down mechanism.

Whenever the engine speed exceeds the overspeed governor (if used) setting, the oil in the line flows to the sump, resulting in a decrease in oil pressure. The oil pressure bellows then releases the latch and permits the air shut-off valve to close.

When an engine is stopped by the action of the shutdown system, the engine cannot be started again until the particular device which actuated the shut-down mechanism has returned to its normal position. *The abnormal condition which caused the engine to stop must be corrected before attempting to start it again.*

AUTOMATIC ELECTRICAL SHUT-DOWN SYSTEM

The automatic electrical shut-down system shown in Fig. 3 protects the engine against a loss of coolant, overheating of the coolant, loss of oil pressure, or overspeeding. In the event one of the foregoing conditions arises, a switch will close the electrical circuit and energize the solenoid switch, causing the shut-down solenoid to release the air shut-down latch and stop the engine.

Operation

The electrical circuit is de-energized under normal operating conditions. When the engine is started, the oil pressure switch opens when the oil pressure reaches approximately 10 psi and the fuel oil pressure switch Page 34 closes at approximately 20 psi fuel pressure. The water temperature switch remains open.

If the oil pressure drops below 10 psi, the oil pressure switch will close the circuit and energize the shut-down solenoid. This will activate the shut-down mechanism and stop the engine.

A loss of coolant or an increase in coolant temperature to approximately 203° F. will close the contacts in the water temperature switch, thus dosing the electrical circuit and activating the shut-down mechanism.

The water temperature switch consists of a temperature-sensing valve and a micro-switch. The valve contacts a copper plug (heat probe) which extends into the exhaust manifold outlet. Engine water is directed



Fig. 3. Automatic Electrical Shut-Down System Diagram

over the power element of the valve and should the water temperature exceed approximately 203° F., the valve will close the contacts in the micro-switch and energize the shut-down circuit. If a loss of water occurs, the heat of the exhaust gases will be transmitted through the copper plug to the temperature-sensing valve and cause the shut-down circuit to be activated.

If the engine speed exceeds the high speed setting of the overspeed governor, the governor switch will close and activate the shut-down mechanism.

When the engine is shut-down, the decrease in speed will open the governor switch, and the decrease in oil and fuel pressures will close the oil pressure switch and open the fuel pressure switch, thus de-energizing the circuit.

The cause of the abnormal conditions must then be determined and corrected before the engine is started again. Also, the air shut-off valve must be manually reset in the open position before the engine can be started.



Fig. 4. Automatic Electrical Shut-Down System Incorporating Hot Wire Relay

Some engines are equipped with an electrically operated automatic shut-down system which incorporates a hot wire relay (Fig. 4).

Since the fuel pressure builds up rapidly, the fuel oil pressure switch could close before the lubricating oil pressure switch opens, and effect a shut-down of the engine. The hot wire relay, however, delays the closing of the fuel oil pressure switch for several seconds to enable the lubricating oil pressure to build up and open the oil pressure switch contacts.

When the lubricating oil pressure falls below 10 ± 2 psi, the contacts in the oil pressure switch used in this system will close and current will flow through the hot wire relay to the solenoid. The few seconds required to heat the hot wire relay provides sufficient delay to avoid an engine shut-down when low oil pressure is caused by a temporary condition such as an air bubble or a temporary overlap in the operation of the oil pressure switch and the fuel oil pressure switch when starting or stopping the engine.

The water temperature switch, which remains open during normal engine operation, is installed in the side of the thermostat housing. The switch contacts close when the water temperature reaches approximately 205° F. and activate the shut-down solenoid.

ALARM SYSTEM



Fig. 5. Alarm System Wiring Diagram

The alarm system shown in Fig. 5 is similar to the automatic electrical shut-down system, but uses a warning bell in place of the air shut-off valve solenoid. The bell warns the engine operator if the engine coolant overheats or the oil pressure drops below the safe operating limit.

When the engine is started and the oil pressure is sufficient to open the oil pressure switch contacts (opening pressure is stamped on the switch cover), the alarm switch must be turned on manually to put the system in operation. The water temperature switch is normally open. Should the engine coolant exceed 205 ± 5°F., the water temperature switch will close the electrical circuit and sound the alarm bell. Likewise, if the oil pressure drops below the setting of the oil pressure switch, the switch will close and cause the bell to ring. The bell will continue to ring until the engine operator turns the alarm switch off. The alarm switch must also be turned off before a routine stop since the decreasing oil pressure will close the oil pressure switch and cause the bell to ring.

If the alarm bell rings during engine operation, stop the engine immediately and determine the cause of the abnormal condition. *Make the necessary corrections before starting the engine again*.

STARTING SYSTEMS

ELECTRICAL STARTING SYSTEM

The electrical system on the engine generally consists of a battery-charging alternator, a starting motor, voltage regulator, storage battery, starter switch and the necessary wiring. Additional electrical equipment may be installed on the engine unit at the option of the owner.

Starting Motor

The starting motor has a Sprag overrunning clutch. Pressing the starting switch engages the starting motor pinion with the teeth of the flywheel ring gear and energizes the starting motor. The starting motor drives the pinion and rotates the crankshaft. When the engine begins to operate, the Sprag clutch permits the pinion to overrun on its shaft, until the starting switch is released, and prevents overspeeding the starting motor.

Starter Switch

To start the engine, a switch is used to energize the starting motor. Release the switch immediately after the engine starts.

Alternator

The battery-charging alternator provides the electrical current required to maintain the storage battery in a charged condition and to supply sufficient current to carry any other electrical load requirements up to the rated capacity of the alternator.

Regulator

A voltage regulator is introduced into the electrical system to regulate the voltage and current output of the battery-charging alternator and to maintain a fully charged storage battery.

Storage Battery

The lead-acid storage battery is an electrochemical device for converting chemical energy into electrical energy.

The battery has three major functions:

1. It provides a source of electrical power for starting the engine.
2. It acts as a stabilizer to the voltage in the electrical system.
3. It can, for a limited time, furnish current when the electrical demands of the unit exceed the output of the alternator.

The battery is a perishable item which requires periodic servicing. A properly cared for battery will give long and trouble-free service.

1. Check the level of the electrolyte regularly. Add water if necessary, but do not overfill. Overfilling can cause poor performance or early failure.
2. Keep the top of the battery clean. When necessary, wash with a baking soda solution and rinse with fresh water. Do not allow the soda solution to enter the cells.
3. Inspect the cables, clamps and hold-down bracket regularly. Clean and re-apply a light coating of grease when needed. Replace corroded, damaged parts.
4. Use the standard, quick in-the-unit battery test as the regular service test to check battery condition.
5. Check the electrical system if the battery becomes discharged repeatedly.

If the engine is to be stored for more than 30 days, remove the battery. The battery should be stored in a cool, dry place. Keep the battery fully charged and check the level of the electrolyte regularly.

The Lubrication and Preventive Maintenance section of this manual covers the servicing of the starting motor and alternator.

Consult an authorized *Detroit Diesel Allison Service Outlet* for information regarding the electrical system.

HYDRAULIC STARTING SYSTEM (HYDROSTARTER)

The Hydrostarter System schematically illustrated in Fig. 6 is a complete hydraulic system for starting internal combustion engines. The system is automatically recharged after each start, and can be manually recharged. The starting potential remains during long periods of inactivity, and continuous exposure to hot or cold climates has no detrimental effect upon the Hydrostarter system. Also, the Hydrostarter torque for a given pressure remains substantially the same regardless of the ambient temperature.

The Hydrostarter system consists of a reservoir, an engine-driven charging pump, a hand pump, a piston type accumulator, a starting motor and connecting hoses and fittings.

Operation

Hydraulic fluid flows by gravity, or a slight vacuum, from the reservoir to either the engine-driven pump or the hand pump inlet. Fluid discharging from either pump outlet at high pressure flows into the accumulator and is stored at 3250 psi under the pressure of compressed nitrogen gas.

When the starter is engaged with the engine flywheel ring gear and the control valve is opened, fluid under pressure is forced out of the accumulator, by the expanding nitrogen gas, and flows into the starting motor which rapidly accelerates the engine to a high cranking speed. The used fluid returns directly to the reservoir from the starter.

The engine-driven charging pump runs continuously during engine operation and automatically recharges the accumulator. When the required pressure is attained in the accumulator, a valve within the pump body opens and the fluid discharged by the pump is by-passed to the reservoir. The system can be shut down and the pressure in the accumulator will be maintained.

The precharge pressure of the accumulator is the pressure of the nitrogen gas with which the accumulator is initially charged. This pressure must be checked before the system pressure is raised for the initial engine start. To check the precharge pressure, open the relief valve, on the side of the hand pump, approximately 1/2 turn, allowing the pressure gage to return to zero. Close the relief valve and pump several strokes on the hand pump. The gage should show a rapid pressure rise from zero to the nitrogen precharge pressure, where it will remain without change for several additional strokes of the pump.



Fig. 6. Schematic Diagram of Hydrostarter System Showing Oil Flow

Initial Engine Start
Use the hand pump to raise the accumulator pressure.

An accumulator pressure of 1500/psi when the ambient temperature is above 40° F. will provide adequate cranking to start the engine. Between 40° F. and 0° F., 2500 psi should be sufficient. Below 0°F., the accumulator should be charged to the maximum recommended pressure. Although the Hydrostarter cranks the engine faster than other starting systems, starting aids should be. used in cold weather.

> **NOTE: Use the priming pump to make sure the filters, lines, manifolds and injectors are full of fuel before attempting to start the engine.**

For ambient temperatures below 40°F., use a fluid starting aid. Add the starting fluid just prior to moving the Hydrostarter lever and during the cranking cycle as required. Do not wait to add the starting fluid after the engine is turning over, otherwise the accumulator charge may be used up before the engine can start. In this case, the accumulator charge must be replaced with the hand pump.

With the engine controls set for start (throttle at least half-open), push the Hydrostarter control lever to simultaneously engage the starter pinion with the flywheel ring gear and to open the control valve. Close the valve quickly when the engine starts, te conserve the accumulator pressure and prevent excessive overrunning of the starter drive clutch assembly.

Three different basic types of flywheel ring gears are used; no chamfer, Bendix chamfer, or Dyer chamfer on the gear teeth. Some difficulty may be encountered in engaging the starter pinion with the Dyer chamfered ring gears. When this happens, it is necessary to disengage and re-engage until the starter pinion is cammed in the opposite direction enough to allow the teeth to mesh.

Remote Control System
The Hydrostarter remote control system (Fig. 7) consists of a master cylinder, a pedal, a lever arm, two springs and a flexible hose. It is an independent hydraulic system using diesel fuel oil as a hydraulic fluid to actuate the Hydrostarter control valve by means of the pedal operated master cylinder.

The master cylinder is connected to the control valve on the Hydrostarter by a flexible hose. Pressing on the pedal forces the fluid through the hose to the control valve which engages the starter pinion with the engine flywheel ring gear. Release the pedal as soon as the engine starts.

The Hydrostarter-motor is equipped with a control valve that incorporates a threaded valve housing plug with a 1/8"-27 tapped hole in the center for installation of the flexible hose. A 1/8"-27 pipe plug is installed when the remote control system is not used.


ADJUST TO GIVE 1.31" MAXIMUM TRAVEL AT "A"
PEDAL
MASTER CYLINDER
¼" COPPER OR STEEL TUBE
PEDAL RETURN SPRING (INITIAL TENSION 15 LBS.)
"A"
TO RESERVOIR
HOSE (MAXIMUM LENGTH 15')
FROM ACCUMULATOR
STARTER CONTROL VALVE
STARTER CONTROL LEVER RETURN SPRING (INITIAL TENSION 15 LBS.)

Fig. 7. ·Hydrostarter Remote Control System

Springs are used to return the master cylinder pedal and the Hydrostarter control lever to the off position.

Filling
Remove the filler cap from the reservoir and add a sufficient quantity of hydraulic fluid (a mixture of 75% diesel fuel and 25% SAE 10 or 30 lubricating oil) to fill the system.

The required. amount of hydraulic fluid will vary depending upon the size of the reservoir, length of hydraulic hoses and the size and number of accumulators. The reservoirs are available in 10, 12, 16 and 23 quart capacities. In a 10 quart capacity reservoir, add approximately 8 quarts of hydraulic fluid, 10 quarts in a 12 quart reservoir, 14 quarts in a 16 quart reservoir or 21 quarts in a 23 quart reservoir.

NOTE: When the accumulator is charged to 3000 psi and all hoses are filled, there should be enough hydraulic fluid remaining in the reservoir to completely cover the screen in the bottom of the reservoir.

Purging

A by-pass valve is located on the inlet side of the hand pump. Loosen the lock nut and rotate this valve approximately one turn counterclockwise with a screw driver. Operate the hand pump for 12 to 15 complete strokes. Do not pump too rapidly. Close the by-pass valve tightly and tighten the lock nut.

1. Move the starter control lever to engage the pinion with the flywheel and open the control valve. While holding the lever in this position, operate the hand pump until the starter has turned several revolutions. Close the control valve. Loosen the swivel hose fitting at the discharge side of the engine-driven pump about two turns. Operate the hand pump to force air out until oil begins to appear at the loose fitting. Tighten the swivel hose fitting and pressurize the system with the hand pump sufficiently to start the engine.
2. Perform the initial starting instructions under *Preparation for Starting Engine First Time*. Then, with the engine running at least 1500 rpm, purge the engine-driven pump of air. Break the hose connection at the discharge side of the engine driven-pump until a full stream of oil is discharged from the pump. Connect the hose to the pump and alternately loosen and tighten the swivel fitting on the discharge hose until the oil leaking out, when the fitting is loose, appears to be free of air bubbles. Tighten the fitting securely and observe the pressure gage. The pressure should rise rapidly to the accumulator ptecharge pressure (1250 psi at 70"F.), then increase slowly, reaching 2900 to 3300 psi.
3. After the pressure has stabilized near 3000 psi, examine all of the high pressure hoses, connections and fittings for leaks.
4. The engine-driven pump must by-pass oil to the reservoir when the accumulator pressure reaches 29003300 psi. To determine whether the pump by-pass valve is operating properly, remove the reservoir filler cap, disconnect the pump by-pass hose at the reservoir, and hold the hose over the open reservoir filler spout. An occasional spurt of oil may be emitted from the hose prior to by-passing. When the by-pass valve opens, a full and continuous stream of oil will flow from the hose. Reconnect the hose to the reservoir and install the filler cap.
5. Fill the reservoir to the proper level.

The Hydrostarter remote control system. may be purged of air as follows:

1. Fill the master cylinder with fuel oil.
2. Loosen the hose fitting at the Hydrostarter control valve.
3. Actuate the master cylinder pedal until all of the air is discharged from the system and a solid stream of fuel oil is being discharged with each stroke.

NOTE: Replenish the fluid in the master cylinder as required during the purging operation.

4. Tighten the hose fitting and check for leaks.

LUBRICATION AND PREVENTIVE MAINTENANCE

Inspect the system periodically for leaks. Primarily, examine the high pressure hoses, connections, fittings and the control valve on the starter. Make certain that the oil level in the reservoir is sufficient to completely cover the screen at the bottom of the tank. Make this check after the accumulator is charged and the engine driven pump is by-passing oil to the reservoir.

Every 2000 hours, or as conditions warrant, drain the reservoir and remove the screen. Flush out the reservoir and clean the screen and filler cap. Then reinstall the screen.

Remove the bowl and element from the filter in the engine-driven pump supply hose. Wash the bowl and element in clean fuel oil and reassemble the filter.

Release the pressure and drain the remaining hydraulic fluid from the system by disconnecting the hoses from the Hydrostarter components. Then reconnect all of the hydraulic hoses.

CAUTION: The oil pressure in the system must be released prior to servicing the Hydrostarter motor or other components to prevent possible injury to personnel or equipment.

NOTE: Make sure all hoses and fittings are clean before any connections are made.

Fill the Hydrostarter system with new clean fluid.

Lubrication

Remove the Hydrostarter from the engine every 2000 hours for lubrication. Before removing the Hydrostarter, release the pressure in the system by means of the relief valve in the hand pump. Then remove the

three bolts which retain the starting motor to the flywheel housing. Remove the starting motor without disconnecting the hydraulic oil hoses. This W-ill prevent dirt and air from entering the hydraulic system.

Apply a good quality, lightweight grease on the drive clutch pinion to make sure the clutch will slide freely while compressing the spring. Also apply grease to the fingers of the clutch fork and on the spool of the clutch yoke engaged by the fork. This lubrication period may be reduced or lengthened according to the severity of service.

Remove the pipe plug from the starting motor drive housing and saturate the shaft oil wick with engine oil. Then reinstall the plug.

After lubricating, install the starting motor on the flywheel housing and recharge the accumulator with the hand pump.

On engines equipped with a hydraulic remote control system, lubricate the shaft in the master cylinder through the pressure grease fitting every 2000 hours.

Cold Weather Operation

Occasionally, when an engine is operated in regions of very low temperatures, the starter drive clutch assembly may slip when the starter is engaged. If the clutch slips, proceed as follows:

1. Release the oil pressure in the system by opening the relief valve in the hand pump.

CAUTION: The oil pressure in the system must be released prior to servicing the Hydrostarter motor or other components to prevent possible injury to personnel or equipment.

2. Disconnect the hydraulic hoses from the starting motor.
3. Remove the three retaining bolts and lock washers and withdraw the starting motor from the flywheel housing.
4. Disassemble the starting motor.
5. Wash the Hydrostarter drive clutch assembly in clean fuel oil to remove the old lubricant.
6. When the clutch is free, apply SAE 5W lubricating oil.
7. Reassemble the starting motor and reinstall it on the engine. Then attach a tag to the starter noting the lubricant used in the clutch.
8. Recharge the accumulator with the hand pump.

Marine Application

In addition to the normal Hydrostarter lubrication and maintenance instructions, the following special precautions must be taken for marine installations or other cases where equipment is subject to salt spray and air, or other corrosive atmospheres:

1. Clean all exposed surfaces and apply a coat of zinc-chromate primer, followed by a coat of suitable paint.
2. Apply a liberal coating of Lubriplate, type 130-AA, or equivalent, to the following surfaces.

   a. The exposed end of the starter control valve and around the control shaft where it passes through the clutch housing.
   b. The exposed ends of the hand pump cam pin.

3. Operate all of the moving parts and check the protective paint and lubrication every week.

Consult an authorized *Detroit Diesel Allison Service Outlet* for any information relating to the Hydrostarter system.

COLD WEATHER STARTING AIDS

In a diesel engine, the fuel injected into the combustion chamber is ignited by the heat of the air compressed into the cylinder. However, when starting an engine in extremely cold weather, a large part of.

the energy of combustion is absorbed by the pistons and cylinder walls, and in overcoming the high friction created by the cold lubricating oil.

When the ambient temperature is low, it may be necessary to use an air heater or a starting fluid to assist ignition of the fuel.

NOTE: Starting aids are NOT intended to correct for a low battery, heavy oil or other conditions which cause hard starting. They are to be used only when other conditions are normal, but the air temperature is too cold for the heat of compression to ignite the fuel-air mixture.

FLUID STARTING AID

The fluid starting aid (Fig. 8) is designed to inject a

highly volatile fluid into the air intake system at low ambient temperatures to assist in igniting the fuel oil injected. The fluid is contained in suitable capsules to facilitate handling.

The starting aid consists of a cylindrical capsule container with a screw cap, inside of which a sliding piercing shaft operates. A tube leads from the capsule container to a hand operated pump and another tube leads to the atomizing nozzle threaded into a tapped hole in the air inlet housing.

The capsule container should be mounted in a vertical position and away from any heat.

Start the engine, using the fluid starting aid, as follows:

1. Remove the threaded cap and insert a fluid capsule in an upright position within the container.

CAUTION: The starting fluid is toxic and inflammable. Use caution when handling.

2. Pull the piercing shaft all the way out and install and tighten the cap on the container.



Fig. 8. Typical Fluid Starting Aid

3. Push the piercing shaft all the way down. This will rupture the capsule and fill the container with the starting fluid.

4. Move the engine throttle to the maximum speed position.

5. Engage the starter and at the same time pull the pump plunger all the way out. Push the plunger in slowly, forcing the starting fluid through the atomizing nozzle into the air intake. Continue to push the pump in until the engine starts. If the plunger is not all the way in when the engine starts, push it in slowly until it locks in the IN position.

6. Unscrew the cap and remove the capsule. *Do not leave the empty capsule in the container.*

7. Replace the cap on the capsule container and make sure the piercing shaft is all the way down.

Service

The cold weather fluid starting aid will require very little service. Replace the piston seal packing if the pump leaks. If there is an excessive resistance to pumping, the nozzle may be plugged. Remove the nozzle and clean it.

PRESSURIZED CYLINDER STARTING AID

Start the engine during cold weather, using the "Quick Start" starting aid system (Fig. 9) as follows: I. Press the engine starter button.

2. Pull out the "Quick Start" knob for one or two seconds, then release it.

3. Repeat the procedure if the engine does not start on the first attempt.

CAUTION: Do not crank the engine more than 30 seconds at a time when using an electric starting motor. Always allow one minute intervals between cranking attempts to allow the starting motor to cool.

Service

Periodically perform the following service items to assure good performance:

1. Remove the fluid cylinder and lubricate the valve around the pusher pin under the gasket with a few drops of oil.



Fig. 9.· Quick-Start Assembly

2. Lubricate the actuator cable.

3. Actuate the valve with the cable to distribute the oil on the cable and allow the oil to run down through the valve.

4. Remove any dirt from the orifice by removing the air inlet housing fitting, the orifice block and the screen. Then blow air through the orifice end only.

5. Assemble and tighten the air inlet housing fitting to the actuator valve and tube.

6. Check for leakage of fluid (fogging) on the outside of the engine air inlet housing by actuating the starting aid while the engine is stopped. If fogging occurs, disassemble and retighten the air inlet housing fitting to the housing.

> **CAUTION: Do not actuate the starting aid more than once with the engine stopped. *Over-loading the engine air box with this high volatile fluid could result in a minor explosion*.**

7. Check the fluid cylinder for hand tightness.

GOVERNORS

Horsepower requirements of an engine may vary continually due to the fluctuating loads; therefore, some means must be provided to control the amount of fuel required to hold the engine speed reasonably constant during such load fluctuations. To accomplish this control, one of three types of governors is used on the engines. Installations requiring maximum and minimum speed control, together with manually controlled intermediate speeds, ordinarily use a limiting speed mechanical governor. Applications requiring a near constant engine speed under varying load conditions, that may be changed by the operator, are equipped with a variable speed mechanical governor. The hydraulic governor is used where uniform engine speed is required under varying load conditions with a minimum speed droop.

Lubrication

The mechanical governors are lubricated by oil splash from the engine gear train. Oil entering the governor is directed by the revolving governor weights to the various moving parts requiring lubrication.

The hydraulic governor is lubricated by oil under pressure from the engine.

Service

Governor difficulties are usually indicated by speed variations of the engine. However, speed fluctuations are not necessarily caused by the governor and, therefore, when improper speed variations become evident, the unit should be checked for excessive load, misfiring or bind in the governor operating linkage. If none of these conditions are contributing to faulty governor operation, contact an authorized Detroit Diesel Allison Service Outlet.

TRANSMISSIONS

POWER TAKE-OFF ASSEMBLIES

The front and rear power take-off units are basically similar in design, varying in clutch size to meet the requirements of a particular application. The power take-off unit is attached to either an adaptor (front power take-off) or the engine flywheel housing (rear power take-off).

Clutch Adjustment

These instructions refer to field adjustment for clutch facing wear. Frequency of adjustment depends upon the amount and nature of the load. To ensure a long clutch facing life and the best performance, the clutch should be adjusted before slippage occurs.

When the clutch is properly adjusted, a heavy pressure is required at the outer end of the hand lever to move the throwout linkage to the "over center" or locked position.

Adjust the clutch as follows:

1. Disengage the clutch with the hand lever.

2. Remove the inspection hole cover to expose the clutch adjusting ring. Rotate the clutch, if necessary, to bring the adjusting ring lock within reach.

3. Remove the clutch adjusting ring spring lock screw and lock from the inner clutch pressure plate and adjusting ring. Then, while holding the clutch drive shaft to prevent the clutch from turning, turn the clutch adjusting ring counterclockwise as shown in fig. 10 and tighten the clutch until the desired pressure on the outer end of the hand lever, or at the

Fig. 10. Adjusting Clutch

Clutch Diameter	Hand Lover Length	Pressure lbs.	Torque Wrench lb-ft
8"	15-1/2"	55	56-63
10"	15-1/2"	80	87-94
*11-1/2"	15-3/8"	100	129
11-1/2"	20"	105	112-120

*Twin Disc Clutch

TABLE 1

clutch release shaft (Fig. 11), is obtained as shown in Table 1.

When properly adjusted, the approximate pressure required at the outer end of the hand lever to engage the various diameter clutches is shown in the table. These specifications apply only with the hand lever which is furnished with the power take-off.

A suitable spring scale may be used to check the pounds pressure required to engage the clutch. However, a more accurate method of checking the ,clutch adjustment is with a torque wrench as shown in Fig. 11.

To fabricate an adaptor, saw the serrated end off of a clutch hand lever and weld a 1-1/8" nut (across the hex) on it as shown in Fig. 11. Then saw a slot through the nut.

When checking the clutch adjustment with a torque wrench, engage the clutch slowly and note the amount of torque immediately before the clutch engages (goes over center). The specified torque is shown in Table 1.

CAUTION: The thrust load on the bronze clutch release bearing should be kept at an absolute minimum. Therefore, the hand lever should be positioned on the shaft as near the 12 o'clock or 6 o'clock position as possible. The 9 and 3 o'clock positions are to be avoided.



Fig. 11. Checking Clutch Adjustment with a Torque Wrench and Adaptor

Make a final clutch adjustment with the engine running as follows:

1. Start the engine and operate it at idling speed (approximately 500 rpm) with the clutch disengaged. The speed will be sufficient to move the segments out to the operating position.
2. Check the pounds pressure required to engage the clutch. The engagement pressure should be the same as that following the adjustment. If the clutch engages at a lower pressure, the adjustment was probably made against the unworn portion of the facing.
3. Stop the engine and readjust the clutch, making sure all disc segments are properly positioned. Install the inspection hole cover.

TORQMATIC CONVERTERS

The Torqmatic converter is a self contained unit which transfers and multiplies the torque of the prime mover. This unit transmits the power through the action of oil instead of through gears and in addition to multiplying the torque also acts as a fluid coupling between the engine and the equipment to be powered.

The converter will automatically adjust the output torque to load requirements.

There are various combinations of Torqmatic converters with features such as: an automotive or industrial flange on the shaft, a hydraulically operated lock-up clutch, a manual input disconnect clutch, and an accessory drive for either a governor or tachometer.
Check the oil level daily. If the converter is equipped with an input disconnect clutch, additional checks and service will be necessary daily or at intervals determined by the type of operation.

Adjust the disconnect clutches as outlined under power take-off clutch adjustment.

Contact an authorized *Detroit Diesel Allison Service Outlet* for service on Torqmatic converters.

WARNER MARINE GEAR

The Warner hydraulic marine gear assembly consists of a hydraulically operated multiple disc clutch in combination with a hydraulically) actuated reversing gear train, an oil pressure regulator, an oil sump independent of the engine oil system and an oil cooler mounted on the engine.

Oil pressure for the operation of the marine gear is provided by an oil pump incorporated within the gear housing and driven continuously while the engine is running. The oil is delivered under pressure from the pump to a combination marine gear control valve and pressure regulator valve.

The pressure regulator valve maintains constant pressure over a wide speed range and the control valve directs the oil under pressure to either the forward or reverse piston cylinder. The operating oil pressure range for the marine gear at operating speed is 120 to 140 psi and the maximum oil temperature is 225° F. Minimum oil pressure is 100 psi at idle speed (600 rpm).

Shifting from forward to reverse drive through neutral may be made at any speed; however, it is advisable to shift at low speeds, below 1000 engine rpm, to avoid damage to the engine, reverse gear or shaft.

The marine reverse and reduction gear is lubricated by pressure and splash. The quantity of oil in the marine gear will vary with the inclination of the engine and must be properly maintained to the full mark on the dipstick to ensure satisfactory operation.

It is recommended that vessels utilizing a marine gear have a suitable locking device or brake to prevent rotation of the propeller shaft when the vessel is not under direct propulsion. If the marine gear is not in operation and the forward motion of the vessel causes the propeller shaft to rotate, lubricating oil will not be circulated through the gear because the oil pump is not in operation. Overheating and damage to the marine gear may result unless rotation of the propeller shaft is prevented.

Consult an authorized *Detroit Diesel Allison Service Outlet* for major repairs or reconditioning of the marine gear.

OPERATING INSTRUCTIONS

ENGINE OPERATION INSTRUCTION

PREPARATION FOR STARTING ENGINE FIRST TIME

Before starting an engine for the first time, carefully read and follow these instructions. Attempting to run the engine before studying these instructions may result in serious damage to the engine.

NOTE: When preparing to start a new or overhauled engine or an engine which has been in storage, perform all of the operations listed below. Before a routine start (at each shift), see Daily Operations in the Lubrication and Preventive Maintenance Chart.

Cooling System

Install all of the drain cocks or plugs in the cooling system (drain cocks are removed for shipping).

Open the cooling system vents, if the engine is so equipped.

Remove the filler cap and fill the cooling system with clean, soft water or a protective solution consisting of high boiling point type antifreeze, if the engine will be exposed to freezing temperatures. Refer to Engine Coolant. Keep the liquid level about two inches below the filler neck to allow for fluid expansion.

Use a quality rust inhibitor if only water is used in the cooling system.

Close the vents, if used, after filling the cooling system.

On marine installations, prime the raw water cooling system and open any sea cocks in the raw water pump intake line. Prime the raw water pump by removing the pipe plug or electrode provided in the pump outlet elbow and pour water in the pump.

CAUTION: Failure to prime the raw water pump may result in damage to the pump impeller.

Lubrication System

The lubricating oil film on the rotating parts and bearings of a new or overhauled engine, or one which has been in storage, may be insufficient for proper lubrication when the engine is started for the first time.

It is recommended that the engine lubricating system be charged with a pressure prelubricator, set to supply a minimum of 25 psi oil pressure, to ensure an immediate flow of oil to all bearings at the initial engine start-up. The oil supply line should be attached to the engine so that oil under pressure is supplied to the main oil gallery.

With the oil pan dry, use the prelubricator to prime the engine with sufficient oil to reach all bearing surfaces. Use heavy-duty lubricating oil as specified under Lubricating Oil Specifications. Then remove the dipstick, wipe it with a clean cloth, insert and remove it again to check the oil level in the oil pan. Add sufficient oil, if necessary, to bring it to the full mark on the dipstick. Do not overfill.

If a pressure prelubricator is not available, fill the crankcase to the proper level with heavy-duty lubricating oil as specified. Then pre-lubricate the upper engine parts by removing the valve rocker covers and pouring lubricating oil, of the same grade and viscosity as used in the crankcase, over the rocker arms.

Turbocharger

Disconnect the turbocharger oil inlet line and pour approximately one pint of clean engine oil in the line, thus making sure the bearings are lubricated for the initial start. Reconnect the oil line.

Air Cleaner

If the engine is equipped with oil bath air cleaners, fill the air cleaner oil cups to the proper level with clean engine oil. Do not overfill.

Transmission

Fill the transmission case, marine gear or torque converter supply tank to the proper level with the lubricant specified under Lubrication and Preventive Maintenance.

Fuel System

Fill the fuel tank with the fuel specified under Diesel Fuel Oil Specifications.

If the unit is equipped with a fuel valve, it must be opened.

To ensure prompt starting, fill the fuel system between the pump and the fuel return manifold with fuel. If the engine has been out of service for a considerable length of time, prime the filter between the fuel pump and the injectors. The filter may be primed by removing the plug in the top of the filter cover and slowly filling the filter with fuel.

In addition to the above, on an engine equipped with a Hydrostarter, use a priming pump to make sure the fuel lines and the injectors are full of fuel before attempting to start the engine.

NOTE: The fuel system is filled with fuel before leaving the factory. If the fuel is still in the system when preparing to start the engine, priming should be unnecessary.

Lubrication Fittings

Fill all grease cups and lubricate at all fittings with an all purpose grease. Apply lubricating oil to the throttle linkage and other moving parts and fill the hinged cap oilers with a hand oiler.

Drive Belts

Adjust all drive belts as recommended under *Lubrication and Preventive Maintenance.*

Storage Battery

Check the battery. The top should be clean and dry, the terminals tight and protected with a coat of petroleum jelly and the electrolyte must be at the proper level.

NOTE: When necessary, check the battery with a hydrometer; the reading should be 1.265 or higher. However, hydrometer readings should always be corrected for the temperature of the electrolyte.

Generator Set

Where applicable, fill the generator end bearing housing with the same lubricating oil as used in the engine.

A generator set should be connected and grounded in accordance with the applicable local electrical codes.

CAUTION: The base of a generator set must be grounded.

Clutch Disengage the clutch, if the unit is so equipped.

STARTING

Before starting the engine for the first time, perform the operations listed under Preparation For *Starting Engine First Time*.

Before a routine start, see *Daily Operations* in the *Lubrication and Preventive Maintenance Chart*.

If a manual or an automatic shut-down system is incorporated in the unit, the control must be set in the open position before starting the engine.

The blower will be seriously damaged if operated with the air shut-off valve in the closed position.

Starting at air temperatures below 40 F. requires the use of a cold weather starting aid. See *Cold Weather Starting.*

The instructions for the use of a cold weather fluid starting aid will vary dependent on the type being used. Reference should be made to these instructions , before attempting a cold weather start.

CAUTION: Starting fluid used in capsules is highly inflammable, toxic and possesses anesthetic properties.

Initial Engine Start (Electric) Start an engine equipped with an electric starting motor as follows: Set the speed control lever at part throttle, then bring it back to the desired no-load speed. In addition, on mechanical governors, make sure the stop lever on the governor cover is in the run position. Then press the starting motor switch firmly.

If the engine fails to start within 30 seconds, release the starting switch and allow the starting motor to cool a few minutes before trying again. If the engine fails

Ambient Temperature	Pressure Gage Reading
Above 40° F	1500 psi
40 ° to 0° F	2500 p1
Below 0° F	3300 psi

TABLE 1

to start after four attempts, an inspection should be made to determine the cause.

CAUTION: To prevent serious damage to the starter, if the engine does not start, do not press the starting switch again while the starting motor is running.

Initial Engine Start (Hydrostarter) An engine equipped with a Hydrostarter may be started as follows:

Raise the Hydrostarter accumulator pressure with the hand pump until the gage reads as indicated in Table 1.

Ambient Temperature	Pressure Gauge Reading
Above 40°F.	1500 psi
40°F. to 0°F.	2500 psi
Below 0°F.	3300 psi

Set the engine controls for starting with the throttle at least half open.

NOTE: During cold weather add starting fluid at the same time the Hydrostarter motor lever is moved. Do not wait to add the fluid after the engine is turning over.

Push the Hydrostarter control lever to simultaneously engage the starter pinion with the flywheel ring gear and to open the control valve . Close the valve as soon as the engine starts to conserve the accumulator pressure and to avoid excessive over-running of the starter drive clutch assembly.

RUNNING

Oil Pressure

Observe the oil pressure gage immediately after starting the engine. If there is no pressure indicated within 10 to 15 seconds, stop the engine and check the lubricating oil system. The minimum oil pressure should be at least 18 psi at 1200 rpm. The oil pressure at normal operating speed should be 40-60 psi.

Warm-Up

Run the engine at part throttle and no-load for approximately five minutes, allowing it to warm-up before applying a load.

If the unit is operating in a closed room, start the room ventilating fan or open the windows, as weather conditions permit, so ample air is available for the engine.

Clutch

Do not engage the clutch at engine speeds over 1000 rpm.

Inspection

While the engine is running at operating temperature, check for coolant, fuel or lubricating oil leaks. Tighten the line connections where necessary to stop leaks.

Engine Temperature

Normal engine coolant temperature is 160°F. to 185° F.

Crankcase

If the engine crankcase was refilled, stop the engine after normal operating temperature has been reached, allow the oil to drain back into the crankcase for approximately twenty minutes and check the oil level. Add oil, if necessary, to bring it to the proper level on the dipstick.

Use only the *heavy duty* lubricating oil specified under *Lubricating Oil Specifications.*

Cooling System

Remove the radiator or heat exchanger tank cap *slowly* after the engine has reached normal operating temperature and check the engine coolant level. The coolant level should be near the top of the opening. If necessary, add clean soft water or a high boiling point type antifreeze (refer to *Engine Coolant*).

Marine Gear

Check the marine gear oil pressure. The operating oil pressure range for the marine gear at operating speed is 120 to 160 psi and minimum oil pressure is 100 psi at idle speed (600 rpm).

Turbocharger

Make a visual inspection of the turbocharger for leaks and excessive vibration. Stop the engine immediately if there is an unusual noise in the turbocharger.

Avoid Unnecessary Engine Idling

During long engine idling periods, the engine coolant temperature will fall below the normal operating range. The incomplete combustion of fuel in a cold engine will cause crankcase dilution, formation of lacquer or gummy deposits on the valves, pistons and rings and rapid accumulation of sludge in the engine.

NOTE: When prolonged engine idling is necessary, maintain at least 800 rpm.

STOPPING

Normal Stopping

1. Release the load and decrease the engine speed. Put all shift levers in the neutral position.

2. Allow the engine to run at half speed or slower with no load for a short time, then move the stop lever to stop to shut down the engine.

Emergency Stopping

If the engine does not stop after using the normal stopping procedure, pull the "Emergency Stop" knob all the way out. This control cuts off the air to the engine. Do not try to restart again until the cause for the malfunction has been found and corrected.

CAUTION: The emergency shut-down system should never be used except in an emergency.

Use of the emergency shut-down can cause oil to be sucked past the oil seals and into the blower housing.

The air shut-off valve, located on the blower air inlet housing, must be reset by hand and the "Emergency Stop" knob pushed in before the engine is ready to start again.

Fuel System

If the unit is equipped with a fuel valve, close it. Fill the fuel tank; a full tank minimizes condensation.

Exhaust System

Drain the condensation from the exhaust line or silencer.

Cooling System

Drain the cooling system if it is not protected with antifreeze and freezing temperatures are expected.

Leave the drains open. Open the raw water drains of a heat exchanger cooling system.

Crankcase

Check the oil level in the crankcase. Add oil, if necessary, to bring it to the proper level on the dipstick.

Transmission

Check and, if necessary, replenish the oil supply in the transmission.

Clean Engine

Clean and check the engine thoroughly to make certain it will be ready for the next run.

Refer to Lubrication and Preventive Maintenance and perform all of the daily maintenance operations. Also perform the operations required for the number of hours or miles the engine has been in operation.

Make the necessary adjustments and minor repairs to correct difficulties which became apparent to the operator during the last run.

ALTERNATING CURRENT POWER GENERATOR SET OPERATING INSTRUCTIONS

These instructions cover the fundamental procedures for operating an alternating current power generator set (Fig. 1). The operator should read these instructions before attempting to operate the generator set.

Never operate a generator set for a short (15 minute) interval the engine will not reach normal operating temperature in so short a period.

Avoid operating the set for extended periods at noload.

Ideally, operate the set for one hour with at least 40% load (generator rating).

When a test must be made with a line load of less than 40% of the generator rating, add a supplementary' load.

Connect the supplementary load to the load terminals of the control cabinet circuit breaker so that the generator can be "loaded" whenever the breaker is closed.

Make certain that the supplementary load is such that it can be controlled to permit a reduction in the load should a normal load increase occur while the set is operating. Locate the supplementary load outside the engine room, if desirable, to provide adequate cooling.

Loading the generator set to 40% of the generator rating and operating it for one-hour intervals will bring the engine and generator to normal operating temperatures and circulate the lubricants properly. Abnormal amounts of moisture, carbon and sludge are due primarily to low internal operating temperatures which are much less likely to occur when the set is tested properly.

PREPARATION FOR STARTING

Before attempting to start a new or an overhauled engine or an engine which has been in storage, perform all of the operations listed under Preparation for Starting Engine First Time. Before a routine start, see Daily Operations in the Lubrication and Preventive Maintenance Chart.

In addition to the Engine Operating Instructions, the



Fig. 1. Location of Controls on Power Generator Set

following instructions also apply when operating an alternating current power generator set.

1. Before the first start, check the generator main bearing oil reservoir. If necessary, add sufficient lubricating oil, of the same grade as used in the engine crankcase, to bring it to the proper level on the sight gage.

2. Check the interior of the generator for dust or moisture. Blow out dust with low pressure air (25 psi maximum). If there is moisture on the interior of the generator, it must be dried before the set is started. Refer to the appropriate Delco Products Maintenance bulletin.

3. The air shut-off valve located in the air inlet housing must be in the open or reset position.

4. Refer to Fig. 1 and place the circuit breaker in the off position.

5. If the generator set is equipped with synchronizing lamps, place the lamp switch in the off position.

6. Turn the voltage regulator rheostat knob counterclockwise to its lower limit.

7. Make sure the power generator set has been cleared of all tools or other objects which might interfere with its operation.

STARTING

If the generator set is located in a closed space, start the ventilating fan or open the doors and windows, as weather permits, to supply ample air to the engine.

The engine may require the use of a cold weather starting aid if the ambient temperature is below 40° F. Refer to *Cold Weather Starting Aids.*

Press the throttle button and turn the throttle control (Fig. 1) counterclockwise to a position midway between **run** and **stop.** Then press the starting switch firmly.

If the engine fails to start within 30 seconds, release the starting switch and allow the starting motor to cool a few minutes before trying again. If the engine fails to start after four attempts, an inspection should be made to determine the cause.

CAUTION: To prevent serious damage to the starter, if the engine does not start, do not press the starting switch again while the starting motor is rotating.

RUNNING

Observe the engine oil pressure gage immediately after starting the engine. If there is no oil pressure indicated within 10 to 15 seconds, stop the engine and check the engine lubricating system. If the oil pressure is observed to be normal, increase the throttle setting to cause the engine to run at its synchronous speed.

PREPARING GENERATOR FOR LOAD

After the engine is warmed up (or the oil pressure has stabilized) prepare the generator set for load as follows:

1. Bring the engine up to the rated speed.

2. Turn the instrument switch to the desired position.

3. Turn the voltage regulator rheostat knob slowly in a clockwise direction to raise the voltage, while watching the voltmeter, until the desired voltage is attained.

4. If the generator set is equipped with a frequency meter, adjust the engine speed with the vernier throttle knob until the desired frequency is indicated on the meter.

5. Make sure all power lines are clear of personnel, then place the circuit breaker control in the on position.

NOTE: Perform Step 5 only if the generator set is not being paralleled with an existing power source. If it is being paralleled with a power source already on the line, read and follow the instructions under *Paralleling* before turning the circuit breaker control to the on position.

PARALLELING

If the load conditions require an additional unit to be placed on the line, the following instructions will apply to power generator sets of equal capacity, with one generator set in operation on the line.

1. Prepare the generator set to be paralleled as outlined under *Preparation For Starting, Starting, Running* and Items 1 through 4 under *Preparing Generator for Load.*

2. Check the voltmeter (Fig. 1); the voltage must be the same as the line voltage. Adjust the voltage regulator rheostat control if the voltages are not the same.

3. Place the synchronizing lamp switch, of the generator set to be paralleled, in the on position.

4. Turn the vernier throttle knob until both units are operating at approximately the same frequency as indicated by the slow change in the brilliancy of the synchronizing lamps.

5. When the synchronizing lamps glow and then go out at a very slow rate, time the dark interval. Then, in the middle of this interval, turn the circuit breaker control to the on position. This places the incoming generator set on the line, with no load. The proper share of the existing load must now be placed on this generator.

6. The division of the kilowatt load between the alternating current generators operating in parallel depends on the power supplied by the engines to the generators as controlled by the engine governors and is practically independent of the generator excitation. Divide the kilowatt load between the generators by turning the vernier throttle knob counterclockwise on the incoming generator and clockwise on the generator that has been carrying the load (to keep the frequency of the generators constant) until both ammeters read the same, indicating that each generator is carrying its proper percentage of the total K.W. load.

7. The division of the reactive KVA load depends on the generator excitation as controlled by the voltage regulator. Divide the reactive load between the generators by turning the voltage regulator rheostat control on the incoming generator (generally clockwise to raise the voltage) until the ammeters read the same on both generator sets and the sum of the readings is minimum.

NOTE: The generator sets are equipped with a resistor and current transformer connected in series with the voltage coil of the regulator (crosscurrent compensation) which equalizes most but not all of the reactive KVA load between the generators.

8. When the load is 80 per cent power factor lagging (motor and a few lights only), turn the vernier throttle knob on the incoming generator until the ammeter on that unit reads approximately 40 per cent of the total current load.

9. Rotate the voltage regulator rheostat control on the incoming generator clockwise to raise the voltage until the ammeters read the same on both units.

NOTE: If a load was not added during paralleling, the total of the two ammeter readings should be the same as the reading before paralleling. Readjust the voltage regulator rheostat on the incoming generator, if necessary.

10. To reset the load voltage, turn the voltage regulator rheostat controls slowly on each unit. It is necessary to turn the controls the same amount and in the same direction to keep the reactive current equally divided.

Power generator sets with different capacities can also be paralleled by dividing the load proportionately to their capacity.

STOPPING

The procedure for stopping a power generator set or taking it out of parallel is as follows:

1. Turn off all of the load on the generator when stopping a single engine unit.

2. Shift the load from the generator when taking it out of parallel operation by turning the vernier throttle knob until the ammeter reads approximately zero.

3. Place the circuit breaker control in the of position.

4. Turn the voltage regulator rheostat control in a counterclockwise direction to the limit of its travel.

5. Press the throttle button and turn the throttle control to stop to shut-down the engine.

NOTE: When performing a tune-up on a generator set that will be operated in parallel with another unit, adjust the speed droop as specified in Engine Tune-Up.

CAUTION: Machine designed to operate at the following maximum pressure settings and volumes.

FUNCTION SWING						
Pressure Settings and Volumes	*Main Winch*	*Aux Winch*	*Boom Winch*	*Telescope*		
	Main	*Main*	*Main*	*Main*	*Main*	*Ports*
PSI Relief Setting	2200	3000	3000	2500	2800	2500
G.P.M. Volume	10 min	60 min	60 min	34 min	18 min	18 min

NOTE: Priority Valve Pressure Setting 1650 psi. Volume and pressures are to be checked with hydraulic oil at operating temperature and 1780 engine rpm. Unauthorized pressure settings in excess of the above values voids all warranties expressed or implied.

LUBRICATION AND PREVENTIVE MAINTENANCE

To obtain the best performance and long life from a Detroit Diesel engine, the Operator must adhere to the following schedule and instructions on lubrication and preventive maintenance.

The daily instructions pertain to routine or daily starting of an engine and not to a new engine or one that has not been operated for a considerable period of time. For new or stored engines, carry out the instructions given under *Preparation for Starting Engine First Time under Operating Instructions.*

The time intervals given in the chart on the following page are actual operating hours or miles of an engine. If the lubricating oil is drained immediately after an engine has been run for some time, most of the sediment will be in suspension and, therefore, will drain readily.

All authorized *Detroit Diesel Allison Service Outlets* are prepared to service engines with the viscosity and grade of lubricants recommended on the following pages.

LUBRICATION AND PREVENTIVE MAINTENANCE CHART	Time Interval								
Item Operation Hours / Miles		8	50	100	200	300	500	1,000	2,000
	Daily	240	1,500	3,000	6,000	9,000	15,000	30,000	60,000
1. Engine Oil	X								
2. Oil Filter*									
3. Coolant and Filter	X						X	X	
4. Hoses							X		
5. Radiator								X	
6. Heat Exchanger Electrodes and Core							X	X	
7. Raw Water Pump[1]	X								
8. Fuel Tank	X						X		
9. Fuel Strainer and Filter						X			
10. Air Cleaners		X					X		
11. Air Box Drains							X	X	
12. Ventilating System								X	
13. Blower Screen								X	
14. Starting Motor*									
15. Battery-Charging Alternator				X	X		X		X
16. Battery				X					
17. Tachometer Drive and Clutch Controls				X					
18. Throttle Controls					X				
19. Engine Tune-Up*									
20. Drive Belts		X			X				
21. Overspeed Governor							X		
22. Fan Hub Bearings*									
23. Shut-Down System						X			
24. Hydrostarter System*									
25. Air Compressor Air Strainer					X				
26. Turbocharger*									
27. Power Generator				X		X			
28. Power Take-Off		X	X				X		
29. Torqmatic Converter	X		X				X		
30. Marine Gear	X				X			X**	

*See items on following pages

**Twin Disc Marine Gear

Item 1

Check the oil level daily before starting the engine. Add oil, if necessary, to bring it to the proper level on the dipstick.

Select the proper grade of oil in accordance with the instructions in the Lubricating Oil Specifications.

It is recommended that new engines be started with 100 hour oil change periods. The drain interval may then be gradually increased, or decreased, following the recommendations of an independent oil analysis laboratory or the oil supplier (based upon the oil sample analysis) until the most practical oil change period has been established.

Item 2

Install new engine oil filter elements and gaskets each time the engine oil is changed. Check for oil leaks after starting the engine. If the engine is equipped with a governor oil filter, change the element every 1,000 hours.

Item 3

Check the coolant level daily and maintain it near the top of the heat exchanger tank or the radiator upper tank.



Items 1 and 2



Items 3 and 4

Clean the cooling system every 1,000 hours or 30,000 miles using a good radiator cleaning compound in accordance with the instructions on the container. After the cleaning operation, rinse the cooling system thoroughly with fresh water. Then fill the system with soft water, adding a good grade of rust inhibitor or a high boiling point type antifreeze (refer to Engine Coolant). With the use of a proper antifreeze or rust inhibitor, this interval may be lengthened until, normally, this cleaning is done only in the spring or fall. The length of this interval will, however, depend upon an inspection for rust or other deposits on the internal walls of the cooling system. When a thorough cleaning of the cooling system is required, it should be reverse-flushed.

If the cooling system is protected by a coolant filter and conditioner, the filter element should be changed every 500 hours or 15,000 miles.

Item 4

Inspect all of the cooling system hoses at least once every 500 hours or 15,000 miles for signs of deterioration. Replace the hoses if necessary.

Item 5

Inspect the exterior of the radiator core every 1.,000 hours or 30,000 miles and, if necessary, clean it with a quality grease solvents such as Oleum and compressed air. Do not use fuel oil, kerosene or gasoline. It may be necessary to clean the radiator more frequently if the engine is being operated in extremely dusty or dirty areas.

Item 6

Every 500 hours drain the water from the heat exchanger raw water inlet and outlet tubes. Then remove the zinc electrodes from the inlet side of the



Item 5



Item 6



Item 7

raw water pump and the heat exchanger. Clean the electrodes with a wire brush or, if worn excessively, replace with new electrodes. To determine the condition of a used electrode, strike it sharply against a hard surface; a weakened electrode will break.

Drain the cooling system, disconnect the raw water pipes at the outlet side of the heat exchanger and remove the retaining cover every 1,000 hours and inspect the heat exchanger core. If a considerable amount of scale or deposits are present, contact an authorized Detroit Diesel Allison Service Outlet.

Item 7

Check the prime on the raw water pump; the engine should not be operated with a dry pump. Prime the pump, if necessary, by removing the pipe plug provided in the pump inlet elbow and adding water. Reinstall the plug.

Item 8

Keep the fuel tank filled to reduce condensation to a minimum. Select the proper grade of fuel in accordance with the Diesel Fuel Oil Specifications.

Open the drain at the bottom of the fuel tank every 500 hours or 15,000 miles to drain off any water or sediment.

Item 9

Install new elements every 300 hours or 9,000 miles or when plugging is indicated.

A method of determining when elements are plugged to the extent that they should be changed is based on the fuel pressure at the cylinder head fuel inlet manifold and the inlet restriction at the fuel pump.

to the extent that they should be changed is based on the fuel pressure at the cylinder head fuel inlet manifold and the inlet restriction at the fuel pump. In a clean system, the maximum pump inlet restriction must not exceed 6 inches of mercury. At normal operating speeds (1800-28()0 rpm), the fuel pressure is 45 to 70 psi. Change the fuel filter elements whenever the inlet restriction (suction) at the fuel pump reaches 12 inches of mercury at normal operating speeds and whenever the fuel pressure at the inlet manifold falls to 45 psi.

Item 10

Remove the dirty oil and sludge from the oil bath-type air cleaner cups and center tubes every 8 hours or less if operating conditions warrant. Wash the cups and elements in clean fuel oil and refill the cups to the level mark with the same grade of heavy duty oil as used in the engine. The frequency of servicing may be varied to suit local dust conditions.



Item 9



Item 10

It is recommended that the body and fixed element in the heavy-duty oil bath type air cleaner be serviced every 500 hours, 15,000 miles or as conditions warrant.

Clean or replace the element in the dry-type air cleaner when the restriction indicator instrument indicates high restriction or when a water manometer reading at the air inlet housing indicates the maximum allowable air inlet restriction (refer to the Air Inlet Restriction chart in the Trouble Shooting section). Refer to the instructions in the Air System section for servicing the dry-type air cleaner.

Item 11

With the engine running, check for flow of air from the air box drain tubes every 1,000 hours or 30,000 miles. If the tubes are clogged, remove, clean and reinstall the tubes. The air box drain tubes should be cleaned periodically even though a clogged condition is not apparent. If the engine is equipped with an air box drain tank, drain the sediment periodically. If the engine is equipped with an air box drain check valve, replace the valve every 500 hours or 15,000 miles.

Item 12

Clean the externally mounted crankcase breather assemblies every 1,000 hours or 30,000 miles. This cleaning period may be reduced or lengthened according to severity of service. Clean the internally mounted breather pads at time of engine overhaul, or sooner if excessive crankcase pressure is observed.



Item 11

mounted breather pads at time of engine overhaul, or sooner if, excessive crankcase pressure is observed.

Remove the crankcase breather from the engine and wash the steel mesh pad (element) in fuel oil and dry it with compressed air. Reinstall the breather assembly.

Clean the breather cap, mounted on the valve rocker cover, in clean fuel oil every time the engine oil is changed.

Item 13

Inspect the blower screen and gasket assemblies every 1,000 hours or 30,000 miles and, if necessary, clean the screens in fuel oil and dry them with compressed air.



Item 12



Item 13

Reinstall the screen and gasket assemblies with the screen side of the assemblies toward the blower.

Inspect for evidence of blower seal leakage.

Item 14 The electrical starting motor is lubricated at the time of original assembly. Oil can be added to the oil wicks, which project through each bushing and contact the armature shaft, by removing the pipe plugs on the outside of the motor. The wicks should be lubricated whenever the starting motor is taken off the engine or disassembled.

The Sprag overrunning clutch drive mechanism should be lubricated with a few drops of light engine oil whenever the starting motor is overhauled.

Item 15 Lubricate the alternator bearings or bushings with 5 or 6 drops of engine oil at the hinge cap oiler every 200 hours or 6,000 miles.

Some alternators have a built-in supply of grease, while others use sealed bearings. In these latter two cases, additional lubrication is not necessary.

The slip rings and brushes of an alternator can be inspected through the end frame assembly. If the slip rings are dirty, they should be cleaned with 400 grain or finer polishing cloth. Never use emery cloth to clean slip rings. Hold the polishing cloth against the slip rings with the alternator in operation and blow away



Item 14



Item 15

all dust after the cleaning operation. If the slip rings are rough or out of round, replace them.

Inspect the terminals for corrosion and loose connections and the wiring for frayed insulation.

Item 16

Check the specific gravity of the electrolyte in each cell of the battery every 100 hours or 3,000 miles. In warm weather, however, it should be checked more frequently due to a more rapid loss of water from the electrolyte. The electrolyte level should be maintained in accordance with the battery manufacturer's recommendations.

Item 17

Lubricate the tachometer drive every 100 hours or 3,000 miles with an all purpose grease at the grease fitting. At temperatures above +30°F., use a No. 2 grade grease. Use a No. I grade grease below this temperature.

Item 18

Lubricate the throttle control mechanism every 200 hours or 6,000 miles with an all purpose grease. At

Item 17

temperatures above +30°F., use a No. 2 grade grease. Use a No. 1 grade grease below this temperature. Lubricate all other control mechanisms, as required, with engine oil.

Item 19

There is no scheduled interval for performing an engine tune-up. As long as the engine performance is satisfactory, no tune-up should be needed. Minor adjustments In the valve and injector operating mechanisms, governor, etc. should only be required periodically to compensate for normal wear on parts.

Item 20

New drive belts will stretch after the first few hours of operation. Run the engine for 15 seconds to seat the belts and readjust the tension. Then check the belts and retighten the fan drive, pump drive and battery charging alternator drive belts after 1/2 hour or 15 miles and again after 8 hours or 140 miles of operation. Thereafter, check the tension of the drive

belts every 200 hours or 6,000 miles and adjust, if necessary. Too tight a belt is destructive to the bearings of the driven part; a loose belt will slip.

BELT TENSION CHART (lbs/belt)

Model	Fan Drive		Generator Drive		
	2 or 3 belts	Single belt	Two 3/8" or 1/2'-belts	One 1/2" belt	One9/16 belt "
3,4-53	40-50	-	40-50	50-70	40-50
6v-53	60-80	80-100	40-50	50-70	40-50
All	For 3-point or triangular drive use o tension of 90-120.				

Replace all belts In a set when one is worn. Single belts of similar size should not be used as a substitute for a matched belt set; premature belt wear can result because of belt length variation. All belts in a matched set are within .032 " of their specified center distances.

NOTE: When installing or adjusting an accessory drive belt, be sure the bolt at the accessory adjusting pivot point is properly tightened, as well as the bolt in the adjusting slot.

Adjust the belt tension so that a firm push with the thumb, at a point midway between the two pulleys, will depress the belt 1/2" to 3/4". If a belt tension gage such as BT-33-73FA or equivalent is available, adjust the belt tension as outlined in the chart.

Item 21

Lubricate the overspeed governor, if it is equipped with a hinge-type cap oiler or oil cup, with 5 or 6 drops of engine oil every 500 hours. Avoid excessive lubrication and do not lubricate the governor while the engine is running.

Item 22

At a major engine overhaul, discard the bearings in the fan hub assembly used in radiator cooled engines. Pack the hub assembly, using new bearings, with Texaco Premium RB grease or an equivalent Lithium base multi-purpose grease.

Item 23

Check the shut-down system every 300 operating hours or each month to be sure it will function when needed.



Item 20

Item 24

On engines equipped with a Hydrostarter, refer to the *Hydraulic Starting System* in the section on *Engine Equipment* for preventive maintenance and lubrication.

Item 25

To clean either the hair or polyurethane type air compressor air strainer element, saturate and squeeze it in fuel oil, or any other cleaning agent that would not be detrimental to the element, until dirt free. Then dip it in lubricating oil and squeeze it dry before placing it back in the air strainer.

For replacement of the air strainer element, contact the nearest Bendix Westinghouse dealer; replace with the polyurethane element, if available.

Item 26

There is no scheduled interval for performing an inspection on the Airesearch turbocharger. As long as the turbocharger is operating satisfactorily and there



Item 25



Item 27

is no appreciable loss of power, no vibration or unusual noise and no oil leaks, only a periodic inspection is necessary. When service is required, contact an authorized Detroit Diesel Allison Service Outlet.

Item 27

The power generator requires lubrication at only one point the ball bearing in the end frame.

If the bearing is oil lubricated, check the oil level in the sight gage every 300 hours; change the oil every six months. Use the same grade of oil as specified for the engine. Maintain the oil level to the line in the sight gage. Do not overfill After adding oil, recheck the oil level after running the generator for several minutes.

If the bearing is grease lubricated, a new generator has sufficient grease for three years of normal service. Thereafter, it should be lubricated at one year intervals. To lubricate the bearing, remove the filler and relief plugs on the side and the bottom of the bearing reservoir. Add grease until new grease appears at the relief plug opening. Run the generator a few minutes to vent the excess grease; then reinstall the plugs.

The following greases, or their equivalents, are recommended:
Keystone 44H.....Keystone Lubrication Co.
BRB Lifetime..... Socony Vacuum Oil Co.
NY and NJ F926 or F927..... NY and NJ Lubricant Co.

After 100 hours on new brushes, or brushes in generators that have not been in use over a long period, remove the end frame covers and inspect the brushes, commutator and collector rings. If there is no appreciable wear on the brushes, the inspection interval may be extended until the most practicable period has been established (not to exceed six months). To prevent damage to the commutator or the collector rings, do not permit the brushes to become shorter than 3/4 inch.

Keep the generator clean inside and out. Before removing the end frame covers, wipe off the loose dirt. The loose dirt and dust may be blown out with low pressure air (25 psi maximum). Remove all greasy dirt with a cloth.

Item 28

Lubricate all of the power take-off bearings with an all purpose grease such as Shell Alvania No. 2, or

equivalent. Lubricate sparingly to avoid getting grease on the clutch facing.

Open the cover on the side of the clutch housing (8" and 10" diameter clutch) and lubricate the clutch release sleeve collar through the grease fitting every 8 hours. On the 11-1/2" diameter clutch, lubricate the collar through the fitting on the side of the clutch housing every 8 hours.

Lubricate the clutch drive shaft pilot bearing through the fitting in the outer end of the drive shaft (8" and 10" diameter clutch power take-offs) every 50 hours of operation. One or two strokes with a grease gun should be sufficient. The clutch drive shaft pilot bearing used with the 11-1/2" diameter clutch power take-off is prelubricated and does not require lubrication.

Lubricate the clutch drive shaft roller bearings through the grease fitting in the clutch housing every 50 hours under normal operating conditions (not continuous) and more often under severe operating conditions or continuous operation.

Lubricate the clutch release shaft through the fittings at the rear of the housing every 500 hours of operation.

Lubricate the clutch levers and links sparingly with engine oil every 500 hours of operation. Remove the inspection hole cover on the clutch housing and lubricate the clutch release levers and pins with a hand oiler. To avoid getting oil on the clutch facing, do not over lubricate the clutch release levers and pins.

Check the clutch facing for wear every 500 hours. Adjust the clutch if necessary.

Item 29

Check the oil level in the Torqmatic converter and supply tank daily. The oil level must be checked while the converter is operating, the engine idling and the oil is up to operating temperature (approximately 200°F). If the converter is equipped with an input disconnect clutch, the clutch must be engaged.

Check the oil level after running the unit a few minutes. The oil level should be maintained at the proper level on the dipstick. If required, add hydraulic transmission fluid type "C-2" (see chart). Do not *overfill* the converter as too much oil will cause foaming and high oil temperature.

The oil should be changed every 500 hours of operation. Also, the oil should be changed whenever it shows traces of dirt or effects of high operating temperature as evidenced by discoloration or strong odor. If the oil shows metal contamination, contact an authorized *Detroit Diesel Allison Service Outlet* as this usually requires disassembly. Under severe operating conditions, the oil should be changed more often.



Item 28

Prevailing Ambient Temperature	Recommended Oil Specification
Above - 10 F	Hydraulic Transmission Fluid, Type C-2.
Below -10 F	Hydraulic Transmission Fluid, Type C-2Auxiliary preheat required to raise temperature in the sump to a temperature above -10 F.

0IL RECOMMENDATIONS

The converter oil breather, located on the oil level indicator (dipstick), should be cleaned each time the converter oil is changed. This can be accomplished by allowing the breather to soak -in a solvent, then drying it with compressed air.

The full-flow oil filter element should be removed, the shell cleaned and a new element and gasket installed each time the converter oil is changed.

Lubricate the input clutch release bearing and ball bearing every 50 hours with an all purpose grease through the grease fittings provided on the clutch housing. This time interval may vary depending upon the operating conditions. Over-lubrication will cause grease to be thrown on the clutch facing, causing the clutch to slip.



Item 30

Item 30

WARNER MARINE GEAR:
Check the oil level daily. Start and run the engine at idle speed for a few minutes to fill the lubrication system. Stop the engine. Then immediately after stopping the engine, check the oil level in the marine gear. Bring the oil level up to the proper level on the dipstick. Use the same grade of lubricating oil that is used in the engine. **Do not overfill.**

Change the oil every 200 hours. After draining the oil from the unit, clean the removable oil screen thoroughly before refilling the marine gear with oil.

TWIN DISC MARINE GEAR:
Check the marine gear oil level daily. Check the oil level with the engine running at low idle speed and the gear in neutral, Keep the oil up to the proper level on the dipstick. Use oil of the same *heavy-duty* grade and viscosity that is used in the engine.

Change the oil every 200 hours. Remove and clean the oil inlet strainer screen after draining the oil and before refilling the marine gear. The strainer is located in the sump at the lower end of the pump suction line. When refilling after an oil drain, bring the oil up to the proper level on the dipstick (approximately 5 quarts).

DETROIT DIESEL FUEL OIL SPECIFICATIONS

Detroit Diesel designs, develops, and manufactures commercial diesel engines to operate on diesel fuels classified by the A.S.T.M. as Designation D975 (grades I-D and 2-D). These grades are very similar to grades DF-l and DF-2 of Federal Specification VV-F-800.

Residual fuels and furnace oils, generally, are not considered satisfactory for Detroit Diesel engines. In some regions, however. fuel suppliers may distribute one fuel that is marketed as either diesel fuel (A.S.T.M. D-975) or domestic heating fuel (A.S.T.M. D-396) sometimes identified as furnace oil. In this case, the fuel should be investigated to determine whether the properties conform with those shown in the FUEL OIL SELECTION CHART. presented in this specification.

The FUEL OIL SELECTION CHART also will serve as a guide in the selection of the proper fuel for various applications. The fuels used must be clean, completely distilled, stable, and non-corrosive. DISTILLATION RANGE. CETANE NUMBER, and SULFUR CONTENT are three of the most important properties of diesel fuels that must be controlled to insure optimum combustion and minimum wear. Engine speed, load, and ambient temperature influence the selection of fuels with respect to distillation range and cetane number. The sulfur content of the fuel must be as low as possible to avoid excessive deposit formation, premature wear, and to minimize the sulfur dioxide exhausted into the atmosphere.

To assure that the fuel you use meets the required properties, enlist the aid of a reputable fuel oil supplier.

The responsibility for clean fuel lies with the fuel supplier as well as the operator.

During cold weather engine operation, the cloud point (the temperature at which wax crystals begin to form in diesel fuel) should be 10° F below the lowest expected fuel temperature to prevent clogging of the fuel filters by wax crystals.

At temperatures below 20° F, consult an authorized Detroit Diesel service outlet, since particular attention must be given to the cooling system, lubricating system, fuel system, electrical system, and cold weather starting aids for efficient engine starting and operation.

STATEMENT OF POLICY ON FUELS AND LUBRICANTS

In answer to requests concerning the use of fuel and lubricating oil additives. the following excerpts have been taken from a policy statement of General Motors Corporation:

> *"It has been and continues to be Gene(al Motors policy' to build motor vehicles that will operate satisfactorily on the commercial fuels and lubricants of good quality regularly provided by the petroleum industry through retail outlets. It is accordingly contrary to the policy of General Motors to recommend the regular and continued use of supplementary additives in such fuels and lubricants.*
>
> *"This policy should not be confused with the fact that certain supplementary additives may effectively and economically solve specific operating problems which occasionally arise in some vehicles. In such instances, supplementary additives may be developed on the basis of suitable tests to remedy such problems without otherwise causing harm to vehicles. These selected products are then given official GM part numbers and made available for use in appropriate service applications.*
>
> *"While General Motors Corporation assumes responsibility for the additives selected by it to remedy specific operating problems, it cannot, of course, accept responsibility for the many other additives which are constantly being marketed."*

Although the stated Corporation policy is self-explanatory, the following is emphasized: Detroit Diesel does not recommend or support the use of any supplementary fuel or lubricant additives. These include all products marketed as fuel conditioners, smoke suppressants, masking agents, reodorants, tune-up compounds, top oils, break-in oils, graphitizers and friction reducing compounds.

NOTE: The manufacturer's warranty applicable to Detroit Diesel engines provides in part that the provisions of such warranty shall not apply to any engine unit which has been subject to misuse, negligence or accident. Accordingly, malfunctions attributable to neglect or failure to follow the manufacturer's fuel or lubricating recommendations indicated above may not be within the coverage of the warranty.

FUEL OIL SELECTION CHART

Typical Application	General Fuel Classification	Final Boiling Point (Max)	Cetane No. (Min)	Sulfur Content (Max)
City Buses	No. 1-D	550° F	45	0.30%
All Other Applications	Winter No. 2-D	675° F	45	0.50%
	Summer No. 2-D	675° F	40	0.50%

NOTE: When prolonged idling periods or cold weather conditions below 320 F are encountered, the use of lighter distillate fuels may be more practical. The same consideration must be made when operating at altitudes above 5,000 ft.

DETROIT DIESEL LUBRICATING OIL SPECIFICATIONS

OIL QUALITY

OIL QUALITY is the responsibility of the oil supplier. (The term oil supplier is applicable to refiners, blenders, and rebranders of petroleum products, and does not include distributors of such products).

There are hundreds of commercial crankcase oils marketed today. Obviously, engine manufacturers or users cannot completely evaluate the numerous commercial oils. The selection of a suitable lubricant in consultation with a reliable oil supplier, observance of his oil drain recommendations (based on used oil sample analysis and experience) and proper filter maintenance, will provide the best assurance of satisfactory oil performance.

Detroit Diesel lubricant recommendations are based on general experience with current lubricants of various types and give consideration to the commercial lubricants presently available.

RECOMMENDATION

Detroit Diesel engines have given optimum performance and experienced the longest service life with the following oil performance levels having the ash and zinc limits shown:

Former Military and Commercial Lube Identification	New API Letter Code Service Classification	SAE Grade †
MIL-L-2104B/1964 MS Supplement 1	CC/SC CB	30 or 40 30 or 40

† SAE 30 and 40 grades have both performed satisfactorily in Detroit Diesel engines. Obviously, the expected ambient temperatures and engine cranking capability must be considered by the engine owner/operator when selecting the proper grade of oil.

ASH LIMIT
The sulfated ash limit (A.S.T.M. D-874) of the above lubricants shall not exceed 1.000% by weight, except lubricants that contain only barium detergent-dispersant salts where 1.500% by weight is allowed. The majority of lubricants marketed under the performance levels shown above have a sulfated ash content between 0.55 to 0.85% by weight.

ZINC CONTENT
The zinc content, as zinc diorganodithiophosphate, shall be a minimum of 0.07% by weight.

RECOMMENDATIONS REGARDING THE USE OF CURRENT OIL PERFORMANCE LEVEL PRODUCTS MEETING PRESENT MILITARY LUBRICANT SPECIFICATIONS

The petroleum industry is currently marketing engine crankcase oils that may be identified as follows:

Military or Commercial Identification	API Letter Code Service Classification	Comment on Application and Performance
MIL-L-2104C	CD/SC	Supersedes MIL-L-45199B (Series 3) intended for diesel service.
MIL-L-46152	CC/SE	Supersedes MIL-L-2104B intended for gasoline engine passenger cars.
Universal	Numerous	Meets the performance criteria of all industry accepted tests and all current military specifications including MIL-L-2104C and MIL-L-46152.

Detroit Diesel does not have sufficient experience with any of the above described lubricants to recommend their use. Some oil suppliers have reported satisfactory performance of the above identified products marketed by them. If an owner/operator intends to use any of the above described products, it is recommended he obtain evidence from the oil supplier that the lubricant has performed satisfactorily in Detroit Diesel engines. The above products may be satisfactory for use in Detroit Diesel engines under the following conditions:

1. The sulfated ash (A.S.T.M. D-874) limit of the above lubricants shall not exceed 1.000% by weight, except lubricants that contain only barium detergent-dispersant salts where 1.500% by weight is allowed.

2. The zinc content, as zinc diorganodithiophosphate, shall be a minimum of 0.07% by weight.

3. Sufficient evidence of satisfactory performance in Detroit Diesel engines has been provided to Detroit Diesel and/or the customer.

LUBRICANTS NOT RECOMMENDED

The following lubricants are NOT recommended because of a history of poor performance in Detroit Diesel engines:

Military or Commercial Identification	API Letter Code Service Classification	Comment on Performance
MIL-L-2104B/1968 MS	CC/SD	Excessive ash deposits formed
MIL-L-45199B (Series 3)	CD	Excessive ash deposits formed
Multigrade oils	Numerous	History of poor performance in most heavy duty diesel engines

COLD WEATHER OPERATION

Cold weather starting will be facilitated when immersion type electrical coolant heaters can be used. Other practical considerations, such as the use of batteries, cables and connectors of adequate size, generators or alternators of ample capacity, proper setting of voltage regulators, ether starting aids, oil and coolant heater systems, and proper fuel selection will accomplish starting with the use of SAE 30 or SAE 40 oils. For complete cold weather starting information, consult an authorized Detroit Diesel service outlet. Ask for Engineering Bulletin No. 38 entitled: "Cold Weather Operation"

NORTH SLOPE & OTHER EXTREME SUB-ZERO OPERATIONS

Some new special arctic lubricants have recently been developed for Military use in extremely cold climates. The oils that have shown best cold temperature performance may be described as multigrades having a synthetic base stock and low volatility characteristics. At this time a new Military arctic oil specification is being developed. The good oil performers have passed the oil performance criteria defined in (tentative) Federal Test Method 354 of Federal Test Standard 791. The lubricants may be used where continuous sub-zero temperatures prevail and where engines are shut down for periods longer than eight (8) hours. These are not comparable to the performance of SAE 30 or 40 oils at operating conditions and should be considered only as a last resort when engine cranking is a severe problem and auxiliary heating aids are not available.

OIL CHANGES

The oil change period is dependent on the operating conditions (e.g. load factor, etc.) of an engine that will vary with the numerous service applications. It is recommended that new engines be started with 150 hour oil change periods. For highway vehicles this corresponds to approximately 4,500 miles, and for "city" service vehicles, approximately 2,500 miles. The drain interval may then be gradually increased, or decreased with experience on a specific lubricant while also considering the recommendations of the oil supplier (analysis of the drained oil can be helpful here) until the most practical oil drain period for the particular service has been established.

Solvents should not be used as flushing oils in running engines. Dilution of the fresh refill oil supply can occur, which may be detrimental.

Full flow oil filtration systems have been used in Detroit Diesel engines since they have been manufactured. For the best results, the oil filter element should be replaced each time the oil is changed.

NEW ENGINE OIL CLASSIFICATION SYSTEM

A relatively new engine oil classification system has been introduced to industry that describes the criteria required to meet each performance level. A simplified cross-reference of oil and current commercial and military specifications is shown below.

CROSS-REFERENCE OF LUBE OIL CLASSIFICATION SYSTEMS

API Code Letters	Comparable Military or Commercial Industry Spec.
CA	MIL-L-2104A
CB	Supplement 1
CC	MIL-L-2104B (see Note 1 below)
CD	MIL-L-45199B (Series 3)
‡	MIL-L-46152 (supersedes MIL-L-2104B for Military only)
■	MIL-L-2104C (supersedes MIL-L-45199B for Military only)
SA	none
SB	none
SC	1964 MS oils — Auto passenger car
SD	1968 MS oils — Auto passenger car
SE	1972 MS oils — Auto passenger car

NOTE 1: MIL-L-2104B Lubricants are currently marketed and readily available for Commercial use. MIL-L-2104B oils are obsolete for Military service applications only.

‡ Oil performance meets or exceeds that of CC and SE oils.
■ Oil performance meets or exceeds that of CD and SC oils.

For complete descriptions, consult the following publications:

1. Society of Automotive Engineers (SAE) Technical Report J-183a.
2. Federal Test Method Standard 791a.

PUBLICATION AVAILABLE SHOWING COMMERCIAL "BRAND" NAME LUBRICANTS

A list of "brand" name lubricants distributed by the majority of worldwide oil suppliers can be purchased from the Engine Manufacturers Association (EMA). The publication is titled, "EMA Lubricating Oils Data Book for Heavy Duty Automotive and Industrial Engines." The publication shows the brand names, oil performance levels, viscosity grades, and sulfated ash contents of most "brands" marketed.

ENGINE MANUFACTURERS ASSOCIATION
111 EAST WACKER DRIVE
CHICAGO, ILLINOIS 60601

ENGINE COOLANT

Engine coolant is considered as any solution which is circulated through the engine to provide the means for heat transfer from the various engine components. In general, water containing various materials in solution is used for this purpose.

The function of the coolant is basic in the design and the successful operation of the engine and must be carefully selected and properly maintained.

COOLANT REQUIREMENTS

A suitable coolant solution must meet the following five basic requirements:

1. Provide for adequate heat transfer.

2. Provide a corrosion resistant environment within the cooling system.

3. Prevent formation of scale or sludge deposits in the cooling system.

4. Be compatible with the cooling system hose and seal materials.

5. Provide adequate freeze protection during cold weather operation.

Normally requirements 1 through 4 are satisfied by combining a suitable water with reliable inhibitors. When operating conditions dictate the need for freeze protection, a solution of suitable water and an ethylene glycol type antifreeze containing adequate inhibitors will provide a satisfactory coolant.

WATER

Any water, whether of drinking quality or not, will produce a corrosive environment in the cooling system.

Also, scale deposits may form on the internal surfaces of the cooling system due to the mineral content of the water. Therefore, water selected as a coolant must be properly treated with inhibitors to control corrosion and scale deposition.

To determine if a particular water is suitable for use as a coolant when properly inhibited, the following characteristics must be considered. The concentration of (I) chlorides, (2) sulfates, (3) total hardness and (4) dissolved solids. These materials are objectionable for a number of reasons: chlorides and/or sulfates will accelerate corrosion, while hardness (percentage of magnesium and calcium present) will cause deposits of scale. Total dissolved solids may cause scale deposits, sludge deposits, corrosion or a combination of these. Chlorides, sulfates, magnesium and calcium are among but not necessarily all the materials which make up dissolved solids. Water, within the limits specified in Tables 1 and 2 of Figure 1, is satisfactory as an engine coolant when proper inhibitors are added.

CORROSION INHIBITORS

A corrosion inhibitor is a water soluble chemical compound which protects the metallic surfaces of the cooling system against corrosive attack. Some of the more commonly used corrosion inhibitors are chromates, borates, nitrates, nitrites and soluble oil. Depletion of all types of inhibitors occur through normal operation and therefore strength levels must be maintained by the addition of inhibitors at prescribed intervals. Always follow the supplier's recommendations on inhibitor usage and handling.

Chromates

Sodium chromate and potassium dichromate are two of the best and more commonly used water system corrosion inhibitors. However, the restrictive use of these materials, due to ecology considerations, has deemphasized their use in favor of non-chromates. Care should be exercised in handling these materials due to their toxic nature.

Chromate inhibitors must not be used in ethylene glycol antifreeze solutions. Chromium hydroxide, commonly called "green slime", can result from the use of chromate inhibitors with permanent type antifreeze. This material deposits on the cooling system passages, reducing the heat transfer rate and will result in engine overheating. Engines which have operated with a chromate inhibited water must be chemically cleaned before the addition of ethylene glycol type antifreeze. A commercial heavy duty descaler should be used in accordance with the manufacturer's recommendation for this purpose.

Soluble Oil

Soluble oil has been used as a corrosion inhibitor for many years. It has, however, required very close attention relative to the concentration level due to adverse effects on heat transfer if the concentration exceeds 1% by volume. For example: 1-1/4% of soluble oil in the cooling system increases fire deck temperatures 6% and a 2-1/2% concentration raises

TABLE 1

	PARTS PER MILLION	GRAINS PER GALLON
Chlorides (Maximum)	40	2.5
Sulfates (Maximum)	100	5.8
Total Dissolved Solids (Maximum)	340	20
Total Hardness (Maximum)	170	10

Refer to Table 2 for evaluation of water intended for use in a coolant solution

TABLE 2


Determine The Concentrations Of Chlorides, Sulfates, And Total Dissolved Solids In The Water
Chlorides Under 40 ppm, And Sulfates Under 100 ppm, And Total Dissolved Solids Under 340 ppm.
Chlorides Over 40 ppm, Or Sulfates Over 100 ppm, Or Total Dissolved Solids Over 340 ppm.
Determine Total Hardness Of The Water
Distill, De-mineralize, Or De-ionize The Water
Total Hardness Under 170 ppm
Total Hardness Over 170 ppm
Water Suitable For Use in Coolant
Plus Inhibitors
Soften The Water
Water Suitable For Use In Coolant
Plus Inhibitors

Figure 1

fire deck temperature up to 15%. Soluble oil is not recommended as a corrosion inhibitor.

Non-Chromates

Non-chromate inhibitors (borates, nitrates, nitrites, etc.) provide corrosion protection in the cooling system with the basic advantage that they can be used with either water or a water and ethylene glycol solution.

INHIBITOR SYSTEMS

An inhibitor system is considered as a combination of

COOLANT INHIBITOR CHART

Inhibitor or Inhibitor System	Corrosion Inhibitor Type	Complete Inhibitor System	Water	Inhibitor Ethylene Glycol Base Antifreeze	Compatability *Methoxy Propanol Base Antifreeze
Sodium chromate	Chromate	No	Yes	No	No
Potassium dichromate	Chromate	No	Yes	No	No
Perry filter elements:					
5020 (type OS)	Chromate	Yes	Yes	No	No
S-453 (Spin-on)	Chromate	Yes	Yes	No	No
5030 (type OS)	@Non-chromate	Yes	Yes	Yes	No
S-331 (Spin-on)	@Non-chromate	Yes	Yes	Yes	No
5070 (type OS)	#Non-chromate	Yes	Yes	Yes	No
S-473 (Spin-on)	# Non-chromate	Yes	Yes	Yes	No
Lenroc filter element	Non-chromate	Yes	Yes	Yes	No
Fleetguard filter elements:					
DCA (canister)	Non-chromate	Yes	Yes	Yes	No
DCA (Spin-on)	Non-chromate	Yes	Yes	Yes	No
AC filter elements:					
DCA (canister)	Non-chromate	Yes	Yes	Yes	No
DCA (Spin-on)	Non-chromate	Yes	Yes	Yes	No
Luber-Finer filter elements:					
LW-4739 (canister)	Non-chromate	Yes	Yes	Yes	No
LFW-4744 (spin-on)	non-chromate	Yes	Yes	Yes	No
Nalcool 2000 (liquid)	Non-chromate	Yes	Yes	Yes	No
Perry LP-20 (liquid)	Non-chromate	Yes	Yes	Yes	No
Lubercool (liquid)	Nonchromate	Yes	Yes	Yes	No
Dowtherm cooling system conditioner	Non-chromate	Yes	Yes	Yes	Yes

***Dowtherm 209, or equivalent.**
(@Perry "Year Around" formula.
 # Perry "Universal" formula.

Figure 2

chemical compounds which provide corrosion protection, pH control and water softening ability. Corrosion protection has been discussed earlier under the section on Corrosion Inhibitors. The pH control is used to maintain an acid free solution. The water softening ability deters formation of mineral deposits. Inhibitor systems are available in various forms such as coolant filter elements, liquid and dry bulk inhibitor additives and as an integral part of permanent antifreeze.

Coolant Filter Elements

Replaceable elements are available with various chemical inhibitor systems. Care should be used in the selection of elements relative to inhibitor compatibility with coolant solutions shown in Figure 2.

Problems have developed from the use of the magnesium lower support plate used by some manufacturers in their coolant filters. The magnesium



Figure 3

plate will be attacked by solutions which will not be detrimental to other metals in the cooling system. The dissolved magnesium will be deposited in the hottest zones of the engine where heat transfer is most critical (Figure 3). The use of aluminum or zinc in preference to magnesium is recommended to eliminate this type of deposit.

A high chloride coolant will have a detrimental effect on the water softening capabilities of systems using ion-exchange resins. Accumulations of calcium and magnesium ions removed from the coolant and held captive by the zeolite resin can be released into the coolant by a regenerative process caused by high chloride content solutions.

Bulk Inhibitor Additives

Commercially packaged inhibitor systems are available which can be added directly to the engine coolant or to bulk storage tanks containing coolant solution.

Both chromate and non-chromate systems are available and care should be taken regarding inhibitor compatability with other coolant constituents (Figure 2).

A non-chromate inhibitor system is recommended for use in Detroit Diesel engines. The non-chromate systems can be used with either water or ethylene glycol antifreeze solutions and provide corrosion protection, pH control and water softening. Some of the approved non-chromate inhibitor systems offer the additional advantage of a simple on site test to determine protection level and, since they are added directly to the coolant, require no additional hardware or plumbing.



Figure 4

ANTIFREEZE

When freeze protection is required, an ethylene glycol base permanent antifreeze should be used. An inhibitor system is included in this type of antifreeze and no additional inhibitors are required on initial fill if a minimum antifreeze concentration of 30% by volume is used. Solutions of less than 30% concentration do not provide sufficient corrosion protection. Concentrations over 67% adversely affect freeze protection and heat transfer rates (Figure 4).

Methoxy propanol base antifreeze may be used for freeze protection in Series 53 engines. Before installing methoxy propanol base antifreeze in an engine, the entire cooling system should be drained, flushed with clean water, and examined for rust, scale, contaminants, etc.

If deposits are present, the cooling system must be chemically cleaned with a commercial grade heavy-duty de-scaler.

Inhibitor depletion will occur in ethylene glycol base antifreeze through normal service. The inhibitors should be replenished at approximately 500 hour or 20,000 mile intervals with a non-chromate inhibitor system. Commercially available inhibitor systems (Fig. 2) may be used to re-inhibit antifreeze solutions.

Several brands of permanent antifreeze are available with sealer additives. The specific type of sealers vary with the manufacturer. Antifreeze with sealer additives is not recommended for use in Detroit Diesel engines due to plugging problems throughout various areas of the cooling system.

COOLANT RECOMMENDATIONS

1. Always use a properly inhibited coolant.

2. If freeze protection is required, always use ethylene glycol antifreeze.

3. Re-inhibit antifreeze with a non-chromate inhibitor system.

4. Always follow the manufacturer's recommendations on inhibitor usage and handling.

5. Do not use soluble oil.

6. Chromate inhibitors should never be used with permanent antifreeze.

7. Sealer type antifreeze should not be used.

8. Maintain prescribed inhibitor strength.

9. Do not mix ethylene glycol base antifreeze with methoxy propanol base antifreeze in the cooling system.

ENGINE TUNE-UP PROCEDURES

There is no scheduled interval for performing an engine tune-up. As long as the engine performance is satisfactory, no tune-up should be needed. Minor adjustments in the valve and injector operating mechanisms, governor, etc. should only be required periodically to compensate for normal wear on parts.

Three types of governors are used. Since each governor has different characteristics, .the tune-up procedure varies accordingly. The three types are:

1. Limiting speed mechanical.

2. Variable speed mechanical.

3. Hydraulic.

The mechanical engine governors are identified by a name plate attached to the governor housing. The letters D.W.-L.S. stamped on the name plate denote a double-weight limiting speed governor. A single-weight variable speed governor name plate is stamped S.W.-V.S.

Normally, when performing a tune-up on an engine in service, it is only necessary to check the various adjustments for a possible change in the settings. However, if the cylinder head, governor or injectors have been replaced or overhauled, then certain preliminary adjustments are required before the engine is started.

The preliminary adjustments consist of the first four items in the tune-up sequence. The procedures are the same except that the valve clearance is greater for a cold engine.

To tune-up an engine completely, all of the adjustments are made by following the applicable tune-up sequence given below after the engine has reached the normal operating temperature. Since the adjustments are normally made while the engine is stopped, it may be necessary to run the engine between adjustments to maintain normal operating temperature.

Tune-Up Sequence for Mechanical Governor

1. Adjust the exhaust valve clearance.
2. Time the fuel injectors.
3. Adjust the governor gap.
4. Position the injector rack control levers.
5. Adjust the maximum no-load speed.
6. Adjust the idle speed.
7. Adjust the buffer screw.
8. Adjust the throttle booster spring (variable speed governor only).
9. Adjust the supplementary governing device (if used).

Tune-Up Sequence for Hydraulic Governor

1. Adjust the exhaust valve clearance.

2. Time the fuel injectors.

3. Adjust the fuel rod.

4. Position the injector rack control levers.

5. Adjust the load limit screw.

6. Adjust the speed droop.

7. Adjust the maximum no-load speed.

NOTE: Use new valve rocker cover gasket(s)after each tune-up.

EXHAUST VALVE CLEARANCE ADJUSTMENT

The correct exhaust valve clearance at normal engine operating temperature is important for smooth, efficient operation of the engine.

Insufficient valve clearance can result in loss of compression, misfiring cylinders, and eventually burned valve seats and valve seat inserts. Excessive valve clearance will result in noisy operation, especially in the low speed range.

Whenever the cylinder head is overhauled, the exhaust valves reconditioned or replaced, or the valve operating mechanism is replaced or disturbed in any way, the valve clearance must first be adjusted to the cold setting to allow for normal expansion of the engine parts during the engine warm-up period. This will ensure a valve setting which is close enough to the specified clearance to prevent damage to the valves when the engine is started.

All of the exhaust valves may be adjusted, in firing order sequence, during one full revolution of the crankshaft. Refer to the General Specifications at the front of the manual for the engine firing order.

TWO VALVE CYLINDER HEADS

Cold Engine

1. Place the speed control lever in the idle speed position. If a stop lever is provided, secure it in the no-fuel position.

2. Remove the loose dirt from the valve rocker cover(s) and remove the cover(s).

3. Rotate the crankshaft, manually or with the starting motor, until the injector follower is fully depressed on the cylinder to be adjusted.

CAUTION: If a wrench is used on the crankshaft bolt, do not turn the engine in a left-hand direction of rotation as the bolt will be loosened.

4. Loosen the exhaust valve rocker arm push rod lock nut.



Fig. 1 - Adjusting Valve Clearance (Two-Valve Cylinder Head)

5. Place a .012" feeler gage, J 9708, between the valve stem and the rocker arm (Fig. 1). Adjust the push rod to obtain a smooth pull on the feeler gage.

6. Remove the feeler gage. Hold the push rod with a 5/16"wrench and tighten the lock nut with a 1/2 "wrench.

7. Recheck the clearance. At this time, if the adjustment is correct, the .010"gage will pass freely between the end of the valve stem and the rocker arm and the .012 " gage will not pass through.

8. Check and adjust the remaining valves in the same manner as outlined above.

Hot Engine

Maintaining normal engine operating temperature is particularly important when making the final valve clearance adjustment. If the engine is allowed to cool off before setting any of the valves, the clearance, when running at full load, may become insufficient.

1. With the engine at normal operating temperature (160 -185°F.), recheck the exhaust valve clearance with feeler gage J 9708. At this time, if the valve clearance is correct, the .008" gage will pass freely between the end of the valve stem and the rocker arm and the .010" gage will not pass through. Readjust the push rod, if necessary.

2. After the exhaust valve clearance has been adjusted, check the fuel injector timing.

FOUR VALVE CYLINDER HEADS



Fig. 2 - Adjusting Valve Clearance (Four-Valve Cylinder Head)

Cold Engine

1. Place the speed control lever in the idle speed position. If a stop lever is provided, secure it in the no-fuel position.

2. Remove the loose dirt from the valve rocker cover(s) and remove the cover(s).

3. Rotate the crankshaft until the injector follower is fully depressed on the cylinder to be adjusted.

CAUTION: If a wrench is used on the crankshaft bolt, do not turn the engine in a left-hand direction of rotation as the bolt will be loosened.

4. Loosen the exhaust valve rocker arm push rod lock nut.

5. Place a .027" feeler gage, J 9708, between the end of one valve stem and the rocker arm bridge (Fig. 2). Adjust the push rod to obtain a smooth pull on the feeler gage.

6. Remove the feeler gage. Hold the push rod with a 5/16"wrench and tighten the lock nut with a 1/2" wrench.

7. Recheck the clearance. At this time, if the adjustment is correct, the .025" gage will pass freely between the end of one valve stem and the rocker arm bridge and the .027" gage will not pass through. Readjust the push rod if necessary.

8. Check and adjust the remaining exhaust valves, in the same manner as above.

Hot Engine

Maintaining normal engine operating temperature is particularly important when making the final valve clearance adjustment. If the engine is allowed to cool off before setting any of the valves, the clearance, when running at full load, may become insufficient.

1. With the engine at normal operating temperature (160°-185"F.), recheck the exhaust valve clearance with gage J 9708. At this time, if the valve clearance is correct, the .023" gage should pass freely between the end of one valve stem and the rocker arm bridge and the .025" feeler gage should not. Readjust the push rod, if necessary.

2. After the exhaust valve clearance has been adjusted, check the fuel injector timing.

TIMING FUEL INJECTOR

Injector	Timing Dimension	Tool Number
*35	1.508	J 8909
35	1.484	J 1242
40	1.484	J 1242
45	1.484	J 1242
S40	1.460	J 1853
S45	1.460	J 1853
S50	1.460	J 1853
L40	1.460	J 1853
N40	1.460	J 1853
N45	1.460	J 1853
N50	1.460	J 1853

*Reefer Car

To time a fuel injector properly, the injector follower must be adjusted to a definite height in relation to the injector body.

All of the injectors can be timed, in firing order sequence, during one full revolution of the crankshaft.

Time Fuel Injector

After the exhaust valve clearance has been adjusted, time the fuel injector as follows:

1. Place the speed control lever in the idle speed position. If a stop lever is provided, secure it in the no-fuel position.

2. Rotate the crankshaft, manually or with the starting motor, until the exhaust valves are fully depressed on the particular cylinder to be timed.

CAUTION: If a wrench is used on the crankshaft bolt at the front of the engine, do not turn the crankshaft in a left-hand direction of rotation or the bolt will be loosened.



Fig. 3 - Timing Fuel Injector

3. Place the small end of the injector timing gage (see table for correct timing gage) in the hole provided in the top of the injector body, with the flat of the gage toward the injector follower as shown in Fig. 3.

4. Loosen the push rod lock nut.

5. Turn the push rod and adjust the injector rocker arm until the extended part of the gage will just pass-over the top of the injector follower.

6. Hold the push rod and tighten the lock nut. Check the adjustment and readjust, if necessary.

7. Time the remaining injectors as outlined above.

8. If no further engine tune-up is required, use a new gasket(s) and install the valve rocker cover(s).

LIMITING SPEED MECHANICAL GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

IN-LINE ENGINES

The double-weight limiting speed governor is mounted on the rear end plate of the engine and is driven by a gear that extends through the end plate and meshes with either the camshaft gear or the balance shaft gear, depending upon the engine model.

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor and position the injector rack control levers.

NOTE: Before proceeding with the governor and injector rack adjustments, disconnect any supplementary governing device. After the adjustments are completed, re-connect and adjust the supplementary governing device.

Adjust Governor Gap

With the engine stopped and at operating temperature, adjust the governor gap as follows:

1. Remove the high-speed spring retainer cover.

2. Back out the buffer screw (Fig. 8) until it extends approximately 5/8" from the lock nut.



Fig. 1 - Adjusting Governor Gap

3. Start the engine and adjust the idle speed screw (Fig. 7) to obtain the desired engine idle speed. Hold the screw an tighten the lock nut to hold the adjustment.

NOTE: The recommended idle speed for non-EPA certified engines is 500-600 rpm, but may vary with special engine applications.

4. Stop the engine, clean and remove the governor cover and the valve rocker cover. Discard the gaskets.

5. Start and run the engine, between 800 and 1000 rpm by manual operation of the injector control tube lever.

CAUTION: Do not overspeed the engine.

6. Check the gap between the low-speed spring cap and the high-speed spring plunger with a .0015 " feeler gage. If the gap setting is incorrect, reset the gap adjusting screw (Fig. 1). If the setting is correct, the .0015" movement can be seen by placing a few drops of oil into the governor gap and pressing a screw driver against the gap adjusting screw. Movement of



Fig. 2 - Positioning the Rear Injector Rack

the cap toward the plunger will force the oil from the gap in the form of a small bead.

7. Hold the gap adjusting screw and tighten the lock nut.

8. Recheck the gap and readjust if necessary.

9. Stop the engine and, using a new gasket, install the governor cover. The governor cover should be placed on the housing with the pin of the speed control lever projecting into the slot of the differential lever.

10. Install the screws and lock washers finger tight. Pull the cover away from the engine and tighten the screws. This step will properly locate the cover on the governor housing.

Position Injector Rack Control Levers

The position of the injector racks must be correctly set in relation to the governor. Their position determines the amount of fuel injected into each cylinder and ensures equal distribution of the load. Properly positioned injector rack control levers with the engine at full-load will result in the following:

1. Speed control lever at the full-fuel position.

2. Governor low-speed gap closed.

3. High-speed spring plunger on the seat in the governor control housing.

4. Injector racks in the full-fuel position. Adjust the rear injector rack control lever first to establish a guide for adjusting the remaining injector rack control levers.



Fig. 3 - Checking Rotating Movement of Injector Control Rack

1. Disconnect any linkage attached to the speed control lever.

2. Turn the idle speed adjusting screw until 1/2"of the threads (12-14 threads) project from the lock nut, when the nut is against the high-speed plunger.

CAUTION: A false fuel rack setting may result if the idle speed adjusting screw is not backed out as noted above.

NOTE: This adjustment lowers the tension of the low-speed spring so it can be easily compressed. This permits closing the low speed gap without bending the fuel rods or causing the yield mechanism springs to yield or stretch.

3. Back out the buffer screw approximately 5/8", if it has not already been done.

4. Loosen all of the inner and outer injector rack control lever adjusting screws (Fig. 2). Be sure all of the levers are free on the injector control tube.

5. Move the speed control lever to the maximum speed position. Turn the inner adjusting screw down on the rear injector rack control lever until a step-up in effort is noted. This will place the rear injector rack in the full-fuel position. Turn down the outer adjusting screw until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws. This should result in placing the governor linkage and control tube assembly in the



Fig. 4 - Checking Injector Rack "Sprint"

same positions that they will attain while the engine is running at full-load.

6. To be sure of the proper rack adjustment, hold the speed control lever in the full-fuel position and press down on the injector rack with a screw driver or finger tip and note "rotating" movement of the injector control rack (Fig. 3) when the speed control lever is in the maximum speed position. Hold the speed control lever in the maximum speed position and, using a screw driver, press downward on the injector control rack. The rack should tilt downward (Fig. 4) and when the pressure of the screw driver is released, the control rack should "spring" back upward.

If the rack does not return to its original position, it is too loose. To correct this condition, back off the outer adjusting screw slightly and tighten the inner adjusting screw slightly.

The setting is too tight if, when moving the speed control lever from the no-speed to the maximum speed position, the injector rack becomes tight before the speed control lever reaches the end of its travel (as determined by the stop under the governor cover). This will result in a step-up in effort required to move the speed control lever to the end of its travel. To correct this condition, back off the inner adjusting screw slightly and tighten the outer adjusting screw slightly.

NOTE: Overtightening of the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lbs.



Fig 5 - Adjusting Maximum No-Load engine Speed (Type A)

IMPORTANT: The above step should result in placing the governor linkage and control tube assembly in the same position that they will attain while the engine is running at full load.

7. To adjust the remaining injector rack control levers, remove the clevis pin from the fuel rod and the injector control tube lever, hold the injector control racks in the full-fuel position by means of the lever on the end of the control tube. Turn down the inner adjusting screw on the injector rack control lever of the adjacent injector until the injector rack has moved into the full-fuel position and the inner adjusting screw is bottomed on the injector control tube. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

8. Recheck the rear injector rack to be sure that it has remained snug on the ball end of the injector rack control lever while adjusting the adjacent injector. If the rack of the rear injector has become loose, back off the inner adjusting screw slightly on the adjacent injector rack control lever. Tighten the outer adjusting screw. When the settings are correct, the racks of both injectors must be snug on the ball end of their respective rack control levers.



Fig. 6 - Governor spring Assemblies

9. Position the remaining injector rack control levers as outlined in Steps 6 and 7.

10. Connect the fuel rod to the injector control tube lever.

11. Turn the idle speed adjusting screw in until it projects 3/16" from the lock nut to permit starting the engine. Tighten the lock nut.

12. Use a new gasket and replace the valve rocker cover.

Adjust Maximum No-Load Engine Speed
All governors are properly adjusted before leaving the factory. However, if the governor has been reconditioned or replaced, and to ensure the engine speed will not exceed the recommended no-load speed as given on the engine option plate, set the maximum no-load speed as follows:

TYPE A GOVERNOR SPRINGS (Fig. 6):

1. Loosen the lock nut (Fig. 5) and back off the high-speed spring retainer approximately five turns.

2. With the engine at operating temperature and no-load on the engine, place the speed control lever in the full-fuel position. Turn the high-speed spring retainer IN until the engine is operating at the recommended no-load speed.

The best method of determining the engine speed is with an accurate tachometer.

3. Hold the high-speed spring retainer and tighten the lock nut.

TYPE B GOVERNOR SPRINGS (Fig. 6):
1. Start the engine and after it reaches normal operating temperature, remove the load from the engine

2 Place the speed control lever in the maximum speed position and note the engine speed.

3. Stop the engine and, if necessary, adjust the no-load speed as follows:

a. Remove the high-speed spring retainer, high-speed spring and plunger.

CAUTION: To prevent the low-speed spring and cap from dropping into the governor, be careful not to jar the assembly while it is being removed.

b. Remove the high-speed spring from the high-speed spring plunger and add or remove shims (Fig. 6) as required to establish the desired engine no-load speed.

NOTE For each .010" shim added, the engine speed will be increased approximately 10 rpm.

c. Install the high-speed spring on the plunger and install the spring assembly in the governor housing. Install the spring retainer in the governor housing and tighten it securely.

d. Start the engine and recheck the engine no-load speed. Repeat the procedure as necessary to establish the no-load speed.

Adjust Idle Speed
With the maximum no-load speed properly adjusted, adjust the idle speed as follows:

1. With the engine running at normal operating temperature and with the buffer screw backed out to avoid contact with the differential lever, turn the idle speed adjusting screw (Fig. 7) until the engine is operating at approximately 15 rpm below the recommended idle speed.

NOTE: The recommended idle speed for non-EPA certified engines is 500-6 rpm, but may vary with special engine applications.

2. Hold the idle speed adjusting screw and tighten the lock nut.



Fig. 7 - Adjusting Engine Idle Speed



Fig. 8 - Adjusting Buffer Screw

3. Install the high-speed spring cover and tighten the two bolts.

Adjust Buffer crew

With the idle peed properly set, adjust the buffer screw as follows:

1. With the engine running at normal operating temperature, turn the buffer screw in (Fig. 8) so it contacts the differential lever as lightly as possible and still eliminates engine roll.

NOTE: Do not increase the engine idle speed more than 15 rpm with the buffer screw.

2. Recheck the maximum no-load speed. If it has increased more than 25 rpm, back off the buffer screw until the increase is less than 25 rpm.

3. Hold the buffer screw and tighten the lock nut.

LIMITING SPEED MECHANICAL GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

6V-53 ENGINE

The limiting speed mechanical governor is mounted at the rear of the engine, between the flywheel housing and the blower (Fig. 1). The governor is driven by the right blower rotor drive gear. The left blower rotor drive gear is driven by a shaft, that passes through the governor housing, from the engine gear train. There are two types of limiting speed governor assemblies. The difference in the two governors is in the spring mechanism (Fig. 7). One has a long spring mechanism, the other has a short spring mechanism.

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor and position the injector rack control, levers.

NOTE: Before proceeding with the governor and injector rack adjustments, disconnect any supplementary governing device. After the adjustments are completed, re-connect and adjust the supplementary governing device.

Adjust Governor Gap

With the engine stopped and at operating temperature, adjust the governor gap as follows:

1. Remove the high-speed spring retainer cover.



Fig. 1 - Limiting Speed Governor Mounting

2. Back out the buffer screw (Fig. 9) until it extends approximately 5/8" from the lock nut.

CAUTION: Do not back the buffer screw out beyond the limits given, or the control link lever may disengage the differential lever.

3. Start the engine and loosen the idle speed adjusting screw lock nut. Then adjust the idle screw (Fig. 8) to obtain the desired engine idle speed. Hold the screw and tighten the lock nut to hold the adjustment.

NOTE: The recommended idle speed for non-EPA certified engines is 500-600 rpm, but may vary with special engine applications.

4. Stop the engine, clean and remove the governor cover and the valve rocker covers. Discard the gaskets.

5. Start and run the engine, between 800 and 1000 rpm, by manual operation of the differential lever.

CAUTION: Do not overspeed the engine.

6. Check the gap between the low-speed spring cap, and the high-speed spring plunger with a .0015 " feeler gage. If the gap setting is incorrect, reset the gap



Fig. 2 - Adjusting Governor Gap

adjusting screw (Fig. 2). If the setting is correct, the .0015 " movement can be seen by placing a few drops of oil into the governor gap and pressing a screw driver against the gap adjusting screw. Movement of the cap toward the plunger will force the oil from the gap in the form of a small bead.

7. Hold the gap adjusting screw and tighten the lock nut.

8. Recheck the gap and readjust if necessary.

9. Stop the engine and, using a new gasket, install the governor cover.

Position Injector Rack Control Levers

The position of the injector racks must be correctly set in relation to the governor. Their position determines the amount of fuel injected into each cylinder and ensures equal distribution of the load.

Properly positioned injector rack control levers with the engine at full-load will result in the following:

1. Speed control lever at the maximum speed position.

2. Governor low-speed gap closed.

3. High-speed spring plunger on the seat in the governor control housing.

4. Injector fuel control racks in the full-fuel position.



Fig. 3 - Positioning No. 3L Injector Rack Control Lever

The letters R or L indicate the injector location in the right or left cylinder bank, viewed from the rear of the engine. Cylinders are numbered starting at the front of the engine on each cylinder bank. Adjust the No. 3L injector rack control lever first to establish a guide for adjusting the remaining injector rack control levers.

1. Disconnect any linkage attached to the speed control lever.

2. Turn the idle speed adjusting screw until 1/2" of the threads (12-14 threads) project from the lock nut when the nut is against the high-speed plunger.

CAUTION: A false fuel rack setting may result if the idle speed adjusting screw is not backed out as noted above.

NOTE: This adjustment lowers the tension of the low-speed spring so it can be easily compressed. This permits closing the low speed gap without bending the fuel rods or causing the yield mechanism springs to yield or stretch.

3. Back out the buffer screw approximately 5/8", if it has not already been done.

4. Remove the clevis pin from the fuel rod and the right cylinder bank injector control tube lever.

5. Loosen all of the inner and outer injector rack control lever adjusting screws on both injector control tubes. Be sure all of the injector rack control levers are free on the injector control tubes.

6. Move the speed control lever to the maximum speed position; hold it in that position with light finger pressure. Turn the inner adjusting screw on the



Fig 4 - Checking Rotating Movement of Injector Control Rack

No. 3L injector rack control lever down as shown in Fig. 3 until a slight movement of the control tube lever is observed or a step-up in effort to turn the screw driver is noted. This will place the No. 3L injector in the full-fuel position. Turn down the outer adjusting screw until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

NOTE: Overtightening of the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lbs

IMPORTANT: The above step should result in placing the governor linkage and control tube assembly in the same position that they will attain while the engine is running at full-load.

7. To be sure of the proper rack adjustment, hold the speed control lever in the maximum speed position and press down on the injector rack with a screw driver or finger tip and note "rotating" movement of the injector control rack (Fig. 4) when the speed control lever is in the maximum speed position. Hold the speed control lever in the maximum speed position and, using a screw driver, press downward on the injector control rack. The rack should tilt downward (Fig. 5) and when the pressure of the screw driver is released, the control rack should "spring" back upward.

If the rack does not return to its original position, it is too loose. To correct this condition, back off the outer adjusting screw slightly and tighten the inner adjusting screw slightly.



Fig. 5 - Checking Injector Control Rack " Spring"

The setting is too tight if, when moving the speed control lever from the no-speed to the maximum speed position, the injector rack becomes tight before the speed control lever reaches the end of its travel (as determined by the stop under the governor cover). This will result in a step-up in effort required to move the speed control lever to the end of its travel. To correct this condition, back off the inner adjusting screw slightly and tighten the outer adjusting screw slightly.

8. Remove the clevis pin from the fuel rod and the left bank injector control tube lever.

9. Insert the clevis pin in the fuel rod and the right cylinder bank injector control tube lever and position the No. 3R injector rack control lever as previously outlined in Step 6 for the No. 3L injector rack control lever.

10. Insert the clevis pin in the fuel rod and the left cylinder bank injector control tube lever. Repeat the check on the 3L and 3R injector rack control levers as outlined in Step 7. Check for and eliminate any deflection which may occur at the bend in the fuel rod where it enters the cylinder head.

11. To adjust the remaining injector rack control levers, remove the clevis pin from the fuel rods and the injector control tube levers, hold the injector control racks in the full-fuel position by means of the lever on the end of the control tube, and proceed as follows:

a. Turn down the inner adjusting screw of the injector rack control lever until the screw bottoms (injector control rack in the full-fuel position).
b. Turn down the outer adjusting screw of the injector rack control lever until it bottoms on the injector control tube.
c. While still holding the control tube lever in the full-fuel position, adjust the inner and outer adjusting screws to obtain the same condition as outlined in Step 7. Tighten the screws.

CAUTION: Once the No. 3L and No. 3R injector rack control levers are adjusted, do not try to alter their settings. All adjustments are made on the remaining control racks.

NOTE: Overtightening of the injector rack control tube lever_ adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lbs.

12. When all of the injector rack control levers are adjusted, recheck their settings. With the control tube lever in the full-fuel position, check each control rack as in Step 7. All of the control racks must have the same "spring" condition with the control tube lever in the full-fuel position.

13. Insert the clevis pin in the fuel rod and the injector control tube levers.

14. Turn the idle speed adjusting screw in until it projects 3/16" from the lock nut to permit starting the engine.

15. Use new gaskets and replace the valve rocker covers.

Adjust Maximum No-Load Engine Speed

All governors are properly adjusted before leaving the factory. However, if the governor has been reconditioned or replaced, and to ensure the engine speed will not exceed the recommended no-load speed as given on the engine option plate, set the maximum no-load speed as follows:

TYPE A GOVERNOR SPRINGS (Fig. 7):
1. Loosen the lock nut-with a spanner wrench and back off the high-speed spring retainer several turns. Then start the engine and increase the speed slowly. If the speed exceeds the required no-load speed before the speed control lever reaches the end of its travel, back off the spring retainer a few additional turns.



Fig. 6 - Adjusting Maximum No-Load Engine Speed

2. With the engine at operating temperature and no- load on the engine, place the speed control lever in the maximum speed position. Turn the high-speed spring retainer in (Fig. 6) until the engine is operating at the recommended no-load speed. Use an accurate hand tachometer to determine the engine speed. The maximum no-load speed varies with the full-load operating speed.

3. Hold the spring retainer and tighten the lock nut.

TYPE B GOVERNOR SPRINGS (Fig. 7):
1. Start the engine and after it reaches normal operating temperature, remove the load from the engine.

2. Place the speed control lever in the maximum speed position and note the engine speed.

3. Stop the engine and, if necessary, adjust the no-load speed as follows:

a. Remove the high-speed spring retainer with tool



Fig. 7 - Governor Spring Assemblies

J 5895 and withdraw the high-speed spring and plunger assembly.

CAUTION: To prevent the low-speed spring and cap from dropping into the governor, be careful not to jar the assembly while it is being removed.

b. Remove the high-speed spring from the high-speed spring plunger and add or remove shims as required to establish the desired engine no-load speed.

NOTE: For each .010"in shims added, the engine speed will be increased approximately 10 rpm.

c. Install the high-speed spring on the plunger and install the spring assembly in the governor housing. Install the spring retainer in the governor housing and tighten it securely. The maximum no-load speed varies with the full-load operating speed desired.

d. Start the engine and recheck the no-load speed. Repeat the procedure as necessary to establish the no-load speed required.

Adjust Idle Speed

With the maximum no-load speed properly adjusted, adjust the idle speed as follows:

1. With the engine running at normal operating temperature and with the buffer screw backed out to avoid contact with the differential lever, turn the idle speed adjusting screw (Fig. 8) until the engine is operating at approximately 15 rpm below the recommended idle speed.

NOTE: The recommended idle speed for non-EPA certified engines is 500-600 rpm, but may vary with special engine applications.

If the engine has a tendency to stall during deceleration, install a new buffer screw. The current buffer screw uses a heavier spring and restricts the travel of the differential lever to the off (no-fuel) position.

2. Hold the idle screw and tighten the lock nut.

3. Install the high-speed spring retainer cover and tighten the two bolts.

Adjust Buffer Screw

With the idle speed properly set, adjust the buffer screw as follows:

1. With the engine running at normal operating temperature, turn the buffer screw in (Fig. 9) so it contacts the differential lever as lightly as possible and still eliminates engine roll.

NOTE: Do not increase the engine idle speed more than 15 rpm with the buffer screw.

2. Recheck the maximum no-load speed. If it has increased more than 25 rpm, back off the buffer screw until the increase is less than 25 rpm.

3. Hold the buffer screw and tighten the lock nut.



Fig. 8 - Adjusting Engine Idle Speed



Fig. 9 - Adjusting Buffer Screw

VARIABLE SPEED MECHANICAL GOVERNOR (OPEN LINKAGE) AND INJECTOR RACK CONTROL ADJUSTMENT

IN-LINE ENGINES

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor (Fig. 1) and the injector rack control levers.

Preliminary Governor Adjustments

1. Clean the governor linkage and lubricate the ball joints and bearing surfaces with clean engine oil.

2. Back out the buffer screw until it projects 9/16" from the boss on the control housing.



Fig. 1 - Variable Speed Open Linkage Governor Mounted on Engine

3. Back out the booster spring eye bolt until it is flush with the outer lock nut.

Adjust Variable Speed Spring Tension

1. Adjust the variable speed spring eye bolt until 1/8"of the threads project from the outer lock nut (Fig. 2).

2. Tighten both lock nuts to retain the adjustment.

NOTE: **This setting of the eye bolt will produce approximately 7% droop in engine speed from no-load to full-load.**

Position Injector Rack Control Levers

The position of the injector control racks must be correctly set in relation to the governor. Their position

Fig. 2 - Adjusting Governor Spring Eye Bolt

determines the amount of fuel injected into each cylinder and ensures equal distribution of the load. Adjust the rear injector rack control lever first to establish a guide for adjusting the remaining levers.

1. Clean and remove the valve rocker cover. Discard the gasket.

2. Disconnect the fuel rod at the stop lever.

3. Loosen all of the inner and outer injector rack control lever adjusting screws. Be sure all of the injector rack control levers are free on the injector control tube.

4. Move the speed control lever to the maximum speed position.

5. Adjust the rear cylinder injector rack control lever adjusting screws (Fig. 3) until both screws are equal in height and tight on the injector control tube.

6. Move the rear injector control rack into the full-fuel position and note the clearance between the fuel rod and the cylinder head bolt. The clearance should be 1/32" or more. If necessary, readjust the injector rack adjusting screws until a clearance of at least 1/32" to 1/16" exists. Tighten the adjustment screws.

Fig. 3 - Adjusting Injector Rack Control Lever Adjusting Screws

7. Loosen the nut which locks the ball joint on the fuel rod. Hold the fuel rod in the full-fuel position and adjust the ball joint until it is aligned and will slide on the ball stud on the stop lever (Fig. 4). Position the shutdown cable clip and tighten the fuel rod lock nut to retain the adjustment.

8. Check the adjustment by pushing the fuel rod toward the engine and make sure the injector control rack is in the full-fuel position. If necessary, readjust the fuel rod.

9. Manually hold the rear injector rack in the full-fuel position, with the lever on the injector control tube, and turn the inner adjusting screw of the adjacent injector rack control lever down until the injector rack moves into the full-fuel position. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

NOTE: Overtightening of the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lb.

10. Recheck the rear injector rack to be sure that it has remained snug on the ball end of the rack control lever while adjusting the adjacent injector rack. If the rack of the rear injector has become loose, back off the inner adjusting screw slightly on the adjacent injector rack control lever and tighten the outer adjusting screw. When the settings are correct, the racks of both injectors must be snug on the ball end of their respective control levers.



Fig. 4 · Adjusting Fuel Rod Length

11. Position the remaining injector rack control levers as outlined in Steps 9 and 10.

Adjust Maximum No-Load Speed

1. With the engine running, move the speed control lever to the maximum speed position. Use an accurate tachometer to determine the no-load speed of the engine.

NOTE: Do not overspeed the engine.

2. Loosen the lock nut and adjust the maximum speed adjusting screw (Fig. 5) until the required no-load speed is obtained.

3. Hold the adjusting screw and tighten the lock nut.

Adjust Engine Idle Speed

1. Make sure the stop lever is in the run position and place the speed control lever in the idle position.

2. With the engine running at normal operating temperature, loosen the lock nut and turn the idle speed adjusting screw (Fig. 6) until the engine idles at the recommended speed. The recommended idle speed is 500 rpm. However, the idle speed may vary with special engine applications.



Fig. 5 - Adjusting Maximum No-Load Engine Speed

3. Hold the idle speed adjusting screw and tighten the lock nut.

Adjust Buffer Screw

1. With the engine running at idle speed, turn the buffer screw in (Fig. 7) so that it contacts the stop lever as lightly as possible and still eliminates engine roll.

NOTE: Do not raise the engine idle speed more than 20 rpm with the buffer screw. Check the maximum no-load speed to make sure it has not increased over 25 rpm by the buffer screw setting.

Adjust Governor Booster Spring

The governor booster spring is used on some engines to reduce the force necessary to move the speed control lever from the idle speed position to the maximum speed position. Adjust the booster spring as follows:

1. Move the speed control lever to the idle speed position.

2. Reduce the tension on the booster spring, if not

Fig. 6 · Adjusting Idle Speed



Fig. 7 - Adjusting Buffer Screw

previously performed, to the minimum by backing off the outer lock nut (Fig. 8) until the end of the booster spring eye bolt is flush with the end of the nut.

3. Adjust the eye bolt in the slot in the bracket so that an imaginary line through the booster spring will align with an imaginary center line through the speed control shaft. Secure the lock nuts on the eye bolt to retain the adjustment.

4. Move the speed control lever to the maximum speed position and note the force required. To reduce the force, back off the inner lock nut and tighten the outer lock nut to increase the tension on the booster spring.

NOTE Before tightening the lock nuts, reposition the booster spring as in Step 3.

The setting is correct when the speed control lever can be moved from the idle speed position to the maximum speed position with a constant force, while the engine is running, and when released it will return to the idle speed position.



Fig. 8 - Adjusting Booster Spring

Adjust Engine Speed Droop

The adjustment of the spring tension as outlined under Adjust Variable Speed Spring Tension will result in approximately 7% droop from the maximum no-load speed to the full-load speed. This is the optimum droop setting for most applications. However, the droop may be changed as necessary for a particular engine application.

1. Lower the speed droop by increasing the spring tension.

2. Raise the speed droop by decreasing the spring tension.

NOTE: A change in the variable speed spring tension will change the maximum no-load speed and the engine idle speed which must also be readjusted.

VARIABLE SPEED MECHANICAL GOVERNOR (ENCLOSED LINKAGE) AND INJECTOR RACK CONTROL ADJUSTMENT

IN-LINE ENGINES

The single-weight variable speed governor is mounted on the rear end plate of the engine and is driven by a gear that extends through the end plate and meshes with either the camshaft gear or the balance shaft gear, depending upon the engine model.

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor and position the injector rack control levers.

NOTE: Before proceeding with the governor and injector rack adjustments, disconnect any supplementary governing device. After the adjustments are completed, reconnect and adjust the supplementary governing device.

Adjust Governor Gap

With the engine stopped and at operating temperature, adjust the governor gap as follows:



Fig. 1 - Checking Governor Gap

1. Disconnect any linkage attached to the governor levers.

2. Back out the buffer screw until it extends approximately 5/8" from the lock nut.

3. Clean and remove the governor cover and valve rocker cover. Discard the gaskets.

4. Place the speed control lever (Fig. 1) in the maximum speed position.

5. Insert a .006" feeler gage between the spring plunger and the plunger guide as shown in Fig. 1. If required, loosen the lock nut and turn the gap adjusting screw in or out until a slight drag is noted on the feeler gage.

6. Hold the adjusting screw and tighten the lock nut. Check the gap and readjust if necessary.

7. Use a new gasket and install the governor cover as follows:

   a. Place the cover on the governor housing, with the

Fig. 2 - Positioning the Rear Injector Rack Control Lever

pin in the throttle shaft assembly entering the slot in the differential lever.

b. Install the four cover screws and lock washers finger tight.

c. Pull the cover assembly in a direction away from the engine, to take up the slack, and tighten the cover screws.

NOTE: This step is required since no dowels are used to locate the cover on the housing.

Position Injector Rock Control Levers

The position of the injector control rack levers must be correctly set in relation to the governor. Their position determines the amount of fuel injected into each cylinder and ensures equal distribution of the load. Properly positioned injector control rack levers with the engine at full-load will result in the following:

1. Speed control lever at the maximum speed position.

2. Stop lever in the RUN position.

3. Injector fuel control racks in the full-fuel position.

Adjust the rear injector rack control lever first to establish a guide for adjusting the remaining levers.

1. Loosen all of the inner and outer injector rack control lever adjusting screws (Fig. 2). Be sure all of the levers are free on the injector control tube.

2. Move the speed control lever to the maximum speed position.



Fig. 3 - Checking Rotating Movement of Injector Control Rack



Fig. 4 · Checking Injector Control Rack "' Spring"

3. Move the stop lever to the RUN position and hold it in that position with light finger pressure. Turn the inner adjusting screw of the rear injector rack control lever down until a slight movement of the control tube is observed or a step-up in effort to turn the screw driver is noted. This will place the rear injector rack in the full-fuel position. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws. This should result in placing the governor linkage and control tube in the respective positions that they will attain while the engine is running at full load.

NOTE: Overtightening of the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36in- lbs.

4. To be sure of proper rack adjustment, hold the stop lever in the RUN position and press down on the injector rack with a screw driver or finger tip and note "rotating" movement of the injector control rack (Fig. 3). Hold the stop lever in the RUN position and, using a screw driver, press downward on the injector control rack. The rack should tilt downward (Fig. 4) and, when the pressure of the screw driver is released, the control rack should "spring" back upward.

If the rack does not return to its original position, it is too loose. To correct this condition, back off the outer adjusting screw slightly and tighten the inner adjusting screw. The setting is too tight if, when moving the stop lever from the STOP to the RUN position, the injector rack becomes tight before the stop lever reaches the end of its travel. This will result in a step-up in effort

required to move the stop lever to the RUN position and a deflection in the fuel rod (fuel rod deflection can be seen at the bend). If the rack is found to be too tight, back off the inner adjusting screw slightly and tighten the outer adjusting screw.

5. To adjust the remaining injector rack control levers, remove the clevis pin from the fuel rod and the injector control tube lever, hold the injector control racks in the full-fuel position by means of the lever on the end of the control tube. Turn down the inner adjusting screw on the injector rack control lever of the adjacent injector until the injector rack has moved into the full-fuel position and the inner adjusting screw is bottomed on the injector control tube. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

6. Recheck the rear injector rack to be sure that it has remained snug on the ball end of the rack control lever while adjusting the adjacent injector rack. If the rack of the rear injector has become loose, back off the inner adjusting screw slightly on the adjacent injector rack control lever and tighten the outer adjusting screw. When the settings are correct, the racks of both injectors must be snug on the ball end of their respective control levers.

7. Position the remaining injector rack control levers as outlined in Steps 4, 5 and 6.

8. When all of the injector rack control levers are adjusted, recheck their settings. With the control tube lever in the full-fuel position, check each control rack as in Step 4. All of the control racks must have the same "spring" condition with the control tube lever in the full-fuel position.

9. Insert the clevis pin in the fuel rod and the injector control tube levers.



Fig. 5 · Locating of Shims and Stops

10. Use a new gasket and replace the valve rocker cover.

Adjust Maximum No-Load Speed

All governors are properly adjusted before leaving the factory. However, if the governor has been reconditioned or replaced, and to ensure the engine speed will not exceed the recommended no-load speed as given on the option plate, the maximum no-load speed may be set as follows: Start the engine and, after it reaches normal operating temperature, determine the maximum no-load speed of the engine with an accurate tachometer. Then stop the engine and make the following adjustments, if required.

1. Refer to Fig. 8 and disconnect the booster spring and the stop lever retracting spring.

2. Remove the variable speed spring housing and the variable speed spring retainer located inside of the housing.

3. Refer to Table 1 and determine the stops or shims required for the desired full-load speed. Do not use more than four thick and one thin shim. A split stop can only be used with a solid stop (Fig. 5).

4. Install the variable speed spring retainer and housing and tighten the two bolts.

5. Connect the booster spring and stop lever spring. Start the engine and recheck the maximum no-load speed.

6. If required, add shims to obtain the necessary operating speed. For each .001 " in shims added, the operating speed will increase approximately 2 rpm.

IMPORTANT: If the maximum no-load speed is raised or lowered more than 50 rpm by the

Full Load Speed RPM	STOPS		SHIMS
	Solid Ring	Split Ring	
2575–2800	0	0	As Required
2101–2575	1	0	As Required
1701–2100	1	1	As Required
1200–1700	1	2	As Required

TABLE 1

Fig. 6 - Adjusting Idle Speed

installation or removal of shims, recheck the governor gap. If readjustment of the governor gap is required, the position of the injector racks must be rechecked.

> **NOTE: Governor stops are used to limit the compression of the governor spring which determines the maximum speed of the engine.**

Adjust Idle Speed

With the maximum no-load speed properly adjusted, adjust the idle speed as follows:

1. Place the stop lever in the RUN position and the speed control lever in the IDLE position.

2. With the engine running at normal operating temperature, back out the buffer screw to avoid contact with the differential lever.

3. Loosen the lock nut and turn the idle speed adjusting screw (Fig. 6) until the engine is operating at approximately 15 rpm below the recommended idle speed.

The recommended idle speed is 550 rpm, but may vary with special engine applications.

4. Hold the idle speed adjusting screw and tighten the lock nut.



Fig. 7 - Adjusting Buffer Screw

Adjust Buffer Skew

1. With the engine running at normal operating temperature, turn the buffer screw in (Fig. 7) so that it contacts the differential lever as lightly as possible and still eliminates engine roll.

> **NOTE: Do not increase the engine idle speed more than 15 rpm with the buffer screw.**

2. Hold the buffer screw and tighten the lock nut.

Adjust Booster Spring

With the engine idle speed adjusted, adjust the booster spring as follows:

1. Move the speed control lever to the idle speed position.

2. Refer to Fig. 8 and loosen the booster spring retaining nut on the speed control lever. Loosen the lock nuts on the eye bolt at the opposite end of the booster spring.

3. Move the spring retaining bolt in the slot of the speed control lever until the center of the bolt is on or slightly over center (toward the idle speed position) of an imaginary line through the bolt, lever shaft and eye bolt. Hold the bolt and tighten the lock nut.

4. Start the engine and move the speed control lever to the maximum speed position and release it. The lever should return to the idle speed position. If it does not, reduce the tension on the booster spring. If it does, continue to increase the spring tension until the point is reached where it will not return to idle.



Fig. 8 · Adjusting Booster Spring

Then reduce the spring tension until the lever does return to idle and tighten the lock nuts on the eye bolt. This setting will result in the minimum force required to operate the speed control lever.

5. Connect the linkage to the governor levers.

VARIABLE SPEED MECHANICAL GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

6V-53 ENGINE

The variable speed mechanical governor assembly is mounted at the rear of the 6V engine, between the flywheel housing and the blower (Fig. 1). The governor is driven by the right-hand blower rotor drive gear.

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor and position the injector rack control levers.

> **NOTE: Before proceeding with the governor and injector rack adjustments, disconnect any supplementary governing device. After the adjustments are completed, reconnect and adjust the supplementary governing device.**

Adjust Governor Gap

With the engine stopped and at normal operating temperature, adjust the governor gap as follows:

1. Disconnect any linkage attached to the governor levers.

2. Back out the buffer screw until it extends approximately 5/8" from the lock nut.



Fig. 1 - Variable Speed Governor Mounting

3. Clean and remove the governor cover and the valve rocker covers. Discard the gaskets.

4. Place the speed control lever in the maximum speed position.

5. Insert a .006" feeler gage between the spring plunger and the plunger guide as shown in Fig. 2. If required, loosen the lock nut and turn the adjusting screw in or out until a slight drag is noted on the feeler gage.

6. Hold the adjusting screw and tighten the lock nut Check the gap and readjust if necessary.

7. Use a new gasket and install the governor cover.

Position Injector Rack Control Levers

The position of the injector control racks must be correctly set in relation to the governor. Their position determines the amount of fuel injected into each cylinder and ensures equal distribution of the load.

1. Speed control lever at the maximum speed position.



Fig. 2 - Adjusting Governor Gap



Fig. 3 · Positioning No. 3L Injector Rack Control Lever

2. Stop lever in the RUN position.

3. Injector fuel control racks in the full-fuel position.

The letters R or L indicate the injector location in the right or left cylinder bank, viewed from the rear of the engine. Cylinders are numbered starting at the front of the engine on each cylinder bank. Adjust the No. 3L injector rack control lever first to establish a guide for adjusting the remaining levers.

Properly positioned injector rack control levers with the engine at full-load will result in the following:

1. Remove the clevis pin from the fuel rod and the right cylinder bank injector control tube lever.

2. Loosen all of the inner and outer injector rack control lever adjusting screws on both injector control tubes. Be sure all of the injector rack control levers are free on the injector control tubes.

3. Move the speed control lever to the maximum speed position.

4. Move the stop lever to the run position and hold it in that position with light finger pressure. Turn the inner adjusting screw of the No. 3L injector rack control lever down (Fig. 3) until a slight movement of the control tube is observed, or a step-up in effort to turn the screw driver is noted. This will place the No. 3L injector rack in the full-fuel position. Turn the outer adjusting screw down until it bottoms lightly on



Fig. 4 - Checking Rotating Movement of Injector Control Rack

the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

NOTE: Overtightening the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lb.

The above steps should result in placing the governor linkage and control tube in the respective positions that they will attain while the engine is running at full load.

5. To be sure of proper rack adjustment, hold the stop



Fig. 5 - Checking Injector Control Rack

lever in the *run* position and press down on the injector rack with a screw driver or finger tip and note the "rotating" movement of the injector control rack (Fig. 4). Hold the stop lever in the run position and, using a screw driver, press downward on the injector control rack. The rack should tilt downward (Fig. 5) and when the pressure of the screw driver is released, the control rack should "spring" back upward. If the rack does not return to its original position, it is too loose. To correct this condition, back off the outer adjusting screw slightly and tighten the inner adjusting screw. The setting is too tight if, when moving the stop lever from the stop to the run position, the injector rack becomes tight before the governor stop lever reaches the end of its travel. This will result in a stepup in effort required to move the stop lever to the run position and a deflection in the fuel rod (fuel rod deflection can be seen at the bend). If the rack is found to be too tight, back off the inner adjusting screw slightly and tighten the outer adjusting screw.

6. Remove the clevis pin from the fuel rod and the left bank injector control tube lever.

7. Insert the clevis pin in the fuel rod and the right cylinder bank injector control tube lever and position the No. 3R injector rack control lever as previously outlined in Step 4 for the No. 3L control lever.

8. Insert the clevis pin in the fuel rod and the left bank injector control tube lever. Repeat the check on the 3L and 3R injector rack control levers as outlined in Step 5. Check for and eliminate any deflection which may occur at the bend in the fuel rod where it enters the cylinder head.

9. To adjust the remaining injector rack control levers, remove the clevis pin from the fuel rods and the injector control tube levers, hold the injector control racks in the full-fuel position by means of the lever on the end of the control tube and proceed as follows:

a. Turn down the inner adjusting screw of the injector rack control lever until the screw bottoms (injector control rack in the full-fuel position).
b. Turn down the outer adjusting screw of the injector rack control lever until it bottoms on the injector control tube.
c. While still holding the control tube lever in the full-fuel position, adjust the inner and outer adjusting screws to obtain the same condition as outlined in Step 5. Tighten the screws.

CAUTION: Once the No. 3L and No. 3R injector rack control levers are adjusted, do not try to alter their settings. All adjustments are made on the remaining control racks.

10. When all of the injector .rack control levers are adjusted, recheck their settings. With the control tube lever in the full-fuel position, check each control rack as in Step S. All of the control racks must have the same "spring" condition with the control tube lever in the full-fuel position.

11. Insert the levis pin in the fuel rods and the injector control tube levers.

12. Use new gaskets and install the valve rocker covers.

Adjust Maximum, No Load Speed

All governors are properly adjusted before leaving the factory. However, if the governor has been reconditioned or replaced, and to ensure the engine speed will not exceed the recommended no-load speed as given on the engine option plate, the maximum no-load speed may be set as follows: Start the engine and after it reaches normal operating temperature, determine the maximum no-load speed of the engine with an accurate tachometer. Then stop the engine and make the following adjustments, if required.

1. Refer to Fig. 9 and disconnect the booster spring and the stop lever retracting spring.

2. Remove the variable speed spring housing and the spring retainer, located inside of the housing, from the governor housing.

3. Refer to Table 1 and determine the stops or shims required for the desired full-load speed. A split stop can only be used with a solid stop (Fig. 6).

4. Install the variable speed spring retainer and housing and tighten the two bolts.



Fig. 6 - Location of Shims and Stop



Fig. 7 · Adjusting Idle Speed

Full Load Speed RPM	STOPS		SHIMS
	Solid Ring	Split Ring	
2575-2800	0	0	As Required
2101-2575	1	0	As Required
1701-2100	1	1	As Required
1200-1700	1	2	As Required

*Maximum amount of shims .325"

TABLE 1

5. Connect the booster spring and the stop lever spring. Start the engine and recheck the maximum no-load speed.

6. If required, add shims to obtain the necessary operating speed. For each .001 "in shims added, the operating speed will increase approximately 2 rpm.

> **IMPORTANT:** If the maximum no-load speed is raised or lowered more than 50 rpm by the installation or removal of shims, recheck the governor gap. If readjustment of the governor gap is required, the position of the injector racks must be rechecked.
>
> **NOTE: Governor stops are used to limit the compression of the governor spring, which determines the maximum speed of the engine.**

Adjust Idle Speed

With the maximum no-load speed properly adjusted, adjust the idle speed as follows:

1. Place the stop lever in the run position and the speed control lever in the idle position.



Fig. 8 - Adjusting Buffer Screw

2. With the engine running at normal operating temperature, back out the buffer screw to avoid contact with the differential lever.

3. Loosen the lock nut and turn the idle speed adjusting screw (Fig. 7) until the engine is operating at approximately 15 rpm below the recommended idle speed. The recommended idle speed is 550 rpm, but may vary with special engine applications.

4. Hold the idle speed adjusting screw and tighten the lock nut.

Adjust Buffer Screw

1. With the engine running at normal operating temperature, turn the buffer screw in (Fig. 8) so that it contacts the differential lever as lightly as possible and still eliminates engine roll.

> **NOTE: Do not raise the engine idle speed more than 15 rpm with the buffer screw.**

2. Hold the buffer screw and tighten the lock nut.

Adjust Booster Spring

With the idle speed adjusted, adjust the booster spring as follows:

1. Move the speed control lever to the idle speed position.

2. Refer to Fig. 9 and loosen the booster spring retaining nut on the speed control lever.



Fig. 9 - Adjusting Booster Spring

Loosen the lock nuts on the eye bolt at the opposite end of the booster spring.

3. Move the spring retaining bolt in the slot of the speed control lever until the center of the bolt is on or slightly over center (toward the idle speed position) of an imaginary line through the bolt, lever shaft and eye bolt. Hold the bolt and tighten the lock nut.

4. Start the engine and move the speed control lever to the maximum speed position and release it. The speed control lever should return to the idle position. If it does not, reduce the tension on the booster spring. If the lever does return to the idle position, continue to increase the spring tension until the point is reached that it will not return to idle. Then reduce the tension until it does return to idle and tighten the lock nut on the eye bolt. This setting will result in the minimum force required to operate the speed control lever.

5. Connect the linkage to the governor levers.

SUPPLEMENTARY GOVERNING DEVICE ADJUSTMENT

ENGINE LOAD LIMIT DEVICE

Engines with mechanical governors may be equipped with a load limit device (Fig. 1) to reduce the maximum horsepower.

This device consists of a load limit screw threaded into a plate mounted between two adjacent rocker arm shaft brackets and a load limit lever clamped to the injector control tube.

The load limit device is located between the No. 2 and No. 3 cylinders of a three or four cylinder engine or between the No. 1 and No. 2 cylinders of each cylinder head on a V-type engine. However, when valve rocker covers with a breather are used, the load limit device is installed between the No. I and No. 2 cylinders on in-line engines and between the No. 2 and No. 3 cylinders on V-type engines to avoid interference with the rocker cover baffles.

When properly adjusted for the maximum horsepower desired, this device limits the travel of the injector control racks and thereby the fuel output of the injectors.



Fig. 1 Engine Load Limit Device

Adjustment

After the engine tune-up is completed, make sure the load limit device is properly installed as shown in Fig. 1. Make sure the counterbores in the adjusting screw plate are up. The rocker arm shaft bracket bolts which fasten the adjusting screw plate to the brackets are tightened to 50-55 lb-ft torque. Then adjust the load limit device, on each cylinder head, as follows:

1. Loosen the load limit screw lock nut and remove the screw.
2. Loosen the load limit lever clamp bolts so the lever is free to turn on the injector rack control tube.
3. With the screw out of the plate, adjust the load limit screw lock nut so the bottom of the lock nut is 7/8" from the bottom of the load limit screw (Fig. 1) for the initial setting.
4. Loosen the load limit lever clamp bolts so the lever is free to turn on the injector rack control tube.
4. Thread the load limit screw into the adjusting screw plate until the lock nut bottoms against the top of the plate.
5. Hold the injector rack control tube in the full-fuel position and place the load limit lever against the bottom of the load limit screw. Then tighten the load limit lever clamp bolts.
6. Check to ensure that the injector racks will just go into the full-fuel position -readjust the load limit lever if necessary.
7. Hold the load limit screw to keep it from turning, then set the lock nut until the distance between the bottom of the lock nut and the top of the adjusting screw plate corresponds to the dimension (or number of turns) stamped on the plate. Each full turn of the screw equals .042", or .007" for each flat on the hexagon head.

> **NOTE: If the plate is not stamped, adjust the load limit screw while operating the engine on a dynamometer test stand and note the number of turns required to obtain the desired horsepower. Then stamp the plate accordingly.**

8. Thread the load limit screw into the plate until the lock nut bottoms against the top of the plate. Be sure the nut turns with the screw.
9. Hold the load limit screw to keep it from turning, then tighten the lock nut to secure the setting.

THROTTLE DELAY MECHANISM

The throttle delay mechanism is used to retard fullfuel injection when the engine is accelerated. This reduces exhaust smoke and also helps to improve fuel economy.

The throttle delay mechanism (Fig. 2) is installed between the No. I and No. 2 cylinders on three cylinder engines, between the No. 2 and No. 3 cylinders on four cylinder engines, or between the No. 1 and No. 2 cylinders on the right-bank cylinder head of V-type engines. It consists of a special rocker arm shaft bracket (which incorporates the throttle delay cylinder), a piston, throttle delay lever, connecting link, oil supply plug, ball check valve and U-bolt.

A yield lever and spring assembly replaces the standard lever and pin assembly on the rear end of the injector control tube on In-line engines (Fig. 3). A yield lever replaces the standard operating lever in the governor of the 6V-53 engine (Fig. 4).

Operation

Oil is supplied to a reservoir above the throttle delay cylinder through a special plug in the drilled oil passage in the rocker arm shaft bracket (Fig. 2). As the injector racks are moved toward the no-fuel position, free movement of the throttle delay piston is assured by air drawn into the cylinder through the ball check valve. Further movement of the piston uncovers an opening which permits oil from the reservoir to enter the cylinder and displace the air. When the



Fig. 3 · Throttle Delay Yield Lever (In-Line Engine)

engine is accelerated, movement of the injector racks toward the full-fuel position is momentarily retarded while the piston expels the oil from the cylinder through a .016"orifice. To permit full accelerator, travel, regardless of the retarded injector rack position, a spring loaded yield lever or link assembly replaces the standard operating lever connecting link to the governor.



Fig. 2 - Throttle Delay Cylinder



Fig. 4 - Throttle Delay Yield Lever (6V Engine)



Fig 5. Adjusting Throttle Delay Cylinder

Inspection

When inspecting the throttle delay hydraulic cylinder, it is important that the check valve be inspected for wear. Replace the check valve if necessary.

To inspect the check valve, fill the throttle delay cylinder with diesel fuel oil and watch for check valve leakage while moving the engine throttle from the idle position to the full fuel position.

Adjustment

Whenever the injector rack control levers are adjusted, disconnect the throttle delay mechanism by loosening the U-bolt which clamps the lever to the injector control tube. After the injector rack control levers have been positioned, the throttle delay mechanism must be re-adjusted. With the engine stopped, proceed as follows:

1. Refer to Fig. 5 and insert gage J 23190 (.454" setting) between the injector body and the shoulder on the injector rack. Then exert a light pressure on the injector control tube in the direction of full fuel.

2. Align the throttle delay piston so it is flush with the edge of the throttle delay cylinder.

3. Tighten the U-bolt on the injector control tube and remove the gage.

4. Move the injector rack from the no-fuel to full-fuel to make sure it does not bind.

ADJUSTMENT OF MECHANICAL GOVERNORSHUTDOWN SOLENOID

When a governor shutdown solenoid is used on an engine equipped with a mechanical governor, the governor stop lever must be properly adjusted to match the shutdown solenoid plunger travel.

The solenoid plunger can be properly aligned to the governor stop lever as follows:

1. Remove the bolt connecting the rod end eye (variable speed governor), or the right angle clip (limiting speed governor) to the stop lever (Figs. 6 and 7). Align and clamp the lever to the shutdown shaft in such a way that, at its mid-travel position, it is perpendicular to the solenoid plunger. This assures that the linkage will travel as straight as possible. The solenoid plunger has available 1/2" travel which is more than adequate to move the injector control racks from the full-fuel to the complete no-fuel position and shutdown will occur prior to attaining complete travel.

2. With the stop lever in the run position, adjust the rod end eye or right angle clip for minimum engagement on the solenoid plunger when the connecting bolt is installed. The oversize hole in the eye or clip will thereby permit the solenoid to start closing the air gap, with a resultant build-up of pull-in force prior to initiating stop lever movement.

3. The bolt through the rod end eye or the right angle clip should be locked to the stop lever and adjusted to a height that will permit the eye or clip to float vertically. The clearance above and below the eye or clip and the bolt head should be approximately 1/32" minimum.

NOTE: The lock nut can be either on top of or below the stop lever.

4. Move the lever to the stop position and observe the plunger for any possible bind. If necessary, loosen the



Fig. 6 - Typical Variable Speed Governor Lever Position



Fig 7 - Typical Limiting Speed Governor Leer Position

mounting bolts and realign the solenoid to provide free plunger motion.

HYDRAULIC GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

IN-LINE ENGINE

The hydraulic governor is mounted on the 3 and 4-53 engines as shown in Fig. 1. The terminal lever return spring and the fuel rod are attached to an external terminal shaft lever. The maximum fuel position of the governor load limit is determined by the internal governor terminal lever striking against a boss that projects from the governor cover.

Adjust engines having a hydraulic governor assembly after adjusting the exhaust valve clearance and timing the fuel injectors.

Adjust Fuel Rod and Injector Rack Control Levers

1. Adjust the inner and outer adjusting screws (Fig. 2) on the' rear injector rack control lever until both screws are equal in height and tight on the control tube. Check the clearance between the fuel rod and the cylinder head casting (below the bolt) for at least 1/16" clearance when the injector rack is in the fullfuel position and the rack adjusting screws are tight. If the fuel rod contacts the bolt or cylinder head casting, readjust the screws to obtain the 1/16" clearance.



Fig. 1 Hydraulic Governor Mounted on Engine

NOTE: Overtightening the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lbs

2. Remove the governor terminal lever return spring.

3. Remove the fuel rod end bearing or ball joint from the terminal shaft lever and the terminal lever from the terminal shaft.

4. Place the terminal lever on the terminal shaft so that the hole for attaching the fuel rod end bearing or ball joint is in line vertically above the terminal lever shaft at one half the arc of travel. Do not tighten the clamping bolt.

5. Hold the injector rack control tube and the terminal lever in the *full-fuel* position and adjust the length of the fuel rod until the end bearing or ball joint will slide freely into the hole of the terminal lever as shown in Fig. 3. Tighten the lock nut to retain the ball



Fig. 2 - Adjusting Height of Rack Control Lever Adjusting Screws



Fig. 3 · Adjusting Length of Fuel Rod

joint or end bearing and the terminal lever clamping bolt securely.

NOTE: It will be necessary to slide the terminal lever partially off of the shaft to attach the fuel rod end bearing or ball joint to the terminal lever.

6. Hold the terminal lever in the full-fuel position and loosen the inner adjusting screw 1/8 of a turn and tighten the outer adjusting screw 1/8 of a turn to retain the adjustment. This is done to prevent the governor from bottoming the injector racks, since there is no load limit screw on this governor.

7. Remove the clevis pin between the fuel rod and the injector control tube lever.

NOTE: Cover the cylinder head oil drain back hole, located under the control lever, when removing the fuel rod clevis pin to prevent its loss and possible damage to the engine.

8. Manually hold the rear injector in the full-fuel position and turn down the inner rack control lever adjusting screw of the adjacent injector until the injector rack of the adjacent injector has moved into the full-fuel position and the inner adjusting screw is bottomed on the injector control tube. Turn the outer adjusting screw down until it bottoms lightly on the



Fig. 4 · Adjusting Droop Bracket

injector control tube. Then alternately tighten both the inner and outer rack control lever adjusting screws.

9. Recheck the rear injector fuel rack to be sure that it has remained snug on the ball end of the rack control lever while adjusting the adjacent injector. If the rack of the rear injector has become loose, back off slightly on the inner adjusting screw on the adjacent injector rack control lever. Tighten the outer adjusting screw.
When the settings are correct, the racks of both injectors must be snug on the ball end of their respective rack control levers.

10. Position the remaining rack control levers as outlined in Steps 8 and 9.

11. Insert the clevis pin between the fuel rod and the injector control tube lever.

12. Install the terminal lever return spring.

Adjust Speed Droop

The purpose of adjusting the speed droop is to establish a definite engine speed at no load with a given speed at rated full load.

The governor droop is set at the factory and further adjustment should be unnecessary. However, if the governor has had major repairs, the speed droop should be readjusted.

The best method of determining the engine speed is with an accurate hand tachometer.

Full Load	No-Load
50 cycles 1000 rpm	52.5 cycles 1050 rpm
60 cycles 1200 rpm	62.5 cycles 1250 rpm
50 cycles 1500 rpm	52.5 cycles 1575 rpm
60 cycles 1800 rpm	62.5 cycles 1875 rpm

TABLE 1

If a full-rated load can be established on the engine and the fuel rod, injector rack control levers and load limit have been adjusted, the speed droop may be adjusted as follows:

1. Start the engine and run it at approximately one-half the rated no-load speed until the lubricating oil temperature stabilizes.

> **NOTE: When the engine lubricating oil is cold, the governor regulation may be erratic. The regulation should become increasingly stable as the temperature of the lubricating oil increases.**

2. Stop the engine and remove the governor cover. Discard the gasket.

3. Loosen the lock nut and back off the maximum speed adjusting screw (Fig. 5) approximately 5/8" .

4. Refer to Fig. 4 and loosen the droop adjusting bolt. Move the droop bracket so that the bolt is midway between the ends of the slot in the bracket. Tighten the bolt.

5. With the throttle in the run position, adjust the engine speed until the engine is operating at 3% to 5% above the recommended full-load speed.

6. Apply the full-rated load on the engine and readjust the engine speed to the correct full-load speed.

7. Remove the rated load and note the engine speed after the speed stabilizes under no-load. If the speed droop is correct, the engine speed will be approximately 3% to 5% higher than the full-load speed.

If the speed droop is too high, stop the engine and again loosen the droop bracket retaining bolt and move the droop adjusting bracket in toward the engine. Tighten the bolt. To increase the speed droop, move the droop adjusting bracket out, away from the engine.

The speed droop in governors which control engines driving generators in parallel must be identical, otherwise, the electrical load will not be equally divided.

Fig 5 Adjusting Maximum Engine Sped

Adjust the speed droop bracket in each engine governor to obtain the desired variation between the engine no-load and full-load speeds shown in Table 1.

The recommended speed droop of generator sets operating in parallel is 50 rpm (2-1/2 cycles) for units operating at 1000 and 1200 rpm and 75 rpm (2-1/2 cycles) for units operating at 1500 rpm and 1800 rpm full load. This speed droop recommendation may be varied to suit the individual application.

Adjust Maximum No-Load Speed

With the speed droop properly adjusted, set the maximum no-load speed as follows:

1. Loosen the maximum speed adjusting screw lock nut and back out the maximum speed adjusting screw three turns.

2. With the engine operating at no-load, adjust the engine speed until the engine is operating at approximately 8% higher than the rated full-load speed.

3. Turn the maximum speed adjusting screw (Fig. 5) in lightly until contact is felt with the linkage in the governor.

4. Hold the maximum speed adjusting screw and tighten the lock nut.

5. Use a new gasket and install the governor cover.

HYDRAULIC GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

6V-53 ENGINE



Fig. 1 - Hydraulic Governor Mounting



Fig. 2 · Hydraulic Governor Controls

The hydraulic governor is mounted between the blower and the rear end plate as shown in Fig. 1. The vertical control link assembly is attached to the governor operating lever and the bell crank lever on the governor drive housing (Fig. 2).

After adjusting the exhaust valves and timing the fuel injectors, adjust the governor as follows:

1. Disconnect the vertical control link assembly from the governor operating lever.

2. Loosen all of the injector rack control lever adjusting screws.

3. While holding the bell crank lever (on the governor drive housing) in a horizontal position (full-fuel), set the No. 3 injector rack control levers on each bank to full-fuel.

4. Position the remaining rack control levers to the No. 3 control levers.

5. Remove the governor cover. Discard the gasket.

6. To determine the full-fuel position of the terminal lever, adjust the load limit screw to obtain a distance of 2" from the outside face of the boss on the governor sub-cap to the end of the screw.

7. Adjust the operating lever (on the governor) so that it is horizontal, or slightly below (as close as the serrations on the shaft will permit) when the shaft is rotated to the full-fuel position, or clockwise when viewed from the front of the engine.

8. Loosen the lock nut and adjust the length of the vertical link assembly, attached to the bell crank lever, to match the full-fuel position of the governor operating lever and the injector rack control levers. This length should be approximately 6-5/16" Tighten the lock nut.

9. With the governor operating lever held in the fullfuel position, turn the load limit screw ((Fig. I) inward until the injector racks just loosen on the ball end of the control levers, to prevent the injector racks from bottoming.

10. Release the governor operating lever and hold the adjusting screw while tightening the lock nut.

11. Use new gaskets and install the governor cover and the valve rocker covers.

TROUBLE SHOOTING

Certain abnormal conditions which sometimes interfere with satisfactory engine operation, together with methods of determining the cause of such conditions, are covered on the following pages.

Satisfactory engine operation depends primarily on:

1. An adequate supply of air compressed to a sufficiently high compression pressure.

2. The injector of the proper amount of fuel at the right time.

Lack of power, uneven running, excessive vibration, stalling at idle speed and hard starting may be caused by either low compression, faulty fuel injection in one or more cylinders, or lack of sufficient air.

Since proper compression, fuel injection and the proper amount of air are important to good engine performance, detailed procedures for their investigation are given as follows:

Locating a Misfiring Cylinder

1. Start the engine and run it at part load until it reaches normal operating temperature.

2. Stop the engine and remove the valve rocker cover(s). Discard the gasket(s).

3. Check the valve clearance. The clearance should be .009" (two valve cylinder head) or .024" (four valve cylinder head).



Fig. 1 Checking Compression Pressure

4. Start the engine and hold an injector follower down with a screw driver to prevent operation of the injector. If the cylinder has been misfiring, there will be no noticeable difference in the hound and operation of the engine. If the cylinder has been firing properly, there will be a noticeable difference in the sound and operation when the injector follower is held down. This is similar to short-circuiting a spark plug in a gasoline engine.

5. If the cylinder is firing properly, repeat the procedure on the other cylinders until the faulty one has been located.

6. Provided that the injector operating mechanism of the faulty cylinder is functioning satisfactorily, remove the fuel injector and install a new one by performing the removal and installation procedure outlined in Fuel System.

7. If installation of a new injector does not eliminate misfiring, check the compression pressure.

Checking Compression Pressure

Compression pressure is affected by altitude as shown in Table 1.

Check the compression pressure as follows:

1. Start the engine and run it at approximately one-half rated load until normal operating temperature is reached.

2. Stop the engine and remove the fuel pipes from the No. I injector and the fuel connectors.

3. Remove the injector and install adaptor J 7915-02 and pressure gage and hose assembly J 6992 (Fig. I).

4. Use a spare fuel pipe and fabricate a jumper connection between the fuel inlet and return fuel

Minimum Compression Pressure psi		Altitude, Feet Above Sea Level
Std. Engine	"N" Engine	
430	540	0
400	500	2,500
370	465	5,000
340	430	7,500
315	395	10,000

TABLE 1

connectors to permit fuel to flow directly to the fuel return manifold.

5. Start the engine and run it at 600 rpm. Observe and record the compression pressure indicated on the gage.

> **NOTE: Do not crank the engine with the starting motor to check the compression pressure.**

6. Perform Steps 2 through 5 on each cylinder. The compression pressure in any one cylinder should not be less than 430 psi (540 psi for "N" engines) at 600 rpm. In addition, the variation in compression pressures between cylinders of the engine must not exceed 25 psi at 600 rpm.

> **EXAMPLE:** If the compression pressure readings were as shown in Table 2, it would be evident that No. 3 cylinder should be examined and the cause of the low compression pressure be determined and corrected.

Note that all of the cylinder pressures are above the low limit for satisfactory engine operation. Nevertheless, the No. 3 cylinder compression pressure indicates that something unusual has occurred and that a localized pressure leak has developed.

Low compression pressure may result from any one of several causes:

A. Piston rings may be stuck or broken. To determine the condition of the rings, remove the air box cover and press on the compression rings with a blunt tool. A broken or stuck compression ring will not have a "spring-like" action.
B. Compression pressure may be leaking past the cylinder head gasket, valve seats, injector tubes or through a hole in the piston.

Engine Out of Fuel

The problem in restarting the engine after it has run out of fuel stems from the fact that after the fuel is exhausted from the fuel tank, fuel is then pumped from the primary fuel strainer and sometimes partially removed from the secondary fuel filter before the fuel supply becomes insufficient to sustain engine firing. Consequently, these components must be refilled with fuel and the fuel pipes rid of air in order for the system to provide adequate fuel for the injectors.

Cylinder	Gage Reading*
1	525 psi
2	520 psi
3	485 psi
4	515 psi

*The above pressures ore for an engine operating at on altitude near sea level.

TABLE 2

When an engine has run out of fuel, there is a definite procedure to follow for restarting it. The procedure is outlined below:

1. Fill the fuel tank with the recommended grade of fuel oil. If only partial filling of the tank is possible, add a minimum of ten gallons of fuel.
2. Remove the fuel strainer shell and element from the strainer cover and fill the shell with fuel oil. Install the shell and element.
3. Remove and fill the fuel filter shell and element with fuel oil as in Step 2.
4. Start the engine. Check the filter and strainer for leaks.

> **NOTE**: **In some instances, it may be necessary to remove a valve rocker cover and loosen a fuel pipe nut in order to bleed trapped air from the fuel system. Be sure the fuel pipe is retightened securely before replacing the rocker cover.**

Primer J 5956 may be used to prime the engine fuel system. Remove the filler plug in the fuel filter cover and install the primer. Prime the system. Remove the primer and install the filler plug.

Fuel Flow Test

1. Disconnect the fuel return hose from the fitting at the fuel tank and hold the open end in a suitable container.
2. Start and run the engine at 1200 rpm and measure the fuel flow for a period of one minute. At least .6 gallon of fuel should flow from the fuel return hose per minute.
3. Immerse the end of the fuel return hose in the fuel in the container. Air bubles rising to the surface of the fuel will indicate air being drawn into the fuel system on the suction side of the pump.

If, air is present, tighten all feel line connections between the fuel tank and the fuel pump.

If the fuel flow fails to meet the amount specified, the fuel strainer, filter or pump should be serviced.

CRANKCASE PRESSURE (max. in inches of water)					
Engine	Speed (rpm)				
	1800	2000	2200	2500*	2800*
3-53	.5	.5	.5	.9	1.0
4-53	.5	.5	.5	.9	1.0
4-53T	—	—	—	1.0	—
6V-53	—	—	—	.9	1.0

***Engines with four valve cylinder head(s).**

TABLE 3.

Crankcase Pressure

The crankcase pressure indicates the amount of air passing between the oil control rings and the cylinder liner into the crankcase, most of which is clean air from the air box. A slight pressure in the crankcase is desirable to prevent the entrance of dust. A loss of engine lubricating oil through the breather tube, crankcase ventilator or dipstick hole in the cylinder block is indicative of excessive crankcase pressure.

The causes of high crankcase pressure may be traced to excessive blow-by due to worn piston rings, a hole or crack in a piston crown, loose piston pin retainers, worn blower oil seals, defective blower, cylinder head or end plate gaskets, or excessive exhaust back pressure. Also, the breather tube or crankcase ventilator should be checked for obstructions.

The crankcase pressure may be checked with a manometer connected to the oil level dipstick opening in the cylinder block. Check the readings obtained at various engine speeds with the specifications in Table 3.

EXHAUST BACK PRESSURE (max. in inches of Mercury)					
Engine	No-Load Speed (rpm)				
	1800	2000	2200	2500*	2800*
3-53	1.3	1.7	2.1	2.7	2.7†
4-53	1.3	1.7	2.1	2.7	2.7†
4-53T	—	—	—	1.8	—
6V-53	—	—	—	2.7	2.7†

***Engines with four valve cylinder head(s).**
† 3.8 for Marine engines.

TABLE 4.

AIR BOX PRESSURE (min. in inches of Mercury)					
Max. Exhaust Back Pressure (Full Load)					
Engine	Speed (rpm)				
	1800	2000	2200	2500*	2800*
3-53	5.5	6.9	8.6	8.0	9.3
4-53	5.5	6.9	8.6	8.0	9.3
4-53T	—	—	—	33.5	—
6V-53	—	—	—	8.0	9.3
(Zero Exhaust Back Pressure)					
3-53	3.8	4.9	6.2	4.8	6.1
4-53	3.8	4.9	6.2	4.8	6.1
4-53T	—	—	—	31.5	—
6V-53	—	—	—	4.8	6.1

***Engines with four valve cylinder head(s).**

TABLE 5.

Exhaust Back Pressure

A slight pressure in the exhaust system is normal. However, excessive exhaust back pressure seriously affects engine operation. It may cause an increase in the air box pressure with a resultant loss in the efficiency of the blower. This means less air for scavenging, which results in poor combustion and higher temperatures.

Causes of high exhaust back pressure are usually a result of an inadequate or improper type of muffler, an exhaust pipe which is too long or too small in diameter, an excessive number of sharp bends in the exhaust system, or obstructions such as excessive carbon formation or foreign matter in the exhaust system.

The exhaust back pressure, measured in inches of mercury, may be checked with a manometer, or pressure gage, connected to the exhaust manifold. Remove the 1/8" pipe plug, which is provided for that purpose, from the manifold. If there is no opening provided, one can be made by drilling an 11/32 " hole in the exhaust manifold companion flange and tapping a 1/8" pipe thread.

Check the readings obtained at various speeds (no load) with the specifications in Table 4.

AIR INLET RESTRICTION (inches of water)					
Engine	Speed (rpm)				
	1800	2080	2200	2500*	2800*
Max. with dirty air cleaner (oil bath or dry)					
3-53	13.4	—	18.8	23.0	25.0
4-53	13.4	—	18.8	23.0	25.0
6V-53	—	—	18.8	23.0	25.0
Max. with clean air cleaner (oil bath)					
3-53	9.5	10.8	12.0	14.0	16.0
4-53	9.5	10.8	12.0	14.0	16.0
6V-53	—	—	12.0	14.0	16.0
Max. with clean air cleaner (Dry with precleaner)					
3-53	6.8	10.8	12.0	—	—
4-53	6.8	10.8	12.0	—	—
Max. with clean air cleaner (Dry less precleaner)					
3-53	5.5	6.5	7.4	8.7	10.0
4-53	5.5	6.5	7.4	8.7	10.0
6V-53	—	—	7.4	8.7	10.0
Max. with air silencer (full load)					
4-53T	—	—	—	20.0	—

***Engines with four valve cylinder heads.**

TABLE 6.

Air Box Pressure

Proper air box pressure is required to maintain sufficient air for combustion and scavenging of the burned gases. Low air box pressure is caused by a high air inlet restriction, damaged blower rotors, an air leak from the air box (such as a leaking end plate gasket), or a clogged blower air inlet screen.

Lack of power or black or grey exhaust smoke are indications of low air box pressure.

To check the air box pressure, connect a manometer to an air box drain tube.

Check the readings obtained at various speeds with the specifications in Table 5.

Air Inlet Restriction

Excessive restriction of the air inlet will affect the flow of air to the cylinders and result in poor combustion and lack of power. Consequently, the restriction must be kept to a minimum considering the size and capacity of the air cleaner. An obstruction in the air inlet system or dirty or damaged air cleaners will result in a high blower inlet restriction.

The air inlet restriction may be checked with a manometer connected to a fitting in the air intake ducting located 2" above the air inlet housing. When practicability prevents the insertion of a fitting at this point, the manometer may be connected to the engine air inlet housing. The restriction at this point should be checked at a specific engine speed. Then the air cleaner and ducting should be removed from the air, inlet housing and the engine again operated at the same speed while noting the manometer reading.

The difference between the two readings, with and without the air cleaner and ducting, is the actual restriction caused by the air cleaner and ducting.

Check the normal air intake vacuum at various speeds (at no-load) and compare the results with Table 6.

PROPER USE OF MANOMETER



Fig. 2 Comparison of Column Height for Mercury and Water Manometers

The U-tube manometer is a primary measuring device indicating pressure or vacuum by the difference in the height of two columns of fluid.

Connect the manometer to the source of pressure, vacuum or differential pressure. When the pressure is imposed, add the number of inches one column of fluid travels up to the amount the other column travels down to obtain the pressure (or vacuum) reading.

The height of a column of mercury is read differently than that of a column of water. Mercury does not wet the inside surface; therefore, the top of the column has a convex meniscus (shape). Water wets the surface and therefore has a concave meniscus. A mercury column is read by sighting horizontally between the top of the convex mercury surface (Fig. 2) and the scale. A water manometer is read by sighting horizontally between the bottom of the concave water surface and the scale.

PRESSURE CONVERSION CHART		
1" water	=	.0735" mercury
1" water	=	.0361 psi
1" mercury	=	.4919 psi
1" mercury	=	13.6000" water
1 psi	=	27.7000" water
1 psi	=	2.0360" mercury

TABLE 7.

Should one column of fluid travel further than the other column, due to minor variations in the inside diameter of the tube or to the pressure imposed, the accuracy of the reading obtained is not impaired.

Refer to Table 7 to convert manometer readings into other units of measurement.

ENGINE ELECTRICAL GENERATING SYSTEM

Whenever trouble is indicated in the engine electrical generating system, the following quick checks can be made to assist in localizing the cause.

A fully charged battery and low charging rate indicates normal alternator-regulator operation.

A low battery and high charging rate indicates normal alternator-regulator operation.

A fully charged battery and high charging rate condition usually indicates the voltage regulator is set too high or is not limiting the alternator output. A high charging rate to a fully charged battery will damage the battery and other electrical components.

A low battery and low or no charging rate condition could be caused by: Loose connections or damaged wiring, defective battery or alternator, or defective regulator or improper regulator setting.

Contact an authorized Detroit Diesel Allison Service Outlet if more information is needed.

STORAGE

PREPARING ENGINE FOR STORAGE

When an engine is to be stored or removed from operation for a period of time, special precautions should be taken to protect the interior and exterior of the engine, transmission and other parts from rust accumulation and corrosion. The parts requiring attention and the recommended preparations are given below.

It will be necessary to remove all rust or corrosion completely from any exposed part before applying a rust preventive compound. Therefore, it is recommended that the engine be processed for storage as soon as possible after removal from operation.

The engine should be stored (in a building which is dry and can be heated during the winter months. Moisture absorbing chemicals are available commercially for use when excessive dampness prevails in the storage area.

TEMPORARY STORAGE (30 days or less)

To protect an engine for a temporary period of time, proceed as follows:

1. Drain the engine crankcase.

2. Fill the crankcase to the proper level with the recommended viscosity and grade of oil.

3. Fill the fuel tank with the recommended grade of fuel oil. Operate the engine for two minutes at 1200 rpm and no load.

NOTE : Do not drain the fuel system or the crankcase after this run.

4. Check the air cleaner and service it, if necessary, as outlined under Air System.

5. If freezing weather is expected during the storage period, add a high boiling point type antifreeze solution in accordance with the manufacturer's recommendations. Drain the raw water system and leave the drain cocks open.

6. Clean the entire exterior of the engine (except the electrical system) with fuel oil and dry it with air.

7. Seal all of the engine openings. The material used for this purpose must be waterproof, vapor proof and possess sufficient physical strength to resist puncture and damage from the expansion of entrapped air.

An engine prepared in this manner can be returned to service in a short time by removing the seals at the engine openings, checking the engine coolant, fuel oil, lubricating oil, transmission, and priming the raw water pump, if used.

EXTENDED STORAGE (30 days or more)

When an engine is to be removed from operation for an extended period of time, prepare it as follows:

1. Drain and thoroughly flush the cooling system with clean, soft water.

2. Refill the cooling system with clean, soft water.

3. Add a rust inhibitor to the cooling system (refer to Corrosion Inhibitor under Cooling System).

4. Remove, check and recondition the injectors, if necessary, to make sure they will be ready to operate when the engine is restored to service.

5. Reinstall the injectors in the engine, time them, and adjust the valve clearance.

6. Circulate the coolant through the entire system by operating the engine/until normal operating temperature is reached (160°F. to 1850F.) 7. Stop the engine.

8. Remove the drain plug and completely drain the engine crankcase. Reinstall and tighten the drain plug. Install new lubricating oil filter elements and gaskets.

9. Fill the crankcase to the proper level with a 30weight preservative lubricating oil MIL-L-21260, Grade 2 (P10), or equivalent.

10. Drain the engine fuel tank.

11. Refill the fuel tank with enough rust preventive fuel oil such as American Oil Diesel Run-In Fuel (LF

4089), Mobil 4Y17, or equivalent, to enable the engine to operate 10 minutes.

12.Drain the fuel filter and strainer. Remove the retaining bolts, shells and elements. Discard the used elements and gaskets. Wash the shells in clean fuel oil and insert new elements. Fill the cavity between the element and shell about two-thirds full of the same rust preventive compound as used in the fuel tank and reinstall the shell.

13.Operate the engine for 10 minutes to circulate the rust preventive throughout the engine.

14.Refer to Air System and service the air cleaner.

15. MARINE GEAR

a. Drain the oil completely and refill with clean oil of the proper viscosity and grade as is recommended. Remove, clean or replace the strainer and replace the filter element.

b. Start and run the engine at 600 rpm for 5 minutes so that clean oil can coat all of the internal parts of the marine gear. Engage the clutches alternately to circulate clean oil through all of the moving parts.

16. TORQMATIC CONVERTER

a. Start the engine and operate it until the temperature of the converter oil reaches 150° F.
b. Remove the drain plug and drain the converter.
c. Remove the filter element.
d. Start the engine and stall the converter for twenty seconds at 1000 rpm to scavenge the oil from the converter. Due to lack of lubrication, do not exceed the 20 second limit.
e. Install the drain plug and a new filter element.
f. Fill the converter to the proper operating level with a commercial preservative oil which meets Government specifications MIL-L-21260, Grade 1. Oil of this type is available from the major oil companies.
g. Start the engine and operate the converter for at least 10 minutes at a minimum of 1000 rpm. Engage the clutch; then stall the converter to raise the oil temperature to 225 F.

CAUTION: Do not allow the oil temperature to exceed 225° F. If the unit does not have a temperature gage, do not stall the converter for more than thirty seconds.

h. Stop the engine and permit the converter to cool to a temperature suitable to touch.
i. Seal all of the exposed openings and the breather with moisture proof tape.
j. Coat all exposed, unpainted surfaces with preservative grease. Position all of the controls for minimum exposure and coat them with grease. The external shafts, flanges and seals should also be coated with grease.

17. POWER TAKE-OFF

a. With an all purpose grease such as Shell Alvania No. 2, or equivalent, lubricate the clutch throw out bearing, clutch pilot bearing, drive shaft main bearing, clutch release shaft, and the outboard bearings (if so equipped).
b. Remove the inspection hole cover on the clutch housing and lubricate the clutch release lever and link pins with a hand oiler. Avoid getting oil on the clutch facing.
c. If the unit is equipped with a reduction gear, drain and flush the gear box with light engine oil. If the unit is equipped with a filter, clean the shell and replace the filter element. Refill the gear box to the proper level with the oil grade indicated on the name plate.

18. TURBOCHARGER

The turbocharger bearings are lubricated by pressure through the external oil line leading from the engine cylinder block while performing the previous operations above and no further attention is required. However, the turbocharger air inlet and turbine outlet connections should be sealed off with moisture resistant tape.

19. HYDROSTARTER SYSTEM

Refer to Hydraulic Starting System in the section on Engine Equipment for the lubrication and preventive maintenance procedure.

20. Apply a non-friction rust preventive compound, to all exposed parts. If it is convenient, apply the rust preventive compound to the engine flywheel. If not, disengage the clutch mechanism to prevent the clutch disc from sticking to the flywheel.

CAUTION : Do not apply oil, grease or any wax base compound to the flywheel. The cast iron will absorb these substances which can "sweat" out during operation and cause the clutch to slip.

21.Drain the engine cooling system.
22.The oil may be drained from the engine crankcase if so desired. If the oil is drained, reinstall and tighten the drain plug.
23.Remove and clean the battery and battery cables with a baking soda solution and rinse them with freshwater. Do not allow the soda solution to enter the battery. Add distilled water to the electrolyte, if necessary, and fully charge the battery. Store the battery in a cool (never below 32 °F.) dry place. Keep the battery fully charged and check the level and the specific gravity of the electrolyte regularly.
24.Insert heavy paper strips between the pulleys and belts to prevent sticking.
25.Seal all of the openings in the engine, including the exhaust outlet, with moisture resistant tape. Use cardboard, plywood or metal covers where practical.
26.Clean and dry the exterior painted surfaces of the engine. Spray the surfaces with a suitable liquid automobile body wax, a synthetic resin varnish or a rust preventive compound.
27.Cover the engine with a good weather-resistant tarpaulin or other cover if it must be stored outdoors. A clear plastic cover is recommended for indoor storage.

The stored engine should be inspected periodically. If there are any indications of rust or corrosion, corrective steps must be taken to prevent damage to the engine parts. Perform a complete inspection at the end of one year and apply additional treatment as required.

PROCEDURE FOR RESTORING AN ENGINE TO SERVICE WHICH HAS BEEN IN EXTENDED STORAGE

1. Remove the valve rocker cover(s) and pour at least one-half gallon of oil, of the same grade as used in the crankcase, over the rocker arms and push rods.
2. Reinstall the valve rocker cover(s).
3. Remove the covers and tape from all of the openings of the engine, fuel tank, and electrical equipment. Do not overlook the exhaust outlet.
4. Wash the exterior of the engine with fuel oil to remove the rust preventive.
5. Remove the rust preventive from the flywheel.
6. Remove the paper strips from between the pulleys and the belts.
7. Check the crankcase oil level. Fill the crankcase to the proper level with the heavy-duty lubricating oil recommended under Lubricating Oil Specifications.
8. Fill the fuel tank with the fuel specified under Diesel Fuel Oil Specifications.
9. Close all of the drain cocks and fill the engine cooling system with clean soft water and a rust inhibitor. If the engine is to be exposed to freezing temperatures, add a high boiling point type antifreeze solution to the cooling system (the antifreeze contains a rust inhibitor).
10. Install and connect the battery.
11. Service the air cleaner as outlined under Air System.
12. POWER GENERATOR

Prepare the generator for starting as outlined under Operating Instructions.

13. MARINE GEAR

Check the Marine gear; refill it to the proper level, as necessary, with the correct grade of lubricating oil.

14. TORQMATIC CONVERTER
    a. Remove the tape from the breather and all of the openings.
    b. Remove all of the preservative grease with a suitable solvent.
    c. Start the engine and operate the unit until the temperature reaches 150°F. Drain the preservative oil and remove the filter. Start the engine and stall the converter for twenty seconds at 1000 rpm to scavenge the oil from the converter.

CAUTION: A Torqmatic converter containing preservative oil should only be operated enough to bring the oil temperature up to 150 ° F.

    d. Install the drain plug and a new filter element.
    e. Refill the converter with the oil that is recommended under Lubrication and Preventive Maintenance.

15. POWER TAKE-OFF

Remove the inspection hole cover and inspect the clutch release lever and link pins and the bearing ends of the clutch release shaft. Apply engine oil sparingly, if necessary, to these areas.

16. HYDROSTARTER
    a. Open the relief valve on the side of the hand pump and release the pressure in the system.
    b. Refer to the filling and purging procedures outlined in Hydraulic Starting System. Then, drain, refill and purge the Hydrostarter system.
17. TURBOCHARGER

Remove the covers from the turbocharger air inlet and turbine outlet connections. Refer to the lubricating procedure outlined in Preparation for Starting Engine First Time.

18. After all of the preparations have been completed, start the engine. The small amount of rust preventive compound which remains in the fuel system will cause a smoky exhaust for a few minutes.

NOTE: Before subjecting the engine to a load or high speed, it is advisable to check the engine tune-up.

BUILT-IN

PARTS BOOK

for

DETROIT DIESEL ENGINES



Progress in industry comes at a rapid pace. In order for the engine manufacturer to keep pace with progress he needs a versatile product for the many models and arrangements of accessories and mounting parts needed to suit a variety of equipment. In addition, engine refinements and improvements are constantly being introduced. All of this dynamic action must be documented so that the equipment can be serviced if and when it's needed. It is fully documented in the manufacturer's plant and in dealer Parts Departments with Master Files and adequate supporting records. But, what about YOU the user of this equipment? You have neither the time nor the inclination to ferret out specific part number data. What is the answer? It is Detroit Diesel's exclusive BUILTIN PARTS BOOK which is furnished with each engine. It takes the form of an "Option Plate" mounted on the rocker cover of the engine. With it, ordering parts becomes as simple as A, B, C. You have merely to provide the Dealer with ...

A. The "Model" number **B. The "UNIT" number** **C. The "TYPE" number**



From that much information, the dealer with his complete records on all engine models, can completely interpret your parts requirements.

What is this "built in" book? It is an anodized aluminum plate that fits into a holding channel on the engine rocker cover.



ON THE LEFT SIDE of the plate is the Startup Inspection Tab which is removed by the dealer when he has completed the inspection.


.TYPE EQUIPMENT .TYPE EQUIPMENT .TYPE
. 30 ENG LIFT BKT . 345 F/W HOUSING . 608
. 242 OIL DIST .NONE OIL FIL TUBE . 268
. 227 OIL FILTER . 197 VENT SYSTEM . 44
. 171 C/S PULLEY . 187 C/S PUL BELT . 145
. 318 WAT BY-PASS . 102 WAT OTLT ELBO. 179
. 181 FUEL FILTER . 628 FUEL LINES . 141
.1122 GOVERNOR MECH. 430 ENGINE MOUNTS. 40
.NONE BATT CHRG GEN. 174 STARTING MTR . 255
50437001 SPEC 510-239

NEXT is the type number and the equipment description. On the left is the type number. The type number designates all service parts applicable to the equipment. On the right is a brief description of the equipment.

ON THE RIGHT SIDE of the plate is pertinent data on the model number, serial number and the related governor setting.

All engine components are divided into groups of functionally related parts. A complete listing of the twelve major groups and their many sub-groups is shown below.

1.0000 ENGINE (less major assemblies)
- 1.1000 Cylinder Block
- 1.1000A Air Box Drains
- 1.2000 Cylinder Head
- 1.2000A Engine Lifter B
- 1.3000 Crankshaft
- 1.3000A Crankshaft Front Cover
- 1.3000B Vibration Damper
- 1.3000C Crankshaft Pulley
- 1.3000D Crankshaft Pulley Belt
- 1.4000A Flywheel
- 1.5000A Flywheel Housing
- 1.5000B Flywheel Housing Adaptor
- 1.6000 Connecting Rod and Piston
- 1.7000 Camshaft and Gear Train
- 1.7000A Balance Weight Cover
- 1.7000B Accessory Drive
- 1.8000 Valve and Injector Operating Mechanism
- 1.8000A Rocker Cover

2.0000 FUEL SYSTEM
- 2.1000A Fuel Injector
- 2.2000 Fuel Pump
- 2.2000A Fuel Pump Drain
- 2.3000A Fuel Filter
- 2.4000 Fuel Manifold and/or Connections
- 2.5000A Fuel Lines
- 2.6000A Fuel Tank
- 2.7000A Mechanical Governor
- 2.8000A Hydraulic Governor
- 2.9000 Injector Controls
- 2.9000A Throttle Controls

3.0000 AIR SYSTEM
- 3.1000A Air Cleaner and/or Adaptor
- 3.2000A Air Silencer
- 3.3000A Air Inlet Housing
- 3.4000 Blower
- 3.4000A Blower Drive Shaft
- 3.5000A Turbocharger

4.0000 LUBRICATING SYSTEM
- 4.1000A Oil Pump
- 4.1000B Oil Distribution System
- 4.1000C Oil Pressure Regulator
- 4.2000A Oil Filter
- 4.3000A Oil Filter Lines
- 4.4000A Oil Cooler
- 4.5000A Oil Filler
- 4.6000A Dipstick
- 4.7000A Oil Pan
- 4.8000A Ventilating System

5.0000 COOLING SYSTEM
- 5.1000 Fresh Water Pump
- 5.1000A Fresh Water Pump Cover
- 5.2000A Water Outlet Manifold and/or Elbow
- 5.2000B Thermostat
- 5.2000C Water By-pass Tube
- 5.3000A Radiator
- 5.3000B Water Connections
- 5.4000A Fan
- 5.4000B Fan Shroud
- 5.5000A Heat Exchanger or keel Cooling
- 5.6000A Raw Water Pump
- 5.7000A Water Filter

6.0000 EXHAUST SYSTEM
- 6.1000A Exhaust Manifold
- 6.2000A Exhaust Muffler and/or Connections

7.0000 ELECTRICAL INSTRUMENTS
- 7.1000A Battery Charging Generator
- 7.2000B Automatic Starting
- 7.3000A Starting Motor
- 7.4000A Instruments
- 7.4000B Tachometer Drive
- 7.4000C Shut-off or Alarm System
- 7.5000A Power Generator
- 7.6000A Control Cabinet
- 7.7000A Wiring harness
- 7.8000A Air Heater

8.0000 POWER TAKE-OFF
- 8.1000A Power Take-off and/or clutch
- 8.3000A Torque Converter'
- 8.3000B Torque Converter Lines

9.000 TRANSMISSION AND PROPULSION
- 9.1000A Hydraulic marine Gear
- 9.3000A Power Transfer Gear
- 9.4000 Transmission highway
- 9.7000 Transmission-Off highway

10.0000 SHEET METAL
- 10.1000A Engine Hood

11.0000 ENGINE MOUNTING
- 11.1000A Engine Mounting and Base

12.0000 MISCELLANEOUS
- 12.2000A Bilge Pump
- 12.3000A Vacuum Pump
- 12.4000A Air Compressor
- 12.5000A Hydraulic Pump
- 12.6000A Gasoline Starter
- 12.6000B Air Starter
- 12.6000C Cold Weather Starting Aid
- 12.6000D Hydraulic Starter
- 12.6000E Hydraulic Starter Accessories

Within each of these sub-groups, various designs of similar equipment are categorized as "Types" and identified by a Type Number.

The Distributor/Dealer has a Model Index for each engine model. The Model Index lists all of the "Standard" and "Standard Option" equipment for that model.

STANDARD AND STANDARD OPTION EQUIPMENT

GROUP NAME	GROUP NO.	TYPE
Cylinder Block	1.1000	31
Air Box Drains	1.1000A	62
Cylinder Head (4 valve)	1.2000	26
Engine Lifter Bracket	1.2000A	44
Crankshaft	1.3000	44
Crankshaft front Cover	1.3000A	65
Crankshaft Pulley (2 grooves)	1.3000C	171
Crankshaft Pulley Belt	1.3000D	121
	1.4000A	313
Flywheel Housing (SAE #3)	1.5000A	350
Connecting Rod and Piston	1.6000	68
Camshaft and Gear Train	1.7000	127
Valve operating Mechanism	1.8000	33
Rocker Cove (with oil filler in one cover)	1.8000A	64
Fuel Injector N50	2.1000A	74
Fuel Pump (3/3” inlet) (mounted on L. Bank camshaft	2.2000	73
Fuel Filter	2.3000A	358
Fuel Manifold Connections	2.4000A	48
Fuel Lines	2.5000A	786
Governor Mechanical	2.7000A	514

NOTE The option plate reflects which choice of options has been built into the engine. The Distributor, Dealer uses his model index to interpret the standard equipment. The plate, therefore, lists only the nonstandard or choice items.

So, give the dealer the
A-Model No._____
B-Unit No. _____
*C-Type No._____
*(If not shown, indicate 'NONE". The dealer knows the "standard" for the model).

FOR READY REFERENCE, Record the information on the Option Plate to this record.

MODEL NO._____ **UNIT NO.**_____

EQUIPMENT	TYPE	EQUIPMENT	TYPE	EQUIPMENT	TYPE
Engine Base		Water Bypass Tube		Battery Chrg. Generator	
Engine Lifter Brkt.		Thermostat		Starter	
Flywheel Housing		Water Filter		Hyd. Starter Acces.	
Vibration Damper		Exhaust Manifold		Starting Aid	
Flywheel		Air Cleaner or Silencer		Marine Gear	
Flywheel Hsg. Adptr.		Fuel Pump		Torque Converter	
Oil Pan		Injector		Torque Converter Lines	
Oil Pump		Blower		Muffler & Conn.	
Oil Distribution		Blower Drive Shaft		Engine Hood	
Dipstick		Fuel Filter		Wiring Harness	
Oil Pan Drain Tube		Fuel Lines		Instruments	
Oil Filler Tube or Cap		Air Inlet Housing		Tach. Drive	
Oil Cooler		Alarm or Shutoff		Radiator	
Oil Filter		Overspeed Governor		Heat Ex. or Keel Cooling	
Oil Lines		Throttle Controls		Raw Water Pump	
Ventilating System		Injector Controls		Power Generator	
Crankshaft Cover		Governor Mech or Hyd		Control Cabinet	
Balance Wgt. Cover		Engine Mounts		Cylinder Head	
Fan		Power Take-off		Conn Rod & Piston	
Crankshaft Pulley		Hydraulic Pump		Valve Mechanism	
Crankshaft Pulley Belt		Air Compressor		Fuel Manifold Conn	
Fan Shroud		Camshaft & Gear Train			
Water Connections		Rocker Cover			
Water Pump Cover		Accessory Drive			
Water Manifold					

OTHER USEFUL INFORMATION:

Each fuel and lube oil filter on your engine has a decal giving the service package part number for the element. It is advisable to have your own personal record of these part numbers by filling in the chart provided below:

TYPE	LOCATION	PACKAGE PART NO.
Fuel Strainer		
Fuel Filter		
Lube Oil Filter Full-Flo		
Lube Oil Filter By-Pass*		

*Not Standard

AIR CLEANER

If dry-type, indicate make and number of filter element:

_____

_____

Wet type, indicate capacity _____qts.



CYLINDER HEAD



CRANKSHAFT

P 628



CONNECTING ROD, PISTON AND LINER



CAMSHAFT AND GEAR



IDLER GEAR

P 629



ACCESSORY DRIVE FOR BELT DRIVEN ACCESSORY (DRIVE HUB TYPE)



ACCESSORY DRIVE FOR BELT DRIVEN ACCESSORY (DRIVE PLATE TYPE)



ACCESSORY DRIVE FOR DIRECT DRIVEN ACCESSORY (CAMSHAFT GEAR) P 630



VALVE OPERATING MECHANISM (4 VALVE)



FUEL PUMP DRIVE (6V53)



TYPICAL FUEL PUMP



TYPICAL FUEL OIL STRAINER



TYPICAL FUEL OIL FILTER



INJECTOR AND CONTROLS



AIR SHUT-DOWN HOUSING



BLOWER ASSEMBLY AND DRIVE (4 CYL.)



BLOWER ASSEMBLY AND DRIVE (6 CYL.)

P 635


OIL COOLER BY-PASS VALVE
LOWER ENGINE FRONT COVER
OIL SEAL
OIL PRESSURE REGULATOR VALVE
PLUG
GASKET
SPRING
PUMP COVER PLATE
OUTER ROTOR
PUMP DRIVE GEAR
PLUG
GASKET
SPRING
BOLT
GASKET
DRIVE SCREW
INNER ROTOR
PUMP BODY
BOLT
OIL PUMP AND REGULATOR
P 636



OIL FILTER



OIL COOLER P 637



OIL COOLER (6V-53)





FRESH WATER PUMP



THERMOSTAT

THERMOSTAT (6V-53)

P 639



FAN MOUNT (6V-83)

P 640



FAN MOUNT



HEAT EXCHANGER



HEAT EXCHANGER (6V-53)



WATER TEMPERATURE SHUTDOWN SWITCH P 642



TACHOMETER DRIVE COVERS AND ADAPTORS



AIR COMPRESSOR AND DRIVE



HYDRAULIC PUMP AND DRIVE P 644

ALPHABETICAL INDEX

Subject	Page
A	
Accessory Drive	129
Adjustments:	
Injector Timing	76
Mechanical Governor Shutdown Solenoid	104
Power Take-Off	44
Valve Clearance	74
Air Compressor	143
Air System:	
Air Box Drains	21
Air Cleaners	17
Air Silencer	21
Crankcase Ventilation	21
Alarm System	36
B	
Blower Assembly and Drive	133
Breathers	137
Built-In Parts Book	9, 121
C	
Camshaft and Gears	128
Cold Weather Starting Aids	41
Compression Pressure.	111
Connecting Rod	128
Cooling System:	
Antifreeze Solutions	71
Capacity	27
Corrosion Inhibitor	68
Flushing	28
Fresh Water Pump	29, 138
Heat Exchanger Cooling	25, 140
Radiator Cooling	25
Raw Water Pump	29
Coolant Filter	70
Crankshaft	127
Cylinder Head	127
D	
Description, General	5
Description, Model	6
E	
Engine Coolant	68
Engine Cross-Section Views	10
Engine Model Description Chart	6
Engine Protective Systems	33, 132
Electrical Starting System	37
F	
Fan Mounting	139
Filters:	
Fuel Oil	15
Lubricating Oil	22
Fuel Oil Specifications	66
Fuel System:	
Injector	13
Pump	15, 130
Strainer and Filter	15, 131
Tank	16
G	
General Description	5
General Specifications	8
Governors	44
H	
Heat Exchanger	140
Hydraulic Pump	143
Hydraulic Starting System	38
I	
Idler Gear	128
Injector and Controls	131
Instruments and Controls	31
L	
Liner	128
Lubricating Oil Specifications	67
Lubrication and Preventive Maintenance	55
Lubrication Chart	56
Lubricating System	22
M	
Maintenance, Preventive	55

ALPHAETICAL INDEX

Subject	Page
Marine Gear	46
Misfiring Cylinder	111
Model and Serial Number	9
O	
Oil Cooler	136
Oil Filter	136
Oil Pump and Regulator	135
Operating Instructions:	
Cold Weather Starting	41
Engine	47
Power Generator Set	51
Preparation for First Start	47
P	
Piston	128
Power Take-Off	44
Preventive Maintenance	55
Principles of Operation	4
Pump, water	25
S	
Shut-Down Systems	33, 141
Specifications:	
Coolant	68
Fuel Oil	66
General	8
Lubrication Oil	67
Starting Systems:	
Electrical	37
Hydraulic	38
Storage:	
Preparation	117
Restoration	119
Tachometer Drive	142
Thermostat	138
Torqmatic Converter	45
Transmissions	44
Trouble Shooting:	
Air Box Pressure	114
Air Inlet Restriction	114
Checking Compression Pressures	111
Crankcase Pressure	113
Electrical Generating System	115
Engine out of Fuel	112
Exhaust Back Pressure	113
Fuel Flow Test	112
Misfiring Cylinder	111
Use of Manometer	115
Tune-Up Procedures:	
Engine	73
Exhaust Valve Clearance Adjustment	74
Hydraulic Governor:	
In-Line Engine	106
6V Engine	109
Mechanical Governor:	
Limiting Speed (In-Line Engine)	77
Limiting Speed (6V Engine)	82
Variable Speed (Open Linkage)	87
Variable Speed (Enclosed Linkage)	91
Variable Speed (6V Engine)	96
Supplementary Governing Device	101
Engine Load Limit	101
Governer Shutdown Solenoid	104
Throttle Delay Mechanism	102
Timing Fuel Injector	76
V	
Valve Operating Mechanism	130

PART TWO

ENGINE SERVICE MANUAL

SERIES 53
SERVICE MANUAL
DETROIT DIESEL ENGINES

DETROIT DIESEL ALLISON
DIVISION OF GENERAL MOTORS CORPORATION
DETROIT, MICHIGAN, 48228

© 1972 General Motors Corp.

Form 6SE201 (Rev. 7/72)
Printed in U.S.A.

FOREWORD

This manual contains instructions on the overhaul, maintenance and operation of the basic Series 53 Detroit Diesel Engines.

Full benefit of the long life and dependability built into these engines can be realized through proper operation and maintenance.
Of equal importance is the use of proper procedures during engine overhaul.

Personnel responsible for engine operation and maintenance should study the sections of the manual pertaining to their particular duties.
Similarly, before beginning a repair or overhaul job, the serviceman should read the manual carefully to familiarize himself with the parts or sub-assemblies of the engine with which he will be concerned.

The information, specifications and illustrations in this publication are based on the information in effect at the time of approval for printing. This publication is revised and reprinted periodically. It is recommended that users contact an authorized Detroit Diesel Service Outlet for information on the latest revisions. The right is reserved to make changes at any time without obligation.

IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all motor vehicles. The service procedures recommended by Detroit Diesel Allison and described in this service manual are effective methods for performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that some warnings against the use of specific service methods that can damage the vehicle or render it unsafe are stated in this service manual. It is also important to understand these warnings are not exhaustive. Detroit Diesel Allison could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Detroit Diesel Allison has not undertaken any such broad evaluation. Accordingly, anyone who uses a service procedure or tool which is not recommended by Detroit Diesel Allison must first satisfy himself thoroughly that neither his safety nor vehicle safety will be jeopardized by the service method he selects.

TABLE OF CONTENTS

SUBJECT	SECTION
GENERAL INFORMATION	
ENGINE (less major assemblies)	1
FUEL SYSTEM AND GOVERNORS	2
AIR INTAKE SYSTEM	3
LUBRICATION SYSTEM	4
COOLING SYSTEM	5
EXHAUST SYSTEM	6
ELECTRICAL EQUIPMENT, INSTRUMENTS AND PROTECTIVE SYSTEMS	7
POWER TAKE-OFF AND TORQMATIC CONVERTER	8
TRANSMISSIONS	9
SPECIAL EQUIPMENT	12
OPERATION	13
TUNE-UP	14
PREVENTIVE MAINTENANCE, TROUBLE SHOOTING AND STORAGE	15

1972 General Motors Corp.

Feb., 1972

SCOPE AND USE OF THE MANUAL

This manual covers the basic Series 53 Diesel Engines built by the Detroit Diesel Allison Division of General Motors Corporation. Complete instructions on operation, adjustment (tune-up), preventive maintenance and lubrication, and repair (including complete overhaul) are covered. The manual was written primarily for persons servicing and overhauling the engine and, in addition, contains all of the instructions essential to the operators and users. Basic maintenance and overhaul procedures are common to all Series 53 engines and therefore apply to all engine models.

The manual is divided into numbered sections. The first section covers the engine (less major assemblies). The following sections cover a complete system such as the fuel system, lubrication system or air system. Each section is divided into sub-sections which contain complete maintenance and operating instructions for a specific subassembly on the engine. For example, Section 1, which covers the basic engine, contains sub-section 1.1 pertaining to the cylinder block, sub-section 1.2 covering the cylinder head, etc. The subjects and sections are listed in the Table of Contents on the preceding page. Pages are numbered consecutively, starting with a new Page 1 at the beginning of each sub-section. The illustrations are also numbered consecutively, beginning with a new Figure 1 at the start of each sub-section.

Information regarding a general subject, such as the -lubrication system, can best be located by using the Table of Contents. Opposite each subject in the Table of Contents is a section number which registers with a tab printed on the first page of each section throughout the manual. Information on a specific sub-assembly or accessory can then be found by consulting the list of contents on the first page of the section. For example, the cylinder liner is part of the basic engine, therefore, it will be found in Section 1. Looking down the list of contents on the first page of Section 1, the cylinder liner is found to be in sub-section 1.6.3. An Alphabetical Index at the back of the manual has been provided as an additional aid for locating information.

SERVICE PARTS AVAILABILITY

Genuine Detroit Diesel "Factory Engineered" replacement parts are available from authorized Detroit Diesel Service Outlets conveniently located within the United States, in Canada from the distribution organization of Diesel Division, General Motors of Canada Limited, and abroad through the sales and service outlets of General Motors Overseas Operations Divisions.

CLEARANCES AND TORQUE SPECIFICATIONS

Clearances of new parts and wear limits on used parts are listed in tabular form at the end of each section throughout the manual. It should be specifically noted that the "New Parts" clearances apply only when all new parts are used at the point where the various specifications apply. This also applies to references within the text of the manual. The column entitled "Wear Limits" lists the amount of wear or increase in clearance which can be tolerated in used engine parts and still assure satisfactory performance. It should be emphasized that the figures given as "Wear Limits" must be qualified by the judgment of personnel responsible for installing new parts. These wear limits are, in general, listed only for the parts more frequently replaced in engine overhaul work. For additional information, refer to the paragraph entitled Inspection under General Procedures in this section.

Bolt, nut and stud torque specifications are also listed in tabular form at the end of each section.

© 1972 General Motors Corp.

PRINCIPLES OF OPERATION

The diesel engine is an internal combustion power unit, in which the heat of fuel is converted into work in the cylinder of the engine.

In the diesel engine, air alone is compressed in the cylinder; then, after the air has been compressed, a charge of fuel is sprayed into the cylinder and ignition is accomplished by the heat of compression.

The Two-Cycle Principle

In the two-cycle engine, intake and exhaust take place during part of the compression and power strokes respectively as shown in Fig. 1. In contrast, a four-cycle engine requires four piston strokes to complete an operating cycle; thus, during one half of its operation, the four-cycle engine functions merely as an air pump.

A blower is provided to force air into the cylinders for expelling the exhaust gases and to supply the cylinders with fresh air for combustion. The cylinder wall contains a row of ports which are above the piston when it is at the bottom of its stroke. These ports admit the air from the blower into the cylinder as soon as the rim of the piston uncovers the ports as shown in Fig. 1 (scavenging).

The unidirectional flow of air toward the exhaust valves produces a scavenging effect, leaving the cylinders full of clean air when the piston again covers the inlet ports.

As the piston continues on the upward stroke, the exhaust valves close and the charge of fresh air is subjected to compression as shown in Fig. 1 (compression).

Shortly before the piston reaches its highest position, the required amount of fuel is sprayed into the combustion chamber by the unit fuel injector as shown in Fig. 1 (power). The intense heat generated. during the high compression of the air ignites the fine fuel spray immediately. The combustion continues until the injected fuel has been burned.

The resulting pressure forces the piston downward on its power stroke. The exhaust valves are again opened when the piston is about half way down, allowing the burned gases to escape into the exhaust manifold as shown in Fig. 1 (exhaust). Shortly thereafter, the downward moving piston uncovers the inlet ports and the cylinder is again swept with clean scavenging air. This entire combustion cycle is completed in each cylinder for each revolution of the crankshaft, or, in other words, in two strokes; hence, it is a "two-stroke cycle".



Fig. 1 - The Two Stroke Cycle

© 1972 General Motors Corp.

GENERAL DESCRIPTION

The blower is mounted on top of the engine between the two banks of cylinders and is driven by the gear train. The governor is mounted on the rear end of the 6V-53 blower.

The meaning of each digit in the model numbering system is shown in Fig 1. The letter indicates right-hand engine rotation as viewed from the front of the engine. The letter A designates the location of the oil cooler and starter on the V-type engines. Each engine is equipped with an oil cooler full-flow oil filter, fuel oil strainer and fuel oil filter, an air cleaner governor, fan and radiator, and a starting motor.

Full pressure lubrication is supplied to all main, connecting rod and camshaft bearings and to other moving parts. A rotor-type pump draws oil from the oil pan through a screen and delivers it to the oil filter. From the filter, the oil flows to the oil cooler and then enters a longitudinal oil gallery in the cylinder block where the supply divides. Part of the oil goes to the camshaft bearings and up through the rocker arm assemblies; the remainder of the oil goes to the main bearings and connecting rod bearings via the drilled oil passages in the crankshaft.

Coolant is circulated through the engine by a centrifugal-type water pump. Heat is removed from the coolant, which circulates in a closed system, by the or radiator. Control of the engine temperature is accomplished by thermostat(s) which regulate the flow of the coolant within the cooling system.

Fuel is drawn from the supply tank through the fuel strainer by a gear-type fuel pump. It is then forced through a filter and into the fuel inlet manifold in the cylinder head(s) and to the injectors. Excess fuel is returned to the supply tank through the fuel outlet manifold and connecting lines. Since the fuel is constantly circulating through the injectors, it serves to cool the injectors and to carry off any air in the fuel system.

Air for scavenging and combustion is supplied by a blower which pumps air into the engine cylinders via the air box and cylinder liner ports. All air entering the blower first passes through an air cleaner.

Engine starting is provided by either a hydraulic or electric starting system. The electric starting motor is energized by a storage battery. A battery-charging generator, with a suitable voltage regulator, serves to keep the battery charged.

Engine speed is regulated by a mechanical or hydraulic type engine governor, depending upon the engine application.

© 1972 General Motors Corp.


5 0 6 3 — 5 2 0 0
SERIES 53
NUMBER OF CYLINDERS
APPLICATION DESIGNATION
BASIC ENGINE ARRANGEMENT * (see below)
DESIGN VARIATION
SPECIFIC MODEL NUMBER
APPLICATION DESIGNATION
5067-5040 FAN to F/W VEHICLE
DESIGN VARIATION
5062-3000 "N" ENGINE
* BASIC ENGINE ARRANGEMENTS
Rotation: R-(right) designates rotation as viewed from the end of the engine opposite the flywheel.
Type: A designates location of starter and oil cooler as viewed from the flywheel end of the engine.
Cylinder Bank: Left and right cylinder banks are determined from the flywheel end of the engine.
BLOWER THRUST REAR
CAM SHAFT
CAM SHAFT
IDLER
STARTER
CRANK SHAFT
OIL COOLER
FLYWHEEL
OIL COOLER
STARTER
RA (XXXX-5XXX)
4017

ALL ABOVE VIEWS FROM REAR FLYWHEEL END OF ENGINE

Fig. 1.6. Engine Model Description, Rotation and Accessory Arrangement

© 1972 General Motors Corp.

GENERAL SPECIFICATIONS

	6V-53
Type	2 Cycle
Number of Cylinders	6
Bore	3.875 in.
Stroke	4.5 in.
Compression Ratio (Nominal) ("N" Engines)	21 to 1
Total Displacement - Cubic Inches	318
Firing Order - R.H. Rotation	1L-3R-3L 2R-2L-1R
Number of Main Bearings	4



Fig 2. - Series 53 Cylinder Arrangement

© 1972 General Motors Corp.

ENGINE MODEL, SERIAL NUMBER AND OPTION PLATE



Fig. 3. Typical Model and Serial Numbers as Stamped on Cylinder Block (6 and 8V Engines)

The model number and serial number on the V-type engines are located on the top right-hand front corner of the cylinder block, as viewed from the rear of the engine (Fig. 3).



Fig.4. - Option Plate

An option plate, attached to the valve rocker cover, is also stamped with the engine serial number and model number and, in addition, lists any optional equipment used on the engine (Fig. 4). Where required, a smoke emission certification plate is installed next to the option plate.

With any order for parts, the engine model number and serial number must be given. In addition, if a type number is shown on the option plate covering the equipment required, this number should also be included on the parts order.

All groups of parts used on a unit are standard for the engine model unless otherwise listed on the option plate.

© 1972 General Motors Corp.



Cross Sections of a 6V-53 Engine

© 1972 General Motors Corp.



Typical Fan-to-Flywheel Unit (6V-53)

© 1972 General Motors Corp.

GENERAL PROCEDURES

In many cases, a serviceman is justified in replacing parts with new material rather than attempting repair. However, there are times when a slight amount of reworking or reconditioning may save a customer considerable added expense. Crankshafts, cylinder liners and other parts are in this category. For example, if a cylinder liner is only slightly worn and within usable limits, a honing operation to remove the glaze may make it suitable for reuse, thereby saving the expense of a new part. Exchange assemblies such as injectors, fuel pumps, water pumps and blowers are also desirable service items.

Various factors such as the type of operation of the engine, hours in service and next overhaul period must be considered when determining whether new parts are installed or used parts are reconditioned to provide trouble-free operation.

For convenience and logical order in disassembly and assembly, the various sub-assemblies and other related parts mounted on the cylinder block will be treated as separate items in the various sections of the manual.

DISASSEMBLY

Before any major disassembly, the engine must be drained of lubricating oil. water and fuel.

Lubricating oil should also be drained from any transmission attached to the engine.

To perform a major overhaul or other extensive repairs, the complete engine assembly, after removal from the engine base and drive mechanism, should be mounted on an engine overhaul stand; then the various sub-assemblies should be removed from the engine. When only a few items need replacement, it is not always necessary to mount the engine on an overhaul stand.

Parts removed from an individual engine should be kept together so they will be available for inspection and assembly. Those items having machined faces, which might be easily damaged by steel or concrete, should be stored on suitable wooden racks or blocks, or a parts dolly.

CLEANING

Before removing any of the sub-assemblies from the engine (but after removal of the electrical equipment), the exterior of the engine should be thoroughly cleaned. Then, after each sub-assembly is removed and disassembled, the individual parts should be cleaned. Thorough cleaning of each part is absolutely necessary before it can be satisfactorily inspected. Various items of equipment needed for general cleaning are listed below.

The cleaning procedure used for all ordinary cast iron parts is outlined under Clean Cylinder Block in Section 1.1; any special cleaning procedures will be mentioned in the text wherever required.

Steam Cleaning
A steam cleaner is a necessary item in a large shop and is most useful for removing heavy accumulations of grease and dirt from the exterior of the engine and its sub-assemblies.

Solvent Tank Cleaning

A tank of sufficient size to accommodate the largest part that will require cleaning (usually the cylinder block) should be provided and provisions made for heating the cleaning solution to 180 °F.-200 °F.

Fill the tank with a commercial heavy-duty solvent which is heated to the above temperature. Lower large parts directly into the tank with a hoist. Place small parts in a wire mesh basket and lower them into the tank. Immerse the parts long enough to loosen all of the grease and dirt.

Rinsing bath
Provide another tank of similar size containing hot water for rinsing the parts.

Drying
Parts may be dried with compressed air. The heat from the hot tanks will quite frequently complete drying of the parts without the use of compressed air.

© 1972 General Motors Corp.

Rust Preventive

If parts are not to be used immediately after cleaning, dip them in a suitable rust preventive compound. The rust preventive compound should be removed before installing the parts in an engine.

INSPECTION

The purpose of parts inspection is to determine which parts can be used and which must be replaced. Although the engine overhaul specifications given throughout the text will aid in determining which parts should be replaced, considerable judgment must be exercised by the inspector.

The guiding factors in determining the usability of worn parts. which are otherwise in good condition, is the clearance between the mating parts and the rate of wear on each of the parts. If it is determined that the rate of wear will maintain the clearances within the specified maximum allowable until the next overhaul period, the reinstallation of used parts may be justified. Rate of wear of a part is determined by dividing the amount the part has worn by the hours it has operated.

Many service replacement parts are available in various undersize and/or oversize as well as standard sizes. Also, service kits for reconditioning certain parts and service sets which include all of the parts necessary to complete a particular repair job are available.

A complete discussion of the proper methods of precision measuring and inspection are outside the scope of this manual. However, every shop should be equipped with standard gages, such as dial bore gages, dial indicators, and inside and outside micrometers.

In addition to measuring the used parts after cleaning, the parts should be carefully inspected for cracks, scoring, chipping and other defects.

ASSEMBLY

Following cleaning and inspection, the engine should he assembled using new parts as determined by the inspection.

Use of the proper equipment and tools makes the job progress faster and produces better results. Likewise, a suitable working space with proper lighting must be provided. The time and money invested in providing the proper tools, equipment and space will be repaid many times.

Keep the working space, the equipment, tools and engine assemblies and parts clean at all times. The area where assembly operations take place should, if possible, be located away from the disassembly and cleaning operation. Also, any machining operations should be removed as far as possible from the assembly area.

Particular attention should be paid to storing of parts and sub-assemblies, after removal and cleaning and prior to assembly, in such a place or manner as to keep them clean. If there is any doubt as to the cleanliness of such parts, they should be recleaned.

When assembling an engine or any part thereof, refer to the table of torque specifications at the end of each section for proper bolt, nut and stud torques.

WORK SAFELY

A serviceman can be severely injured if caught in the pulleys, belts or fan of an engine that is accidentally started. To avoid such a misfortune, take these precautions before starting to work on an engine:

Disconnect the battery from the starting system by removing one or both of the battery cables. With the electrical circuit disrupted, accidental contact with the starter button will not produce an engine start.

Make sure the mechanism provided at the governor for stopping the engine is in the stop position. This will mean the governor is in the no-fuel position. The possibility of the engine firing by accidentally turning the fan or, in-the case of vehicle application, by being bumped by another vehicle is minimized.

Some Safety Precautions To Observe When Working On The Engine

1. Consider the hazards of the job and wear protective gear such as safety glasses, safety shoes, hard hat, etc. to provide adequate protection.

© 1972 General Motors Corp.

2. When lifting an engine, make sure the lifting device is fastened securely. Be sure the item to be lifted does not exceed the capacity of the lifting device.

3. Always use caution when using power tools.

4. When using compressed air to clean a component, such as flushing a radiator or cleaning an air cleaner element, use a safe amount of air. Recommendations regarding the use of air are indicated throughout the manual. Too much air can rupture or in some other way damage a component and create a hazardous situation that can lead to personal injury.

5. Avoid the use of carbon tetrachloride as a cleaning agent because of the harmful vapors that it releases. Use perchlorethylene or trichlorethylene. However, while less toxic than other chlorinated solvents, use these cleaning agents with caution. Be sure the work area is adequately ventilated and use protective gloves, goggles or face shield, and apron.

Exercise caution against burns when using oxalic acid to clean the cooling passages of the engine.

6. Use caution when welding on or near the fuel tank. possible explosion could result if heat build-up inside the tank is sufficient.

7. Avoid excessive injection of ether into the engine during start attempts. Follow the instructions on the container or by the manufacturer of the starting aid.

8. When working on an engine that is running, accidental contact with the hot exhaust manifold can cause severe burns. Remain alert to the location of the rotating fan, pulleys and belts. Avoid making contact across the two terminals of a battery which can result in severe arcing.

© 1972 General Motors Corp.

SECTION 1
ENGINE (less major assemblies)
CONTENTS

Cylinder Block	1.1
Cylinder Block End Plates	1.1.1
Air Box Drains	1.1.2
Cylinder Head	1.2
Valve and Injector Operating Mechanism	1.2.1
Exhaust Valves	1.2.2
Valve Rocker Cover	1.2.4
Crankshaft	1.3
Crankshaft Oil Seals	1.3.2
Crankshaft Main Bearings	1.3.4
Engine Front Cover (Lower)	1.3.5
Crankshaft Outboard Bearing Support	1.3.5.1
Crankshaft Vibration Damper	1.3.6
Crankshaft Pulley	1.3.7
Flywheel	1.4
Clutch Pilot Bearing	1.4.1
Engine Drive Shaft Flexible Coupling	1.4.2
Flywheel Housing	1.5
Piston and Piston Rings	1.6
Connecting Rod	1.6.1
Connecting Rod Bearings	1.6.2
Cylinder Liner	1.6.3
Engine Balance and Balance Weights	1.7
Gear Train and Engine Timing	1.7.1
Camshaft, Balance Shaft and Bearings	1.7.2
Camshaft and Balance Shaft Gears	1.7.3
Idler Gear and Bearing Assembly	1.7.4
Crankshaft Timing Gear	1.7.5
Blower Drive Gear and Support Assembly	1.7.6
Accessory Drives	1.7.7
Engine Front Cover (Upper)	1.7
Shop Notes-Trouble Shooting-Specifications- Service Tools	1.0

© 1972 General Motors Corp.

CYLINDER BLOCK

The cylinder block (Figs. 1 is a one-piece casting which forms the main structural part of the engine. Transverse webs provide rigidity and strength and ensure alignment of the block bores and bearings under load.

The block is bored to receive replaceable wet-type cylinder liners. On the and 6V cylinder blocks, a water jacket surrounds the upper half of each cylinder liner.

The water jacket and air box are sealed off by a seal ring compressed between the liner and a groove in the block (Fig. 2).

On the V-type engine, the camshaft bores are located on the inner side of each cylinder bank, near the top of the block.

The upper halves of the main bearing supports are cast integral with the block. The main bearing bores are line-bored with the bearing caps in place to ensure longitudinal alignment. Drilled passages in the block carry the lubricating oil to all moving parts of the engine and thus eliminate external piping.

box openings in both sides of the block on the V-type engines, permit access to the air box and inspection of the pistons and rings through the air inlet ports.

The top surface of the V-block is grooved to accommodate a block-to-head seal ring. Also, each water or oil hole is counterbored to provide for individual seal rings (Fig. 30). In addition, the V-type engine block is grooved around the air inlet opening, between the cylinder banks, to accommodate a blower-to-block seal ring.

Each cylinder liner is retained in the block by a flange at its upper end, which seats in the counterbore in the

© 1972 General Motors Corp.



1. Cylinder Block
2. Bore for Cylinder Liner
5. Camshaft Bore
6. Air Box
7. Water Passage from Oil Cooler to Block
8. Oil Gallery--Main
11. Oil Passage to Oil Cooler
12. Oil Passage from Oil Cooler
14. Cap--Main Bearing (Front)
15. Oil Passage to Cylinder Head
18. Oil Gallery to Camshaft
20. Cap--Main Bearing (Rear)
21. Water Passage to Cylinder Head
22. Oil Passage to Filter from Pump
23. Oil Passage from Filter to Oil Cooler
24. Oil Passage to Main Gallery Via Front Cover
25. Oil Passage from Oil Pump to Filter
26. Oil Pressure Take-Off Opening

Fig. 1. - Cylinder Block (6V Cast Iron Cylinder Block Shown)

block bore. An individual compression gasket is used at each cylinder.

When the cylinder head is installed, the individual gaskets and seal rings compress sufficiently to form a tight seal between the head and the block.

© 1972 General Motors Corp.



Fig. 2. - Air and Water Passages in 6V Cast Iron Cylinder Block

Since the cylinder block is the main structural part of the engine, the various sub-assemblies must be removed when an engine is overhauled.

The hydraulically operated overhaul stand (Fig. 4.) provides a convenient support when stripping a cylinder block. The engine is mounted in an upright position. It may then be tipped on its side, rotated in either direction 90 ° or 180 °, where it is locked in place, and then, if desired, tipped back with either end or the oil pan side up.

Remove and Disassemble Engine

Before mounting an engine on an overhaul stand, it must be removed from its base and disconnected from the transmission or other driven mechanism. Details of this procedure will vary from one application to another. However, the following steps will be necessary:

1. Drain the cooling system.
2. Drain the lubricating oil from the oil pan.
3. Disconnect the fuel lines.
4. Disconnect and remove or air cleaner and mounting bracket.
5. Disconnect the exhaust piping and remove the exhaust manifold(s).
6. Disconnect and remove the starting motor, battery charging generator and other electrical equipment.
7. Remove the air compressor or vacuum pump, if used.
8. Remove the air box drain tubes and fittings.
9. Remove the air box covers.
10. Disconnect any other lubricating oil lines, fuel lines or electrical connections.
11. Remove the radiator and fan guard and other related cooling system parts.
12. Separate the engine from the transmission or other driven mechanism.
13. Remove the engine mounting bolts.
14. Use a chain hoist and suitable sling attached to the engine lifting brackets to lift the engine.
15. Place the side of the cylinder block against the

© 1972 General Motors Corp.

adaptor plate on the overhaul stand (Fig. 4). Use adaptor plate J 8683 (6V engine) with overhaul stand J 6837-01.


OIL PASSAGE SEAL RING
CYLINDER LINER COMPRESSION GASKET
OIL PASSAGE SEAL RING
CYLINDER HEAD SEAL STRIP
WATER PASSAGE SEAL RINGS

Fig. 3 - Cylinder Head Gaskets and Seals in Place on Cylinder Block

CAUTION: Do not lift a V-type engine by the webs in the air inlet openings at the top of the cylinder block.

16. Align the bolt holes in the adaptor plate with the holes in the cylinder block. Then install the 3/8 "-16 and 5/16 "-18 bolts, with a flat washer under the head of each bolt, and tighten them securely.

CAUTION: Be sure the engine is securely mounted to the overhaul stand before releasing the lifting sling. Severe injury to personnel and destruction of engine parts will result if the engine breaks away from the overhaul stand.

17. With the engine mounted on the overhaul stand, remove all of the sub-assemblies and parts from the cylinder block.

The procedure for removing each assembly and subassembly from the cylinder block, together with

© 1972 General Motors Corp.

disassembly, inspection, repair and reassembly of each, will be found in the various sections of this manual.

After removal and before any of the parts are reassembled to the cylinder block, the block must be cleaned thoroughly and inspected for any conditions which would render it unfit for further use.

Clean Cylinder Block

1. Remove all of the plugs (except cup plugs) and scrape all old gasket material from the block.

2. Clean the block with live steam. Make sure the oil galleries, air box floor and air box drain openings are thoroughly cleaned. Jets are not machined in the camshaft bushing bores in the 6V cylinder blocks. Oil is directed to the cam followers through small slots incorporated in the camshaft bearings.

3. Dry the block with compressed air.

Pressure Test Cylinder Block

After the cylinder block has been cleaned, it must be pressure tested for cracks or leaks by one of two methods. In either method it will be necessary to make a steel plate of 1/21" stock to cover each cylinder bank of the block (Fig. 5). The plate(s) will adequately seal the top surface of the block when used with cylinder liner compression gaskets and water hole seal rings. It will also be necessary to use water hole cover plates and gaskets to seal the water inlet openings in the sides of the block. One cover plate should be drilled and tapped to provide a connection for an air line so the water jacket can be pressurized.



Fig.4. - Engine Mounted on Overhaul Stand

© 1972 General Motors Corp.



Fig. 5. - Cylinder Block Prepared for Pressure Test

METHOD" A"
This method may be used when a large enough water tank is available and the cylinder block is completely stripped of all parts.

1. Make sure the seal ring grooves in the cylinder bores of the block are clean. Then install new seal rings in the grooves (above the air inlet ports).

> **NOTE**: The ~~current~~ blocks have two seal ring grooves above the air inlet ports of each cylinder bore Only one seal ring is required, however. Install the seal ring in the upper groove, if it is in good condition; if the upper groove is pitted or eroded, install the seal ring in the lower groove.

2. Apply a light coating of hydrogenated vegetable type shortening or permanent type antifreeze solution to the seal rings.

3. Slide the cylinder liners into the block, being careful not to roll or damage the seal rings. Install new compression gaskets and water hole seal rings in the counterbores in the top surface of the block.

4. Secure the plate(s) on the top of the block with 5/8 "-11 bolts and flat washers.

5. Install the water hole cover plates and gaskets on the sides of the block.

6. Immerse the cylinder block for twenty minutes in a tank of water heated to 180 ° 200 ° F.

7. Attach an air line to the water hole cover plate and apply 80-100 psi air pressure to the water jackets and observe the water in the tank for bubbles which will indicate cracks or leaks.

8. Remove the block from the water tank. Then remove the plates, seals, gaskets and liners and blow out all of the passages in the block with compressed air.

9. Dry the cylinder liners with compressed air and coat them with oil to prevent rust.

METHOD" B

This method may be used when a large tank for water testing is unavailable.

1. Prepare the block as outlined in Method "A".

However, before installing the large sealing plate, fill the water jacket with a mixture of water and one gallon of permanent type antifreeze. The antifreeze will penetrate small cracks and its color will aid in detecting their presence.

2. Install the plate(s) and water hole covers as outlined in Method "A".

© 1972 General Motors Corp.



Fig. 6 - Checking Cylinder Block Bore with Tool J 5347

3. Apply 80-100 psi air pressure to the water jacket and maintain this pressure for at least two hours to give the water and antifreeze mixture ample time to work its way through any cracks which may exist.

4. At the end of this test period, examine the cylinder bores, air box, oil passages, crankcase and exterior of the block for water and antifreeze mixture, which will indicate the presence of cracks.

5. After the pressure test is completed, remove the plate(s) and drain the water jacket. Then remove the liners and seal rings and blow out all of the passages in the block with compressed air.

6. Dry the cylinder liners with compressed air and coat them with oil to prevent rust.

Inspect Cylinder Block

After cleaning and pressure testing, inspect the cylinder block as follows:

1. Check the top of the block for flatness with an accurate straight edge and a feeler gage. The top surface must not vary more than .003 " transversely and not over .006" 6V-53



Fig. 7 - Block Bore Measurement Diagram



Fig.8 Typical Cylinder Block Markings

© 1972 General Motors Corp.

engine)
longitudinally.

2. Check the block bores as follows:

   a. Make sure the seal ring grooves are thoroughly clean. Then inspect the grooves and lands for evidence of pitting and erosion. Two grooves are provided above the air inlet ports of each cylinder bore in the block.

      However, a cylinder liner seal ring is required in the upper groove only. The lower groove is provided for the seal ring if inspection reveals extensive pitting or erosion along the upper land or inner surface of the upper groove. If both grooves are eroded to the extent that sealing is affected, then the block must be replaced.

   b. Measure the entire bore of each cylinder with cylinder bore gage J 5347 (Fig.6.) which has a dial indicator calibrated in .0001 " increments. Use dial bore gage setting tool J 23059 to preset the cylinder bore gage to zero. Measure each block bore at the positions indicated in Fig.7., on axis 90 ' apart. If the diameter does not exceed 4.5235 " at position "A", 4.4900 " at position "B" (and a sealing problem hasn't occured), or 4.3595 " at position "C" and "D", then the block may be reused. Also, the taper and out of round must not exceed .0015 ".

3. Check the main bearing bores as follows:

   a. Lubricate the threads and the underside of each bolt head with a small quantity of International Compound No. 2, or equivalent. Install the bearing caps and tighten the bolts to the specified torque.

   IMPORTANT: It is imperative that the main bearing caps are reinstalled in their original positions to maintain the main bearing bore alignment. The bearing caps are numbered to correspond with their respective positions in the block. The number of the front bearing cap is also stamped on the face of the oil pan mounting flange of the block, adjacent to its permanent location in the engine as established at the time of manufacture. The No. I cylinder and main bearing cap is always located at the end opposite the flywheel end of the block (Fig. 8).

   NOTE: Main bearing cap bolts are especially designed for this purpose and must not be replaced by ordinary bolts.

   b. Measure the bearing bores. The bearing bores must be 3.751 " to 3.752 " (V-type block). If the bores do not fall within these limits, discard the block.
   c. Check the main bearing bores for alignment. The bearing bores may be considered properly aligned with one another if the crankshaft can be rotated freely by hand, after new main bearing shells have been installed and lubricated and the bearing caps have been secured as in Step 3a.
   d. Finished and unfinished service replacement main bearing caps are available. However, when using the finished replacement caps, it may be necessary to try several caps in each location required before the proper fit is obtained. When using the unfinished main bearing caps, install the caps in the cylinder block as in Step 3a. Then, with the caps in place, line-bore the main bearing caps to the finished main bearing bore dimensions specified in Step 3b. If a replacement bearing cap is installed, be sure to stamp the correct bearing number on the new cap.

   NOTE: Use the unfinished caps in the front and intermediate journal positions only.

4. Make sure the cylinder liner counterbores in the block are clean and free of dirt. Then check the depth. The depth must be from .300 " to .302 " and must not vary more than .0015 " throughout the entire circumference. The counterbored surfaces must be smooth and square with the cylinder bore within .001 " total indicator reading. There must not be over .001 " difference between any two adjacent cylinder counterbores, when measured along the cylinder longitudinal centerline of the cylinder block.

5. Check all of the machined surfaces and threaded holes in the block. Remove nicks and burrs from the machined surfaces with a file. Clean-up damaged threads in the tapped holes with a tap or install helical thread inserts.

6. Replace loose or damaged dowel pins.

7. Install all required plugs. Use a good grade of sealing compound on the threads of the plugs. If a new service block is used, make sure the top surface is plugged correctly to prevent low oil pressure or the accumulation of abnormal quantities of-oil in the cylinder head.

8. If a new service replacement block is used, stamp the engine serial number and model number on the top

© 1972 General Motors Corp.

right-hand corner of the V-type block. Also make sure the bearing caps are properly numbered (Fig. 8).

9. After inspection, if the cylinder block is not to be used immediately, spray the machined surfaces with engine oil. If the block is to be stored for an extended period of time, spray or dip the block in rust preventive compound. Castings free of grease or oil will rust when exposed to the atmosphere.

Assemble and Install Engine

After the cylinder block has been cleaned and inspected, assemble the engine as follows:

> **NOTE**: Before a reconditioned or new service cylinder block is used, steam clean it to remove the rust preventive and blow out the oil galleries with compressed air.

1. Mount the block on an overhaul stand.

2. Clean and inspect all of the engine parts and subassemblies and, using new parts as required, install them on the cylinder block by reversing the sequence of disassembly.

3. Remove the engine from the overhaul stand.

4. Install the air box covers and tighten the bolts.

Tighten the bolts to 10-15 Ib-ft torque.

5. Install the accessories that were removed from the engine before it was mounted on the overhaul stand.

6. Fill the crankcase to the proper level with the recommended grade of lubricating oil (Section 13.3).

7. Close the drains and fill the cooling system. Then close the cooling system vents (if used) and check for both lubricating and cooling system leaks.

8. Check the engine on a dynamometer, following the RUN-IN procedure outlined in Section 13.2.1.

9. Reinstall the engine in the unit and recheck the lubricating oil and coolant levels.

© 1972 General Motors Corp.

CYLINDER BLOCK END PLATES

A flat steel plate is bolted to the rear end of the cylinder block to provide a means of attaching the flywheel housing. At the time of a complete engine overhaul or of a cylinder block change, the cylinder block rear end plate must be removed and subsequently reinstalled.

Inspection

When the end plate is removed, it is essential that all of the old gasket material be removed from both surfaces of the end plate and the end plate cleaned as outlined under *Clean Cylinder Block* in Section 1.1.

Check the surfaces of the end plate for nicks, dents, scratches or score marks; also make sure it is flat.

Check the plug nuts in the end plate for cracks and damaged threads. If nicks or scratches on the sealing surfaces of the end plate are too deep to be cleaned up, or the plug nuts are damaged, replace the end plate or plug nuts.

When installing a plug nut, support the end plate on a solid flat surface to avoid distorting the plate. Then press the nut in the end plate until the head on the nut seats on the end plate.

Install Cylinder Block Rear End Plate

1. Affix a new gasket to the end of the cylinder block (flywheel end), using a non-hardening gasket cement;



Fig.1. - Cylinder Block Rear End Plate Mounting (V-Type Engine)

also apply an even coating of gasket cement to the outer surface of the gasket next to the end plate.

2. Align the dowel pin holes in the end plate with the dowel pins in the cylinder block. Then, start the end plate over the dowel pins and push it up against the cylinder block.

> **NOTE**: When installing the end plate, the heads of the plug nuts In the side of the end plate on the V-type engine, should always face the forward end of the cylinder block.

3a On a V-type engine, refer to Fig. 1 for the location and install the 3/8" -16 x 1" bolts with lock washers.

© 1972 General Motors Corp.

Also, install the two special washers and two l/2" -13 x 1-1/2" bolts as shown when the fuel pump is driven off the camshaft, or one special washer and bolt when the fuel pump is driven by the accessory gear. Tighten the 3/8" -16 bolts to 30-35 lb-ft torque and the 1/2" 13 bolts to 71-75 lb-ft torque.

© 1972 General Motors Corp.

AIR BOX DRAINS

During normal engine operation, water vapor from the air charge, as well as a slight amount of fuel and lubricating oil fumes, condense and settle on the bottom of the air box. This condensation is removed by the air box pressure through air box drain tubes mounted on the sides of the cylinder block.

Two drain tubes are used on the 6V engines (Fig.1.) at the rear end of the cylinder block.



Fig. 1. Air Box Drain Tube Mounting (6V Engine)

Inspection

During engine operation, a periodic check is recommended for air flow from the air box drain tubes. A partially plugged air box drain tube may allow air to escape and still cause liquid accumulation within the air box. This liquid accumulation can be seen by removing the cylinder block air box covers.

ó **1971 General Motors Corp** **April, 1971**

Remove the accumulation with rags or blow out with compressed air. If there is any sign of liquid accumulation or if there is no air flow from the air box drain tubes, remove the tubes and connectors and clean them thoroughly.

ó **1971 General Motors Corp.**

CYLINDER HEAD

The cylinder head (Fig. 1) is a one-piece casting. It may be removed from the engine as an assembly containing the cam followers, cam follower guides, rocker arms, exhaust valves and injectors. The head is securely held to the top of the cylinder block with bolts.

Located in the cylinder head are the exhaust valves, a fuel injector and three rocker arms for each cylinder. One rocker arm operates the injector plunger; the other two operate the exhaust valves. The rocker arms are operated by a camshaft through cam followers and push rods.

Exhaust valve inserts (valve seats), pressed into the cylinder head, permit accurate seating of the valves under varying conditions of temperature and materially prolong the life of the cylinder head. The inserts are ground to very close limits and their freedom from



Fig. 1. Cylinder Head Assembly

© 1970 General Motors Corp

warpage, under ordinary conditions, reduces valve reconditioning to a minimum.

To ensure efficient cooling, each fuel injector is inserted into a thin-walled tube which passes through the water space in the cylinder head. The lower end of the injector tube is pressed into the cylinder head and flared over; the upper end is flanged and sealed with a neoprene seal. The flared lower end and sealed upper end prevent water leaks around the copper tube.

The exhaust passages from the exhaust valves of each cylinder lead through a single port to the exhaust manifold. The exhaust passages, exhaust valve inserts and injector tubes are completely surrounded by cooling system water.

In addition to being surrounded by water, cooling of these areas is further assured by the use of double jet spray nozzles installed between each pair of cylinders in the water inlet ports of four valve cylinder heads.
Nozzle holes are so positioned in the cylinder head that the comparatively cool water which enters the head is directed at high velocity against the sections of the head which are subjected to the greatest heat.

To seal compression between the cylinder head and the cylinder liner, separate laminated metal gaskets are provided at each cylinder. Water and oil passages between the block and head are sealed with synthetic rubber seal rings which fit into counterbored holes in the block. A synthetic rubber seal fits into a milled groove in the block near the outer edge of the area covered by the cylinder head. When the cylinder head is pulled down, a positive leakproof metal-to-metal contact is assured between the head and block.

Certain service operations on the engine require the removal of the cylinder head. These operations are:

1. Removing and installing the pistons.
2. Removing and installing the cylinder liners.
3. Removing and installing the exhaust valves.
4. Removing and installing the valve guides.
5. Reconditioning the exhaust valves and valve seats.
6. Replacing the injector tubes.
7. Installing new cylinder head gaskets.
8. Removing and installing a camshaft.

Cylinder Head Maintenance

Engine temperatures should be maintained between 160° and 185°F. and the cooling system should be inspected daily and kept full at all times.

Unsuitable water in the cooling system may result in lime and scale formation which prevent proper cooling. The cylinder head should be inspected around the exhaust valve water jackets. This can be done by removing an injector tube. Where inspection discloses such deposits, a reliable non-corrosive scale remover should be used to remove the deposits from the cooling system of the engine, since a similar condition will exist in the cylinder block and other components of the engine. Refer to Section 13.3 for engine coolant recommendations.

Adding cold water to a hot engine may result in head cracks. Water must be added slowly to a hot engine to avoid rapid cooling which will result in distortion and cracking of the cylinder head (and cylinder block).

Loose or improperly seated injector tubes may result in compression leaks into the cooling system and cause a loss of engine coolant. The tubes should be tight and properly seated. Refer to Section 2.1.4.

The development of cracks in the cylinder head may be caused by abnormal operating conditions or through neglect of certain maintenance items. If this type of failure should occur, a careful inspection should be made to determine the cause so that a recurrence of the failure will be prevented.

Overtightening the injector clamp bolts may also result in head cracks. Always use a torque wrench to tighten the bolts to the specified torque.

Other conditions which may eventually result in head cracks are:
1. Excess fuel in the cylinders due to leaking injectors.
2. Oil pullover due to an overfilled air cleaner sump, or improper viscosity oil in the air cleaner.
3. Neglected cylinder block air box drains which allow accumulated oil to be drawn into the cylinders.

Remove Cylinder Head

Only the general steps for removal of the cylinder head are covered. If the engine is equipped with special accessories that affect cylinder head removal, note the position of each before disconnecting or removing them to assure the correct reinstallation.

© 1970 General Motors Corp.

1. Disconnect the exhaust piping at the exhaust manifold.
2. Drain the cooling system.
3. Remove the air cleaner(s)
4. Disconnect the fuel lines at the cylinder head.
5 Remove the thermostat housing and the thermostat as an assembly.
6. Clean and remove the valve rocker cover.
7. Disconnect and remove the fuel rod between the governor and the injector control tube lever. Remove the fuel rod cover, if used.
8. Remove the exhaust manifold.
9. Remove the injector control tube and brackets as an assembly.
10. If the cylinder head is to be stripped for reconditioning of valves and valve seats or for a complete cylinder head overhaul, remove the fuel pipes and injectors at this time. Refer to Section 2.1.1 for removal of the injectors.
11. Remove the cylinder head bolts. Then, lift the cylinder head off of the cylinder block, with lifter tool J 22062-01 (Fig. 2).

CAUTION: When resting the cylinder head assembly on a bench, protect the cam follower rollers and the injector spray tips by resting the valve side of the head on 2" thick wood blocks.

12. Remove the cylinder head compression gaskets, oil seals and water seals.

Disassemble Cylinder Head

If a cylinder head is removed for inspection and possible repair or replacement, remove the following parts:
1. Fuel injectors, if not previously removed.
2. Fuel connectors.
3. Cam follower guides and cam followers.
4. Rocker arms, rocker arm shafts, brackets, push rods, push rod springs, spring seats and spring seat retainers.
5. Exhaust valves and valve springs.

Fig. 2. - Lifting Cylinder Head Assembly Off Cylinder Block with Tool J 22062-01

The removal procedures to be followed, when removing the parts mentioned above, are covered in their respective sections of this manual.

Clean Cylinder Head

After the cylinder head has been stripped of all the component parts and all of the plugs (except cup plugs) have been removed, steam clean the head thoroughly.

Thoroughly clean a new service cylinder head to remove all of the rust preventive compound, particularly from the integral fuel manifolds, before the plugs are installed in the fuel manifolds and the head is mounted on the engine. A simple method of removing the rust preventive compound is to immerse the head in solvent, oleum or fuel oil; then, go over the head and through all of the openings with a soft bristle brush. A suitable brush for cleaning the fuel manifolds can be made by attaching a 1/8" brass rod to brush J 8152. After cleaning, dry the cylinder head with compressed air.

Inspect Cylinder Head

1. Check the cylinder head for leaks as follows:

a. Seal off the Water holes in (the head with steel plates and suitable rubber gaskets held in place by bolts.

ó **1970 General Motors Corp.**



Fig. 3. - Checking Bottom Face of Cylinder Head for Warpage

b. Install dummy or scrap injectors to ensure seating of the injector tubes. Dummy injectors may be made from old injector nuts and bodies - the injector spray tips are not necessary. Tighten the injector clamp bolts to 20-25 lb-ft torque.

c. Drill and tap into one of the water hole cover plates for an air hose connection and apply 80- 100 psi air pressure to the water jacket. Then, immerse the head in a tank of water previously heated to 180-200°F. for twenty minutes to thoroughly heat the cylinder head. Observe the water in the tank for bubbles indicating cracks or leaks.

d. Remove the cylinder head from the tank and dry it with compressed air.

e. If inspection revealed cracks, replace the cylinder head.

f. Replace any leaking injector tubes as outlined in Section 2.1.4.

Over a prolonged period of operation, the cylinder head may assume a contour to match that of the cylinder block, which is normal. However, if the cylinder head is allowed to become overheated because of coolant loss, the resultant high temperatures cause stresses to occur in the casting which will affect the flatness of the head.

2. Check the bottom (fire deck) of the cylinder head for flatness as follows:

a. Use an accurate straightedge and feeler gage J 3172 to check for transverse warpage at each end and between all of the cylinders. Also, check for longitudinal warpage in six places as shown in Fig. 3.Maximum allowable warpage is given in the following chart:

Engine	Maximum Longitudinal Warpage	Maximum Transverse Warpage
6V-53	.005"	.040"

b. The maximum allowable warpage limits should be used as a guide in determining the advisability of reinstalling the head on the engine or of refacing it. The number of times a cylinder head may be refaced will, of course, depend upon the amount of stock removed from the head during previous reworking operations.

c. If the cylinder head is to be refaced, remove the injector tubes prior to machining. Not over .020" of metal should be removed from the fire deck of the cylinder head. The distance from the top to the bottom (fire deck) of the cylinder head must not be less than 4376", as shown in (Fig. 4).

Stamp the amount of stock removed on the face of the fire deck near the outer edge of the head, in an area not used as a sealing surface.

d. After a cylinder head has been refaced and new injector tubes have been installed as outlined in Section 2.1.4, pressure check the cylinder head as outlined in Step 1.

3. Inspect the cam follower bores in the cylinder head for scoring or wear. Light score marks may be cleaned



Fig. 4. - Minimum Distance Between Top and Bottom Faces of Cylinder Head

ó **1970 General Motors Corp.**

up with crocus cloth wet with fuel oil. If the bores are excessively scored or worn so that the cam follower-to-head clearance exceeds .006", replace the cylinder head.

4. Inspect the valve seat inserts for cracks or burning. Also, check the valve guides for scoring.

5. Check the water nozzles*

Be sure they are not loose. Water nozzles are used only in the passages between the cylinders. If necessary, install or replace the water nozzles as follows:

a. Be sure the water inlet ports in the bottom of the head are clean and free of scale. The water holes may be cleaned up with a 5/8" diameter drill. Break the edges of the holes slightly.
b. If the water holes in the head have been enlarged by corrosion, use a wooden plug or other suitable tool to expand the nozzles so that they will remain tight after installation.
c. Press the nozzles in place with the outlet holes positioned as shown in Fig. 5. The angle between the outlet holes in the nozzle is 90°. Press the nozzles from flush to 1/32" below the bottom surface of the cylinder head.

6. Inspect the parts removed from the cylinder head before they are reinstalled in the old head or transferred to a new cylinder head.

Assemble Cylinder Head

New service cylinder heads include valve guides, valve seat inserts, water nozzles, injector tubes and the necessary plugs.

> **CAUTION:** When installing the plugs in the fuel manifolds, apply a small amount of sealant merchandized as a "dual purpose sealer" to .the threads of the plugs only. Work the sealant into the threads and wipe off the excess with a clean, lint-free cloth so that the sealant will not be washed into the fuel system and result in damage to the injectors.

When a new cylinder head is to be used, remove) the parts listed below from the old head and install them in the new head. If the old cylinder head is to be reused, install the parts in the old head prior to assembling the head on the cylinder block.

1. Exhaust manifold studs.



Fig. 5. - Correct Installation of Water Nozzles in Cylinder Head

2. Exhaust valves and springs (Section 12.2).

3. Install the fuel injectors at this time or after installing the cylinder head (Section 2.1.1).

4. Cam followers, cam follower guides, push rod assemblies, rocker arm shafts and rocker arms; do not tighten the rocker arm bracket bolts at this time (Section 1.2.1).

5. Place new washers on the fuel connectors, then install the fuel connectors and tighten them to 20-28 lb-ft torque.

Pre-Installation Inspection

Perform the following inspections just prior to installing the cylinder head on the engine.

1. Check the cylinder liner flange height as outlined in Section 1.6.3.

2. Check to be sure the tops of the pistons are clean and free of foreign material.

3. Check to see that each push rod is threaded into the clevis until the end of the push rod projects through the clevis. This is important since serious engine damage will be prevented when the crankshaft is rotated during tune-up.

4. Check to be sure that the groove and the counterbores in the top of the cylinder block are clean and smooth.

© 1970 General Motors Corp.

Install Cylinder Head

1. Install new cylinder head compression gaskets and seals as outlined below:
   a. Place a new compression gasket on each cylinder liner.
   b. Place new seal rings in the counterbores of the water and oil holes in the cylinder block.
   c. Install a new oil seal in the milled groove in the cylinder block near the outer edge of the area covered by the cylinder head.

NOTE: Used water seals, oil seals and compression gaskets should *never* be used.

2. To install the cylinder head on the engine without disturbing the gaskets and seals, use guide stud set J 9665. Install the guide studs in the end cylinder block bolt holes (Fig. 2).

3. Make a final visual check of all of the cylinder head gaskets and seals to ensure that they are in place just before the cylinder bead is lowered onto the cylinder block. This is a very important check. Compression gaskets and seals which are jarred out of their proper position will lead to leaks and "blow-by" with resultant poor engine performance and damage to the engine.

4. Wipe the bottom of the cylinder head clean; then, lower the head on the block.

5. Lubricate the threads and the underside of each cylinder head bolt with a small quantity of International Compound No. 2, or equivalent. Then, install the bolts.

NOTE: Cylinder head bolts are especially designed for this purpose and -must not be replaced by ordinary bolts.



6V-53 CYLINDER HEAD

Fig. 6. - Sequence for Tightening Cylinder Head Bolts

© 1970 General Motors Corp.

6. The cylinder head must be gradually and uniformly drawn down against the gaskets and seals to ensure a good seal between the cylinder head and the block. Therefore, it is vitally important that the cylinder head be installed with the utmost care.
7. Then, begin on the camshaft side of the head to take up the tension in the cam follower springs by tightening the bolts lightly. Finally tighten the bolts to 170-180 lb-ft torque with a torque wrench, about one-half turn at a time, in the sequence shown in Fig. 6. Under no circumstances should the torque exceed the specified limits, otherwise the bolts may become stretched beyond their elastic limits.
8. Cover the oil drain holes in the cylinder head to prevent foreign objects from falling into the holes.

9. If the injectors were not previously installed, refer to Section 2.1.1 and install them at this time.

10. Tighten the rocker arm bracket bolts to 50-55 lb-ft torque.

> **CAUTION: There is a possibility of damaging the exhaust valves if the exhaust valve bridge is not resting on the ends of the exhaust valves when tightening the rocker arm bracket bolts. Therefore, note the position of the exhaust valve bridge before, during and after tightening the bolts.**

11. Align the fuel pipes and connect them to the injectors and the fuel connectors. Use socket J 8932-01 to tighten the connections to 12-15 lb-ft torque.

> **CAUTION: Do not bend the fuel pipes and do not exceed the specified torque. Excessive tightening will twist or fracture the flared ends of the fuel pipes and result in leaks. Lubricating oil diluted by fuel oil can cause serious damage to the engine bearings.**

12. Set the injector control tube assembly in place on the cylinder head and tighten the bolts, finger tight only. When positioning the injector control tube, be sure that the ball end of each injector rack control lever engages the slot in the corresponding injector control rack. With one end of the control tube return spring hooked around an injector rack control lever and the other end hooked around a control tube bracket, tighten the bracket bolts to 10-12 lb-ft torque.

13. After tightening the bolts, revolve the tube and see if the return spring pulls the injector racks out (no-fuel position) after they have been moved all the way in (full-fuel position). Since the injector control tube is mounted in self-aligning bearings, tapping the tube lightly with a soft hammer will remove any bind that exists. The injector racks must return to the no-fuel position freely by aid of the return spring only. Do not bend the return spring to bring about this condition.

14. Install the fuel rod and the fuel rod cover (if used).

15. Remove the covers from the drain holes in the head.

16. Install the exhaust manifold and connect the exhaust piping.

17. Install the thermostat housing and the thermostat.

18. Install the air cleaners.

19. Connect the fuel lines.

20. Fill the cooling system and check for leaks.

21. With the throttle in the OFF position, crank the engine over to be sure that all of the parts function freely.

22. Before starting the engine, perform an engine tune-up as outlined in Section 14.

23. Refer to Section 13.1 and start the engine. After starting the engine, check all fuel line connections to ensure that no fuel oil leaks into the cylinder head compartment to dilute the lubricating oil.

24. After the engine has been warmed up (to at least 1600F.), recheck the torque on the cylinder head bolts.

25. Recheck the exhaust valve clearance and the injector timing after the engine reaches normal operating temperature.

26. Examine all fuel oil, lubricating oil and water connections for possible leaks. Tighten the connections, if necessary.

27. Install the valve rocker cover, using a new gasket.

ó **1970 General Motors Corp**

VALVE AND INJECTOR OPERATING MECHANISM

Three rocker arms are provided for each cylinder; the two outer arms operate the exhaust valves and the center arm operates tie fuel injector.

Each set of rocker arm assemblies pivots on a shaft supported by two brackets. A single bolt secures each bracket to the top of the cylinder head. Consequently, the removal of two bracket bolts permits the rocker arm assembly for one cylinder to be raised, providing easy access to the fuel injector and valve springs.

The rocker arms are operated by the camshaft through cam followers and short push rods extending through the cylinder head (Fig. 1).

Each cam follower operates in a bore in the cylinder head. A guide for each set of three cam followers is attached to the bottom of the cylinder head to keep the follower rollers in line with the cams and serves as a retainer during assembly and disassembly.

A coil spring, located inside of each cam follower, is held in place in the cylinder head by a spring seat and spring seat retainer.

Several operations may be performed on the valve mechanism without removing the cylinder head from the cylinder block, while the head must be removed for certain other operations. The operations NOT requiring removal of the cylinder head are:

1. Adjusting valve clearance.

2. Removing and installing a valve spring.

3. Removing and installing a rocker arm.

4. Removing and installing a rocker arm shaft or shaft bracket.

5. Removing and installing an injector.

It is also possible, if occasion requires, to remove or replace a push rod, push rod spring, spring seats or cam follower without removing the cylinder head. These parts, however, are more easily changed from the lower side of the cylinder head when the head is off the engine. Both methods are covered in this Section.

To remove and install valves, valve guides, valve seat inserts and to recondition valves and valve seats, the cylinder head must be removed. Exhaust valves, guides and inserts are covered in Section 1.2.2.

Lubrication

The valve and injector operating mechanism is lubricated by oil from a longitudinal oil passage, on the camshaft side of the cylinder head, which connects with oil passages in the cylinder block. Oil from this



Fig. 1. - Injector Operating Mechanism (Shown)



Fig 2. - Cam follower and Guide Location

ó **1972 General Motors Corp** **July, 1972**

Fig. 3. - Removing Push Rod from Upper Side of Cylinder Head with Tool J 3092-01

longitudinal passage enters the drilled rocker arm shafts through the lower end of the drilled rocker shaft bracket bolts and lubricates the rocker arms.

Excess oil from the rocker arms lubricates the exhaust valves and cam followers. Additional cam follower lubrication is provided by oil from grooves in the camshaft bushing bores which is directed against the cam follower rollers.

Remove Rocker Arms and Rocker Arm Shaft

1. Clean and remove the valve rocker cover.

2. Remove the fuel pipes from the injector and the fuel connectors.

> **CAUTION: Immediately after removing the fuel pipes, cover each injector opening with a shipping cap to prevent dirt or other foreign matter from entering the injector.**

3. Bar the engine over in the direction of engine rotation or crank the engine with the starting motor to bring the push rod ends -- the outer ends -- of the injector and valve rocker arms in line horizontally.



Fig. 4. - Testing Push Rod Spring

4. Remove the two bolts which hold the rocker arm shaft brackets to the cylinder head. Remove the brackets and the shaft.
5. Loosen the lock nut at the upper end of the push rod, next to the clevis, and unscrew the rocker arm from the push rod.



Fig. 5. - Cam Roller Wear and Clearance Diagram

© 1972 General Motors Corp.

Inspection

Wash the rocker arms, rocker arms shaft and brackets thoroughly in clean fuel oil and dry them with compressed air. Make certain that the oil passages in the rocker arms, rocker arm shaft and bracket bolts are open and clean.

Inspect all of the parts for excessive wear.

The maximum clearance between the rocker arm shaft and the injector rocker arm bushing or an exhaust valve rocker arm (which has no bushing),is .004 "with used parts.

Examine each rocker arm pallet (contact face) for wear or galling. Also check the contact surfaces of the exhaust valve bridge.

Remove Cam Follower and Push Rod Assembly (Cylinder Head Removed from Engine)

With the cylinder head removed from the engine, remove the cam followers as follows:

1. Rest the cylinder head on its side and remove the two bolts and lock washers securing the cam follower guide to the bottom of the cylinder head (Fig. 2). Remove the guide.
2. Pull the cam followers from the bottom of the cylinder head.
3. Remove the fuel pipes from the injector and the fuel connectors.
4. Loosen the lock nuts at the upper end of the push rods and unscrew the push rods from the rocker arm clevises.
5. Pull the push rod and spring assemblies from) the bottom of the cylinder head.
6. Remove the push rod lock nut, upper spring seat, spring and lower spring seat from each push rod for cleaning and inspection.

The push rod spring seat retainers remain in the cylinder head. If the head is to be changed, these retainers must be removed and installed in the new head.

Remove Cam Follower and Push Rod Assembly (Cylinder Head Not Removed from Engine)

A push rod, push rod spring, spring seats and cam follower may be removed from the top of the cylinder head by using tool J 3092-01 as shown in Fig. 3.



Fig. 6. - Cam Follower

1. Clean and remove the valve rocker cover.
2. Remove the fuel pipes from the injector and the fuel connectors.
3. Remove the rocker arm brackets and rocker arm shaft as outlined in Steps 3 and 4 under *Remove Rocker Arms and Rocker Arm Shaft.*
4. Loosen the lock nut at the upper end of the push rod, next to the clevis, and unscrew the rocker arm from the push rod to be removed. Remove the lock nut from the push rod.
5. Install the remover J 3092-01, a flat washer and nut on the push rod (Fig. 3). Screw the nut down on the end of the push rod to compress the push rod spring.
6. Remove the retainer from the cylinder head with a screw driver or similar tool as shown in Fig. 3.
7. Unscrew the nut at the outer end of the push rod, thus releasing the spring.
8. Pull the push rod, spring, spring seats and cam follower out through the top of the cylinder head.

© 1972 General Motors Corp.



Fig. 7. - Removing or Installing Cam Follower Roller and Pin with Tool J 5840

Inspection

Proper cam follower inspection and service are necessary in obtaining continued efficient engine performance. When any appreciable change in injector timing or exhaust valve clearance occurs during engine operation, the cam followers, and their related parts, should be removed and inspected for excessive wear. This change in injector timing or exhaust valve clearance during engine operation can usually be detected by excessive noise at idle speed.

After the cam followers are removed, wash them with lubricating oil or Cindol 1705 and wipe dry. Do not use fuel oil. Fuel oil working its way in between the roller and bushing may cause scoring on the initial engine start-up since fuel oil does not provide adequate lubrication. Wash only the cam follower associated parts with fuel oil and dry them with compressed air.

Inspect the rounded end of the push rods for wear. Replace any push rod which is worn or bent.

The purpose of a push rod spring is to maintain a predetermined load on the cam follower to insure contact of the cam roller on the camshaft lobe at all times. Check the push rod spring load whenever the cam followers and related parts are removed for inspection.

Use spring tester J 9666 and an accurate torque wrench to check the push rod spring load (Fig. 4). Replace the spring when a load of less than 250 pounds will compress it to a length of 2-9/ 64 ".

Examine the cam follower bores in the cylinder head

ó 1972 General Motors Corp.



Fig. 8. - Valve and Injector Operating Mechanism Details and Relative Location of Parts

to make sure they are clean, smooth and free of score marks to permit proper functioning of the cam followers. Any existing score marks must be cleaned up.

Check the cam follower-to-cylinder head clearance. The clearance must not exceed .006 " with used parts. The cam follower roller must turn smoothly and freely



Fig. 9. - Checking the Clearance Between the Cam Follower Guide and Cam Follower Legs

on its pin and the roller must be free from flat spots or scuff marks. If the roller does not turn freely or has been scored or worn flat, then examine the cam on which it operates. If the cam is excessively worn or damaged, replace the camshaft.

Measure the total clearance between the roller bushing and pin, crosswise of the pin, as shown in Fig. 5 and, if the bushing is worn to the extent that more than



Fig. 10. - Adjusting Cam Follower Guide

ó **1972 General Motors Corp.**

.010" diametric clearance exists, replace the cam follower assembly or install a new cam roller and pin, which are serviced as a set. Be sure the follower legs are beveled (Fig. 6) and check the total side clearance between the roller and follower; this clearance must not be less than .015 " nor more than .023 ".

Oversize roller and pin sets are available for service when required. However, DO NOT attempt to bore out the legs of a standard cam follower for an oversize roller and pin set. This cannot be over emphasized because of the extremely close manufacturing tolerances.

Remove and Install Cam Follower Roller and Pin

1. Clamp fixture J 5840 securely in a vise as shown in Fig. 7 and place the cam follower in the groove in the top of the fixture with the follower pin resting on top of the corresponding plunger in the fixture.

2. Drive the pin from the roller with a suitable drift. Exercise caution in removing the cam follower body and roller from the fixture as the follower pin is seated on top of a spring-loaded plunger in the fixture body.

3. Before installing the new roller and pin kit, remove the preservative by washing the parts with clean lubricating oil or Cindol 1705. Do not use fuel oil.



Fig. 11. - Push Rod Spring Identification

4. Prior to installing a new roller and- pin, remove any burrs on the surfaces of the cam follower at the pin holes.

5. Position the follower body in the groove of the fixture with the proper size fixture plunger extending through the roller pin hole in one of the legs of the follower body.

6. Position the-roller in the cam follower body (Fig. 7). The small plunger in the tool will align the roller with the pin holes in the follower body.

7. Align the pin with the hole in the follower body and carefully drive the pin into the body until the ends of the pin are centered in the legs of the body.

8. Check the side clearance between the roller and the follower body. This clearance must be .015 " to .023 ".

Install Cam Follower and Push Rod Assembly (Cylinder Head Removed from Engine)

1. Install a serrated lower spring seat on each push rod.

2. Place the push rod springs (Fig. 11) on the push rods.

3. Install the upper spring seat on each push rod.

4. Install the spring seat retainer in the cylinder head. Then slide the push rod, lower spring seat, spring and upper spring seat as an assembly into the cam follower bore from the bottom of the cylinder head.

5. Screw the push rod lock nut down on the upper end of the push rod as far as possible. Then screw the push rod into the clevis {until the end of the rod is flush with or above the inner side of the clevis.

6. Immerse the cam follower assemblies in clean Cindol 1705 (heated to 100°-125°F.) for at least one hour before placing them in the cylinder head, to ensure initial lubrication between the cam follower roller pins and the roller bushings. Rotate the cam follower roller during the soaking period to aid in purging any air from the bushing-roller area. The heated Cindol 1705 results in better penetration as it is less viscous than engine oil and flows more easily between the pin and roller bushing surfaces. After the cam follower is removed from the Cindol 1705, the cooling action of any trapped air in the pin and bushing area tends to pull the oil into the cavity.

ó 1972 General Motors Corp.



Fig. 12. - Relationship Between Exhaust Valve Bridge and Valve Stems

NOTE: **Heat the Cindol 1705 in a small pail, with a screen insert. The screen insert will prevent the follower assemblies from touching the bottom of the pail during soaking, thus avoiding the possibility of contamination.**

IMPORTANT: When installing a new cam / follower assembly, wash it with clean lubricating oil or Cindol 1705 to remove the preservative.

7. Note the oil hole in the bottom of the cam follower. With this oil hole pointing away from the exhaust valves, slide the cam follower into position from the bottom of the head.

8. Attach the cam follower guide (Fig. 8) to the bottom of the cylinder head to hold the group of cam followers in place. Tighten the cam follower guide bolts to 12-15 lb-ft torque. Check to be sure there is at least .005" clearance between the cam follower legs and the cam follower guide (Fig. 9). If there is insufficient clearance, loosen the guide bolts slightly and tap each corner of the guide with a brass rod (Fig. 10). Then retighten the bolts to 12-15 lb-ft torque and recheck the clearance.

Install Cam Follower and Push Rod Assembly (Cylinder Head Not Removed from Engine)

1. Lubricate the cam follower as stated in Step 6 under Install Cam Follower and Push Rod Assembly (Cylinder Head Removed from Engine).

2. Note the oil hole in the bottom of the cam follower. With this hole pointing away from the exhaust valves, slide the cam follower into position.

3. Install a serrated lower spring seat on each push rod.

4. Place the push rod springs (Fig. 11) on the push rods.

5. Install the upper spring seat on each push rod.

6. Set the push rod, lower spring seat, spring and upper spring seat down in the cam follower.

7. Install a flat washer and nut on the push rod. Then place tool J 3092-01 on the push rod, between the flat washer and upper spring seat. Screw the nut down on the push rod until the spring is compressed sufficiently to permit the retainer to be installed. Partially collapse the retainer and install it in the cylinder head groove.

8. Remove the nut, flat washer and tool from the push rod.

9. Reinstall the nut on the push rod. Screw the nut down as far as possible on the push rod. Then screw the rocker arm clevis down on the push rod until the end of the push rod is flush with or above the inner side of the clevis.

NOTE: The injector rocker arm (the center arm of the group) is slightly different from the exhaust valve rocker arms; the boss for the shaft on the valve rocker arms is longer on one side of the arm than on the other. The extended boss of the valve rocker arms must face the injector rocker arm.

© 1972 General Motors Corp.

Install Rocker Arms and Rocker Arm Shaft

1. Install the cylinder head, if removed, as outlined in Section 1.2.
2. Apply clean engine oil to the surface of the rocker arm shaft.
3. Install the rocker arms and rocker arm shaft by reversing the sequence of operations for removal. Tighten the rocker arm shaft bracket bolts to 50-55 Ib- ft torque. After tightening the bolts, check for some side clearance to prevent bind between the rocker arms.

> **CAUTION**: **There is a possibility of damaging the exhaust valves if the valve bridges are not resting on the ends of the valves when tightening the rocker arm shaft bracket bolts (Fig. 12). Therefore, note the position of the exhaust valve bridges before, during and after tightening the rocker arm shaft bracket bolts**.

4. Align the fuel pipes and connect them to the injectors and the fuel connectors. Tighten the fuel pipe nuts to 12-15 Ib-ft torque with socket J 8932-01.

> **CAUTION**: **Do not bend the fuel pipes and do not exceed the specified torque. Excessive tightening will twist or fracture the flared ends of the fuel pipes and result in leaks. Lubricating oil diluted by fuel oil can cause serious damage to the engine bearings.**

5. Fill the cooling system.

6. Adjust the exhaust valve clearance and time the fuel injector as outlined in Section 14.1 and 14.2 before starting the engine.
7. Start the engine and check for leaks in the fuel, cooling and lubrication systems.

8. Tune-up the engine, as outlined in Section 14, after the engine reaches normal operating temperature.

ó **1972 General Motors Corp.**

EXHAUST VALVES

Four exhaust valves are provided for each cylinder, (Fig. 1). The valve heads are heat treated and ground to the proper seat angle and diameter. The valve stems are ground to size and hardened at the end which contacts the rocker arm or the exhaust valve bridge.

The exhaust valve stems are contained within exhaust valve guides which are pressed into the cylinder head. Exhaust valve seat inserts, pressed into the cylinder head, permit accurate seating of the exhaust valves under varying conditions of temperature and materially prolong the life of the cylinder head. The exhaust valves and exhaust valve seat inserts are ground to a 30° seating angle.

The exhaust valve springs are held in place by the valve spring caps and tapered two-piece valve locks.

Excess oil from the rocker arms lubricates the exhaust valve stems. The valves are cooled by the flow of air from the blower past the valves each time the air inlet ports are uncovered.

Exhaust Valve Maintenance

Efficient combustion in the engine requires that the exhaust valves be maintained in good operating condition. Valve seats must be true and unpitted to assure leak-proof seating, valve stems must work freely and smoothly within the valve guides and the correct valve clearance (Section 14.1) must be maintained.



Fig. 1. - Location of Exhaust Valves

Proper maintenance and operation of the engine is important to long valve life. Engine operating temperatures should be maintained between 160°F. and 185°F. Low operating temperatures (usually due to extended periods of idling or light engine loads) result in incomplete combustion, formation of excessive carbon deposits and fuel lacquers on valves and related parts. and a greater tendency for lubricating oil to sludge.

Unsuitable fuels may also cause formation of deposits on the valves, especially when operating at low temperatures.

When carbon deposits, due to partially burned fuel, build up around the valve stems and extend to that portion of the stem which operates in the valve guide, sticking valves will result. Thus, the valves cannot seat properly and pitted and burned valves and valve seats and loss of compression will result.

Lubricating oil and oil filters should be changed periodically to avoid accumulation of sludge.

Valve sticking may also result from valve stems which have been scored due to foreign matter in the lubricating oil, leakage of antifreeze (glycol) into the lubricating oil which forms a soft sticky carbon and gums the valve stems, and bent or worn valve guides.
Sticking valves may eventually result in valves being held in the open position, being struck by the piston and becoming bent or broken.

It is highly important that injector timing and valve clearance be accurately adjusted and checked periodically. Improperly timed injectors will have adverse effects upon combustion. Tightly adjusted valves will cause rapid pitting of the valve seats and a hotter running condition on the valve stems.



Fig. 2. - Removing Valve Spring

ó **1972 General Motors Corp.**

The cylinder head must first be removed before the exhaust valves, valve seat inserts or valve guides can be removed for replacement or reconditioning. However, the valve springs may be replaced without removing the cylinder head.

Remove Exhaust Valve Spring (Cylinder Head Installed)

An exhaust valve spring may be removed, without removing the cylinder head from-the engine, as follows:

1. Clean and remove the valve rocker cover.

2. Crank the engine over to bring the valve and injector rocker arms in line horizontally.

3. Disconnect and remove the fuel pipes from the injector and the fuel connectors.

> **CAUTION**: **Immediately after removing the fuel pipes, cover each injector opening with a shipping cap to prevent dirt or other foreign matter from entering the injector.**

4. Remove the two bolts holding the rocker arm shaft brackets to the cylinder head and remove the brackets and shaft.

5. Remove the cylinder block air box cover so that the



Fig. 3. - Testing Valve Spring



Fig. 4. - Cleaning Valve Guide

piston travel may be observed, then turn the crankshaft until the piston is at the top of its stroke.
6. Thread the spring compressor tool into one of the rocker arm support bolt holes (Fig. 2). Then compress the spring and remove the two-piece valve lock.
7. Release the tool and remove the valve spring cap, valve spring and spring seat.

Remove Exhaust Valves and Valve Springs (Cylinder Head Removed)

With the cylinder head removed from the engine, remove the exhaust valves and springs as follows:

1. Support the cylinder head on 2" thick wood blocks to keep the cam followers clear of the bench.

2. Disconnect and remove the fuel pipes from the injectors and the fuel connectors.

> **CAUTION**: **Immediately after removing the fuel pipes, cover each injector opening with a shipping cap to prevent dirt or other foreign matter from entering the injector.**

3. Remove the two bolts holding the rocker arm shaft

© 1972 General Motors Corp.

brackets to the cylinder head and remove the brackets and the shaft.

4. Remove the fuel injector.

5. Place a block of wood under the cylinder head to support the exhaust valves. Remove the exhaust valve springs as outlined in Steps 6 and 7 above.

6. Turn the cylinder head over, using care to keep the valves from falling out of the head. If the valves are to be reused, number each valve to facilitate reinstallation in the same position. Then withdraw the valves from the cylinder head.

7. Remove the cam followers and push rod assemblies as outlined in Section 1.2.1 under Remove Cam *Follower and Push Rod Assembly (Cylinder Head Removed from Engine).*

Inspection

Clean the springs with fuel oil, dry them with compressed air and inspect them. Replace a pitted or fractured spring.

Check the springs with spring tester J 9666 and an accurate torque wrench. Replace a spring a load of less than 25 pounds will compress a four valve cylinder head spring to 1.93 inches. The difference in the load between a pair of springs must not exceed 6 pounds or the valve bridge will be unbalanced.

The exhaust valve spring has a wire-diameter of 148"

For service replacement, change the spring when a load of less than 25 lbs. will compress it to 1.93" (installed length).

Inspect the valve spring seats and caps for wear. If worn, replace with new parts.

Carbon on the face of a valve indicates blow-by due to a faulty seat. Black carbon deposits extending from the valve seats to the valve guides may result from cold operation due to light loads or the use of too light a grade of fuel. Rusty brown valve heads with carbon deposits forming narrow collars near the valve guides is evidence of high operating temperatures. High operating temperatures are normally due to overloads, inadequate cooling, or improper timing which results in carbonization of the lubricating oil.

Clean the carbon from the valve stems and wash the valves with fuel oil. The valve stems must be free from scratches or scuff marks and the valve faces must be free from ridges, cracks or pitting. If necessary, reface the valves or install new valves. If the valve heads are warped, replace the valves.

Clean the inside diameter of the valve guides with or brush J 7793 as shown in Fig. 4. This brush will remove all gum and carbon deposits from the valve guides.

Inspect the valve guides for fractures, scoring or excessive wear. Check the valve-to-guide clearance, since worn valve guides may eventually result in improper valve seat contact. If the clearance exceeds .006" .005" replace the valve guides.

The valve guides, which are not machined for use with oil seals, have a 45° chamfer at the upper end.

© 1972 General Motors Corp.

Remove Exhaust Valve Guide

1. Support the cylinder head, bottom side up, on 3" thick wood blocks.
2. Drive the valve guide out of the cylinder head with valve guide remover: or J 7775 (four valve head) as shown in Fig. 5.

Install Exhaust Valve Guide

Turn the cylinder head right side up and install the valve guide as follows:

1. Insert the internally threaded end of the valve guide in the valve guide installing tool (refer to the Valve Guide Installing Tool chart). Be sure to use the correct tool to avoid damage to the valve guide and to locate the valve guide to the proper dimension.

2. Position the valve guide squarely in the bore in the cylinder head and press the installing tool gently to start the guide in place (Fig. 6). Then press the guide in until the tool contacts the cylinder head (the bottom of the counterbore in the four valve cylinder head).

Fig. 5. - Removing Valve Guide



Fig. 6. - Installing Valve Guide

CAUTION: Do not use the valve guides as a means of turning the cylinder head over or in handling the cylinder head.

Inspect Exhaust Valve Seat Insert

Inspect the exhaust valve seat inserts for excessive wear, pitting or cracking.

Remove Exhaust Valve Seat Insert

The valve seat inserts are pressed into the cylinder head and must be removed as outlined in the following procedure to avoid damage to the cylinder head:

Tool No.	Cyl. Head	Valve Guide	Distance of Guide Below Top of Head
J24519	**4 VALVE**	*****	**150" - 180"**

*Machined for use with valve guide oil seal.

Valve Guide Installing Tools

© 1972 General Motors Corp.



Fig. 7. - Removing Valve Seat Insert

1. Place the cylinder head on its side on a bench as shown in Fig. 7.

2. Place the collet of tool J 7774 inside the valve insert so that the bottom of the collet is flush with the bottom of the insert.

3. Hold the collet handle and turn the T handle to expand the collet cone until the insert is held securely by the tool.

4. Insert the drive bar of the tool through the valve guide

5. Tap the drive bar once or twice to move the insert about 1/16" away from its seat in the cylinder head.

6. Tin the T handle to loosen the collet cone and move the tool into the insert slightly so the narrow flange .t the bottom of the collet is below the valve seat insert.

7. Tighten the collet cone and continue to drive the insert out of the cylinder head.

Install Exhaust Valve Seat Insert

1. Clean the valve seat insert counterbores in the head with trichloroethylene or over suitable solvent. Also wash the valve seat inserts with the same solvent. Dry the counterbores and the inserts with compressed air.

2. Inspect the counterbores for cleanliness, concentricity, flatness and cracks The counterbores have a diameter of 1.159" to 1I60" and a

Fig 8. - Installing Valve Seat Insert
depth .300" to .312"

> **NOTE**: Valve seat inserts which are .010" oversize on the outside diameter are available, if required.

3. Immerse the cylinder head for at least 30 minutes in water heated to 180°F. to 200°F.

4. Rest the cylinder head, bottom side up, on a bench and place an insert in the counterbore--valve seat side up. This must be done quickly while the cylinder head is still hot and the insert is cold (room temperature). If the temperature of the two parts is allowed to become nearly the same, installation may become difficult and damage to the parts may result.

5. Drive the insert in place with installer or J 7790 as shown in

Fig. 8 until it seats solidly in the cylinder head.

6. Grind the valve seat insert and check it for concentricity in relation to the valve guide as outlined below.

ó **1972 General Motors Corp.**



Fig. 9.- Refacing Exhaust Valve

Recondition Exhaust Valve and Valve Insert

An exhaust valve which is to be reused may be refaced, if necessary (Fig. 9). To provide sufficient valve strength and spring tension, the edge of the valve at the valve head must not be less than 1/32" in thickness and must still be within the specifications shown in Fig. 11 after refacing.

Before either a new or used valve is installed, examine the valve seat in the cylinder head for proper valve seating. The angle of the valve seat insert must be exactly the same as the angle of the valve face to provide proper seating of the valve. The proper angle for the seating face of both the valve and valve seat insert is 30°.



Fig. 10.- Grinding Valve Seat Insert

When a new valve seat insert is installed or an old insert refaced, the work must be done with a grinding wheel (Fig. 10).

The eccentric grinding method for reconditioning valve seat inserts is recommended. This method produces a finer, more accurate finish since only one point of the grinding wheel is in contact with the valve seat at any time. A micrometer feed permits feeding the grinding wheel into the work .001" at a time.

To grind the valve seat inserts use the following tools:

1. Grinder J 8165-1
2. Dial Gage J 8165-2
3. Pilot J 7792-1
4. Grinding Wheel (15°) J 7792-2
5. Grinding Wheel (30°) J 7792-3
6. Grinding Wheel (60°) J 7792-4

Grind the valve seat inserts as follows:

1. First apply the 30° grinding wheel on the valve seat insert.

ó **1972 General Motors Corp.**



Fig. 11. - Relationship Between Exhaust Valve, Insert and Cylinder Head

2. Use the 60° grinding wheel to open the throat of the insert.

3. Then grind the top surface with a 15° wheel to narrow the width of the seat from 3/64" to 5/64" (Fig. 11). The 30° face of the insert may be adjusted relative to the center of the valve face with the 15° and 60° grinding wheels.

> **CAUTION**: Do not permit the grinding wheel to contact the cylinder head when grinding the insert. If necessary, replace the insert.

The maximum amount that the exhaust valve should protrude beyond the cylinder head (when the valve is in the closed position), and still maintain the proper piston-to-valve clearance, is shown in Fig. 11



Fig. 12. - Grinding Wheel Dressing Tool of Set J 8165

Grinding will reduce the thickness of the valve seat insert and cause the valve to recede into the cylinder head. If, after several grinding operations, the valve recedes beyond the specified limits, replace the valve seat insert.

When occasion requires, the grinding wheel may be dressed to maintain the desired seat angle with the dressing tool provided with the grinder set (Fig. 13.)

After grinding has been completed, clean the valve seat insert thoroughly with fuel oil and dry it with compressed air. Set the dial indicator J 8165-2 in position as shown in Fig. 13 and rotate it to determine the concentricity of each valve seat insert relative to the valve guide. If the runout exceeds .002", check for a bent valve guide before regrinding the insert.

4. After the valve seat insert has been ground, determine the position of the contact area between the valve and the valve seat insert as follows:

a. Apply a light coat of Prussian Blue or similar paste to the valve seat insert.

b. Lower the stem of the valve in the valve guide and "bounce" the valve on the seat. Do not rotate the valve. This procedure will show the area of contact (on the valve face). The most desirable area of contact is at the center of the valve face.

After the valve seat inserts have been ground and checked, thoroughly clean the cylinder head before installing the valves.

Install Exhaust Valves and Springs

When installing exhaust valves, check to see that the valves are within the specifications shown in Fig, 11

ó **1972 General Motors Corp.**



Fig. 13. Checking Relative Concentricity of Valve Seat Insert with Relation to Valve Guide



Exhaust

Fig. 14. Exhaust Valve

1. Lubricate the valve stems and slide the valves all the way into the guides.

> **IMPORTANT:** If reconditioned valves are used, install them in the same relative location from which they were removed.

2. Hold the valves in place temporarily with a strip of masking tape. Then, turn the cylinder head right side up on the work bench. Place a board under the head to support the valves and to provide clearance between the cam followers and the bench.

3. Install the valve spring seats.

4. Install the valve guide oil seals, if used, on the valve guide as follows:

   a. Place the plastic seal installation cap on the end of the valve stem. If the cap extends more than 1/16" below the groove on the valve stem, remove the cap and cut off the excess length.

   b. Lubricate the installation cap and start the seal carefully over the valve stem. Push the seal down slowly until it rests on top of the valve guide.

   c. Remove the installation cap.

5. Install the valve springs and valve spring caps.

6. Thread the valve spring compressor J 7455 into one of' the rocker shaft bolt holes in the cylinder head (Fig. 2).

7. Apply pressure to the free end of the tool to compress the valve spring and install the two-piece tapered valve lock. Exercise care to avoid scoring the valve stem with the valve cap Then compressing the spring.

ó **1972 General Motors Corp.**



Fig. 15.- Checking Valve Opening Pressure with Gage WRE-500-60

NOTE: If valve guide oil seals are used, compress the valve spring only enough to permit installation of the valve locks. Compressing the spring too far may result in damage to the oil seal.

8. Release the tool and install the valve locks on the remaining exhaust valves in the same manner.

9. Check the position of the exhaust valve (Fig. 11).

10. With the exhaust valves installed in the cylinder head, use spring checking gage WRE -500-60 and note the gage reading the moment the exhaust valve starts to open (Fig. 15). The minimum pressure required to start to open the exhaust valve must not be less than 25 pounds.

11. Install the injectors, rocker arms, shafts, brackets and any other-parts that were previously removed from the cylinder head.

12. Install the cylinder head. Refer to *Pre-installation Inspection and Install Cylinder Head* in Section 1.2.

13. Perform a complete engine tune-up.

ó **1972 General Motors Corp.**

VALVE ROCKER COVER

The valve rocker cover assembly (Fig. 1) completely encloses the valve and injector rocker arm compartment at the top of the cylinder head. The top of the cylinder head is sealed against oil leakage by a gasket located in the flanged edge of the cover.

An option plate is inserted in a retainer (Fig. 1) attached to one of the covers on a v-type engine.



Fig 1. - Typical Valve Rocker Cover Assembly

Remove and Install Valve Rocker Cover

Clean the cover before removing it from the engine to avoid dust or dirt from entering the valve mechanism. Then remove the valve cover screws and lift the cover straight up from the cylinder head. Use a new gasket when installing the valve rocker cover.

ó **1970 General Motors Corp**

CRANKSHAFT

The crankshaft (Fig. 1) is a one-piece steel forging, heat-treated to ensure strength and durability. All main and connecting rod bearing journal and oil seal surfaces are induction hardened.

Complete static and dynamic balance of the crankshaft has been achieved by counterweights incorporated in the crankshaft.

The crankshaft end thrust is controlled by thrust washers located at the rear main bearing cap of the engine. Full pressure lubrication to all connecting rod and main bearings is provided by drilled passages within the crankshaft and cylinder block.

Six tapped holes are provided in the rear end of the crankshaft for attaching the flywheel.

A crankshaft with splines at the front end is used. The engine uses a splined crankshaft pulley and pulley mounting components.

On the v-type engine the main bearing journals are 3-1/2" in diameter and the connecting rod journals are 2-3/4" in diameter.

Remove Crankshaft

When removal of the crankshaft becomes necessary, first remove the transmission, then proceed as follows:

1. Clean the exterior of the engine.

2. Drain the cooling system.

3. Drain the engine crankcase.

4. Remove all engine to base attaching bolts; then with a chain hoist and sling attached to the lifter brackets at each end of the engine, remove the engine from its base.

5. Remove all of the accessories and assemblies with their attaching parts as necessary to permit the engine to be mounted on an overhaul stand.

© 1972 General Motors Corp.



Fig. 1. - Crankshaft Details and Relative Location of Parts.

6. Mount the engine on an overhaul stand and fasten it securely to the mounting plate.

CAUTION: Be absolutely sure the engine is securely attached to the stand before releasing the lifting sling. Severe injury to personnel and destruction of engine parts will result if the engine breaks away from the stand.

7. Remove the oil pan.
8. Remove the oil pump inlet pipe and screen.
9. Remove the flywheel and flywheel housing.
10. Remove the crankshaft pulley.
11. Remove the front engine support, if used.
12. Remove the engine lower front cover and oil pump assembly.
13. Remove the cylinder head(s).
14. Remove the main bearing cap stabilizers.
15. Remove the connecting rod bearing caps.
16. Remove the main bearing caps.
17. Remove the thrust washers from each side of the rear main bearing.
18. Remove the pistons, connecting rods and liners.
19. Remove the crankshaft, including the timing gear (Fig. 21).
20. Refer to Section 1.7.5 for removal of the crankshaft timing gear and Section 4.1 for the procedure covering removal of the oil pump drive gear.

Inspection

After the crankshaft has been removed, clean and inspect it thoroughly before reinstalling it in the engine.

Remove the plugs and clean out the oil passages thoroughly with a stiff wire brush. Clean the



Fig. 2. - Lifting or Lowering Crankshaft from into Cylinder Block

© 1972 General Motors Corp.



Fig. 3. - Typical Ridging of Crankshaft

crankshaft with fuel oil and dry it with compressed air. Then, reinstall the plugs.

Inspect the keyways for evidence of cracks or wear. Replace the crankshaft, if necessary.

If the crankshaft has been subjected to excessive overheating, the heat treatment will be destroyed and a new crankshaft should be installed.

Used crankshafts will sometimes .show a certain amount of ridging caused by the groove in the upper main bearing shell or lower connecting rod bearing shell (Fig. 3). Ridges exceeding 1.0002" must be removed. If the ridges are not removed, localized high unit pressures on new bearing shells will result during engine operation.

The ridges may be removed by working crocus cloth, wet with fuel oil, around the circumference of the crankshaft journal. If the ridges are greater than .0005", first use 120 grit emery cloth to clean up the ridge, 240 grit emery cloth for finishing, and wet crocus cloth for polishing. Use of a piece of rawhide or other suitable rope wrapped around the emery cloth or crocus cloth and drawn back and forth will minimize the possibility of an out-of-round condition developing (keep the strands of rawhide apart to avoid bind). If rawhide or rope is not used, the crankshaft should be rotated at intervals. If the ridges are greater than .001", the crankshaft may have to be reground.

Carefully inspect the front and rear end of the crankshaft in the area of the oil seal contact surface for evidence of a rough or grooved condition. Any imperfections of the oil seal contact surface will result in oil leakage at this point.

Slight ridges on the crankshaft oil seal contact surfaces may be cleaned up with emery cloth and crocus cloth in the same manner as- detailed for the crankshaft journals. If the crankshaft cannot be cleaned up satisfactorily, the oil seals may be repositioned in the flywheel housing and front cover as outlined in Section 1.3.2.

Check the crankshaft thrust surfaces for excessive wear or grooving. If only slightly worn, the surfaces may be dressed with a stone. Otherwise, it will be necessary to regrind the thrust surfaces.

Check the oil pump drive gear and the crankshaft timing gear for worn or chipped teeth. Replace the gears, if necessary.

Inspect the crankshaft for cracks as outlined under Inspection for Cracks.

Crankshaft Measurements

Support the crankshaft on its front and rear journals on V-blocks or in a lathe and check the alignment at the adjacent intermediate main journals with a dial indicator.

The maximum runout on the intermediate journals must not exceed .002" total indicator reading.

On the 6V crankshaft, when the runout on the adjacent journals is in opposite directions, the sum must not exceed .003" total indicator reading. When the runout on the adjacent journals is in the same direction, the difference must not exceed .003" total indicator reading. When high spots of runout on the adjacent journals are at right angles to each other, the sum must not exceed .004" total indicator reading, or .002" on each journal. If the runout limit is greater than given above, the crankshaft must be replaced.

Measure all of the main and connecting rod bearing journals. Measure the journals at several places on the circumference so that taper, out-of-round and bearing clearances can be determined. If the crankshaft is worn so that the maximum connecting rod journal-to- bearing shell clearance (with new shells) exceeds .0041" (V-type engine), or the main bearing journal-to-bearing shell clearance

© 1972 General Motors Corp.



Fig. 4.- Critical Crankshaft Loading Zones

(with new shells) exceeds .0040" the crankshaft must be reground. Also, if the journal taper or out-of-round is greater than .003", the crankshaft must be reground. Measurements of the crankshaft should be accurate to the nearest .002".

Inspection for Cracks

Carefully check the crankshaft for cracks which start at an oil hole and follow the journal surface at an angle of 45° to the axis. Any crankshaft with such cracks must be rejected. Several methods of determining the presence of minute cracks not visible to the eye are outlined below.



Fig. 6. - Crankshaft Fatigue Cracks

Magnetic Particle Method: The part is magnetized and then covered with a fine magnetic powder or solution. Flaws, such as cracks, form a small local magnet which causes the magnetic particles in the powder or solution to gather there, effectively marking the crack. The crankshaft must be demagnetized after the test.

Fluorescent Magnetic Particle Method:
This method is similar to the magnetic particle method, but is more sensitive since it employs magnetic particles which are fluorescent and glow under "black. light". Very fine cracks that may be missed under the first method, especially on discolored or dark surfaces, will be disclosed under the "black light".

Fluorescent Penetrant Method: This is a method which may be used on *non-magnetic* materials such as stainless steel, aluminum and plastics. A highly fluorescent liquid penetrant is applied to the part. Then, the excess penetrant is wiped off and the part is dried. A developing powder is then applied which helps to draw the penetrant out of the flaws by capillary action. Inspection is carried out under black light".

A majority of indications revealed by the above inspection methods are normal and harmless and only

1972 General Motors Corp.

in a small percentage of cases is reliability of the part impaired when indications are found. Since inspection reveals the harmless indications with the same intensity as the harmful ones, detection of the indications is but a first step in the procedure. Interpretation of the indications is the most important step.

All Detroit Diesel crankshafts are magnetic particle inspected after manufacture to ensure against any shafts with harmful indications getting into the original equipment or factory parts stock.

Crankshaft failures are rare and when one cracks or breaks completely, it is very important to make a thorough inspection for contributory factors. Unless abnormal conditions are discovered and corrected, there will be a repetition of the failure.

There are two types of loads imposed on a crankshaft in service -- a *bending* force and a *twisting* force. The design of the shaft is such that these forces produce practically no stress over most of the surface. Certain small areas, designated as critical areas, however, sustain most of the load (Fig.-4).

Bending fatigue failures result from bending of the crankshaft which takes place once per revolution.

The crankshaft is supported between each of the cylinders by a main bearing, and the load imposed by the gas pressure on top of the piston is divided between the adjacent bearings. An abnormal bending stress in the crankshaft, particularly in the crank fillet, may be a result of misalignment of the main bearing bores, improperly fitted bearings, bearing failures, a loose or broken bearing cap, or unbalanced pulleys. Also, drive belts which are too tight may impose a bending load upon the crankshaft.

Failures resulting from bending start at the pin fillet and progress throughout the crank cheek, sometimes extending into the journal fillet. If main bearings are replaced due to one or more badly damaged bearings, a careful inspection must be made to determine if any cracks have started in the crankshaft. These cracks are most likely to occur on either side of the damaged bearing.

Torsional fatigue failures result from torsional vibration which takes place at high frequency.

A combination of abnormal speed and load conditions may cause the twisting forces to set up a vibration, referred to as torsional vibration, which imposes high stresses at the locations shown in Fig. 4.

Torsional stresses may produce a fracture in either the connecting rod journal or the crank cheek. Connecting



Fig. 6. Dimensions of Crankshaft Journals - V-Type Engine

rod journal failures are usually at the fillet at 45° to the axis of the shaft.

A loose, damaged or defective vibration damper, a loose flywheel or the introduction of improper or additional pulleys or couplings are usual causes of this type of failure. Also, overspeeding of the engine, or resetting the governor at a different speed than intended for the engine may be contributory factors.

As previously mentioned, most of the indications found during inspection of the crankshaft are harmless. The two types of indications to look for are circumferential fillet cracks at the critical areas, and 45° cracks (45° with the axis of the shaft) starting from either the critical fillet locations or the connecting rod



Fig. 7. Crankshaft Journal Fillets

ó **1972 General Motors Corp.**

journal holes as shown in Fig.5 Replace the crankshaft when cracks of this nature are found.

Crankshaft Grinding

In addition to the standard size main and connecting rod bearings, .002", .010, .020" and .030" undersize bearings are available.

> **NOTE:** The .002" undersize bearings are used only to compensate for slight wear on crankshafts on which regrinding is unnecessary.

If the crankshaft is to be reground, proceed as follows:

1. Compare the crankshaft journal measurements taken during inspection with the dimensions in Table 1 and Fig. 6 and determine the size to which the journals are to be reground.

Measurement of the crankshaft journals, and comparison of these measurements to the diameters required for various undersize bearings shown in Fig. 6 and Table 1, will determine the size to which the crankshaft journals must be reground.

2. If one or more main or connecting rod journals require grinding, then grind all of the main journals or all of the connecting rod journals to the same required size.

3. All journal fillets must have a .100" to .130" radius between the crank cheek and the journal, and must not have any sharp grind marks (Fig. 7). The fillet must blend smoothly into the journal and the crank cheek, and must be free of scratches. The radius may be checked with a fillet gage.

Bearing Size	Conn. Rod Journal Dia.	Main Bearing Journal Dia.
V-Engines		
Standard	2.750"	3.500"
.002" Undersize	2.750"	3.500"
.010" Undersize	2.740"	3.490"
.020" Undersize	2.730"	3.480"
.030" Undersize	2.720"	3.470"

TABLE 1

4. Care must be taken to avoid localized heating which often produces grinding cracks. Cool the crankshaft while grinding, using coolant generously. Do not crowd the grinding wheel into the work.

5. Polish the ground surfaces to an 8-12 R.MS. finish. The reground journals will be subject to excessive wear unless polished smooth.

6. If the thrust surfaces of the crankshaft are worn or grooved excessively, they must be reground and polished. Care must be taken to leave a .100" to .130" radius on the 6V engine, between each thrust surface and the bearing journal (Fig. 7).

7. Stone the edge of all oil holes in the journal surfaces smooth to provide a radius of approximately 3/32".

8. After grinding has been completed, inspect the crankshaft by the magnetic particle method to determine whether cracks have originated due to the grinding operation.

9. Demagnetize the crankshaft.

10. Remove the plugs and clean the crankshaft and oil passages thoroughly with fuel oil. Dry the shaft with compressed air and reinstall the plugs.

Install Crankshaft

If a new crankshaft is to be installed, steam clean it to remove the rust preventive, blow out the oil passages with compressed air and install the plugs. Then, install the crankshaft as follows:

> **NOTE:** When a new or reground crankshaft is

Nominal Size	Thrust Washer Thickness	
	Min.	Max.
Standard	.1190"	.1220"
.005" Oversize	.1255"	.1270"
.010" Oversize	.1300"	.1320"

TABLE 2

© 1972 General Motors Corp.



Fig. 8. Standard Dimensions at Rear Main Bearing Thrust Washers and V-Type Engines

installed, ALL new main and connecting rod (upper and lower) bearing shells and new thrust washers must also be installed.

1. Assemble the crankshaft timing gear (Section 1.7.5) and the oil pump drive gear (Section 4.1) on the crankshaft.

2. Install the upper *grooved* bearing shells in the block. If the old bearing shells are to be used again, install them in the same locations from which they were removed.

3. Apply clean engine oil to all crankshaft journals and install the crankshaft in place so that the timing marks on the crankshaft timing gear and the idler gear match). Refer to Section 1.7.1 for the correct method of timing the gear train.

4. Install the upper halves of the crankshaft thrust washers on each side of the rear main bearing support and the doweled lower halves on each side of the rear main bearing cap. *The grooved side of the thrust washers must face toward the crankshaft thrust surfaces.*

NOTE: If the crankshaft thrust surfaces were reground, it may be necessary to install oversize thrust washers on one or both sides of the rear main journal. Refer to Fig. 8 and Table 2.



Fig. 1. - Checking Crankshaft End Play

5. Install the lower bearing shells (no oil grooves) in the bearing caps. If the old bearing shells are to be used again, install them in the same bearing caps from which they were removed. Lubricate the bolt threads and bolt head contact surfaces with a small quantity of International Compound No. 2, or equivalent. Install the bearing caps and draw the bolts up snug. Then, rap the caps sharply with a soft hammer to seat them properly.

6. Draw the bearing cap bolts uniformly tight, starting with the center cap and working alternately toward both ends of the block, to 120-130 lb-ft torque. On a V-type engine, tighten the stabilizer to cylinder block bolts to 46-50 lb-ft torque. Rotate the crankshaft to make sure that it rotates freely.

> **NOTE**: If the bearings have been installed properly, the crankshaft will turn freely with all of the main bearing cap bolts drawn to the specified torque.

7. Check the crankshaft end play by moving the crankshaft toward the gage (Fig. 9') with a pry bar. Keep a constant pressure on the pry bar and set the dial indicator to zero. Then, remove and insert the pry bar on the other side of the bearing cap. Force the crankshaft in the opposite direction and note the amount of end play on the dial. The end play should be .004" to .011" with new parts or a maximum of .018" with used parts. Insufficient end play can be the

© 1972 General Motors Corp.

result of a misaligned rear main bearing or a burr or dirt on the inner face of one or more of the thrust washers.

8. Install the cylinder liner, piston and connecting rod assemblies (Section 1.6.3).

9. Install the cylinder head(s) (refer to Section 12).

10. Install the flywheel housing (Section 1.5), then install the flywheel.

11. Install the crankshaft lower engine front cover and the lubricating oil pump assembly

(Section 1.3.5).

12. Install the engine front support, if used.

13. Install the crankshaft pulley (Section 1.3.7).

14. Install the oil pump inlet pine and screen (Section 4.1).

15. Affix a new gasket to the oil pan flange and install the oil pan.

16. Use a chain hoist and sling attached to the lifting bracket at each end of the engine and remove the engine from the overhaul stand.

17. Install all of the accessories that were removed.

18. After the engine has been completely reassembled, refer to the Lubricating Oil Specifications in Section 13.3 and refill the crankcase to the proper level on the dipstick.

19. Close all of the drains and fill the cooling system.

20. After replacing the main or connecting rod bearings or installing a new crankshaft, operate the engine as outlined in the run-in schedule, Section 13.2.1.

1972 General Motors Corp.

CRANKSHAFT OIL SEALS

An oil seal is used at each end of the crankshaft to prevent the lubricating oil from escaping from the crankcase. The seals also provide protection against the entrance of dirt, dust, mud or oil from the external portion of the engine (Figs. 1 and 2).

The front oil seal is pressed into the lower front cover.

A single-lip oil seal is used at the rear end of the crankshaft. The rear oil seal is pressed into the flywheel housing.

Remove Crankshaft Oil Seals

1. Remove the engine front cover, or the flywheel housing and remove the oil seals as follows:

2. Support the forward face of the front cover, on two wood blocks next to the oil seal bore. Then press or drive the oil seal out of the front cover.
Discard the oil seal.

3. Support the forward face of the flywheel housing on two wood blocks next to the oil seal bore. Then press or drive the oil seal out of the housing. Discard the oil seal.

4. Clean the oil seal bore in the front cover or flywheel housing thoroughly before installing a new oil seal.

When necessary, the crankshaft oil seals may be removed without removing the front cover or flywheel housing. This may be done by drilling diametrically opposite holes in the seal casing and threading metal screws, backed by flat washers, into the casing. Then the seal may be removed by prying against the washers with pry bars.



Fig. 1. Crankshaft Front Oil Seal

Inspection

Oil leaks indicate worn or damaged oil seals. Oil seals may become worn or damaged due to improper installation, excessive main bearing clearances, excessive flywheel housing bore runout, or grooved sealing surfaces on the crankshaft. To prevent a repetition of any oil seal leaks, these conditions must be checked and corrected.

Inspect the front and rear end of the crankshaft and the crankshaft front end for wear due to the rubbing action of the oil seal or dirt build-up.



Fig. 2. Crankshaft Rear Oil Seal

© 1972 General Motors Corp

Inspect the rear end of the crankshaft at the flywheel connection for signs of fretting.

The rear seal area of the crankshaft must be clean and smooth to prevent damaging the seal lip when a new oil seal is installed. Slight ridges may be removed from the crankshaft as outlined under Inspection in Section 1.3.

If the crankshaft cannot be cleaned up satisfactorily, the oil seal may be pressed into the flywheel housing or the front cover I/8" from its original position.

If excessive wear or grooving is present, install an oil seal sleeve (Figs. 3, 4 which provides a replaceable wear surface for the lip-type oil seal. An oversize seal will be required with use of the sleeve.

Install the rear oil seal sleeve (Figs. 3 and 4) as follows:

1. Stone the high spots from the oil seal contact surface of the crankshaft.

2. Coat the area of the shaft where the sleeve will be positioned with shellac or an equivalent sealant.



Fig. 3. Use of Rear Oil Seal Sleeve on. Grooved Crankshaft

3. Drive the sleeve squarely on the shaft with crankshaft rear oil seal sleeve installer J 21277.

4. Wipe off any excess sealant.

Install the front oil seal sleeve (Fig.4) as follows:

1. Stone the high spots from the oil seal contact surface of the crankshaft.

2. Coat the area of the shaft where the sleeve will be positioned with shellac or an equivalent sealant.



Fig. 4. Use of Front Oil Seal Sleeve on Grooved Crankshaft.

© 1972 General Motors Corp.

3. Position the sleeve on the crankshaft with the radius on the sleeve facing away from the engine.

4. Press the sleeve squarely on-the crankshaft with front oil seal sleeve installer J 22524 and the crankshaft pulley retaining bolt.

5. Wipe off any excess sealant.

To remove a worn sleeve, peen the sleeve until it stretches sufficiently so that it can be slipped off of the shaft.

Oil Seals

Current oil seals are made of an oil resistant synthetic rubber which is pre-lubricated with a special lubricant. Do not remove this lubricant. Keep the sealing lip clean and free from scratches. In addition, a plastic coating which acts as a sealant has been applied to the outer surface of the casing. Do not remove this coating.

Install Crankshaft Front Oil Seal

1. If the outside diameter of the seal is not pre-coated with sealant, apply a non-hardening sealant to the periphery of the metal casing.

2. Apply grease or vegetable shortening to the sealing lip; then, position the seal in the cover with the lip of the seal pointing toward the inner face of the cover.



Fig. 5. Installing Oil Seal in Flywheel Housing

3. Place the cover or in an arbor press (inner face down).

4. Use installer J 9783 to press the oil seal into the cover until the seal is flush with the outside face of the cover.

5. Remove all excess sealant.

6. Install the engine front cover.

Install Crankshaft Rear Oil Seal

1. Support the inner face of the flywheel housing in an arbor press.

2. If the seal is not pre-coated, apply a non-hardening sealant to the periphery of the metal casing.

3. If not previously lubricated, apply grease or vegetable shortening to the lip of the oil seal; then, position the seal in the flywheel housing bore with the lip of the seal pointing toward the inner face of the housing.

4. Use installer J 9479 to press the oil seal into the flywheel housing until the seal is flush with the outside face of the housing (Fig. 5).

If the flywheel housing was not removed from the engine, place oil seal expander J 9769 (standard size seal) or J 21278 (oversize seal) up against the rear end of the crankshaft; then, with the lip of the oil seal pointed toward the flywheel housing, slide the seal over the expander and on the crankshaft. Next, thread the guide studs J 9479-2 into the crankshaft. Now drive the seal into the flywheel housing with installer J 9479-1 until the seal is flush with the face of the housing

5. all excess sealant from the housing and the seal.

(c) 1972 General Motors Corp.

CAUTION: : If the oil seal is of the type which incorporates a brass retainer in the inner diameter of the seal, be sure the retainer is in place in the seal before installing the flywheel housing on the engine. If the retainer is left out, it will cause excessive oil leakage.

7. Install the flywheel housing as outlined in Section 1.5..

© 1972 General Motors Corp.

CRANKSHAFT MAIN BEARINGS

The main bearing shells are precision made and are replaceable without machining. They consist of an upper shell seated in each cylinder block main bearing support and a lower shell seated in each main bearing cap. The bearing shells are prevented from endwise or radial movement by a tang at the parting line at one end of each shell.

The bearing caps are numbered 1, 2, 3, etc., indicating their respective positions and, when removed, must always be reinstalled in their original position.

The upper main bearing spell has six 1/4" holes and one 7/16" hole (Fig. 2) The additional holes in the upper main bearing shell improves piston cooling by allowing more oil, under pressure, to flow to the drilled passage in the crankshaft.

The lower main bearing shells have no oil grooves; therefore, the upper and lower bearing shells are not interchangeable.

The tangs on the lower bearing shells are off-center while the tangs on the upper bearing shells are



Fig. 1. Main Bearing Shells, Bearing Caps and Crankshaft Thrust Washers V-Type Engines

© 1972 General Motors Corp.



Fig. 2. Shell Upper Main Bearing

centered to aid in the correct installation of the main bearing shells.

Crankshaft thrust washers (Fig. 1.) absorb the crankshaft thrust. The lower halves of the two-piece washers are doweled to the bearing cap, the upper halves are not doweled.

Main bearing trouble is ordinarily indicated by low or no oil pressure and, in extreme cases, may cause the flywheel to wobble. All of the main bearing load is carried on the lower bearings; therefore, wear will occur on the lower shells first. The condition of the lower main bearing shells may be observed by removing the main bearing caps.

If main bearing trouble is suspected, remove the oil pan, then remove the main bearing caps, one at a time, as outlined below and examine the bearing shells.

Remove Main Bearing Shells (Crankshaft in Place)

All crankshaft main bearing journals, except the rear, are drilled for an oil passage. The procedure, therefore, for removing the shells with the crankshaft in place is somewhat different on the drilled journals than on the one at the rear which is not drilled. Remove the main bearing shells as follows:

1. Drain and remove the oil pan to expose the main bearing caps.



Fig. 3. Removing Main Bearing Upper Shell (Except Rear Main) Crankshaft in Place

Fig. 4. Removing Rear Main Bearing Upper Shell Crankshaft in Place

© 1972 General Motors Corp.

2. Remove the oil pump intake pipe and screen assembly.

3. Remove one main bearing cap at a time and inspect the bearing shells as outlined under Inspection. Complete replacement of the bearing shells and reinstallation of the bearing cap before removing another bearing cap.

a. To remove all except the rear main bearing shell, insert a 1/4" x 3/4" bolt, with a 1/2" diameter and 1/16" thick head (made from a standard bolt), into the crankshaft journal oil hole, then revolve the shaft to the right (clockwise) and roll the bearing shell out of position. The head of the bolt should not extend beyond the outside diameter of the shell (Fig.3).

b. The lower halves of the crankshaft thrust washers will be removed along with the rear main bearing cap. Remove the upper halves of the washers by pushing on the ends of the washers with a small rod, thus forcing them around and out of the main bearing support.

c. Remove the rear main bearing upper shell by driving on the edge of t e bearing shell with a small curved rod (Fig. 4) and revolving the crankshaft at the same time, thus rolling the shell from its position.

Inspection

Bearing failures may result from deterioration (acid formation) or contamination of oil or loss of oil which results in scratching, etching, scoring or excessive wear. An analysis of the lubricating oil may be required to determine if corrosive acid and 'sulphur are present which cause acid etching, flaking and pitting. Bearing seizure may be due to low oil or no oil.

Check the oil filter elements and replace them if necessary. Also, check the oil by-pass valve to make sure it is operating freely.

After removal, clean the bearings and inspect them for scoring, pitting, flaking, etching and dirt grooving. If any of these defects are present, the bearings must be discarded. The lower bearing shells, which carry the load, will normally show signs of distress before the upper shells do.

Inspect the backs of the bearing shells for bright spots which indicate they have been moving in the caps or the cylinder block. If such spots are present, discard the bearing shells.

Measure the thickness of the bearing shells at point "C", 90° from the parting line, as shown in Fig; © 1972 General Motors Corp. Tool J 4757, placed between the shell and a micrometer as illustrated in Fig.7. will give an accurate measurement. The bearing shell thickness will be the total thickness of the steel ball and the bearing shell, less the diameter of the ball. This is the only practical method for measuring the shell thickness, unless a special micrometer is available for this purpose.

Minimum thickness of a worn standard main bearing shell is .123" and, if any of the shells are thinner than this dimension, all of the shells must be replaced.

Check the clearance between the main bearings and the crankshaft journals. This clearance (Section 1.0) may be determined with the crankshaft in place by means of a soft plastic measuring strip which is squeezed between the journal and the bearing, or, with the crankshaft removed, by measuring the outside diameter of the crankshaft main bearing journals and the inside diameter of the main bearing shells when installed in place with the proper torque on the main bearing cap bolts. If the clearance between any crankshaft main bearing journal and its bearing shells exceed .006", all of the bearing shells must be discarded and replaced with new shells.

The two bearing shells do not form a true circle when not installed. Measure the inside diameter with the bearing shells installed in the cylinder block and the caps bolted in place (crankshaft removed). The two halves of the shells have a squeeze fit in the main bearing bore, and must be tight when the cap is drawn down. This crush assures a tight, uniform contact between the bearing shell and seat. Bearing shells that do not have sufficient crush will not have uniform seat contact, as shown by shiny spots on the bearing shell backs, and must be replaced.

Before installing new replacement bearings, it is very important to thoroughly inspect the crankshaft journals. Very often, after prolonged engine operation, a ridge is formed on the crankshaft journals in line with the journal oil holes. If this ridge is not removed before new bearings are installed, then, during engine operation, localized high unit pressures in the center area of the bearing shell will cause pitting of the bearing surface. Also, damaged bearings may cause bending fatigue and resultant cracks in the crankshaft. See Section 1.3 under Crankshaft Inspection for removal of the ridge and inspection of the crankshaft.

The crankshaft journals may be inspected for scoring, over-heating or wear without removing the crankshaft. However, to measure the diameter of the journals, the crankshaft must be removed. Refer to Crankshaft Inspection in Section 1.3.

Do not replace one main bearing shell alone. If one bearing shell requires replacement, install both new

© 1972 General Motors Corp.



Fig. 5. Comparison of Main Bearing Shells

upper and lower shells. Also, if a new or reground crankshaft is used, install all new bearing shells.

Bearing shells are available in .010", .020" and .030" undersize for service with crankshafts which have been ground to a smaller journal diameter.

Bearings which are .002" undersize are available to compensate for slight journal wear in those cases where it is unnecessary to regrind the crankshaft.

> **NOTE**: Bearing shells are NOT reworkable from one undersize to another under any circumstances.

Table 1 gives the minimum bearing shell thickness for new standard and various undersize bearings, and gives the crankshaft main bearing journal diameters corresponding to each bearing size.

Excessive crankshaft end play due to an improper flywheel or improper clutch adjustment can contribute to excessive wear or scoring of the crankshaft thrust washers.

Measure the crankshaft end play as outlined under Install Crankshaft in Section 1.3. With new parts, the Page 4 end play must be within .004" to .011". The maximum allowable end play with used parts is .018". Replace the thrust washers if necessary.

Inspect the crankshaft thrust surfaces and, if necessary, recondition the thrust surfaces as outlined under Crankshaft Grinding in Section 1.3. If, after "dressing up" or grinding the crankshaft, new standard size thrust washers do not hold the end play within the specified limits, then oversize thrust washers must be used. If one of the thrust surfaces of the crankshaft is worn or ground considerably more than the other, it may be necessary to install thrust washers of different thickness on either side of the main bearing to properly center the crankshaft main journal on the bearing. The oversize thrust washers are listed in Table 2.

Install Main Bearing Shells (Crankshaft in Place)

Make sure all of the parts are clean. Apply clean engine oil to each crankshaft journal and install the main bearing shells by reversing the sequence of operations given for removal.

© 1972 General Motors Corp.



Fig. 6 - Inside Diameter of Main Bearing Shell at Parting Line and 90 Degrees to Parting Line



Fig. 7. Measuring Thickness of Main Bearing Shell

Nominal Size of Bearing	Minimum New Bearing Shell Thickness	Crankshaft Main Bearing Journal Dia.
V-Type Engines		
Standard	.1240"	3.499"-3.500"
.002" Undersize	.1250"	3.497"-3.498"
.010" Undersize	.1290"	*3.489"-3.490"
.020" Undersize	.1340"	*3.479"-3.480"
.030" Undersize	.1390"	*3.469"-3.470"

Table 1

The upper and lower main bearing shells are not alike; the upper shell is grooved and drilled for lubrication -the lower shell is not. Be sure to install the grooved and drilled shells in the cylinder block and the plain shells in the bearing caps, otherwise the oil flow to the upper end of the connecting rods will be blocked off. Used bearing shells must be reinstalled on the same journal from which they were removed.

1. When installing the upper main bearing shells with the crankshaft in place, start the plain end of the shell around the crankshaft journal so that, when the shell is in place, the tang will fit into the groove in the bearing support.

2. Assemble the crankshaft thrust washers before installing the main bearing cap. Clean both halves of the thrust washer carefully and remove any burrs from the washer seats -the slightest particle of dirt may decrease the clearance between the washers and the crankshaft beyond limits. Slide the upper halves of he thrust washers into place in their grooves (Fig.8), then assemble the lower halves over the dowel pins in the bearing cap.

Nominal Size	Washer Thickness
Standard	.1190"/.1220"
.005" Oversize	.1255"/.1270"
.010" Oversize	.1300"/.1320"

TABLE 2

NOTE: The main bearing caps are bored in position and marked 1, 2,4, etc. They must be replaced in their original positions with the marked side of the caps facing the same side of

© 1972 General Motors Corp.



Fig. 8 · Crankshaft Thrust Washer Mounting

the cylinder block that carries the engine serial number.

3. With the lower bearing shells installed in the bearing caps, install the caps and stabilizers on a V-type engine, in their original position. Lubricate the bolt threads and the bolt head contact areas with a small quantity of International Compound No. 2, or equivalent, and install them in the bearing caps. Draw the bolts up snug. Then, rap the caps sharply with a soft hammer to seat them properly and draw the bearing cap bolts uniformly tight, starting with the center cap and working alternately towards both ends of the block, to 120-130 lb-ft torque. On a V-type engine, tighten the stabilizer to cylinder block 7/16"-14 bolts to 46-50 lb ft torque.

> **NOTE**: If the bearings have been installed properly, the crankshaft will turn freely with all of the main bearing cap bolts drawn to the specified torque.

4. Check the crankshaft end play as outlined under Install Crankshaft in Section 1.3.

5. Install the lubricating oil pump intake pipe assembly.

6. Use a new gasket and install the oil pan.

7. Fill the crankcase to the proper level (indicated on the dipstick) with heavy-duty lubricating oil of the viscosity recommended (see Lubricating Oil Specifications in Section 13.3).

8. After installing new bearing shells, operate the engine on a run-in schedule as outlined in Section 13.2.1.

© 1972 General Motors Corp.

ENGINE FRONT COVER (Lower)

In-Line and 6V Engines

The engine lower front cover is mounted against the cylinder block at the lower front end of the engine (Figs. 1.). It serves as a housing for the crankshaft front oil seal, the lubricating oil pump, the oil pressure regulator valve and the oil cooler by-pass valve. The clean-out openings in the periphery of the cover incorporate tapped holes and 1/2"-14 threaded plugs.

Current 6V engines include a regulator valve with a non-replaceable stop swaged in the valve. When it becomes necessary to replace the regulator valve or plug in an early engine, both must be replaced together. Also, when the valve and plug in either side of the engine lower front cover needs to be replaced, the valve and plug in both sides of the cover must be replaced.

Remove Engine Front Cover

1. Remove the crankshaft pulley as outlined in Section 1.3.7.

2. Remove the oil pan drain plug and drain the lubricating oil. Install and tighten the drain plug.

3. Remove the oil pan and gasket.

4. Remove the two bolts and lock washers that secure the lubricating oil pump inlet tube elbow to the engine front cover.

5. Remove the bolts and lock washers that secure the engine front cover to the cylinder block.

6. Strike the cover with a soft hammer to free it from the dowels. Pull the cover straight off the end of the crankshaft.

7. Remove the cover gasket.

8. Inspect the oil seal and lubricating oil pump as outlined in Sections 1.3.2 and 4.1. Also, check the oil



Fig. 7 - Engine Front Cover Mounting (Lower) -- 6V-Engine.

© 1972 General Motors Corp.

reassure regulator valve and oil cooler by-pass valve as outlined in Sections 4.1.1 and 4.4.

Install Engine Front Cover

1. Affix a new cover gasket to the cylinder block.

2. Install oil seal expander J 7454 over the front end of the crankshaft.

3. Thread two 3/8"-16 pilot studs approximately 8" long into two diametrically opposite bolt holes in the cylinder block to guide the cover in place

4. Apply a light coat of cup grease to the lip of the oil seal. Slide the engine front cover over the oil seal expander and pilot studs, Push the cover forward until the inner rotor of the oil pump contacts the pump drive gear on the crankshaft. Rotate the crankshaft slightly to align the teeth, then push the cover up against the gasket and block. Do not force the cover.

5. Remove the oil seal expander and pilot studs.

6. Refer to Fig:. 1 and install the 3/8"-16 bolts and lock washers. Tighten the bolts to 30-35 lb-ft torque.

7. Affix new gasket to the elbow on a 6V-engine. Attach the elbow to the front cover with bolts and lock washers. Tighten the bolts to 13-17 lb-ft torque.

8. Affix a new oil pan gasket to the bottom of the cylinder block; then secure the oil pan to the block with bolts and lock washers. Tighten the bolts to 13-17 lb-ft torque.

9. Install the crankshaft pulley as outlined in Section 1.3.7.

10. Refer to Lubricating Oil Specifications in Section 13.3 and refill the crankcase to the proper level on the dipstick.

© 1972 General Motors Corp.

CRANKSHAFT PULLEY

The crankshaft pulley is secured to the front end of the crankshaft by a special washer and a bolt.

Remove Crankshaft Pulley

1. Remove the belts from the crankshaft pulley.

2. Remove the crankshaft pulley retaining bolt and special washer.

3. If a rigid type pulley is being removed install the pulley retaining bolt and puller J 4/94-01 as shown in Fig. 1. Then force the pulley off the crankshaft by turning the puller center screw in.



Fig. 1 · Removing Crankshaft Pulley Using Puller J 4794-01

Install Crankshaft Pulley

1. Lubricate the end of the crankshaft to facilitate pulley installation.

© 1970 General Motors Corp.

2. A splined crankshaft pulley is used. Place a drive flange washer over the splined end of the crankshaft. Align the splines and tap the pulley on the crankshaft with a plastic hammer. Place another drive flange washer on the bolt and thread it into the end of the crankshaft. Tighten the 3/4"16 bolt to 290-300 lb-ft torque.

3. Install and adjust the belts.

© 1970 General Motors Corp.

FLYWHEEL

The flywheel is attached securely to the rear end of the crankshaft with six self-locking bolts. The bolt heads are prevented from "biting" into the flywheel by a scuff plate, which is used between the flywheel and the heads of the bolts. A ring gear is shrunk onto the rim of the flywheel.



Fig. 1. Removing Flywheel with Tool J 6361 01

The rugged construction of the flywheel makes necessity for service very remote. However, the flywheel must be removed for other service operations such as removing and replacing the ring gear.

Remove Flywheel (Transmission Removed)

Remove the flywheel as follows

a. Remove the flywheel attaching bolts and the scuff plate while holding the flywheel in position by hand; then, reinstall one bolt.

CAUTION: When removing or installing the attaching bolts, hold the flywheel firmly against the crankshaft by hand to prevent it from slipping off the end of the crankshaft.

b. Attach flywheel lifting tool J 6361-01 to the flywheel with two 3/8" -16 bolts of suitable length as shown in Fig. 1.

c. Attach a chain hoist to the lifting tool.

d. Remove the remaining flywheel attaching bolt.

e. Move the upper end of the tool back and forth to loosen the flywheel; then, withdraw the flywheel.

Inspection

Check 'the clutch contact face of the flywheel for cracks, scoring or overheating. If the flywheel clutch surface is scored, it may be refaced. However, do not

© 1970 General Motors Corp.

remove more than .020" of metal from the flywheel and maintain all radii when refacing the flywheel.

The flywheel seldom wears to the point of requiring service or replacement. However, the flywheel ring gear may become worn due to normal usage or damage by improper use of the starting motor to the extent that it must be replaced. Examine the teeth on the ring gear. If replacement is necessary, remove the ring gear as outlined below.

Remove Ring Gear from Flywheel

1. Support the flywheel, crankshaft side down, on a solid flat surface or a hardwood block which is slightly smaller than the inside diameter of the ring gear. Before removing the gear, note the chamfer, if any, on the gear teeth so that the new gear may be installed in the same position.

2. Drive the ring gear off of the flywheel with a suitable drift and hammer. Work around the circumference of the ring gear to avoid binding the gear on the flywheel.

Install Ring Gear on Flywheel

1. Support the flywheel, ring gear side up, on a solid flat surface.

2. Rest the ring gear on a flat metal surface and heat the gear uniformly with an acetylene torch, keeping the torch moving around the gear to avoid hot spots.

> **CAUTION**: Do not, under any circumstances, heat the gear over 400°F.; excessive heating may destroy the original heat treatment.
>
> **NOTE**: Heat indicating "crayons", which are placed on the ring gear and melt at a predetermined temperature, may be obtained from most tool vendors. Use of one of these "crayons" will insure against overheating the gear.

3. Use a pair of tongs to place the gear on the flywheel with the chamfer, if any, facing the same direction as on the gear just removed.

4. Tap the gear in place against the shoulder on the flywheel. If the gear cannot be tapped into place readily, remove it and apply additional heat, heeding the caution about overheating.

Install Flywheel

1. Mount the flywheel, using lifting tool J 6361-01 and a chain hoist, in position against the rear end of the crankshaft.

2. a small quantity of International Compound No. 2, or equivalent, to the bolt threads and bolt head contact areas of the flywheel attaching bolts.

3. While holding the flywheel in place by hand, remove the flywheel lifting tool and install the flywheel attaching bolts and scuff plate. Tighten the bolts on to 110-120 lb ft torque.

4. Mount a dial indicator on the flywheel housing and check the runout of the flywheel at the clutch contact face. Maximum allowable runout is .001" total indicator reading per inch of radius (the radius is measured from the center of the flywheel to the outer edge of the clutch contact face of the flywheel).

© 1970 General Motors Corp.

FLYWHEEL HOUSING

The flywheel housing is a one-piece casting mounted against the rear end of the cylinder block. The flywheel housing provides a cover for the gear train and flywheel and also serves as a support for the starting motor and transmission.

The crankshaft rear oil seal, which is pressed into the housing, may be removed or installed without removing the housing (Section 1.3.2).

Remove Flywheel Housing

1. Remove the engine from its base as outlined in Section 1.1.

2. Remove the starter from the flywheel housing or the

3. Remove the flywheel.

4. Remove the oil pan.

5. Remove the fuel pump.



Fig. 1. Installing Flywheel Housing



Fig. 2 Location of Shim

6. Remove the blower drive cover the blower drive shaft retainer ring, and the blower drive shaft;

7. Remove the governor and blower drive support.

8. Remove all of the bolts from the flywheel housing.

> **NOTE:** When removing the flywheel housing bolts, note the location of the various size bolts, lock washers, flat washers and copper washers so they may be reinstalled in their proper location.

9. To guide the flywheel housing until the oil seal clears the end of the crankshaft, thread two pilot studs J 7540 into the cylinder block (Fig. 1).

10. Thread eyebolts into the tapped holes in the pads (if provided) on the top or sides of the flywheel housing, and attach a chain hoist with a suitable sling to the eyebolts. Then, strike the front face of the housing alternately on each side of the engine with a soft hammer to loosen and work it off the dowel pins.

11. Remove all traces of the old gaskets from the cylinder block rear end plate and the flywheel housing.

Inspection

Clean and inspect the flywheel housing for cracks or any other damage. Replace the housing if it is damaged.

Inspect the crankshaft rear oil seal as outlined in Section 1.3.2.

© 1970 General Motors Corp.

Install Flywheel Housing

1. Lubricate the gear train teeth with clean engine oil.

2. Affix a new flywheel housing gasket to the rear face of the cylinder block rear end plate engines employ two gaskets (one large and one small). Affix the small (7/8" dia.} gasket near the top of the end plate.

3. If the flywheel housing has an integral cast hub, install a flywheel housing-to-end plate shim (.015" thick). Use grease to affix the shim to the cylinder block rear end plate (Fig. 2).

4. Coat the lip of the crankshaft oil seal lightly with grease or vegetable shortening. Do not scratch or nick the sealing edge of the oil seal.

5. To pilot the oil seal on the crankshaft successfully, use oil seal expander J 9769 (standard size seal) or J 21278 (oversize seal) on the end of the crankshaft. Also thread two pilot studs

J 7540 into the cylinder block to guide the housing in place (Fig.1).

6. With the housing suitably supported, position it over the crankshaft and up against the cylinder block rear end plate and gasket(s).

7. Install all of the flywheel housing bolts, lock washers, flat washers and copper washers in their proper location -finger tight only.

8. Start at No. 4 on a right-hand rotation engine and draw the bolts up snug in the sequence shown in Fig. 3.



Fig. 3. Flywheel Housing Bolt Tightening Sequence (Operation 1)--6V (Engine

© 1970 General Motors Corp.

9. Refer to Fig.4 -for the final bolt tightening sequence then, start at No. 1 and tighten the bolts to the specified torque. Tighten the 5/16"-18 bolts (numbers 13 and 14) to 19-23 lb-ft torque and the 3/8" -16 bolts (numbers 9 through 12) to 40-45 lb-ft torque. Tighten the remaining 3/8" -16 and 3/8" -24 bolts to 25-30 lb-ft torque.

10. Install the blower and governor drive support assembly as outlined in Section 2.7.1.1.

11. Check the flywheel housing concentricity and bolting flange face with tool J 9737 as follows:

a. Refer to Fig. {and thread the base post J 9737-3 tightly into one of the tapped holes in the flywheel. Then, assemble the dial indicators on the base post with the attaching parts provided in the tool set.



Fig. 4. Flywheel Housing Bolt Tightening Sequence (Operation 2).6V Engine

© 1970 General Motors Corp.

b. Position the dial indicators straight and square with the flywheel housing and make sure each indicator has adequate travel in each direction.



Fig. 5 - Checking Flywheel Housing Concentricity with Tool J 9737

c. Tap the front end of the crankshaft with a soft hammer or pry it with a pry bar to ensure end play is in one direction only.

d. Adjust each dial indicator to read zero at the twelve o'clock position. Then, rotate the crankshaft one full revolution, taking readings at 45° intervals (8 readings each on the flywheel housing bore and bolting flange face). Stop and remove the wrench or cranking bar before recording each reading to ensure accuracy. The maximum total indicator reading must not exceed .013" for either the bore or face.

e. If the run-out exceeds the maximum limits, remove the flywheel housing and check for dirt or foreign material (such as old gasket material) between the flywheel housing and the end plate and between the end plate and the cylinder block.

f. Reinstall the flywheel housing and tighten the attaching bolts in the proper sequence and to the specified torque. Then, recheck the run-out. If necessary, replace the flywheel housing.

© 1970 General Motors Corp.

12. Install the fuel pump,

13. Install the flywheel.

14. Use a new gasket and install the oil pan.

15. Remove the engine from the overhaul stand and install all accessories previously removed.

16. Install the transmission.

17. Install the engine in the unit.

18. Fill the crankcase with lubricating oil.

19. Refill the cooling system.

© 1970 General Motors Corp.

PISTON AND PISTON RINGS

The trunk type malleable iron piston (Fig. 1) is plated with a protective coating of tin which permits close fitting, reduces scuffing and prolongs piston life. The top of the piston forms the combustion chamber bowl and is designed to compress the air into close proximity to the fuel spray.

The piston is cooled by a spray of lubricating oil directed at the underside of the piston head from a nozzle in the top of the connecting rod, by fresh air from the blower to the top of the piston and indirectly by the water jacket around the cylinder.

Each piston is balanced to close limits by machining at a balancing rib, provided on the inside at the bottom of the piston skirt.

Two bushings, with helical grooved oil passages, are pressed into the piston to provide a bearing for the hardened, floating piston pin. After the piston pin has been installed, the hole in the piston at each end of the pin is sealed with a steel retainer. Thus, lubricating oil returning from the underside of the piston head and working through the grooves in the piston pin bushings is prevented from reaching the cylinder walls.

The piston pin is subject to downward loading only since the piston is at all times under pressures of compression or expansion in the two-stroke cycle.

Consequently, free movement of the piston pin is desirable to secure perfect alignment and uniform wear. The piston pin is therefore assembled with a full floating fit in both the connecting rod and the piston bushings. Rotation of the pin and positive lubrication through the helical bushing grooves reduce wear to a minimum. Moreover, worn clearances can be comparatively large and still be satisfactory.

Each piston is fitted with six piston rings. Four compression rings are placed above the piston pin and two oil control rings are placed below the pin to scrape off the excess lubricating oil thrown onto the cylinder liner by the crankshaft and the lower end of the connecting rod. Two piece oil control rings are used in both the upper and lower positions on the piston, Equally spaced holes are drilled just below each oil control ring land to permit the excess oil that is scraped off the cylinder walls to return to the crankcase.

Inspect Piston Rings

When an engine is hard to start, runs uneven or lacks power, the cause may be worn or sticking compression rings which must be replaced to restore uniform compression pressure in the cylinders.

The compression rings may be inspected through the ports in the cylinder liners after removing the air box covers. If the rings are free and are not worn to the extent that the plating or grooves have disappeared, the compression should be within operating specifications. Refer to Section 15.2 for the procedure for checking the compression pressure.

However, if excessive wear on any part of the piston assembly is indicated by inspection through the cylinder liner ports, the piston and connecting rod must be removed in the following manner:



Fig. 1. - Typical Piston Assembly

© 1972 General Motors Corp.

Fig. 2. - Removing or Installing Piston Ring

Remove Piston and Connecting Rod

1. Drain the lubricating system and remove the oil pan.

2. Remove the cylinder head as outlined in Section 1.2.



Fig. 3. - Cleaning Piston

3. Remove the carbon from the upper inner surface of the cylinder liner.

4. If there is a ridge in the cylinder liner at the top of the piston ring travel, remove the ridge with a ridge cutter.

> NOTE: Move the piston to the bottom of its travel and place a cloth on top of the piston to collect the cuttings.

5. After the ridge is removed, turn the crankshaft until the piston is at the top of its stroke and carefully remove the cloth with the cuttings.

6. Refer to Figs. I and 2 in Section 1.6.1, and remove the bearing cap and the lower bearing shell from the lower end of the connecting rod; then push the piston and rod assembly out through the top of the cylinder block. The piston and rod cannot be removed from the bottom of the block.

7. Reassemble the bearing cap and the bearing shell to the connecting rod.

Disassemble Piston and Connecting Rod

1. Secure the connecting rod in a vise equipped with soft jaws and remove the piston rings with tool J 8128 as shown in Fig. 2.

2. Punch a hole through the center of one of the piston pin retainers with a narrow chisel or punch and pry the retainer from the piston, being careful not to damage the piston or bushings.

3. Withdraw the piston pin from the piston, thus freeing the connecting rod.

4. The other piston pin retainer may be driven out from the inside, using a brass rod or other suitable tool.

Clean Piston

Clean the piston with fuel oil and dry it with compressed air. If fuel oil will not remove the carbon deposits, use a chemical solvent that will not attack the piston pin bushings or the tin coating on the piston (Fig. 3).

The upper part of the piston, including the ring lands and grooves, is not coated with tin and may be wirebrushed to remove any hard carbon. However, use care to avoid damage to the tin, coating on the piston skirt.

Clean the ring grooves with a suitable tool or a piece of an old piston ring that has been ground to a bevel edge.

© 1972 General Motors Corp.

Clean the inside surfaces of the piston and the oil return holes in the piston skirt. Exercise care to avoid enlarging the holes while cleaning them.

Inspection

The presence of the tin coating on the piston and the original grooves in the piston rings indicates very little wear.

An excessively worn or scored piston, rings or cylinder liner may be the result of abnormal maintenance or operating conditions which should be corrected to avoid recurrence of the failure. Proper maintenance of the lubricating oil filters and air cleaners will reduce to a minimum the amount of abrasive dust and foreign material introduced into the cylinders and will, in turn, reduce the rate of wear. Extended periods of operation at idle speed or the use of improper lubricating oil or fuel should be avoided, otherwise heavy carbon formation and sticking rings will result. Always maintain the lubricating oil and engine coolant at the specified levels to avoid overheating the engine.

Examine the piston for scoring, overheating, cracks and damaged ring grooves. Replace the piston, if necessary. A piston with light score marks may be cleaned up and reused. Refer to Fig. 4 for a comparison of pistons.

Check for cracks across the struts in the piston as outlined in Section 1.3 under Crankshaft Inspection.

Other factors that contribute to piston failure are oil leaks into the air box, oil pull-over from the air cleaner, dribbling injectors, combustion blow-by and dilution of the lubricating oil.

Inspect and measure the piston pin and piston pin bushings. The piston pin-to-bushing clearance with new parts is .0025" to .0034". A maximum clearance of .010" is allowable with worn parts. The piston pin bushings in the connecting rod are covered in Section 1.6.1.

Remove Bushings from Piston

1. Place the piston in the holding fixture J 1513-1 so that the bushing bores are in alignment with the hole in the fixture base.

2. Drive each bushing from the piston with the bushing remover J 49724 and handle J 1513-2 in the manner illustrated in Fig. 5.

Install Bushings in Piston

1. Place the spacer J 7587-1 in the counterbore in the fixture J 1513-1 (small end up).


THIS PISTON SUITABLE FOR INSTALLATION AS IS
SLIGHTLY SCORED, USE ONLY AFTER REMOVING SCORE MARKS BY POLISHING WITH CROCUS CLOTH OR HARD INDIA STONE
BADLY SCORED—UNFIT FOR USE
4094

Fig. 4. - Comparison of Pistons

©1972 General Motors Corp..



Fig. 5. - Removing or Installing Piston Pin Bushings

2. Place the piston on the fixture so that the spacer protrudes into the bushing bore.

3. Insert the installer J 4972-2 in a bushing, then position the bushing and installer over the lower bushing bore.

NOTE: Locate the joint in the bushing toward the bottom of the piston (Fig. 6).

4. Insert the handle J 1513-2 in the bushing installer and drive the bushing in until it bottoms on the spacer.

5. Install the second bushing in the same manner.

Ream Bushings in Piston

1. Clamp the reaming fixture J 5273 in a vise (Fig. 7), then insert the guide bushing J 4970-5 in the fixture and secure It with the set screw.



Fig. 6. - Location of Joint in Piston Pin Bushings

2. Place the piston assembly in the fixture and insert the pilot end of the reamer J 4970-4 through the clamping bar, bushings and into the guide bushing

3. With the piston, fixture and reamer in alignment, tighten the wing nuts securely.

4. Ream the bushings by turning the reamer in a



Fig. 7. - Reaming Piston Pin Bushings

© 1972 General Motors Corp

clockwise direction only, when reaming or withdrawing the reamer. For the best results, use only moderate pressure on the reamef.

5. Withdraw the reamer and remove the piston from the fixture. Blow out the chips and check the inside diameter of the bushings. The inside diameter of the bushings must be 1.3775" to 1.3780".

Fitting Piston

Piston and cylinder liner measurements should be taken at room temperature (70°F.).

Measure the piston skirt diameter in the area between the bottom of the oil compression ring grooves and the top of the oil control ring grooves, except near the piston pin bore.

The diameter of a new piston is 3.8699" to 3.8721'. The inside diameter of a new cylinder liner is 3.8752" to 3.8767". Therefore, with new parts, the piston to liner clearance .0031" to .0068" and should not exceed .010" with used parts.

After inspecting and installing the cylinder liner (new or used) as outlined in Section 1.6.3, check the piston-to-liner clearance. Check this clearance in four places, 90° apart, while holding the piston upside down in the cylinder liner (Fig. 8).

Feeler gage set J 5438 may be used for checking the piston-to-liner clearance. The spring scale, attached to the appropriate feeler gage, is used to measure the force in pounds required to withdraw the feeler gage from between the piston and liner.

The clearance will be .001" greater than the thickness of the feeler gage used, i.e., a .004" thick feeler gage will indicate a clearance of .005" when it is withdrawn at a pull of six pounds. The feeler gage must be perfectly flat and free of nicks and bends.

If any bind between the piston and liner is detected, remove the piston and inspect the piston and liner for burrs. Remove the burrs with a fine hone (a flat one is preferable) before proceeding with the clearance check.

Fitting Piston Rings

Use new piston rings whenever a piston is removed for inspection or replacement.

The top compression (fire) ring can be identified by the bright chrome on the bottom side and oxide (rust color) on the top.

Insert one piston ring at a time far enough down in the cylinder liner to be within the normal area of ring travel. Use a piston to push the ring down to be sure it is parallel with the top of the liner. Then measure the ring gap with a feeler gage as shown in Fig. 9. Refer to Section 1.0 for the specified ring gap.

If the piston ring gap is below the specified limits, it may be increased by filing or stoning the piston ring in such a direction that the file or stone will cut from the outside (chrome plated) surface of the ring toward the inside surface. This will prevent any chipping or peeling of the chrome plate. The ends of the ring must remain square and the chamfer must be approximately .015" on the outer edge.

Check the ring clearances in the piston grooves as



Fig. 8. · Measuring Piston-to-Liner Clearance

©1972 General Motors Corp.

Fig. 9. - Measuring Piston Ring Gap

Fig. 10. - Measuring Piston Ring Side Clearance

illustrated in Fig. 10. Refer to Section 1.0 for the specified ring clearances and allowable wear limits.

Install Compression Rings on Piston

With the connecting rod assembly inspected and assembled to the piston as outlined in Section 1.6.1, refer to Fig. I for the proper location of the piston rings on the piston.

> **IMPORTANT**: Lubricate the piston rings and piston with engine oil before assembling.

Assemble the compression rings on the piston with tool J 8128, as shown in Fig. 2, and stagger the ring gaps around the piston. When installing the compression or oil control rings, do not spread the rings more than is necessary to slip them on the piston to avoid overstressing the rings.

Install Oil Control Rings on Piston

Install the oil control rings by hand, with the scraping edge of each ring down, as follows:

1. Install an expander in the upper oil ring groove (Fig. 1), being careful not to overlap the ends.

> **NOTE: The oil control ring expander must be completely seated in the oil ring groove. The ends of the expander can very easily be overlapped. If this occurs, the oil control rings will protrude slightly and be broken when the piston ring compressor is installed over the piston and rod assembly, or when the piston and rod assembly is installed in the cylinder liner.**

2. Install the top oil ring with the gap 180° from the ends of the expander.

3. Check the ends of the expander to be sure they are not overlapped.

4. Install the bottom oil ring with the gap 45° from the gap of the top oil ring. Recheck to be sure the ends of the expander are not overlapped.

> **NOTE: Do not, at any time, cut off or grind the ends of the oil ring expander to prevent the ends from overlapping. Cutting off or grinding the ends of the expander will decrease the tension on the oil control rings and result in high lubricating oil consumption.**

5. Install the second set of oil control rings and expander in the same manner as described above.

© 1972 General Motors Corp.

CONNECTING ROD

Each connecting rod (Figs. 1 and 2) is made of steel forged to an "I" section with a closed hub at the upper end and a cap at the lower end. The rod is drilled to provide lubrication to the piston pin at the upper end and is equipped with an oil spray nozzle for cooling the underside of the piston head,

A helically-grooved bushing is pressed into each side of the connecting rod at the upper end. A cavity of approximately 1/8" between the inner ends of these bushings, registering with the drilled oil passage in the connecting rod, forms a duct around the piston pin. A portion of the oil from this duct lubricates the piston pin and bushings, the remainder of the oil is forced out of the spray nozzle. The piston pin floats in both the piston and connecting rod bushings.

Service connecting rod assemblies include the lower bearing cap, bolts, nuts, spray nozzle and the upper piston pin bushings pressed in place and bored to size.



Fig. 1. Connecting Rod Mounting



Fig. - 2..-Typical Connecting Rod Details and Relative Location of Parts

Disassemble Connecting Rod from Piston (Rod and Piston Assembly Removed from Engine)

Disassemble the piston and connecting rod as outlined in Section 1.6.

Inspect Connecting Rod and Piston Pin

Clean the connecting rod and piston pin with fuel oil and dry them with compressed air.

Blow dry compressed air through the oil passage in the connecting rod and the spray nozzle to be sure the holes are open.

© 1970 General Motors Corp.


DO NOT USE OR ATTEMPT TO SALVAGE RODS WITH INDICATIONS OVER .005 DEEP EXTENDING OVER EDGES OF "H" SECTION ON BOTH SIDES OF FLANGE SHADED AREAS ARE MOST HIGHLY STRESSED
SECTION A-A
START OF FATIGUE CRACK RESULTING FROM OVERLOADING (DUE TO HYDRO STATIC LOCK) DO NOT ATTEMPT TO SALVAGE (THIS TYPE OF INDICATION IS NOT VISIBLE WITH BUSHINGS IN PLACE)
SECTION B-B
EXAMPLE OF AN INDICATION FOLLOWING LONGITUDINAL FORGING FLOW LINES
EXAMPLE OF A TRANSVERSE INDICATION THAT DOES NOT FOLLOW LONGITUDINAL FORGING FLOW LINES CAN BE EITHER A FORGING LAP, HEAT TREAT CRACK, OR START OF A FATIGUE CRACK
NON-CRITICAL AREA
CRITICAL AREA ACCEPTABLE LIMITS
NON-CRITICAL AREA
INDICATIONS IN NON-CRITICAL AREAS ARE ACCEPTABLE UNLESS THEY CAN BE OBSERVED AS OBVIOUS CRACKS WITHOUT MAGNETIC INSPECTION
LONGITUDINAL INDICATIONS FOLLOWING FORGED FLOW LINES ARE USUALLY SEAMS AND ARE NOT CONSIDERED HARMFUL IF LESS THAN 1/32 DEEP DEPTH CAN BE DETERMINED BY GRINDING A SMALL AREA NEAR THE CENTER OF THE INDICATION
TRANSVERSE INDICATIONS (ACROSS FLOW LINES) HAVING A MAXIMUM LENGTH OF 1/2, WHICH CAN BE REMOVED BY GRINDING NO DEEPER THAN 1/64 ARE ACCEPTABLE AFTER THEIR COMPLETE REMOVAL. AN EXCEPTION TO THIS IS A ROD HAVING AN INDICATION WHICH EXTENDS OVER THE EDGE OF "H" SECTION AND IS PRESENT ON BOTH SIDES OF THE FLANGE. IN THIS CASE MAXIMUM ALLOWABLE DEPTH IS .005 (SEE SECTION A-A)
GRINDING NOTES
CARE SHOULD BE TAKEN IN GRINDING OUT INDICATIONS TO ASSURE PROPER BLENDING OF GROUND AREA INTO UNGROUND SURFACE SO AS TO FORM A SMOOTH CONTOUR
POOR PRACTICE
GOOD PRACTICE

Fig. 3. · Magnetic Particle Inspection Limits for Connecting Rod

Check the connecting rod for cracks (Fig. 3) as outlined in Section 1.3 under Crankshaft Inspection.

Check the connecting rod bushings for signs of scoring, overheating or other damage. Bushings that have overheated may become loose and creep together, thus blocking off the lubricating oil to the piston pin, bushings and spray nozzle.

Check the clearance between the piston pin and the connecting rod bushings. If the clearance exceeds .010" with used parts, replace the piston pin and/or the bushings.

Remove Bushings from Connecting Rod

If it is necessary to replace the connecting rod bushings, remove them as follows:

1. Clamp the upper end of the connecting rod in holder J 7632 (Fig. 4) so that the bore in the bushings is aligned with the hole in the base of the holder.

2. Set the bushing remover J 4972-4 in the connecting rod bushing, insert handle J 1513-2 in the remover and drive the bushings from the rod.

Replace Spray Nozzle

If it is necessary to replace the spray nozzle, remove the old nozzle as follows:

1. Remove the piston pin bushings from the connecting rod as outlined above.



Fig. 4. - Removing or Installing Bushings

© 1970 General Motors Corp.

2. Place the connecting rod, spray nozzle remover J 8995 and a short sleeve in an arbor press as shown in Fig. 5.

NOTE: The orifice in the lower end of the drilled passage in the connecting rod is not serviced separately, and it is not necessary to remove it when replacing the spray nozzle.

3. Press the spray nozzle out of the connecting rod.

Install a new spray nozzle in the connecting rod as follows:

1. Start the spray nozzle, with the holes positioned as shown in Fig. 6, straight into the counterbore in the top of the connecting rod.

2. Support the connecting rod in an arbor press. Then, place a short, 3/8" I.D. sleeve on top of the spray nozzle and under the ram of the press.

3. Press the spray nozzle into the connecting rod until it bottoms in the counterbore.

Install Bushings in Connecting Rod

1. Clamp the upper end of the connecting rod assembly in holder J 7632 so that the bore for the bushings aligns with the hole in the base of the tool.

2. Start a new bushing straight into the bore of the connecting rod.



Fig. 5. - Removing Spray Nozzle from Connecting Rod



Fig. 6. - Location of Spray Nozzle in Connecting Rod

NOTE: When installing a bushing in the connecting rod, locate the joint at the top of the connecting rod (Fig. 7).

3. Insert installer J 4972-2 in the bushing, then insert handle J 1513-2 in the installer and drive the bushing into the connecting rod until the flange of the installer bottoms on the connecting rod (Fig. 4).

4. Turn the connecting rod over in the holder and install the second bushing in the same manner.

Roam Bushings in Connecting Rod

The bushings must be finished reamed after being installed in the connecting rod. Refer to Fig. 8 and ream the bushings as follows:



Fig. 7. · Location of Joint in Piston Pin Bushings

©1970 General Motors Corp.



Fig. 8. - Reaming Piston Pin Bushings

1. Clamp reaming fixture J 7608-4 in a vise.

2. Slide sleeve J 7608-5 on the arbor of the fixture (V-type engine connecting rod).

3. Place the crankshaft end of the connecting rod on the arbor of the fixture. Tighten the nuts on the 3/8" 24 bolts to 40-45 lb-ft torque.

4. Install the front guide bushing J 4971-6 in the fixture (pin end out).

5. Install spacer J 7608-3 in the fixture.

6. Align the upper end of the connecting rod with the hole in the reaming fixture.

7. Install the rear guide bushing J 1686-5 on the reamer J 7608-21; then, slide the reamer and bushing into the fixture.

8. Turn the reamer in a clockwise direction only, when reaming or withdrawing the reamer. For best results, use only moderate pressure on the reamer.

9. Remove the reamer and the connecting rod from the fixture, blow out the chips and measure the inside diameter of the bushings. The inside diameter of the bushings should be 1.3760" to 1.3765"

Assemble Connecting Rod to Piston

1. Apply clean engine oil to the piston pin and bushings.

2. Rest the piston in the holding fixture (Fig. 9).

3. Place a new piston pin retainer in the piston; then, place the crowned end of the installer J 4895-01 on the retainer and strike the tool just hard enough to deflect the retainer and seat it evenly.

CAUTION: Do not drive too hard on the retainer or the bushing may be moved inward and result in reduced piston pin end clearance.

4. Slide the piston pin into the piston and the upper end of the connecting rod. The piston pin will slip readily into position without forcing it if the clearances are correct.

5. Install the second piston pin retainer as outlined above.

6. After the piston pin retainers have been installed, check for piston pin end clearance by cocking the connecting rod on the pin and shifting the pin in its bushings.

7. One important function of the piston pin retainer is to prevent the oil, which cools the underside of the piston and lubricates the piston pin bushings, from reaching the cylinder walls. Check the retainers for proper sealing as follows:

a. Place the piston and connecting rod assembly upside down on a bench.

b. Pour clean fuel oil in the piston to a level, above the piston pin bosses.



Fig. 9. - Installing Piston Pin Retainer with Tool J 4895-01

©1970 General Motors Corp.

c. Dry the external surfaces of the piston in the area around the retainers and allow the fuel oil to set for about fifteen minutes.

d. Check for seepage of fuel oil around the retainers. If the fuel oil leaks around the retainers, install new retainers. In extreme cases it may be necessary to replace the piston.

e. After the leakage test is completed, empty the fuel Connecting Rod 1.6.1 oil from the piston, dry the parts with compressed air and lubricate the piston pin with clean engine oil.

8. Install the piston rings on the piston as outlined in Section 1.6.

9. Install the piston and connecting rod assembly in the engine as outlined in Section 1.6.3.

© 1970 General Motors Corp.

CONNECTING ROD BEARINGS

The connecting rod bearing shells are of the replaceable precision type and consist of an upper shell seated in the connecting rod and a lower shell seated in the connecting rod cap (Fig. 2, Section 1.6.1). The bearing shells are located by and prevented from end wise or radial movement by a tang at the parting line at one end of each shell. The connecting rod bearing shells used in the engines incorporate a relief groove in each end of the shell to provide clearance for the connecting rod bolts.

The connecting rod bearing caps are numbered 1R, 1L, 2R, 2L, etc. on the V-type engine, with matching numbers stamped on the connecting rod. Each bearing cap (and bearing shell) must be installed on its original connecting rod.

Since the upper and lower connecting rod bearing shells are different, they must not be interchanged. The upper bearing shell has two short oil grooves and two oil holes; each groove begins at the end of the shell and terminates at an oil hole. The lower bearing shell has a continuous oil groove from one end of the shell to the other. These grooves maintain registry with the oil holes in the crankshaft journals, thereby providing a constant supply of lubricating oil to the connecting rod bearings and to the piston pin bushings and spray nozzle through the oil passage in the connecting rod.

Remove Bearing Shells from Connecting Rod (Connecting Rod, Piston and Liner in Place)

1. Drain the engine lubricating oil.

2. Remove the oil pan.
3. Disconnect and remove the oil pump inlet tube assembly.

4. Remove one connecting rod bearing cap. Push the connecting rod and piston assembly up into the cylinder liner far enough to permit removal of the upper bearing shell. Do not pound on the edge of the shell with a sharp tool.

5. Inspect the upper and lower bearing shells as outlined under Inspection.

6. Install the bearing shells and bearing cap before another cap is removed.

Inspection

Visual inspection, as well as dimensional measurements, should be made to determine whether the used bearings are satisfactory for further service or must be replaced. Bearing failures may result from deterioration (acid formation) or contamination of the oil or loss of oil which results in scratching, etching, scoring or excessive wear. An analysis of the lubricating oil may be required to determine if corrosive acid and sulfur are present which cause acid etching, flaking and pitting. Bearing seizure may be due to low oil or no lubricating oil.

Check the oil filter elements for heavy sludge deposits. If necessary, replace the elements.

After removal, clean the bearings and inspect them for scoring, pitting, flaking, etching and dirt grooving. If any of these defects are present, the bearings must be discarded. However, babbitt plated bearings may develop minute cracks or small isolated cavities on the bearing surface during engine operation. These are characteristics of and are NOT detrimental to this type of bearing. The bearings should not be replaced for these minor surface imperfections. The upper bearing shells, which carry the load, will normally show signs of distress before the lower shells do.

Inspect the back of the bearing shells for bright spots which indicate they have been moving in their supports. If such spots are present, discard the bearing shells. Also inspect the connecting rod bearing bores for burrs, foreign particles, etc.

Measure the thickness of the bearing shells at point "C", 90° from the parting line, as shown in Fig. 6, Section 1.3.4. Use a micrometer and ball attachment J 4757 as illustrated in Fig. 7, Section 1.3.4.
The minimum thickness of a worn standard bearing shell should not be less than .123". In addition to this thickness measurement, check the clearance between the connecting rod bearing shells and the crankshaft journal. This clearance may be checked with the crankshaft in place by squeezing a soft plastic measuring strip between the crankshaft journal and the bearing shells (see Shop Note in Section 1.0).

One connecting rod bearing shell should not be replaced. If one bearing shell requires replacement, both the upper and lower shells should be replaced.

Inspect the crankshaft journals, as outlined in Section 1.3, for wear before replacement bearings are installed.

Bearing shells in .010", .020" and .030" undersize are available for service with crankshafts which have worn or have been ground to a smaller journal diameter

© 1970 General Motors Corp.

Bearing shells which are .002" undersize are available to compensate for slight journal wear in those cases where it is unnecessary to regrind the crankshaft.

> **NOTE: Bearing shells are NOT reworkable from one undersize to another under any circumstances.**

The following table gives the minimum bearing shell thickness for used standard and various undersize bearings, and the crankshaft connecting rod journal diameters corresponding to each bearing size.

Nominal Size of Bearing	Minimum New Bearing Shell Thickness	Crankshaft Connecting Rod Journal Diameters
V-Type Engine		
Standard	.1247"	2.749"-2.750"
.002" Undersize	.1257"	2.747"-2.748"
.010" Undersize	.1297"	*2.739"-2.740"
.020" Undersize	.1347"	*2.729"-2.730"
.030" Undersize	.1397"	*2.719"-2.720"

* Dimension' of Reground Crankshaft

Install Connecting Rod Bearing Shells (Connecting Rod, Piston and Liner in Place)

1. Rotate the crankshaft until the connecting rod journal is at the bottom of its travel, wipe the journal clean and lubricate it with clean engine oil.

2. Install the upper bearing shell the one with the short groove and oil hole at each parting line in the connecting rod. Be sure the tang on the shell fits in the groove in the rod.

If there is a visible difference in the color of new upper and lower bearing shells, it is due to a change in the manufacturing process and they should not be rejected on the basis of the dissimilar appearance.

3. Pull the piston and rod assembly down until the upper rod bearing seats firmly on the crankshaft journal.

4. Place the lower bearing shell the one with the continuous oil groove in the bearing cap, with the tang of the shell in the groove of the cap, and lubricate it with clean engine oil.

5. Note the identifying marks on the cap and the rod and assemble the cap to the rod. Tighten the nuts on the 3/8" -24 bolts to 40-45 lb.-ft torque.

6. Install the lubricating oil pump inlet tube assembly. Replace the inlet tube seal ring or elbow gasket if hardened or broken.

7. Install the oil pan.

8. Refer to the Lubricating Oil Specifications in Section 13.3 and refill the crankcase to the proper level on the dipstick.

9. If new bearings were installed, operate the engine on the run-in schedule as outlined in Section 13.2.1.

© 1970 General Motors Corp.

CYLINDER LINER

The cylinder liners (Fig. I) are of the replaceable wet type, made of hardened alloy cast iron, and are a slip fit in the cylinder block.

They are inserted in the cylinder bores from the top of the cylinder block. The flange of each liner rests on a counterbore in the top of the block.

A synthetic rubber seal ring, recessed in the cylinder block bore, is used between the liner and the block to prevent water leakage into the air box.

The upper portion of the liner is directly cooled by water surrounding the liner. The center portion of the liner is air cooled by the scavenging air which enters the cylinder through eighteen equally spaced ports.

The angle of the ports in the cylinder liner creates a uniform swirling motion to the intake air as it enters the cylinder. This motion persists throughout the compression stroke and facilitates scavenging and combustion.

The wear on a liner and piston is directly related to the amount of abrasive dust and dirt introduced into the engine combustion chamber through the air intake. This dust, combined with lubricating oil on the cylinder wall, forms a lapping compound and will result in rapid wear. Therefore, to avoid pulling contaminated air into the cylinder, the air cleaners must be serviced regularly according to the surroundings in which the engine is operating.



Fig. 1. - Cylinder Liner



Fig. 2. - Removing Cylinder Liner

If the worn clearance between the piston and cylinder liner becomes excessive or should the liner be badly scored resulting in unsatisfactory engine performance, the cylinder liner must be replaced.

Remove Cylinder Liner

If necessary, a cylinder liner or liners may be removed from the cylinder block as follows:

1. Remove the piston and connecting rod assembly as outlined in Section 1.6 under Remove Piston and Connecting Rod.

2. If the engine has been in service for an extended period, considerable effort may be required to loosen the liner frown its position. When this condition exists, remove the liner with tool set J 22490 (Fig. 2) as follows:
    a. Slip the lower puller clamp up the puller rod and off its tapered seat. Cock the clamp so it will slide down through the liner. The clamp will drop back onto its seat in a horizontal position after it clears the bottom of the liner.

    b. Slide the upper puller clamp down against the top edge of the liner.

    c. With the tool in place, strike the upset head on the upper end of the puller rod a sharp blow with the puller weight, thus releasing the liner. Remove the liner.

© 1970 General Motors Corp.



Fig. 3. - Cylinder Liner Measurement Diagram

d. Remove the cylinder liner seal ring from the groove in the cylinder block bore.

If tool J 22490 is unavailable, tap the liner out with a hardwood block and hammer.

CAUTION: To avoid damage to the top land of the piston, do not at any time try to loosen the cylinder liner by inserting a long bolt or rod through the port openings in the cylinder liner and turning the crankshaft, thus pushing the liner up with the piston.

Inspect Used Cylinder Liner

When the cylinder liner is removed from the cylinder block, it must be thoroughly cleaned and then checked for:

Cracks
Scoring
Poor contact on outer surface
Flange irregularities
Inside diameter
Out-of-roundness
Taper

A cracked or excessively scored liner must be discarded. A slightly scored liner may be cleaned-up and re-used.

Install the liner in the cylinder block and measure the inside diameter of the liner at the various points shown in Fig. 3. If the taper exceeds .002" or the out of-round exceeds .003", replace the liner. To check these dimensions, use dial bore gage J 5347 (Fig. 4) which has a dial indicator calibrated in .0001" increments. Set the gage on zero with master ring J 8385.

NOTE: Dial bore gage master setting fixture J 23059 may be used in place of master ring J 8385.

Home Used Cylinder Liner

If the taper or out-of-round do not exceed the limits, hone the liner to remove any step or ridge at the top of the ring travel and to remove the glaze caused by the rubbing action of the piston rings.



Fig. 4. - Checking Bore of Cylinder Liner

© 1970 General Motors Corp.

Whenever a liner is honed, it must be placed in a fixture (a scrap cylinder block makes an excellent honing fixture). However, if it is necessary to hone a liner in the cylinder block that is to be used in building up the engine, the engine must be dismantled and then, after honing, the cylinder block and other parts must be thoroughly cleaned to ensure that all abrasive material is removed.

Work the hone J 5902-01. equipped with 120 grit stones J 5902-14, up and down the full length of the liner a few times so a "criss-cross" pattern with the hone marks on a 45' axis will result.

After the liner has been honed, remove it from the fixture and clean it thoroughly. Then, dry it with compressed air and check the entire surface for burrs.

After honing, the liner must conform to the same limits on taper and out-of-round as a new liner, and the piston-to-liner clearance must be within the specified limits shown in Section 1.0.

Inspect New Cylinder Liner

Install the cylinder liner in the block and measure the inside diameter at the various points shown in Fig. 3.

Use dial bore gage J 5347 and set the gage on zero with master ring J 8385.

> **NOTE: Dial bore gage master setting fixture J 23059 may be used In place of master ring J 8385.**

A new cylinder liner is 3 8752" to 3.8767" on the inside diameter, and should be straight from top to bottom within .001" and round within .002" total indicator reading when the liner is in place in the block. Refer to Section I 0 for the specified piston-to liner clearance.

> **NOTE: Do not modify the surface finish in a new service cylinder liner. Since the liner is properly finished at the factory, any change will adversely affect the seating of the piston rings.**

Fitting Cylinder Liner in Block Bore

1. Wipe the inside and outside of the liner clean. Also, make sure the block bore and counterbore are clean so the liner flange will seat properly. Then, slide the liner into the block until the flange rests on the bottom of the counterbore in the block.



Fig. 5. - Checking Distance of Liner Flange Below Top Face of Block

> **CAUTION: Do not drop or slam the liner flange against the bottom of the counterbore in the block.**

2. Tap the liner lightly with a soft hammer to make certain the liner flange seats on the bottom of the counterbore.

3. Clamp the liner in place with hold-down clamp J 21793 and measure the distance from the top of the liner flange to the top of the block with dial indicator set J 22273 (Fig. 5). The top of the liner flange should be .0465" to .050" below the top of the block, and there must not be over .0015" difference between any two adjacent liners when measured along the cylinder longitudinal center line. If the above limits are not met, install the liner in another bore and recheck, or use a new liner.

4. Matchmark the liner and the block with chalk or paint, so the liner may be reinstalled in the same position in the same bore. Place the matchmark on the outer edge of the block (V-type engine),

5. Remove the hold-down clamp and the liner.

Install Piston and Connecting Rod Assembly

1. With the piston assembled to the connecting rod and the piston rings in place, as outlined in Sections 1.6 and 1.6.1, apply clean engine oil to the piston, rings and the inside of the piston ring compressor J 6883

.

© 1970 General Motors Corp.



Fig. 6. - Installing Piston and Connecting Rod Assembly in Ring Compressor and Cylinder Liner

NOTE: Inspect the ring compressor for nicks or burrs, especially at the non-tapered inside diameter end. Nicks or burrs on the inside diameter of the compressor will result in damage to the piston rings.

2. Place the piston ring compressor on a wood block 'tapered end up).

3. Position (stagger) the piston ring gaps properly on the piston. Make sure that the oil control ring expanders are not overlapped.

4. Start the top of the piston straight into the ring compressor; then, push the piston down until it contacts the wood block (see Operation 1, Fig. 6).

5. Note the position of the matchmark on the liner and place the liner on a wood block.

6. Place the ring compressor and the piston and rod assembly on the liner, so the numbers on the rod and cap are aligned with the matchmark on the liner (see Operation 2, Fig. 6).

NOTE: The number and letter, on the side of the connecting rod and cap identify the rod with the cap and indicate the particular cylinder in which they are used. If a new service connecting rod is to be installed, the same identification number and letter, must be stamped or etched in the same location as on the connecting rod that was replaced.

7. Push the piston and rod assembly down into the liner until the piston is out of the ring compressor.

CAUTION: Do not force the piston into the liner. The peripheral abutment type expanders apply considerably more force on the oil ring than the standard expander. Therefore, extra care during the loading operation must be taken to prevent ring breakage.

8. Remove the connecting rod cap and the ring compressor.

9. Push the piston down into the liner until the compression rings pass the liner ports.

Install Cylinder Liner, Piston and Connecting Rod Assembly

After the piston and connecting rod assembly have been installed in the liner, the entire assembly may be installed in the engine as follows:

1. Make sure the seal ring grooves in the cylinder block are clean. Then, install the seal ring.

NOTE: The cylinder block has an additional seal ring groove approximately 1/8"



Fig. 7. - Installing Piston, Connecting Rod and Liner Assembly in Cylinder Block

©1970 General Motors Corp.,



Fig. 8. - Cylinder Liner Seal Ring

below the original top groove (Fig. 8). This groove will permit further use of the cylinder block where corrosion or erosion of the upper seal ring groove has occurred.

2. Apply hydrogenated vegetable type shortening or permanent type antifreeze solution to the inner surface of the seal ring.

3. If any of the pistons and liners are already in the engine, use hold-down clamps (Fig. 5) to retain the liners in place when the crankshaft is rotated.

4. Rotate the crankshaft until the connecting rod journal of the particular cylinder being worked on is at the bottom of its travel, wipe the journal clean, and lubricate it with clean engine oil.

5. Install the upper bearing shell -the one with a short groove at each parting line -in the connecting rod. Lubricate the shell with clean engine oil.

6. Hold the piston, rod and liner in line with the block bore (Fig. 7) so the identification number on the rod is facing the outer edge of the block. Also, align the matchmarks on the liner and block. Now slide the entire assembly into the block bore and seal rings, being careful not to damage the seal rings.

7. Pull or push the piston and connecting rod down until the upper bearing shell seats firmly on the crankshaft journal. Use care so the bearing shell will not be dislodged from the rod.

> **CAUTION: On a V engine, the distance from the center of the connecting rod bolts to the sides of the rod are not equal. Therefore, to avoid cocking the rods, the narrow sides of the rods must be together when attached to the crankshaft.**

8. Place the lower bearing shell -the one with the continuous oil groove -in the connecting rod cap with the tang on the bearing in the notch in the cap. Lubricate the bearing shell with clean engine oil.

© 1970 General Motors Corp.

9. Install) the bearing cap and shell on the connecting rod with the numbers on the cap and the rod adjacent to each other.

Tighten the nuts to 40-45 lb-ft torque.

10. Check the connecting rod side clearance. The clearance between the side of the rod and the crankshaft should be .008" to .016" clearance between the connecting rods on a V-type engine.
11. Remove the liner hold-down clamps.
12. Install new compression gaskets and water and oil seals as outlined in Section 1.2. Then, install the cylinder head.
13. Install any other parts which were removed from the engine.
14. After the engine has been completely reassembled, refer to the Lubricating Oil Specifications in Section 13.3 and refill the crankcase to the proper level on the dipstick.

15. Close all of the drains and fill the cooling system.

16. If new parts such as pistons, rings, cylinder liners or bearings were installed, operate the engine on the RUN-IN schedule given in Section 13.2.1.

© 1970 General Motors Corp.

ENGINE BALANCE AND BALANCE WEIGHTS

In the balance of two-cycle engines, it is important to consider disturbances due to the reciprocating action of the piston masses. These disturbances are of two kinds: unbalanced forces and unbalanced couples. These forces and couples are considered as primary or secondary according to whether their frequency is equal to engine speed or twice engine speed. Although it is possible to have unbalanced forces or couples at frequencies higher than the second order, they are of small consequence in comparison to the primary forces and couples. Even the secondary forces and couples are usually of little practical significance.

The reciprocating masses (the piston and upper end of the rod) produce an unbalanced couple due to their arrangement on the crankshaft. On a V-type engine, this unbalanced couple tends to move the ends of the engine in an elliptical path.

This couple is cancelled by incorporating an integral crankshaft balance component and by placing balance weights at the outer ends of the camshafts (V-type engine)

This balance arrangement produces a couple that is equal and opposite in magnitude and direction to the primary couple.

On the camshafts (V-type engine)

each set of weights (weights on the outer ends of each shaft comprise a set) rotates in an opposite direction with respect to the other.
When the weights on either end of the engine are in a vertical plane, their centrifugal forces are in the same direction and oppose the primary couple. When they are in a horizontal plane, the centrifugal forces of these balance weights oppose each other and are, therefore. cancelled. The front balance weights act in a direction opposite to the rear balance weights; therefore, rotation will result in a couple effective only in a vertical plane. This couple, along with that built into the crankshaft, forms an elliptical couple which completely balances the primary couple.

The balance weights are integral with the gears and the circular balance weights (pulleys) on the shafts.

Both the rotating and primary reciprocating forces and couples are completely balanced in the engines.
Consequently, the engines will operate smoothly and in balance throughout their entire speed range.

Remove Front Balance Weights

1. Remove the nut at each end of both shafts as outlined in Section 1.7.2.



Fig. 1. - Removing Front Balance Weight (Pulley Type)

2. Force the balance weight off the end of each shaft, using two screw drivers or pry bars between the balance weight and the upper front cover as shown in Fig. 1.

Install Front Balance Weights

1. Reinstall the Woodruff keys in the shafts, if they were removed.

2. Align the keyway in the balance weight with the key in the shaft; then, slide the weight on the shaft. If the weight does not slide easily onto the shaft, loosen the thrust washer retaining bolts at the opposite end of the shaft; then, to prevent possible damage to the thrust washer, support the rear end of the shaft while tapping the weight into place with a hammer and a sleeve. Retighten the thrust washer retaining bolts to 30-35 lb-ft torque. Install the other weight in the same manner.

3. Wedge a clean rag between the gears. Refer to Fig. 1, Section 1.7.2, and, tighten the gear retaining nuts to 300-325 lb-ft torque. Then tighten the front balance weight retaining nuts to 300-325 lb-ft torque. Remove the rag from the gears.

©1970 General Motors Corp.

GEAR TRAIN AND ENGINE TIMING

A train of helical gears, completely enclosed between the engine end plate and the flywheel housing, is located at the rear of the engine .

The gear train (Fig. 1) consists of a crankshaft gear, an idler gear and two camshaft gears. The accessory drive (fuel pump drive--Section 2.2.1) gear is driven by a camshaft gear.

The crankshaft gear is pressed on and keyed to the end of the crankshaft

The idler gear rotates on a stationary hub.

The camshaft gears are pressed on and keyed to their respective shafts and each gear is secured by a retaining nut and lock plate.

©1972 General Motors Corp.



Fig. 1. - 6V Engine Gear Train Timing Marks (Standard Timing Shown)

The two camshaft gears mesh with each other and run at the same speed as the crankshaft gear. Since the camshaft gears must be in time with each other, and the two as a unit in time with the crankshaft gear, timing marks have been stamped on the face of the gears to facilitate correct gear train timing.

The symbol system of marking the gears makes gear train timing a comparatively easy operation. When assembling the engine, it is important to remember the engine rotation. Then, working from the crankshaft gear to the idler gear and to the camshaft balance shaft gear in that order, line up the appropriate circle symbols on the gears or the appropriate triangles as each gear assembly is installed on the engine. Refer to Fig. 1 for a typical gear train timing arrangement.

NOTE: It is advisable to make a sketch indicating the position of the timing marks BEFORE removing or replacing any of the gears in the gear train.

The circle and the triangle are the basic timing symbols stamped on the gears. The letters stamped on the crankshaft gears identify the proper timing marks for the particular engine:
"V" represents V-type engine, "R" represents right-hand rotation engine, and "A" represents advanced timing.

The timing is advanced by aligning the proper "A" timing mark on the crankshaft gear with the circle-triangle timing mark on the idler gear.

© 1972 General Motors Corp.

The crankshaft gear is stamped "VR-A" on the left side of a triangle timing mark (Fig. 1)for a right-hand rotation engine.

For *advance timing*, the "A" adjacent to the "VR" on the crankshaft gear is aligned with the circle-triangle on the idler gear.

There are no timing marks on the governor drive gear blower rotor gears, blower drive gear or the accessory drive (fuel pump) gear. Therefore, it is not necessary to align these gears in any particular position when meshing the various gears with the camshaft gears.

Gear train noise is usually an indication of excessive gear lash, chipped, pitted or burred gear teeth or excessive bearing wear; therefore, when noise develops in a gear train, remove the flywheel housing and inspect the gear train and its bearings. A rattling noise usually indicates excessive gear lash whereas a whining noise indicates too little gear lash.

The backlash between the various mating-gears in the gear train should he .003" to .005", except the blower rotor gears which should be .0005" to .0025". Maximum permissible backlash between worn blower gears is .0035", and should not exceed .007" clearance between all other gears in the gear train.

6V ENGINE:

The camshaft gears are positioned so that the triangle timing marks are adjacent to each other (Fig. 2). One circle-triangle timing mark on the idler gear is aligned with the second "triangle" on the mating camshaft gear. The other timing mark on the idler gear is aligned with the proper timing mark on the crankshaft gear.

©1972 General Motors Corp.

Lubrication

The gear train is lubricated by the overflow of oil from the camshaft pockets spilling into the gear train compartment. A certain amount of the oil also spills into the gear train compartment from the camshaft end bearings and the idler gear bearing.

The idler gear bearing and the accessory (fuel pump) drive gear is lubricated by oil directly from the cylinder block main oil gallery to the bearing hubs.

ENGINE TIMING

The correct relationship between the crankshaft and camshaft(s) must be maintained to properly control fuel injection and the opening and closing of the exhaust valves.

The crankshaft timing gear can be mounted in only one position since it is keyed to the crankshaft. The camshaft gear(s) can also be mounted in only one position due to the location of the keyway relative to the cams. Therefore, when the engine is properly timed, the markings on the various gears will match as shown in Fig 1

Pre-ignition, uneven running and a loss of power may result if an engine is "out of time".

When an engine is suspected of being out of time, due to an improperly assembled gear train, a quick check can be made without removing the flywheel and flywheel housing by following the procedure outlined below.

Check Engine Timing

Access to the crankshaft pulley, to mark the top dead center position of the selected piston, and to the front end of the crankshaft or the flywheel for turning the crankshaft is necessary when performing the timing check. Then, proceed as follows:

1. Clean and remove the valve rocker cover.

2. Select any cylinder for the timing check.

3. Remove the injector as outlined in Section 2.1.1.

4. Carefully slide a rod, approximately 12" long, through the injector tube until the end of the rod rests on top of the piston. Place the throttle in the no-fuel position. Then, turn the crankshaft slowly in the direction of engine rotation. Stop when the rod reaches the end of its upward travel. Remove the rod and turn the crankshaft, opposite the direction of rotation, between 1/16 and 1/8 of a turn.

5. Select a dial indicator with .001" graduations and a spindle movement of at least l". Provide an extension for the indicator spindle. The extension must be long enough to contact the piston just before it reaches the end of its upward stroke. Also, select suitable mounting attachments for the indicator so it can be mounted over the injector tube in the cylinder head.

6. Mount the indicator over the injector tube. Check to be sure the indicator spindle extension is free in the injector tube and is free to travel at least one inch.

7. Attach a suitable pointer to the engine lower front cover. The outer end of the pointer should extend out over the top of the crankshaft pulley.

8. Turn the crankshaft slowly, in the direction of engine rotation, until the indicator hand just stops moving.

9. Continue to turn the crankshaft, in the direction of rotation, until the indicator starts to move again. Now set the indicator on zero and continue to turn the crankshaft until the indicator reading is .010".

Engine	*INDICATOR READING		
	Standard	Retarded 1-Tooth	Advanced 1-Tooth
ADVANCED TIMING			
(2) .6V	.232"	.206"	.258"

* Indicator readings shown are nominal values. The allowable tolerance is +.005 ;n.

(2) Low velocity type injector com.

TABLE 1

© 1972 General Motors Corp.

10. Scribe a line on the crankshaft pulley in line with the end of the pointer.

11. Slowly turn the crankshaft, opposite the direction of rotation, until the indicator hand stops moving.

12. Continue to turn the crankshaft, opposite the direction of rotation, until the indicator starts to move again. Now set the indicator on zero and continue to turn the crankshaft until the indicator reading is 010".

13. Scribe the second line on the crankshaft pulley in line with the end of the pointer.

14. Scribe a third line on the pulley half way between the first two lines. This is top dead center.

NOTE: If the crankshaft pulley retaining bolt loosened up, tighten it to the torque specified in Section 1.0.

15. Remove the dial indicator and rod from the engine.

16. Install the injector as outlined in Section 2.1.1. Then, refer to Section 14 and adjust the exhaust valve clearance and time the fuel injector.

17. Turn the crankshaft, in the direction of rotation, until the exhaust valves in the cylinder selected are completely open. Reinstall the dial indicator so the indicator spindle rests on the top of the injector follower. Then, set the indicator on zero. Next turn the crankshaft slowly, in the direction of rotation, until the center mark on the pulley is in line with the pointer.

18. Check the front end of the camshaft for an identification mark. For identification purposes, a letter "V" is stamped on each end of a low velocity camshafts

Note the indicator reading and compare it with the dimensions listed in Table 1,

19. Remove the dial indicator; also remove the pointer attached to the front of the engine.

20. Install the valve rocker cover.

© 1972 General Motors Corp.

CAMSHAFT AND BEARINGS

The wo camshafts used in the V-type engines, are located just below the top of the cylinder block.

The camshafts in the V-type engine are positioned according to engine rotation.

The shafts are supported by bearings (bushing type) that are pressed into bores in the cylinder block.

The camshafts are supported by two end bearings and two intermediate bearings.

Lubrication is supplied under pressure to the camshaft end bearings via oil passages branching off from the main oil gallery direct to the camshaft end bearings.

In addition, oil is forced through an oil passage in each camshaft which lubricates the camshaft intermediate bearings.

All of the camshaft bearings incorporate small slots through which lubricating oil is directed to the cam follower rollers.

Remove Camshaft

Whenever an engine is being completely reconditioned or the bearings, thrust washers, or the gears need replacing, remove the shafts from the engine in the following manner:

NOTE: Refer to Shop Notes in Section 1.0 to install a cup plug in the front end of the camshaft.

1. Drain the engine cooling system.

2. Remove all accessories and assemblies with their attaching parts as necessary to permit the engine to be mounted on an overhaul stand.

Procedures for removing accessories and assemblies from the engine will be found in their respective sections of this manual.

3. Mount the engine on an overhaul stand. Be sure the engine is securely mounted on the stand before releasing the lifting sling.

4. Remove the cylinder head(s). Refer to Section 1.2.



Fig. 1. - Removing or Installing Nut on Camshaft or Balance Shaft

©1972 General Motors Corp.



Fig. 2. - Removing or Installing Thrust Washer Retaining Bolts

5. Remove the flywheel and the flywheel housing as outlined in Sections 1.4 and 1.5.

6. Remove the bolts which secure the gear nut retainer plates (if used) to the gears, then remove the retainer plates.

7. Wedge a clean rag between the gears as shown in Fig. 1; then, remove the nuts from each end of both shafts with a socket wrench.

8. Remove the balance weights from the front end of the shafts as outlined in Section 1.7.

9. Remove the upper engine front cover (Section 1.7.8).

10. Remove the oil slinger from the front end of both shafts.

11. Remove the two retaining bolts that secure the camshaft thrust washer to the cylinder block by inserting a socket wrench through a hole in the web of the gear as shown in Fig. 2.

12. Withdraw the shaft, thrust washer and gear as an assembly from the rear end of the cylinder block.

Disassemble Camshaft

1. Remove the gear from the shaft. Refer to Section 1.7.3.

2. Remove the end plugs from the camshaft, to facilitate the removal of any foreign material lodged behind the plugs, as follows:

a. Clamp the camshaft in a vise equipped with soft jaws, being careful not to damage the cam lobes or machined surfaces of the shaft.
b. Make an indentation in the center of the camshaft end plug with a 31/64" drill (carboloy tip).
c. Punch a hole as deeply as possible with a center punch to aid in breaking through the hardened surface of the plug.
d. Then, drill a hole straight through the center of the plug with a 1/4" drill (carboloy tip).
e. Use the 1/4" drilled hole as a guide and redrill the plug with a 5/16" drill (carboloy tip).
f. Tap the drilled hole with a 3/8"-16 tap.
g. Thread a 3/8"-i6 adaptor J 8183 into the plug. Then, attach a slide hammer J 6471-1 to the adaptor and remove the plug by striking the weight against the handle.
h. Insert a length of 3/8" steel rod in the camshaft oil gallery and drive the remaining plug out.

NOTE: If a steel rod is not available, remove the remaining plug as outlined in Steps "a" through "g".



Fig. 3. -· Removing End Bearing

© 1972 General Motors Corp.

Inspection

Soak the camshaft in clean fuel oil. Then, run a wire brush through the oil gallery to remove any foreign material or sludge. Clean the exterior of the camshaft and blow out the oil gallery and the oil holes with compressed air. Clean the camshaft bearings and related parts with fuel oil and dry them with compressed air.

Inspect the cams and journals for wear or scoring. If the cams are scored, inspect the cam rollers as outlined in Section 1.2.1.

Examine both faces of the thrust washers. If either face is scored or if the thrust washers are worn excessively, replace the washers. New thrust washers are .208" to .210" thick.

Also, examine the surfaces which the thrust washers contact; if these surfaces are scratched but not severely scored, smooth them down with an oil stone. If the score marks are too deep to be removed, or if parts are badly worn, use new parts.

The clearance between new shafts and new bearings is .0045" to .006", or a maximum of .008" with worn parts. Excessive clearance between the shafts and the bearings will cause low oil pressure and excessive backlash between the gears.

Bearings are available in .010" and .020" undersize for use with worn or reground shafts.

Oversize camshaft bearings are available in sets, .010" oversize on the outside diameter, to permit reuse of a cylinder block having one or more scored block bearing bores. To use the oversize bearings, the camshaft block bores must be carefully line-bored (machined) to the dimensions shown in Table 1.

Engine	Bearing Location	Dimension	
		Minimum	Maximum
6V	End	2.385"	2.386"
6V	Intermediate	2.375u	2.376"

TABLE 1



Fig. 4. - Installing Intermediate Camshaft Bearing

© 1972 General Motors Corp.



Fig. 5. - Camshaft Bearing Identification

Remove Bearings

The end bearings must be removed prior to removing the intermediate bearings.

> **CAUTION: When removing the bearings be sure to note the position of the bearings in the bore with respect to the notch in the bearings. Replacement bearings must be installed in the same position.**

1. Remove all accessories and assemblies with their attaching parts as is necessary so that tool set J 759302 may be used as shown in Fig. 3 and in A of Fig. 7.

Tool set J 7593-03, designed for use with standard size bearings, may be used to remove and install .010" undersize and .020" undersize bearings by reducing the pilot diameter of the pilot J 7593-2, installer J 7593-3, remover J 7593-5, installer J 7593-6, and installer J 7593-15. The pilot diameter of these tools should be reduced by .020". This reduction in tool diameter does not materially effect usage on standard size bearings. If the tools are used frequently, However, it may be advisable to purchase additional standard pieces. Reduced diameter tools have not been released.

2. Insert the small diameter end of the pilot J 7593-2 into the end bearing.

3. Then. with the unthreaded end of the shaft J 7593-1 started through the pilot, push the shaft through the block bore until the end of the shaft snaps into the remover J 7593-5.
4. Now drive the end bearing out of the cylinder block. The nearest intermediate bearings can be removed now in the same manner.
The large diameter end of pilot J 7593-2 will fit into the camshaft bore and is used when removing the other end bearing and any remaining bearings.



Fig. 6. - Location of Notch in Relation to Shaft Bore Centerline

©1972 General Motors Corp.

Install Intermediate Camshaft Bearings

Camshaft intermediate bearings must be installed prior to installing the camshaft end bearings.

The front intermediate and front bearings are installed by pressing the bearings from the front to the rear of the block.

NOTE: Bearings incorporate lubrication grooves on the inner bearing surface (Fig. 5).

To properly install the camshaft bearings, refer to Fig. 6. for location of the notch in the bearing in relation to the camshaft core centerline in the cylinder block.

Also, to facilitate assembly, the camshaft bearings are color coded on the side and/or end as shown in Table 2.

1. Insert pilot J 7593-2 in the bore of the block as shown in Fig. 4. Use the small end of the pilot if an end bearing has been installed. Refer to B and C of Fig. 7.

2. Insert the new intermediate bearing into the camshaft bore and position it correctly.

Bearing Position	Color Code		Outside Diameter	Inside Diameter
	Current			
End	Brown Brown		Standard .010" Oversize	Standard, .010" & .020" U.S. Standard (only)
Inter-mediate	Orange Orange		Standard .010" Oversize	Standard, .010" & .020" U.S. Standard (only)

Table 2

3. Then, with the unthreaded end of shaft J 7593-1 started through the pilot, push the shaft through the entire length of the block bore.

4. Slide installer J 7593-6 on the shaft until the locating pin registers with the notch in the bearing.
Then, slide installer J 7593-3 or J 7593-15 on the shaft with the large diameter inserted into the end of the block bore. Refer to C and note of Fig. 7.

5. Next, place a spacer (if required), thrust washer, plain washer and hex nut over the threaded end of the puller. The short spacer J 7593-11, shown in Fig. 4., is used on the 6V blocks.

6. Align the shaft in such a way that a "C" washer, J 7593-4, can be inserted in a groove in the shaft adjacent to installer J 7593-6.

7. Place a "C" washer in the groove near the end of the shaft and, using a suitable wrench on the hex nut, draw the bearing into place until the "C" washer butts up against installer J 7593-3 and prevents the shaft from further movement.

Install End Bearings

Refer to the camshaft color code chart and the cylinder block bore machining dimension chart when installing the end bearings.

1. Insert pilot J 7593-2 in the bore of the block as shown in "D" of Fig. 7. Use the small diameter of the pilot if a bearing has been installed.

2. Insert support J 7593-12 in the bore in the opposite end of the block; then, with the unthreaded end of the shaft started through pilot J 7593-2, push the shaft through the block and support J 7593-12.

3. Place a new end bearing on installer J 7593-3 and align the notch in the bearings with the pin on the installer. Then, slide the installer and the bearing on the shaft. Position the bearing correctly with the groove in the camshaft bore.
4. Place "C" washer J 7593-4 in the end notch in the shaft; pull the shaft back until the washer butts against the installer.
5. Next, place a spacer (if required), thrust washer, plain washer and hex nut over the threaded end of the shaft as shown in "D" of Fig. 7. and, using a suitable wrench on the hex nut, draw the bearing into place

© 1972 General Motors Corp.



Fig. 7. - Removing and Replacing Camshaft Bearing

until the shoulder on the installer prevents the shaft from further movement. The bearing is now installed in its correct position.

Install the remaining end bearings in the same manner.

Use of tool J 7593-03 assures that the bearings are properly spaced in relation to the end of the block.

The right rear and left front intermediate bearings for the 6V cylinder block are 5.54" from the rear and front face of the block; and the right front and left rear intermediate bearings are 6.66" from the front and rear face of the block.

© 1972 General Motors Corp.



Fig. 8. - Camshaft and Balance Shaft Details and Relative Location of Parts

Assemble and Install Camshaft

Refer to Fig. 8 and assemble the camshaft

•1. Install new end plugs in the camshaft. Press the plugs in to a depth of 1.940 " to 2.060 ".

2. Install the gears and thrust washers on their respective shafts as outlined in Section 1.7.3.

3. Lubricate the bearings and shafts with engine oil and slide the shaft assemblies into the cylinder block being careful not to damage the bearings or the cams and journals. Make sure that the appropriate timing marks on the gears are aligned. Refer to *Gear Train and Engine Timing* in Section 1.7.1.

4. Slide an oil slinger on the front end of both shafts.

5. Install the upper engine front cover, if used, (Section 1.7.8).

6. Secure the thrust washers in place as shown in Fig. 2. and tighten the bolts to 30-35 Ib-ft torque.

7. Install the front balance weights (Section 1.7).

8. Attach the gear nut retainer plates (if used) to the gears with bolts and lock washers and tighten the bolts to 35-39 Ib-ft torque.

9. Check the clearance between the thrust washer and the gear on both shafts. The clearance should be .G,," to .015 ", or a maximum of .019" with used parts.

10. Check the backlash between the mating gears. The backlash should be .003 " to .005 " and should not exceed .007 " between used gears.

11. Install the flywheel housing and other parts or assemblies that were removed from the engine as outlined in their respective sections of this manual.

©1972 General Motors Corp.

CAMSHAFT

The two camshaft gears on a V-type engine, are located at the flywheel end of the engine and mesh with each other and run at the same speed as the crankshaft.

Since the two camshaft gears on V-type engine must be In time with each other, timing marks are stamped on the rim of each gear. Also, since these two gears as a unit must be in time with the crankshaft, timing marks are located on the idler and crankshaft gears (refer to Section 1.7.1).
Each gear is keyed to its respective shaft and held securely against the shoulder on the shaft by a nut. A gear nut retainer, with a double hexagon hole in the center, fits over the nut. The retainer is attached to the gear by bolts threaded into tapped holes in the gear.

Remove Camshaft Gears

1. Remove the camshaft from the engine as outlined in Section 1.7.2.

2. Place the camshaft and gear assembly in an arbor press with the gear suitably supported as shown in Fig. 1.

3. Place a wood block under the lower end of the camshaft so the threads will not be damaged when the shaft IS pressed from the gear.

4. Place a short piece of 3/4" O.D. brass rod between the end of the camshaft and the ram of the press; then force the camshaft out of the camshaft gear.

5. Remove the thrust washer, Woodruff key and spacer from the camshaft.

GEARS



Fig. 1. - Removing Camshaft Gear

Inspection

Clean the gears with fuel oil and dry them with compressed air. Then examine the gear teeth for evidence of scoring, pitting and wear. Replace the gears if necessary.

Examine both faces of the camshaft thrust washer and, if either face is worn or scored, replace the washer. Also examine the surface on the camshaft which the thrust washer contacts. If this surface is scratched, but not severely scored, smooth it up with a fine oil stone.

Install Camshaft and Balance Shaft Gears

1. Note the letters stamped on the end of the camshaft which signify the engine models in which a camshaft may be used. The letters on the timing gear end of the camshaft must correspond with the engine model of the particular engine being assembled. Refer to the front of this manual for engine model identification.

2. Place the rear camshaft spacer over the timing gear end of the camshaft and install the Woodruff key.

3. Lubricate the thrust washer with clean engine oil and place the thrust washer over the gear end of the camshaft and the spacer.

©1972 General Motors Corp.



Fig. 2. - Installing Camshaft Gear

4. Start the camshaft gear over the end of the camshaft with the key in the shaft registering with the keyway in the gear.

5. Then, with the camshaft supported in an arbor press, place a sleeve on top of the gear and under the ram of the press. Bring the ram of the press down on the sleeve and press the gear tight against the spacer on the shaft (Fig. 2.).

6. Measure the clearance between the camshaft thrust washer and the camshaft. This clearance should be .008" to .015" when new parts are used. With used parts, a maximum clearance of .021" is allowable.

7. Install the gear retaining nut on the camshaft by hand. Tighten the nut after the shaft is installed .in the cylinder block.

8. Install the camshaft in the engine as outlined in Section 1.7.

© 1970 General Motors Corp.

IDLER GEAR AND BEARING ASSEMBLY

The engine idler gear and bearing assembly, located at the flywheel end of the engine, meshes with the camshaft and crankshaft gears and rotates on a stationary hub. The hub is secured directly to the cylinder block by a bolt which gasses through the hub and three bolts which pass through the flywheel housing, hub and end plate (Fig. 1.).

Two timing marks (a triangle within a circle) are stamped on the idler gear diametrically opposite (180°) to one another.

The inside diameter of the idler gear bearing is 2.186 "-2.187 " and the outside diameter of the idler gear hub is 2.1825 "-2.1835 ". Therefore, the clearance between the idler gear hub and the idler gear bearing -is .0025 " to .0045 ", with a maximum allowable wear limit of .007 ".

A thrust washer is provided on both sides of the idler gear and bearing assembly. The standard thickness of the idler gear and bearing assembly is 1.233 " to 1.234 " and the standard thickness of the two thrust washers is .236 " to .240 "; thus, the clearance between the thrust washers and the idler gear is .006" to .013", with a maximum allowable wear limit of .017".



Fig. 1. - Installing Idler Gear Hub

The idler gear is positioned on the right-hand side for a right-hand rotating engine as viewed from the rear. Refer to Fig. 6. under *General Description.*

Remove Idler Gear and Bearing Assembly (Flywheel Housing Removed)

1. Remove the idler gear outer thrust washer from the idler gear hub (Fig. 3.).

2. Slide the idler gear straight back off of the idler gear hub.

3. Remove the bolt which secures the idler gear hub to



Fig. 2. - Installing Idler Gear

©1972 General Motors Corp.



Fig. 3. - Idler Gear Details and Relative Location of Parts

the cylinder block. Then remove the idler gear hub and the idler gear inner thrust washer as an assembly.

Inspection

Wash the idler gear and bearing assembly, hub and thrust washers thoroughly in clean fuel oil and dry them with compressed air. Examine the gear teeth and bearing for scoring, pitting and wear. If the gear teeth are worn or the bearing is scored, pitted or worn excessively, replace the gear and bearing assembly or install a new bearing in the gear. Examine the outside diameter of the idler gear hub and thrust washers; if scored or worn excessively, replace them.

When a new bearing is installed in the idler gear, it must not protrude beyond the gear face on either side.

Install Idler Gear and Bearing Assembly

1. Place the inner thrust washer on the forward end of the idler gear hub with the flat in the inner diameter of the thrust washer over the flat on the end of the gear hub and with the oil grooves in the thrust washer facing the idler gear.

2. Place the small protruding end of the idler gear hub through the end plate and into the counterbore in the cylinder block.

3. Insert two 3/8" - 16 bolts through the idler gear hub and thread them into the cylinder block, as shown in Fig. 1., to be sure the bolt holes will be in alignment when the flywheel housing is installed.

4. Insert the 3/8 "-16x1-3/4 " special bolt through the center of the idler gear hub and thread it into the cylinder block. Tighten the bolt to 40-45 lb-ft torque. Then remove the two 3/8"-16 bolts previously installed for alignment of the gear hub.

5. Lubricate the idler gear hub and idler gear bearings liberally with clean engine oil.

6. Position the crankshaft gear and the camshaft gear - so that their timing marks will align with nose on the idler gear. Refer to Fig, 1. in Section 1.7.1.

7. With these timing marks in alignment, install the idler gear as shown in Fig. 2.

8. Apply a thin film of cup grease to the inner face (face with the oil grooves) of the outer idler gear thrust washer. Then place the thrust washer over the end of the idler gear hub with the oil grooves in the side of the thrust washer facing the idler gear and the flat in the inner diameter of the thrust washer over the flat on the end of the idler gear hub.

9. Check the backlash between the mating gears. The backlash should be .003 " to .005 " between new gears and should not exceed .007 " between used gears.

© 1972 General Motors Corp.

CRANKSHAFT TIMING GEAR

The crankshaft gear is keyed and pressed onto the crankshaft and drives the camshaft gear

through an idler gear. Refer to Fig, 2. under *General Description.*

Since camshaft gears, must be in time with the crankshaft gear, timing marks are located on the rim of the Idler gear with corresponding marks stamped on the crankshaft gear, and camshaft gears (6V engine). Refer to Section 1.7.1.

Remove Crankshaft Timing Gear

The crankshaft timing gear may be removed with the crankshaft in or out of the cylinder block.

1. Attach bar type puller J 4871 to the crankshaft gear with three long bolts or hooks, flat washers and nuts through the holes in the gear as shown in Fig. 1.

2. Turn the center screw of the puller to pull the crankshaft gear off the crankshaft.

Inspection

Wash the gear in clean fuel oil and inspect the teeth for wear, pitting or scoring. Replace the gear if worn



Fig. 1 - Removing Crankshaft Timing Gear With Puller J 4871



Fig. 2. - Installing Crankshaft Timing Gear With Installer J 7557

or damaged. Also, check the other gears in the gear train.

Install Crankshaft Timing Gear

1. If removed, install the Woodruff key in the keyway in the crankshaft.

2. Start the timing gear over the end of the crankshaft with the timing marks on the outer rim of the gear facing out and the keyway in the gear in alignment with the Woodruff key in the crankshaft.

3. Place a heavy hammer against the head of the bolt in the front end of the crankshaft. Place installer J 7557 against the rear face of the timing gear and drive the gear up against the shoulder on the crankshaft as shown in Fig. 2.

4. Check the gear backlash. The specified backlash is .003"-005" with new gears or a maximum of .008" with used gears.

© 1970 General Motors Corp.

BLOWER DRIVE GEAR AND SUPPORT ASSEMBLY

The blower drive gear is driven by the left-bank camshaft gear. The gear is keyed and pressed onto a shaft, which is supported in the blower drive support.

The blower drive support is mounted on the flywheel housing (Fig.).

Service the blower drive support as outlined in Section 2.7.1.1.



Fig..- Blower Drive Support Mounting on 6V-53 Engine

Remove lower Drive Support Assembly

1. Remove the blower and the blower drive shaft as outlined above.

2. Disconnect the lubricating oil tube (Fig. 1.) from the blower drive support.

© 1972 General Motors Corp.

ACCESSORY DRIVE

Accessory drives have been provided at the rear of the engines to accommodate both gear driven and belt driven accessories.

For the possible accessory drive locations and rotation of the drive at a particular position, refer to Fig. 1.

The drive for direct gear driven accessories, such as air compressors or hydraulic pumps, consists of a drive



Fig. 1. - Accessory Drive Locations (V.Engines)

© 1972 General Motors Corp. July, 1972



Fig 2. Air Compressor Drive

hub, coupling and drive plate (Fig.) or a spacer, drive plate, drive coupling and hub (Fig. 3.).

The drive plate and spacer. when used, are bolted to the camshaft 'gear. The accessory is bolted to the flywheel housing and driven by a drive hub keyed to the accessory shaft and splined to the coupling which is splined to the drive plate attached to the camshaft or balance shaft gear



Fig. 3. - Hydraulic Pump Drive

Remove Accessory Drive

Remove the direct gear driven type accessory drive ai follows:

1. Remove any external piping or connections to the accessory.

2. Remove the five bolts and lock washers attaching the accessory to the flywheel housing. Pull the accessory straight out from the flywheel housing

3. Remove the drive coupling.

4. Remove the drive hub from the accessory shaft. if necessary

5. `Place a clean, lintless cloth in the flywheel housing opening, underneath the accessory drive plate to prevent bolts from accidentally falling into the gear train. Remove the lock wires, if used. Then remove the four bolts (and lock washers, if used) and remove the accessory, the drive plate and the spacer, if used.

© 1972 General Motors Corp.

Inspection

Clean the accessory drive parts with clean fuel oil and dry them with compressed air. Examine the gear teeth of the drive shaft, drive coupling, drive hub or drive plate for wear. If worn excessively, replace them with new parts.

© 1972 General Motors Corp.

Install Accessory Drive

1. Remove old gasket material from the flywheel housing. Use care so that no gasket material falls into the gear train compartment.

2. Insert a clean, lintless cloth in the flywheel housing opening to prevent bolts from accidentally falling in the gear train. Align the bolt holes in the accessory drive plate and spacer (if used), or the accessory drive hub, with the tapped holes in the camshaft gear. Then secure the plate and spacer, or drive hub, with four bolts(Remove the cloth from the flywheel housing opening.

3. If a gear driven accessory is used as shown in Figs. 2. and 3., install the accessory drive coupling, then:

CAUTION: When replacing the drive hub on the accessory shaft, drive the hub squarely on the shaft (refer to Section 12.4).

a. Place a new gasket on the flange and align the holes in the gasket with the bolt holes in the flange. Use a light coat of grease to retain the gasket in position.

b. Place the accessory in position against the flywheel housing, rotating it, if necessary, to align the teeth of the accessory hub with those in the drive coupling. Secure the accessory to the flywheel housing with five bolts and lock washers.

© 1972 General Motors Corp.

ENGINE FRONT COVER (Upper)

The upper engine front cover is mounted against the cylinder block at the upper front end of the engine.
On a 6V engine, the crankcase is ventilated through a breather tube connected to the cover (Fig. 1). The camshaft oil seals ore pressed into the cover.

Remove Cover

When necessary, the oil seals may be removed without removing the upper front cover. This may be done by drilling diametrically opposite holes in the seal casing and threading metal screws, backed by flat washers, into the casing. Remove the seal by prying against the washers with pry bars. Install the new seals with installer J 9790.

If necessary, remove the engine cover as follows:

1. Remove the various parts and sub-assemblies from the engine as outlined in their respective sections of this manual.

2. Remove the pulleys from the front end of the camshafts · Refer to Section 1.7.2.

3. Remove the upper front cover-to-cylinder block attaching bolts.



Fig. 1. - 6V Engine Upper Front Cover Mounting

4. Tap the cover and dowel pin assembly away from the cylinder block.

5. Remove the Woodruff keys and oil seal spacers from the shafts.

6. Remove all traces of the old gasket material from the cylinder block and cover.

Inspection

Check the oil seals and the spacers for wear or damage. Replace them if necessary.

Remove, clean and reinstall the wire mesh pad (element) in the upper front cover.

Remove Oil Seals

1. Support the inner face of the cover on wood blocks at least one inch thick to protect the dowel pins in the cover.

2. Drive the oil seals out of the cover.

Install Oil Seals

1. Support the inner face of the cover on wood blocks.

2. If the outside diameter of the oil seal is not precoated with sealant, coat the bore in the cover with non-hardening sealant.

© 1972 General Motors Corp.

3. Position a new oil seal in the cover with the lip of the seal pointing toward the inner face of the cover.

CAUTION: Keep the lip of the oil seal clean and free from scratches.

4. Press the seal into the cover with installer J 9790 until the seal is flush with the bottom of the counterbore.

5. Install the second oil seal in the same manner.

6. Remove excess sealant from the cover and the seals.

Install Cover

1. Affix a new gasket to the cover.
2. Install the cover on the engine and secure it with bolts and lock washers. Tighten the bolts to 35 lb-ft torque.

3. Apply cup grease to the outside diameter of the oil seal spacers. Then slide them on the shafts.

4. Install a Woodruff key in each shaft.

5. Install the pulleys on the shafts.

6. Install and tighten the pulley retaining nuts to 300-325 lb-ft torque.

© 1972 General Motors Corp.

SHOP NOTES - TROUBLE SHOOTING - SPECIFICATIONS - SERVICE TOOLS

SHOP NOTES

TEFLON WRAPPED PIPE PLUGS

Pipe plugs can be hand wrapped satisfactorily with teflon tape to provide a better seal and facilitate plug removal. When a teflon wrapped plug is installed, it is extremely important that the specified torque not be exceeded.

Hand wrap a pipe plug with teflon tape as follows:

1. Be sure the pipe plug is thoroughly clean and dry prior to applying the teflon tape. All dirt, grease, oil and scale must be removed.

2. Start the tape one or two threads from the small or leading edge of the plug, joining the tape together with an overlap of approximately 1/8" .

3. Wrap the tape tightly in the same direction as you would turn a nut. The tape must conform to the configuration of the threads (be pressed into the minor diameter of the threads) without cutting or ripping the tape.

4. Hand tighten and hand torque the pipe plug and do not exceed the specified torque. Do not use power tools.

CHECKING BEARING CLEARANCES

A strip of soft plastic squeezed between the crankshaft journal and the connecting rod bearing or main bearing may be used to measure the bearing clearances.

The strip is a specially molded, plastic "wire" manufactured commercially and is available in three sizes and colors. Type PG-1 (green) has a clearance range of .001" to .003", type PR-1 (red) has a range of .002" to .006" and type PB-1 (blue) has a range of .004" to .009".
The plastic strip may be used for checking the bearing clearances as follows:

1. Remove the bearing cap and wipe the oil from the bearing shell and the crankshaft journal.

> **NOTE: When checking the main) bearing clearances with the engine in a position where the main bearing caps are supporting the weight of the crankshaft and the flywheel, an erroneous reading, due to the weight of the crankshaft and flywheel, can be eliminated by supporting the weight of the crankshaft with a jack under the counterweight adjoining the bearing being checked.**

2. Place a piece of the plastic strip the full width of the bearing shell about ¼" off center (Fig. 1)



Fig. 1. - Using Plastic Strip to Measure Bearing-to-Crankshaft Clearance

© 1972 General Motors Corp.

3. Rotate the crankshaft about 30° from bottom dead center and reinstall the bearing cap. Tighten the bolts to the specified torque.

4. Remove the bearing cap. The flattened plastic strip will be found adhering to either the bearing shell or the crankshaft.

5. the width of the flattened plastic strip at its widest point with the graduations on the envelope (Fig. 1.). The number within the graduation on the envelope indicates the bearing clearance in thousandths of an inch. Taper may be indicated when one end of the flattened plastic strip is wider than the other. Measure each end of the plastic; the difference between the readings is the approximate amount of taper.

CAMSHAFT CUP PLUG INSTALLATION

When an oil leak occurs at the drive plug area in the front end of the camshaft, install a cup plug in the end of the camshaft rather than removing and replacing the drive plug.

> **NOTE: It is not necessary to remove the camshaft from the engine when installing the cup plug.**

Install the cup plug as follows:

1. Clean the hole in the front end of the camshaft and apply Permatex No. 1 sealant, or equivalent, to the outer diameter of the cup plug.

2. Install the plug to a depth of .180" -210" with tool J 24094.

© 1972 General Motors Corp.

TROUBLE SHOOTING


EXHAUST VALVE
Probable Causes
1. STICKING VALVE
2. IMPROPER VALVE SEATING
3. VALVE SEAT PITTED OR OVER HEATED
4. BENT VALVE
5. BROKEN VALVE
6. EXCESSIVE VALVE-TO-GUIDE CLEARANCE
7. CARBON DEPOSITS ON VALVE HEAD
8. VARNISH DEPOSITS ON VALVE STEM
9. SCORED OR SCUFFED VALVE STEM
10. ALL VALVES BENT
11. OIL RUNNING DOWN VALVE STEM

SUGGESTED REMEDY

1. Check for carbon deposits, bent guide, defective spring or antifreeze (glycol) in the lubricating oil. Replace a bent guide. Clean-up and reface the valve. Replace the valve if necessary.

2. Check for excessive valve-to-guide clearance, bent guide or carbon deposits. Replace a bent or worn guide. Clean the carbon from the valve. Reface or replace the valve, if necessary.

3. Check the operating conditions such as engine overload, inadequate cooling or improper timing. Reface the valve and insert. Replace the valve if warped or too badly pitted. Use a harder-face valve if operating conditions warrant.

4. Check for contact between the valve head and the piston as a result of incorrect valve lash, exhaust valve bridge improperly positioned or a defective spring.
Check the valve guide, insert, cylinder head and piston for damage. Replace damaged parts.

5. Check for excessive valve-to-guide clearance, defective spring or etching of the valve stem at the weld. Improper valve lash is also a cause of this type failure. Check the guide, insert, cylinder head and piston for damage. Replace damaged parts.

6. Replace worn valve guide. Check and replace the valve, if necessary.

7. Black carbon deposits extending from the valve seat to the guide indicate cold operation due to light loads or the use of low volatility fuel. Rusty brown valve head with carbon deposits forming narrow collars near guide indicate hot operation due to overloads, inadequate cooling or improper timing which results in carbonization of lubricating oil. Clean-up valves, guides and inserts. Reface valves and inserts; replace if warped, pitted or scored.

8. Check for worn guides or excessive exhaust back pressure. Replace worn guides. Check valve seat for improper seating. Reface the valve and insert or, if necessary, replace.

9. Check for bent valve stem or guide, metal chips or dirt or for lack of lubrication. Clean up valve stem with crocus cloth wet with fuel oil or replace the valve. Replace the guide. When installing the valve, use care in depressing the spring so spring cap DOES NOT scrape the valve stem.

10. Check the gear train timing or for gear train failure.

11. Check the operation of the engine for excessive idling and resultant low engine exhaust back pressure. Install valve guide oil seals.

© 1972 General Motors Corp.

SPECIFICATIONS

Specifications, clearances and wear limits are listed below. It should be specifically noted that the clearances apply only when all new parts are used at the point where the various specifications apply. This also applies to references within the text of the manual. The column entitled "Limits" in this chart lists the amount of wear or increase in clearance which can be tolerated in used engine parts and still ensure satisfactory performance. It should be emphasized that the figures given as "Limits" must be qualified by the judgement of personnel responsible for installing new parts. These wear limits are, in general, listed only for the parts more frequently replaced in engine overhaul work. For additional information, refer to the text.

TABLE OF SPECIFICATIONS, NEW CLEARANCES AND WEAR LIMITS

These limits also' apply to oversize and undersize parts

ENGINE PARTS (Standard Size, New)	MINIMUM	MAXIMUM	LIMITS
Cylinder Block			
Block bore:			
Diameter (top)	4.5195"	4.5215"	4.5235"
Diameter (center)	4.4865"	4.4880"	4.4900"
Diameter (bottom)	4.3565"	4.3575"	4.3595"
Out-of-round		.0015"	
Taper		.0015"	
Cylinder liner counterbore:			
Diameter	4.8200"	4.8350"	
Depth	.3000"	.3020"	
Main bearing bore:			
Inside diameter (vertical axis, V-tpe engine)	3.7510"	3.7520"	
Top surface of block:			
Flatness--transverse (all)			.0030"
Flatness--longitudinal (6 cyl.)			.0060"
Depth of counterbores (top surface):			
Cylinder head seal strip groove	.0970"	.1070"	
Water holes	.1090"	.1150"	
Oil holes	.0920"	0980"	
Cylinder Liner			
Outside diameter (upper seal ring surface)	4.4850"	4.4860"	
Outside diameter (lower seal ring surface)	4.3550"	4.3560"	
Inside diameter	3.8752"	3.8767"	
Out-of-round (inside diameter)		.0020"	.0030"
Taper (inside diameter)		.0010"	.0020"
Depth of flange BELOW block	.0465"	.0500"	.0500"
Variation in depth between adjacent liners		.0015"	.0015"

© 1972 General Motors Corp.

ENGINE PARTS (Standard Size, New)	MINIMUM	MAXIMUM	LIMITS
Pistons and Rings			
Piston:			
Diameter (at skirt):			
Non-turbocharged engines	3.8699"	3.8721"	
Clearance--piston skirt-to-liner:			
Non-turbocharged engines	.0031"	.0068"	.0100"
Out-of-round		.0005"	
Taper		.0005"	
Inside diameter--piston pin bushing	1.3775"	1.3780"	
Compression rings:			
Gap (chrome ring)	.0200.	.0460"	.0600"
Clearance--ring-to-groove:			
Top (No. 1)	.0030"	.0060"	.0120"
No. 2	.0070"	.0100"	.0140"
No. 3 and 4 (21:1 ratio piston)	.0045"	.0070"	.0120"
Oil control rings:			
Gap	.0100"	.0250"	.0440"
Clearance--ring-to-groove	.0015"	0055"	0080"
Piston Pins			
Diameter	1.3746"	1.3750"	
Clearance--pin-to-piston bushing	.0025"	.0034"	.0100"
Clearance--pin-to-conn. rod bushing	.0010"	.0019"	.0100"
Connecting Rod			
Length--center-to-center	8.7990"	8.8010"	
Inside diameter (upper bushing)	1.3760"	1.3765"	
Normal side clearance (v-type engine)	.0080"	.0160"	
Crankshaft			
Journal diameter--main bearing (V-engine)	3.4990"	3.5000"	
Journal diameter--Conn. rod bearing (V-engine)	2.7490"	2.7500"	
Journal out-of-round		.00025"	
Journal taper		.0005"	.0030"
§Runout on journals--total indicator reading:			

Crankshaft for 6V-53 supported on No. 1 and No. 4 journals; runout measured at No. 2 and No. 3 journals.

When the runout on adjacent journals is in the opposite direction, the sum must not exceed .003" total indicator reading. When in the same direction, the difference must not exceed .003"-total indicator reading. When high spots of runout on adjacent journals are at right angles to each other, the sum must not exceed .004 " total indicator reading, or .002" on each journal.

© 1972 General Motors Corp.

ENGINE PARTS (Standard Size, New)	MINIMUM	MAXIMUM	LIMITS
Thrust washer thickness	.1190"	.1220"	
End play (end thrust clearance)	.0040"	.0110"	.0180"
Connecting Rod Bearing			
Inside diameter (vertical axis. V-type engine)	2.7511"	2.7531"	
Bearing-to-journal clearance (V-type engine)	.0011"	.0041"	.0060"
Bearing thickness 90° from parting line (V-engine)	.1247"	.1252"	.1230"
Bearing thickness 90° from parting line (V-engine)	.1240"	.1245"	.1230"
Main Bearings			
Inside diameter (vertical axis, V-type engines)	3.5030"	3.5040"	
Bearing-to-journal clearance (V-type engine)	.0010"	.0040"	.0060"
Camshaft			
Diameter (at bearing journals)	2.1820"	2.1825"	
Runout at center bearing (when mounted on end bearings)		.0020"	
End thrust	.0050"	.0150"	.0190"
Thrust washer thickness	.2080"	.2100"	
Balance Shaft			
Diameter (at bearing journals)	2.1820"	2.1825"	
End thrust	.0050"	.0150"	.0190"
Thrust washer thickness	.2080"	.2100"	
Camshaft Bearings			
Inside diameter	2.1870"	2.1880"	
Clearance--bearing-to-shaft	.0045"	.0060"	.0080"
Camshaft Gears			
Backlash	.0030"	.0050"	.0070"
Idler Gear			
Backlash	.0030"	.0050"	.0070"
Idler gear bearing inside diameter	2.1860"	2.1870"	
Idler gear hub outside diameter	2.1825"	2.1835"	
Clearance--bearing-to-hub	.0025"	.0045"	.0070"
End play	.0060"	.0130"	.0170"
Thrust washer thickness	.1180"	.1200"	
Crankshaft Timing Gear			
Backlash	.0030"	.0050"	.0070"
Blower Drive Gear			
Backlash	.0030"	.0050"	.0070"

© 1972 General Motors Corp.

ENGINE PARTS (Standard Size, New)	MINIMUM	MAXIMUM	LIMITS
Thrust washer thickness (6V-53)	.0930"	.1030"	
End play (blower drive gear shaft)	.0040"	.0060"	
Governor Drive Gear			
Backlash	.0030"	.0050"	.0070"
Cylinder Head			
Cam follower bore.	1.0626"	1.0636"	
Exhaust valve insert counterbore:			
Diameter (4-valve head)	1.1590"	1.1600"	
Exhaust Valve Seat Inserts			
Outside diameter	1.1605"	1.1615"	
Seat width	3/64"	5/64"	5/64"
Valve seat runout		.0020"	.0020"
EXhaust Valves			
Stem diameter	.2480	.2488"	
Valve head-to-cylinder head:			
Current 4-valve head	flush	.024" recess.	.039" recess.
Valve Guide			
Distance below top of head (machined for seal)	.150	.180	
Diameter--inside (4-valve)	.2505"	.2515"	
Clearance--Valve-to-guide	.0017"	.0035"	.0050"
Rocker Arms and Shafts			
Diameter--rocker shaft	.8735"	.8740"	
Diameter--inside (rocker arm bushing)	.8750"	.8760"	
Diameter--inside (valve rocker arm bore)	.8753"	.8763"	
Clearance--shaft-to-injector rocker bushing	.0010"	.0025"	.0040"
Clearance--shaft-to-valve rocker bore	.0013"	.0028"	.0040"
Cam Followers			
Diameter	1.0600	1.0610"	
Clearance--follower-to-current head	0016"	.0036"	.0060"
Rollers and pins:			
Clearance--pin-to-bushing	.0013"	00021"	.010" Horiz.
Side clearance--roller-to-follower	.0150"	.0230"	.0230"

© 1972 General Motors Corp.

STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

THREAD SIZE	TORQUE (lb-ft)	THREAD SIZE	TORQUE (lb-ft)
1/4 -20	7-9	9/16-12	90-100
1/4 -28	8-10	9/16-18	107-117
5/16-18	13-17	5/8 -11	137-147
5/16-24	15-19	5/8 -18	168-178
3/8 -16	30-35	3/4 -10	240-250
3/8 *-24	35-39	3/4 -16	290-300
7/16-14	46-50	7/8 - 9	410-420
7/16-20	57-61	7/8 -14	475-485
1/2 -13	71-75	1- 8	580-590
1/2 -20	83-93	1-14	685-695

EXCEPTIONS TO STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

APPLICATION	THREAD SIZE	TORQUE (lb-ft)
Injector control shaft bracket bolts	1/4 -20	10-12
Cam follower guide bolts	1/4 -20	12-15
Governor to flywheel housing bolts	5/16-18	10-12
Idler gear hub and spacer bolts	5/16-18	19-23
Idler gear hub and spacer bolts	3/8 -16	40-45
Injector clamp bolt	3/8 -16	20-25
Air box cover bolts (6V engine - 3/8" thick clamp)	3/8 -16	10-15
Flywheel housing bolts	3/8 -16	25-30
Flywheel housing bolts	3/8 -24	25-30
Connecting rod nuts (, V-engine)	3/8 -24	4045
Fuel line nuts	3/8 -24	12-15
Fuel connector	3/8 -24	20-28
Rocker arm bracket bolts	7/16-14	50-55
*Flywheel bolts	1/2 -20	110-120
*Main bearing cap bolts	1/9/16-1 2	120-130
*Cylinder head bolts	5/811	170-180
Flange mounted air compressor drive shaft nut	3/4-10	§
Crankshaft end bolt (6V engine)	3/4-16	290-300
Camshaft nut	1-1/8 -18	300-325

*Lubricate at assembly with International Compound No. 2, or equivalent.
§100 lb-ft plus increase torque to line-up cotter pin.

©1972 General Motors Corp.

STANDARD PIPE PLUG TORQUE SPECIFICATIONS

Use sealing compound on plugs without gaskets or Teflon. These specifications apply to plugs installed below the surface of the part of which they are a component.

THREAD SIZE	TORQUE (lb-ft)	THREAD SIZE	TORQUE (lb-ft)
1/8	0-12	3/4	33-37
1/4	14-16	1	7585
3/8	18-22	1-1/4	95-105
1/2	23-27	1-1/2	11130

SERVICE TOOLS

TOOL NAME	TOOL NO.
Cylinder Block	
Bore gage	J 5347
Dial bore gage master setting fixture	J 23059
Dial indicator set	J 22273
Engine overhaul stand	J 6837-01
Adaptor plate (6v)	J 8683
Cylinder Head	
Brush	J 8152
Cam follower holding fixture	J 5840
Cylinder head guides (set of 2)	J 9665
Cylinder head lifter	J 22062-01
Dial gage	J 8165-2
Grinder	J 8165-1
Grinding wheel (15' 4 - valve head)	J 7792-2
Grinding wheel (30' 4 - valve head)	J 7792-3
Grinding wheel (60' 4 - valve head)	J 7792-4
Pilot (4 - valve head)	J 7792-1
Push rod remover (set of three)	J 3092-01
Socket	J 8932-01
Spring tester	J 9666
Valve guide cleaner	J 7793
Valve guide installer	J 24519

© 1972 General Motors Corp.

TOOL NAME	TOOL NO.
Valve guide remover	J 7775
Valve spring checking gage	WRE 500-60
Valve spring compressor	J 7455
Valve seat insert installer	J 7790
Valve seat insert remover	J 7774
Crankshaft	
Camshaft oil seal installer	J 21899
Crankshaft front oil seal installer	J 22153
Crankshaft front oil seal sleeve installer	J 22524
Crankshaft pulley remover	J 5356
Crankshaft rear oil seal (O.S.) expander	J 21278
Crankshaft rear oil seal sleeve installer	J 21277
Handle	J 3154-1
Micrometer ball attachment	J 4757
Oil seal expander	J 9769
Oil seal expander	J 7454
Oil seal installer	J 9479
Installer (part of J 9479)	J 9479-1
Stud (2) (part of J 9479)	J 9479-2
Oil seal installer	J 9727
Oil seal installer	J 9783
Puller	J 4794-01
Flywheel	
Flywheel lifting tool	J 6361-01
Oil seal installer	J J9727
Oil seal installer	J 9783
Puller	J 4794-01
Flywheel	
Flywheel lifting tool	J 6361-01
Flywheel Housing	
Crankshaft rear oil seal expander (O.S. seal)	J 21278
Crankshaft rear oil seal expander (Std. size seal)	J 9769
Dial indicator	J 8001-3
Dial indicator post	J 9748
Flywheel housing aligning studs (set of 2)	J 7540
Flywheel housing concentricity gage	J 9737

© 1972 General Motors Corp.

TOOL NAME	TOOL NO.
Piston, Connecting Rod and-Cylinder Liner	
Adaptor sleeve	J 7608-5
Bore gage	J 5347
Connecting rod bushing reamer	J 4971-4
Connecting rod bushing reamer set	J 7608-01
Connecting rod holder	J 7632
Cylinder hone set (2 1/2" to 5 3/4" range)	J 5902-01
Cylinder liner remover set	J 22490
Dial bore gage master setting fixture	J 23059
Dial indicator set	J 22273
Driver handle	J 1513-2
Feeler gage pack (part of J 5438)	J 3174-01
Fixture and arbor assembly	J 7608-4
Guide	J 1686-5
Guide	J 4970-5
Guide	J 4971-6
Hold down clamp	J 21793
Master ring - cylinder liner	J 8385
Micrometer ball attachment	J 4757
Piston and connecting rod bushing installer and remover set	J 1513-02
Piston bushing reamer	J 4970-4
Piston bushing reaming fixture	J 5273
Piston bushing spacer	J 7587-1
Piston holding fixture	J 1513-1
Piston pin bushing installer	J 4972-2
Piston pin bushing remover	J 49724
Piston pin retainer installer	J 4895-01
Piston ring compressor	J 6883
Piston ring remover and installer	J 8128
Piston-to-liner feeler gage set	J 5438
Spacer	J 7608-3
Spray nozzle remover	J 8995
Spring scale (part of J 5438)	J 8129
Stone (120 grit)	J 5902-14
Camshaft	
Adaptor	J 8183
Bar type puller	J 4871
Camshaft and balance shaft bearing remover and installer set	J 7593-03
Camshaft cup plug installer	J 24094
Camshaft oil seal installer	J 21899
Crankshaft timing gear installer	J 7557
Installer	J 9790
Slide hammer	J 6471-1
Spring scale	J 8129

©1972 General Motors Corp..

SECTION 2

FUEL SYSTEM AND GOVERNORS

CONTENTS

Fuel System	2
Fuel Injector (Needle Valve)	2.1.1
Fuel Injector Tube	2.2
Fuel Pump	2.2
Fuel Strainer and Fuel Filter	2.3
Mechanical Governors	2.7
Variable Speed Mechanical Governor (6V Engine)	2.7.2.1
Shop Notes - Trouble Shooting - Specifications - Service Tools	2.0

FUEL SYSTEM

The fuel system illustrated in Fig 1. includes the following: injectors, fuel pipes (inlet and outlet), fuel manifolds (integral with the cylinder head), fuel pump, fuel strainer, fuel filter and fuel lines.

A restricted fitting is located in the cylinder head fuel return manifold outlet to maintain pressure in the fuel system. On the V-type engine this restricted fitting is located at the rear of the left bank cylinder head.

Fuel is drawn from the supply tank through the fuel strainer and enters the fuel pump at the inlet side. Leaving the pump under pressure, the fuel is forced through the fuel filter and into the upper fuel manifold, then through fuel pipes into the inlet side of the injectors. The fuel manifolds are identified by the words IN (top passage) and OUT (bottom passage) and are cast in several places in the side of the head. This aids in the installation of the fuel manifold inlet and outlet lines. Surplus fuel returns from the outlet side of the injectors through outlet fuel pipes into the return manifold and then back to the fuel tank.

© 1972 General Motors Corp.



Fig. 2. - Fuel System for 6V-53 Engines

© 1972 General Motors Corp.

FUEL INJECTOR (NEEDLE VALVE)

The fuel injector (Fig 1.) is a lightweight compact unit which enables quick. easy starting directly on diesel fuel and permits the use of a simple open type combustion chamber. The simplicity of design and operation provides for simplified controls and easy adjustment. No high pressure fuel lines or complicated air-fuel mixing or vaporizing devices are required.

The fuel injector performs four functions:

1. Creates the high fuel pressure required for efficient infection.

2. Meters and injects the exact amount of fuel required to handle the load.

3. Atomizes the fuel for mixing with the air in the combustion chamber.

4. Permits continuous fuel flow.

Combustion required for satisfactory engine operation Is obtained by injecting under pressure, a small



Fig. 1. - Fuel Injector Assembly



Fig. 2. - Fuel Metering from No-Load to Full Load

quantity of accurately metered and finely atomized fuel oil into the cylinder.

Metering of the fuel is accomplished by an upper and lower helix machined in the lower end of the injector plunger. Figure 2 illustrates the fuel metering from no-load to full-load by rotation of the plunger in the bushing.

Figure 3 illustrates the phases of injector operation by the vertical travel of the injector plunger.

The continuous fuel flow through the injector serves, in addition to preventing air pockets in the fuel system, as a coolant for those injector parts subjected to high combustion temperatures.

To vary the power output of the engine, injectors having different fuel output capacities are used. The fuel output of the various injectors is governed by the



Fig. 3.-· Phases of Injector Operation Through Vertical Travel of Plunger

© 1972 General Motors Corp. July, 1972

helix angle of the plunger and the type of spray tip used. Refer to Fig. 4. for the identification of the injectors and their respective plungers and spray tips.

Each fuel injector has a circular disc pressed into a recess at the front side of the injector body for identification purposes (Fig. 4.). The identification tag indicates the nominal output of the injector in cubic millimeters. A horizontal bar on the injector identification tag between the "GM" and the injector size identifies the needle valve injector



Fig. 4.-· Injector Identification Chart

Each injector control rack (Fig. 1.) is actuated by a lever on the injector control tube which, in turn, is connected to the governor by means of a fuel rod. These levers can be adjusted independently on the control tube, thus permitting a uniform setting of all injector racks.

The fuel injector combines in a single unit all of the parts necessary to provide complete and independent fuel injection at each cylinder.



Fig. 5. - Injector Assembly

© 1972 General Motors Corp.

Operation

Fuel, under pressure, enters the injector at the inlet side through a filter cap and filter (Fig. 1.). From the filter, the fuel passes through a drilled passage into the supply chamber, that area between the plunger bushing and the spill deflector, in addition to that area under the injector plunger within the bushing. The plunger operates up and down in the bushing, the bore of which is open to the fuel supply in the annular chamber by two funnel-shaped ports in the plunger bushing.

The motion of the injector rocker arm is transmitted to the plunger by the follower which bears against the follower spring (Fig. 6.) In addition to the reciprocating motion. the plunger can be rotated, during operation. around its axis by the gear which meshes with the control rack. For metering the fuel, an upper helix and a lower helix are machined in the lower part of the plunger. The relation of the helices to the two ports changes with the rotation of the plunger.

As the plunger moves downward, under pressure of the injector rocker arm, a portion of that fuel trapped under the plunger is displaced into the supply chamber



1. Injector Assembly
3. Pin--Dowel
24. Rack--Injector Control
36. Clamp--Injector
38. Washer
39. Bolt
40. Tube--Injector Hole
47. Shaft--Balance
48. Camshaft
49. Cam Follower Assy.
52. Rod--Push
56. Arm--Injector Rocker
59. Tube--Injector Control
60. Lever--Rack Control
62. Head--Cylinder
68. Pipe--Fuel Inlet (Supply)
69. Pipe--Fuel Outlet (Return)

Fig. 6. - Fuel Injector Mounting

through the lower port until the port is closed off by the lower end of the plunger. A portion of the fuel trapped below the plunger is then forced up through a central passage in the plunger into the fuel metering recess and into the supply chamber through the upper port until that port is closed off by the upper helix of the plunger. With the upper and lower ports both closed off, the remaining fuel under the plunger is subjected to increased pressure by the continued downward movement of the plunger.

When sufficient pressure is built up, it opens the flat, non-return check valve. The fuel in the check valve cage, spring cage, tip passages and tip fuel cavity is compressed until the pressure force acting upward on the needle valve is sufficient to open the valve against the downward force of the valve spring. As soon as the needle valve lifts off of its seat, the fuel is forced through the small orifices in the spray tip and atomized into the combustion chamber.

When the lower land of the plunger uncovers the lower port in the bushing, the fuel pressure below the plunger is relieved and the valve spring closes the needle valve, ending injection.

A pressure relief passage has been provided in the spring cage to permit bleed-off of fuel leaking past the needle pilot in the tip assembly.

A check valve, directly below the bushing, prevents leakage from the combustion chamber into the fuel



Fig 7. - Removing Injector from Cylinder Head

© 1972 General Motors Corp.



Fig. 8. - Checking Rack and Plunger for Free Movement

injector in case the valve is accidentally held open by a small particle of dirt. The injector plunger is then returned to its original position by the injector follower spring. Figure 3 shows the various phases of injector operation by the vertical travel of the injector plunger.

On the return upward movement of the plunger, the high pressure cylinder within the bushing is again filled with fuel oil through the ports. The constant circulation of fresh cool fuel through the injector renews the fuel supply in the chamber, helps cool the injector and also effectively removes all traces of air which might otherwise accumulate in the system and interfere with accurate metering of the fuel.

The fuel injector outlet opening, through which the excess fuel oil returns to the fuel return manifold and then back to the fuel tank, is directly adjacent to the inlet opening.

Changing the position of the helices, by rotating the plunger, retards or advances the closing of the ports and the beginning and ending of the injection period. At the same time, it increases or decreases the amount of fuel injected into the cylinder. Figure 2 shows the various plunger positions from no-load to full-load. With the control rack pulled out all the way (no injection), the upper port is not closed by the helix until after the lower port is uncovered. Consequently, with the rack in this position, all of the fuel is forced back into the supply chamber and no injection of fuel takes place. With the control rack pushed all the way in (full injection), the upper port is closed shortly after the lower port has been covered, thus producing a maximum effective stroke and maximum injection. From this no injection position to full injection position (full rack movement), the contour of the upper helix advances the closing of the ports and the beginning of injection.

General Instructions for Injector Care and Overhaul

The fuel injector is one of the most important and precisely built parts of the engine. The injection of the correct amount of fuel into the combustion chamber at exactly the right time depends upon this unit. Because the injector operates against high compression pressure in the combustion chamber, efficient operation demands that the injector assembly is maintained in first-class condition at all times. Proper maintenance of the fuel system and the use of the recommended type fuel filters and clean water-free fuel are the keys to trouble-free operation of the injectors.

Due to the close tolerances of various injector parts. extreme cleanliness and strict adherence to service instructions is required.

Perform all injector repairs in a clean, well lighted room with a dust free atmosphere. An ideal injector room is slightly pressurized by means of an electric fan which draws air into the room through a filter. This pressure prevents particles of dirt and dust from entering the room through the doors and windows. A suitable air outlet will remove solvent fumes along



Fig. 9. - Injector High Pressure Test

© 1972 General Motors Corp.

with the outgoing air. Also provide a source for 110 volt alternating current electric power.

Provide the injector repair room with a supply of filtered, moisture-proof compressed air for drying the injector parts after they have been cleaned. Use wash pans of rust-proof material and deep enough to permit all of the injector parts to be completely covered by the cleaning agent, usually clean fuel oil, when submerged in wire baskets of 16 mesh wire screen. Use baskets which will support the parts so as to avoid contact with the dirt which settles at the bottom of the pans.

Rags should never be used for cleaning injector parts since lint or other particles will clog parts of the injector when it is assembled. A lint-free cleaning tissue is a good, inexpensive material for wiping injector parts.

When servicing an injector, follow the general instructions outlined below:

1. Whenever the fuel pipes are removed from an Injector, cover the filter caps with shipping caps to keep dirt out of the injectors. Also protect the fuel pipes and fuel connectors from the entry of dirt or other foreign material.

2. After an injector has been operated in an engine, do not remove the filter caps or filters while the injector is



Fig. 10. - Spray Pattern Test

Fuel Injector 2.1.1 in the engine. Replace the filters only at the time of complete disassembly and assembly of an injector.

NOTE: In the offset injector, a filter is used in the inlet side only. No filter is required on the outlet side (Fig. 34).

3. Whenever an injector has been removed and reinstalled or replaced in an engine, make the following adjustments as outlined in Section 14:

a. Time the injector.
b. Position the injector control rack.

4. Whenever an engine is to be out of service for an extended period, purge the fuel system, then fill it with a good grade of rust preventive (refer to Section 15.3).

5. When a reconditioned injector is to be placed in stock, fill it with injector test oil J 8130. *Do not use fuel oil*. Install shipping caps on both filter caps immediately after filling. Store the injector in an upright position to prevent test oil leakage.

NOTE: Make sure that new filters have been installed in a reconditioned injector which is to be placed in stock. This precaution will prevent dirt particles from entering the injector due to a possible reversal of fuel flow when installing the injector in an engine other than the original unit.

Remove Injector

1. Clean and remove the valve rocker cover.

2. Remove the fuel pipes from both the injector and the fuel connectors (Fig. 6.).

NOTE: Immediately after removal of the fuel.



Fig. 11.-- Removing Injector Follower Stop Pin

© 1972 General Motors Corp.

pipes from an injector, cover the filter caps with shipping caps to prevent dirt from entering the injector. Also protect the fuel pipes and fuel connectors from entry of dirt or foreign material.

3. Crank the engine to bring the outer ends of the push rods of the injector and valve rocker arms in line horizontally.

4. Remove the two rocker shaft bracket bolts and swing the rocker arms away from the injector and valves (Fig. 7).

5. Remove the injector clamp bolt, special washer and clamp.

6. Loosen the inner and outer adjusting screws on the injector rack control lever and slide the lever away from the injector.

7. Lift the injector from its seat in the cylinder head (Fig. 7.).

8. Cover the injector hole in the cylinder head to keep foreign material out.

9. Clean the exterior of the injector with clean fuel oil and dry it with compressed air.


Advanced stage of erosion caused by foreign matter in fuel due to improper filtration.
Chipped at lower helix.
The above condition can be caused by either lack of fuel at high speeds or water in fuel.

Fig. 12. - Unusable Plungers

Test Injector

If inspection does not reveal any external damage, then perform a series of tests to determine the condition of the injector to avoid unnecessary overhauling.

An injector that passes all of the tests outlined below may be considered to be satisfactory for service without disassembly, except for the visual check of the plunger.

However, an injector that fails to pass one or more of the tests is unsatisfactory. Perform all of the tests before disassembling an injector to correct any one condition.

Identify each injector and record the pressure drop and fuel output as indicated by the following tests:

INJECTOR CONTROL RACK AND PLUNGER MOVEMENT TEST

Place the injector in the injector fixture and rack freeness tester J 22396. Refer to Fig. 8. and place the handle on top of the injector follower.

If necessary, adjust the contact screw in the handle to ensure the contact screw is at the center of the follower when the follower spring is compressed.



Fig. 13.-· Installing Injector Valve Parts on Auxiliary Tester J 22640

© 1972 General Motors Corp.

With the injector control rack held in the no-fuel position, push the handle down and depress the follower to the bottom of its stroke. Then very slowly release the pressure on the handle while moving the control rack up and down as shown in Fig. 8. until the follower reaches the top of its travel. If the rack does not fall freely, loosen the injector nut, turn the tip, then retighten the nut. Loosen and retighten the nut a couple of times if necessary. Generally this will free the rack. Then, if the rack isn't free, change the injector nut. In some cases it may be necessary to disassemble the injector to eliminate the cause of the misaligned parts.

INJECTOR HIGH PRESSURE TEST

This test is performed to discover any fuel leaks at the injector filter cap gaskets, body plugs and nut seal ring. The high pressure test also indicates whether or not the plunger and bushing clearance is satisfactory.

1. Install the injector in tester J 9787.

> **CAUTION: When testing an injector just removed from an engine, the flow of fuel through the injector on the tester should be the same as in the engine. Connections on the test head of the tester may be changed to obtain the correct direction of flow.**

2. Thoroughly dry the injector with compressed air.

3. Check the fuel connections for leaks. If leaks have occurred, tighten the connections, dry the injector and recheck.

4. With the injector rack in the full-fuel position and the injector tester handle locked in position by means of the handle lock (Fig. 9.), operate the pump handle to build up and maintain the pressure.

At this time, the condition of the plunger and bushing may be established. If there is excessive clearance between the plunger and bushing, pressure beyond the normal valve opening pressure cannot be obtained.

Replacement of the plunger and bushing assembly is then required.

Pump up the injector tester and maintain a pressure of 1600 to 2000 psi by actuating the pump handle. Then inspect for leaks at the injector filter cap gaskets, body plugs and injector nut seal ring. If any of these conditions exist, refer to Trouble Shooting Chart 5 in Section 2.0.

> **NOTE: It is normal for fuel to seep out around the rack due to high pressure fuel being applied (C 1972 General Motors Corp.**

to a normally low pressure area in the injector assembly. However, fuel droplets at the rack indicate excessive leakage.

> **CAUTION: Do not permit the pressure in the injector tester to equal or exceed the capacity of the pressure gage.**

INJECTOR VALVE HOLDING PRESSURE TEST

The injector valve holding pressure test will determine whether the various lapped surfaces in the injector are sealing properly.

Operate the pump handle to bring the pressure up to approximately 450 psi.

Close the fuel shut-off valve and note the pressure drop. The time for a pressure drop from 450 psi to 250 psi must not be less than 40 seconds. If the pressure drop is less than 40 seconds, check the injector as follows:

1. Thoroughly dry the injector with compressed air.

2. Open the tester fuel valve and operate the pump handle to maintain the test pressure.

3. A leak around the spray tip or seal ring usually is caused by a loose injector nut, a damaged seal ring or a brinelled surface on the injector nut or spray tip.

4. A leak at the filter cap indicates a loose filter cap or a damaged filter cap gasket.

5. A "dribble" at the spray tip orifices indicates a leaking valve assembly due to a damaged surface or dirt. Leakage at the tip will cause pre-ignition in the engine.

> **NOTE: A drop or two of fuel at the spray tip is only an indication of the fuel trapped in the spray tip at the beginning of the test and is not detrimental as long as the pressure drop specified is not less than 40 seconds.**

SPRAY PATTERN TEST

After completing the valve holding pressure test, open the fuel shut-off valve, place the injector rack in the full-fuel position and operate the injector several times in succession by operating the tester handle at approximately 40 strokes per minute as shown in Fig. 10. Observe the spray pattern to see that all spray orifices are open and injecting evenly. The beginning and ending of injection should be sharp and the fuel injected should be finely atomized.



Fig. 14. - Injector Needle Valve Test with Auxiliary Tester J 22640

If all of the spray tip orifices are not open and injecting evenly, clean them during injector overhaul. Also refer to *Trouble Shooting Chart 6* in Section 2.0.



Fig. 15. - Checking Needle Valve Lift

CAUTION: To prevent damage to the pressure gage, do not exceed 100 psi during this test.

VISUAL INSPECTION OF PLUNGER

An injector which passes all of the previous tests should have the plunger checked visually, under a magnifying glass, for excessive wear or a possible chip on the bottom helix. There is a small area on the



Fig. 16. - Position of Fuel Flow Pipes In Comparator

1972 General Motors Corp.

bottom helix and lower portion of the upper helix, if chipped, that will not be indicated in any of the tests.

Remove the plunger from the injector as follows:

1. Support the injector, right side up, in holding fixture J 22396.

2. Compress the follower spring. Then raise the spring above the stop pin with a screw driver and withdraw the pin (Fig. 11.). Allow the spring to rise gradually.

3. Remove the injector from the holding fixture. Turn the injector upside down, to prevent the entry of dirt, and catch the spring and plunger as they drop out.

4. Inspect the plunger. If the plunger is chipped (Fig. 12.), replace the plunger and bushing assembly.



Fig. 17. - Placing Injector in Comparator J 7041

5. Reinstall the plunger, follower and spring.

NEEDLE VALVE TESTS

Remove the injector nut and remove all of the parts below the injector bushing as. outlined under Disassemble Injector.

Clean all of the carbon off of the spray tip seat in the injector nut as outlined under Clean Injector Parts.

If the spray pattern test indicated that tip cleaning is necessary, clean the carbon from the tip cavity below the needle valve and orifices as outlined under Clean Injector Parts.

With the injector nut and spray tip cleaned, assemble the check valve, check valve cage, spring, spring seat, spring cage, needle valve and tip assembly on auxiliary tester J 22640 (Fig. 13.). Carefully pilot the injector nut over the spray tip and valve parts and thread it on the body as shown in Fig. 13. Tighten the injector nut to 75-85 lb-ft torque.

Install the shield in the auxiliary tester as shown in Fig. 14. and operate the pump handle until the spray tip valve has opened several times to purge the air from the system.

Operate the pump handle with smooth even strokes (40 strokes per minute) and note the pressure at which the needle valve opens. The valve should open between



Fig. 18. - Setting Comparator Stroke Counter

2300 and 3300 psi. The opening and closing action should be sharp and produce a finely atomized spray.

If the valve opening pressure is below 2300 psi and/or atomization is poor, the cause usually is a worn or fatigued valve spring. Replace the spring.

If the valve opening pressure is within 2300-3300 psi, proceed to check for spray tip seat leakage. Actuate the pump handle several times, then hold the pressure at 1500 psi for 15 seconds. Inspect the spray tip seat for leakage. There should be no fuel droplets although a slight wetting of the end of the valve tip is permissible.

If the spray tip seat is satisfactory, proceed to check the hold time for a pressure drop of from 1500 to 1000 psi. The time should not be less than 5 seconds. If the valve pressure drops from 1500 to 1000 psi in less than 5 seconds, replace the needle valve and tip assembly.

If the needle valve assembly passes the above test, the needle valve lift check can be omitted. To check the needle valve lift , use tool J 9462-01 (Fig. 15.) as follows:

1. Zero the indicator by placing the bottom surface of the plunger assembly on a flat surface and zero the indicator dial.

2. Place the spray tip and needle valve assembly tight against the bottom of the gage with the quill of the needle valve in the hole in the plunger.

3. While holding the spray tip and needle valve assembly tight against the gage, read the needle valve lift on the indicator. The lift should be .008 " to .018 "; if it exceeds .018 ", the tip assembly must be replaced. If it is less than .008 ", inspect for foreign material between the needle valve and the tip seat.

4. If the needle valve lift is within the limits, install a new needle valve spring and recheck the valve opening pressure and valve action. Low valve opening pressure or poor atomization with a new spring and seat

FUEL OUTPUT CHECK CHART				
Injector	J 22410 Calibrator		J 7041 Compactor	
N50	Min 50	Max. 54	Min. 18	Max. 24 5340

Fig. 19. - Fuel Output Check Chart



Fig. 20 - Position of Calibrator Fuel Flow Pipes

indicates the spray tip and needle valve assembly must be replaced.

Reassemble the injector as outlined under Assemble Injector and check it in the comparator or the calibrator.

FUEL OUTPUT TEST

The injector fuel output test can be performed in either the comparator J 7041 or the calibrator J 22410.

When injectors are removed from an engine for fuel output testing and, if satisfactory, reinstalled without disassembly, extreme care should be taken to avoid reversing the fuel flow. When the fuel flow is reversed, dirt trapped by the filter is back-flushed into the injector components.

Before removing an injector from the engine, note the direction of the fuel flow. To avoid reversing the fuel flow when checking injector fuel output, use the appropriate adaptor. The position of the fuel pipes on the comparator (Fig. 16.) depends on the adaptor being used and the direction of fuel flow through the injector. The position of the braided fuel inlet tube and the plastic fuel outlet tube on the calibrator (Fig. 20.) depends on the adaptor being used and the direction of fuel flow through the injector.

NOTE: The fuel passages in adaptors J 7041-61, J-7041-72 and J 7041-88 are drilled straight

1972 General Motors Corp.



Fig. 21. - Injector In Calibrator J 22410

through the adaptors. The fuel passages in adaptor J-7041 130 are cross drilled.

COMPARATOR J 7041

To check the fuel output, operate the injector in the comparator (Fig. 17.) as follows:

1. Place the injector in the comparator and tighten the hand wheel to clamp the injector and adaptor in position.

> **IMPORTANT**: Make sure the counter on the comparator is preset to 1,000 strokes. If, for any reason, this setting has been altered, raise the cover and reset the counter to 1,000 strokes by pulling the selector wheel to be changed to the right and rotating it to its proper setting (Fig. 18). Then release the wheel and close the cover. Refer to the comparator instruction booklet for further information.
>
> **NOTE: When installing a low clamp body injector in the comparator, position the injector in the adaptor at approximately a 45 ° angle, rather than straight into the adaptor, then bring it into a vertical position and secure it in place.**



Fig. 22. - Setting Calibrator Stroke Counter

2. Pull the injector rack out to the no-fuel position.

3. Start the comparator by turning on the switch.

4. After the comparator has started, push the injector rack in to the full-fuel position.



Fig. 23 · Removing or Installing Filter Cap

5. Let the injector run for approximately 30 seconds to purge the air that may be in the system.

6. After 30 seconds, press the fuel flow start button. This will start the flow of fuel into the vial. The comparator will automatically stop the flow of fuel after 1000 strokes.

7. After the fuel stops flowing into the vial, pull the rack out to the no-fuel position.

8. Turn the comparator off and reset the counter.

9. Observe the reading on the vial and refer to Fig. 19. to determine if the injector fuel output falls within its specified limits. If the quantity of fuel in the vial does not fall within the specified limits, refer to Trouble Shooting Chart 6 and Shop Notes in Section 2.0 for the cause and remedy.

CAUBRATOR J 22410

To check the fuel output, operate the injector in the calibrator (Fig. 21) as follows:

> **NOTE: Place the cam shift index wheel and fuel flow lever in their respective positions. Turn on the test fuel oil heater switch and preheat the test oil to 95° to 105° F.**

1. Place the proper injector adaptor between the tie rods and engage it with the fuel block locating pin.



Figure. 24. - Removing or Installing Plunger Follower, Plunger and Spring



Fig. 25. - Removing Injector Nut

Then slide the adaptor forward and up against the fuel block face.

2. Place the injector seat J 22410-226 into the permanent seat (cradle handle in vertical position). Clamp the injector into position by operating the air valve.

> **NOTE: Make sure the counter (Fig. 22.) on the calibrator is preset at 1,000 strokes. If for any reason this setting has been altered, reset the counter to 1,000 strokes by twisting the cover release button to the left and hold the reset lever in the full up position while setting the numbered wheels. Close the cover. Refer to the calibrator instruction booklet for further information.**

3. Pull the injector racks out to the no-fuel position.

4. Turn on the main power control circuit switch. Then start the calibrator by turning on the motor starter switch.

> **NOTE: The low oil pressure warning buzzer will sound briefly until the lubricating oil reaches the proper pressure.**

5. After the calibrator has started, set the injector rack into the full-fuel position. Allow the injector to operate for approximately 30 seconds to purge the air that may be in the system.

6. After the air is purged, press the fuel flow start button (red). This will start the-flow of fuel into the

© 1972 General Motors Corp



Fig. 26. - Removing Spray Tip from Injector Nut

vial. The fuel flow to the vial will automatically stop after 1,000 strokes.

7. Shut the calibrator off (the calibrator will stop in less time at full-fuel).

8. Observe the vial reading and refer to Fig. 19. to determine whether the injector fuel output falls within the specified limits. If the quantity of fuel in the vial does not fall within the specified limits, refer to Trouble Shooting Chart 6 and Shop Notes in section 2.0 for the cause and remedy.



Figure 27. - Cleaning Injector Spray Tip



Fig. 28. - Cleaning Spray Tip Orifices

NOTE: Refer to Section 2.0 for different factors that may affect the injector calibrator output reading.

The comparator or the calibrator may be used to check and select a set of injectors which will inject the same amount of fuel in each cylinder at a given throttle setting, thus resulting in a smooth running, well balanced engine.

An injector which passes all of the above tests may be put back into service. However, an injector which fails to pass one or more of the tests must be rebuilt and checked on the comparator or the calibrator.

Any injector which is disassembled and rebuilt must be tested again before being placed in service.

Disassemble Injector

If required, disassemble an injector as follows:

1. Support the injector upright in injector holding fixture J 22396 (Fig. 23.) and remove the filter caps, gaskets and filters.



Fig. 29. - Cleaning Injector Body Ring

©1972 General Motors Corp..

NOTE: Whenever a fuel injector is disassembled) discard the filters and gaskets and replace with new filters and gaskets. In the offset injector, a filter is used in the inlet side only. No filter is required in the outlet side (Fig. 34.).

2. Compress the follower spring as shown in Fig. 11.. Then raise the spring above the stop pin with a screw driver and withdraw the pin. Allow the spring to rise gradually.

3. Refer to Fig. 24.. and remove the plunger follower, plunger and spring as an assembly.

4. Invert the fixture and, using socket J 4983-01, loosen the nut on the injector body (Fig. 25.).

5. Lift the injector nut straight up, being careful not to dislodge the spray tip and valve parts. Remove. the spray tip and valve parts from the bushing and place them in a clean receptacle until ready for assembly.

When an injector has been in use for some time, the spray tip, even though clean on the outside, may not be pushed readily from the nut with the fingers. In this event, support the nut on a wood block and drive the tip down through the nut, using tool J-1291-02 as shown in Fig. 26.

6. Refer to Fig. 36. and remove the spill deflector. Then lift the bushing straight out of the injector body.

7. Remove the injector body from the holding fixture. Turn the body upside down and catch the gear retainer and gear in your hand as they fall out of the body.

8. Withdraw the injector control rack from the injector body. Also remove the seal ring from the body.

Clean Injector Parts

Since most injector difficulties are the result of dirt particles, it is essential that a clean area be provided on which to place the injector parts after cleaning and inspection.



Fig. 30. - Cleaning Injector Nut Spray Tip Seat -



Fig. 31. - Sealing Surfaces which may Require Lapping

Wash all of the parts with clean fuel oil or a suitable cleaning solvent and dry them with clean, filtered compressed air. Do not use waste or rags for cleaning purposes. Clean out all of the passages, drilled holes and slots in all of the injector parts.

Carbon on the inside of the spray tip may be loosened for easy removal by soaking for approximately 15 minutes in a suitable solution prior to the external cleaning and buffing operation. Methyl Ethyl Keytone J 8257 solution is recommended for this purpose.

Clean the spray tip with tool J 9464-01 (Fig. 27.).

CAUTION: Care must be exercised when inserting the carbon remover J 9464-01 in the spray tip to avoid contacting the needle valve seat in the tip.

Wash the tip in fuel oil and dry it with compressed air. Clean the spray tip orifices with pin vise J 4298-1 and the proper size spray tip cleaning wire. Use wire



Fig. 32. - Examing Sealing Surface with a Magnifying Glass

© 1972 General Motors Corp.

J 21461 to clean .006 " diameter holes (Fig. 28.).

Before using the wire, hone the end until it is smooth and free of burrs and taper the end a distance of 1/16" with stone J 8170. Allow the wire to extend 1/8 " from tool J 4198-1.

The exterior surface of an injector spray tip may be cleaned by using a brass wire buffing wheel, tool J 7944. To obtain a good polishing effect and longer brush life, the buffing wheel should be installed on a motor that turns the wheel at approximately 3000 rpm.

A convenient method of holding the spray tip while cleaning and polishing is to place the tip over the drill end of the spray tip cleaner tool J 1243 and hold the body of the tip against the buffing wheel. In this way, the spray tip is rotated while being buffed.

CAUTION: Do not buff excessively. Do not use a steel wire buffing wheel or the spray tip holes may be distorted.

When the body of the spray tip is clean, lightly buff the tip end in the same manner. This cleans the spray tip orifice area and will not plug the orifices.

Wash the spray tip in clean fuel oil and dry it with compressed air.

Clean and brush all of the passages in the injector body, using fuel hole cleaning brush J 8152 and rack hole cleaning brush J 8150. Blow out the passages and dry them with compressed air.

Carefully insert reamer J 21089 in the injector body (Fig. 29.). Turn it in a clockwise direction a few turns then remove the reamer and check the face of the ring for reamer contact over the entire face of the ring. If necessary, repeat the reaming procedure until the reamer does make contact with the entire face of the ring. Clean up the opposite side of the ring in the same manner.



Fig. 33. - Lapping Spray Tip on Lapping Blocks J 22090

Carefully insert a .375 " diameter straight fluted reamer inside the ring bore in the injector body. Turn the reamer in a clockwise direction and remove any burrs inside the ring bore. Then wash the injector body in clean fuel oil and dry it with compressed air.

Carefully insert carbon remover tool J 9418-1 in the injector nut. Turn it in a clockwise direction to remove the carbon deposits on the flat spray tip seat as shown in Fig. 30. Remove the carbon deposits from the lower end of the injector nut with carbon remover J 9418-5, (Fig. 30.) in the same manner. Use care to prevent removing any metal or setting up burrs on the spray tip seat.

Wash the injector nut in clean fuel oil and dry it with compressed air. Carbon deposits on the spray tip seating surfaces of the injector nut will result in poor sealing and consequent fuel leakage around the spray tip.

When handling the injector plunger, do not touch the finished plunger surfaces with your fingers. Wash the plunger and bushing with clean fuel oil and dry them with compressed air. Be sure the high pressure bleed hole in the side of the bushing is not plugged. If this hole is plugged, fuel leakage will occur at the upper end of the bushing where it will drain out of the injector body vent and rack holes, during engine operation, causing a serious oil dilution problem. Keep the plunger and bushing together as they are mated parts.



Fig. 34. - Location of Filter in Injector Body



Fig. 35. - Details of Injector Filter and Cap Showing Their Location Relative to Injector Body

After washing, submerge the parts if a clean receptable containing clean fuel oil. Keep the parts of each injector assembly together.

Inspect Injector Parts

Inspect the teeth on the control rack and the control rack gear for excessive wear or damage. Also check for excessive wear in the bore of the gear and inspect the gear retainer. Replace damaged or worn parts.

Inspect the injector follower and pin for wear. Refer to Section 2.0.

Inspect both ends of the spill deflector for sharp edges or burrs which could create burrs on the injector body or injector nut and cause particles of metal to be introduced into the spray tip and valve parts. Remove burrs with a 500 grit stone.

Inspect the follower spring for visual defects. Then check the spring with spring tester J 9666 and an accurate torque wrench.



Fig. 36. - Injector Rack, Gear, Spray Tip and Valve Assembly Details and Relative Location of Parts

The injector follower spring (.142 " diameter wire) has a free length of approximately 1.504" and should be replaced when a load of less than 70 lbs. will compress it to 1.028 ".

Check the seal ring area on the injector body for burrs

1972 General Motors Corp

or scratches. Also check the surface which contacts the injector bushing for scratches, scuff marks or other damage. If necessary, lap this surface. A faulty sealing surface at this point will result in high fuel consumption and contamination of the lubricating oil. Replace any loose injector body plugs or a loose dowel pin. Install the proper number tag on a service replacement injector body.

Inspect the injector plunger and bushing for scoring, erosion, chipping or wear. Check for sharp edges on that portion of the plunger which rides in the gear. Remove any sharp edges with a 500 grit stone. Wash the plunger after stoning it. Injector Bushing Inspectalite J 21471 can be used to check the port holes in the inner diameter of the bushing for cracks or chipping. Slip the plunger into the bushing and check for free movement. Replace the plunger and bushing as an assembly if any of the above damage is noted, since they are mated parts. Use new mated factory parts to assure the best performance from the injector.

Injector plungers cannot be reworked to change the output. Grinding will destroy the hardened case at the helix and result in chipping and seizure or scoring of the plunger.

Examine the spray tip seating surface of the injector nut and spray tip for nicks, burrs, erosion or brinelling. Reseat the surface or replace the nut or tip if it is severely damaged.

The injector valve spring plays an important part in establishing the valve opening pressure of the injector assembly. Replace a worn or broken spring.

Inspect the sealing surfaces of the injector parts indicated by arrows in Fig. 31. Examine the sealing surfaces with a magnifying glass as shown in Fig. 32. for even the slightest imperfections will prevent the injector from operating properly. Check for burrs, nicks, erosion, cracks, chipping and excessive wear. Also check for enlarged orifices in the spray tip. Replace damaged or excessively worn parts. Check the minimum thickness of the lapped parts as noted in the chart.

Examine the seating area of the needle valve for wear or damage. Also examine the needle quill and its contact point with the valve spring seat. Replace damaged or excessively worn parts.

Examine the needle valve seat area in the spray tip for foreign material. The smallest particle of such material can prevent the needle valve from seating properly. Polish the seat area with polishing stick J 22964. Coat only the tapered end of the stick with polishing compound J 23038 and insert it directly into the center of the spray tip until it bottoms. Rotate the



Fig. 37. - Injector Plunger, Follower and Relative Location of Parts

Part Name	Minimum Thickness
Tip, Spray (Shoulder)	.199
Cape, Check Valve	.165-.163
Volve, Check	.022
Cage, Valve Spring	.602

MINIMUM THICKNESS (Used Parts)

stick 6 to 12 times, applying a light pressure with the thumb and forefinger.

CAUTION: Be sure that no compound is accidentally placed on the lapped surfaces located higher up in the spray tip. The slightest lapping action on these surfaces can alter the



Fig. 38. - Comparison of Former and New Design Injector Parts

near-perfect fit between the needle valve and tip.

Before reinstalling used injector parts, lap all of the sealing surfaces indicated by the arrows in Fig. 31. It is also good practice to lightly lap the sealing surfaces of new injector parts which may become burred or nicked during handling.

Lapping Injector Parts

Lap the sealing surfaces indicated in Fig. 31. and the chart as follows:

1. Clean the lapping blocks (J-22090) with compressed air. Do not use a cloth or any other material for this purpose.

2. Spread a good quality 600 grit dry lapping powder on one of the lapping blocks.

3. Place the part to be lapped flat on the block as shown in Fig. 33. and, using a figure eight motion, move it back and forth across the block. Do not press on the part, but use just enough pressure to keep the part flat on the block. It is important that the part be kept flat on the block at all times.

4. After each four or five passes, clean the lapping powder from the part by drawing it across a clean piece of tissue placed on a flat surface and inspect the part. Do not lap excessively (refer to the chart on minimum thickness).

5. When the part is flat, wash it in cleaning solvent and dry it with compressed air.

6. Place the dry part on the second block. After applying lapping powder, move the part lightly across the block in a figure eight motion several times to give it a smooth finish. Do not lap excessively. Again wash the part in cleaning solvent and dry it with compressed air.



Fig. 39. - Tightening Injector Nut by Hand

7. Place the dry part on the third block. Do not use lapping powder on this block. Keep the part flat and move it across the block several times, using the figure eight motion. Lapping the dry part in this manner gives it the "mirror" finish required for perfect sealing.

8. Wash all of the lapped parts in clean fuel oil and dry them with compressed air.



Fig. 40. - Tightening Injector Nut With Torque Wrench

1972 General Motors Corp.

Assemble Injector

Use an extremely clean bench to work on and to place the parts when assembling an injector. Also be sure all of the injector parts, both new and used, are clean.

Study Figs. 34. through 37. for the proper relative position of the injector parts, then proceed as follows:

ASSEMBLE INJECTOR FILTERS

Always use new filters and gaskets when reassembling an injector.

1. Insert a new filter, dimple end down, slotted end up, in each of the fuel cavities in the top of the injector body (Fig. 35.).

NOTE: Install a new filter in the inlet side (located over the injector rack) in a fuel injector with an offset body. No filter is required in the outlet side of the offset body injector (Fig. 34.).

2. Place a new gasket on each filter cap. Lubricate the threads and install the filter caps. Tighten the filter caps to 65-75 lb-ft torque with a 9/16 " deep socket (Fig. 23.).

3. Purge the filters after installation by directing compressed air or fuel through the filter caps.

4. Install clean shipping caps on the filter caps to prevent dirt from entering the injector.



Fig. 41. - Installing Injector Follower Stop Pin

ASSEMBLE RACK AND GEAR

Refer to Fig. 36. and note the drill spot marks on the control rack and gear. Then proceed as follows:

1. Hold the injector body, bottom end up, and slide the rack through the hole in the body. Look into the body bore and move the rack until you can see the drill marks. Hold the rack in this position.

2. Place the gear in the injector body so that the marked tooth is engaged between the two marked teeth on the rack (Fig. 36).

3. Place the gear retainer on top of the gear.

4. Align the locating pin in the bushing with the slot in the injector body, then slide the end of the bushing into place.

ASSEMBLE SPRAY TIP, SPRING CAGE AND CHECK VALVE ASSEMBLIES

Refer to Fig. 36. and assemble the parts as follows:

1. Support the injector body, bottom end up, in injector holding fixture J 22396.



Fig. 42. - Checking Injector Spray Tip Concentricity



Fig. 43. - Relationship Between Exhaust Valve Bridge and Valve Stems

2. Place a new seal ring on the shoulder of the body. Then place the spill deflector over the barrel of the bushing.

3. Place the check valve centrally on the top of the bushing. Then place the check valve cage over the check valve and against the bushing.

4. Insert the spring seat in the valve spring, then insert the assembly into the spring cage, spring seat first.

5. Place the spring cage, spring seat and valve spring assembly (valve spring down) on top of the check valve cage.

6. Insert the needle valve, tapered end down, inside of the spray tip (Fig. 1.). Then place the spray tip and needle valve on top of the spring cage with the quill end of the needle valve in the hole in the spring cage.

7. Lubricate the threads in the injector nut and carefully thread the nut on the injector body by hand. Rotate the spray tip between your thumb and first finger while threading the nut on the injector body (Fig. 39.). Tighten the nut as tight as possible by hand. At this point there should be sufficient force on the spray tip to make it impossible to turn with your fingers.

8. Use socket J 4983-01 and a torque wrench to tighten the injector nut to 75-85 lb-ft torque (Fig. 40.).

NOTE: Do not exceed the specified torque. Otherwise, the nut may be stretched and result in improper sealing of the lapped surfaces in a subsequent injector overhaul.

ASSEMBLE PLUNGER AND FOLLOWER

1. Refer to Figs. 24. and 37. and slide the head of the plunger into the follower.

2. Invert the. injector in the assembly fixture (filter cap end up) and push the rack all the way in. Then place the follower spring on the injector body.

3. Refer to Fig. 41. and place the stop pin on the injector body so that the follower spring rests on the narrow flange of the stop pin. Then align the slot in the follower with the stop pin hole in the injector body. Next align the flat side of the plunger with the slot in the follower. Then insert the free end of the plunger in the injector body. Press down on the follower and at the same time press the stop pin into position. When in place, the spring will hold the stop pin in position.

© 1972 General Motors Corp.

Check Spray Tip -Concentricity

To assure correct alignment, check the concentricity of the spray tip as follows:

1. Place the injector in the concentricity gage J 5119 as shown in Fig. 42. and adjust the dial indicator to zero.

2. Rotate the injector 360' and note the total run-out as indicated on the dial.

3. If the total run-out exceeds .008", remove the injector from the gage. Loosen the injector nut,)center the spray tip and tighten the nut to 75-85 lb-ft torque. Recheck the spray tip concentricity. If, after several attempts, the spray tip cannot be positioned satisfactorily, replace the injector nut.

Test Reconditioned Injector

Before placing a reconditioned injector in service, perform all of the tests (except the visual inspection of the plunger) previously outlined under Test Injector.

The injector is satisfactory if it passes these tests. Failure to pass any one of the tests indicates that defective or dirty parts have been assembled. In this case, disassemble, clean, Inspect, reassemble and test the injector again.

Install Injector

Before installing an injector in an engine, remove the carbon deposits from the beveled seat of the injector tube in the cylinder head The, will assure correct alignment of the injector and prevent any undue stresses from being exerted against the spray tip.

Use injector tube bevel retainer J 5286-9, Section 2.1.4, to clean the carbon from the injector tube. Exercise care to remove ONLY the carbon so that the proper clearance between the injector body and the cylinder head is maintained. Pack the flutes of the reamer with grease to retain the carbon removed from the tube.

Be sure the fuel injector is filled with fuel oil. If necessary, add clean fuel oil at the inlet filter cap until it runs out of the outlet filter cap.

Install the injector in the engine as follows:

1. Refer to Fig. 6. and insert the injector into the injector tube with the dowel pin in the injector body registering with the locating hole in the cylinder head.

2. Slide the injector rack control lever over so that it registers with the injector rack.

3. Install the injector clamp, special washer (with curved side toward injector clamp) and bolt. Tighten the bolt to 20-25 lb-ft torque. Make sure that the clamp does not interfere with the injector follower spring or the exhaust valve springs.

> **NOTE: Check the injector control rack for free movement. Excess torque can cause the control rack to stick or bind.**

4. Move the rocker arm assembly into position and secure the rocker arm bracket to the cylinder head by tightening the bolts to 50-55 Ib-ft torque.

> **CAUTION: There is a possibility of damaging the exhaust valves if the exhaust valve bridge is not resting on the ends of the exhaust valves when tightening the rocker shaft bracket bolts. Therefore, note the position of the exhaust valve bridge (Fig. 43.) before, during and after tightening the rocker shaft bolts.**

5. Remove the shipping caps. Then install the fuel pipes and connect them to the injector and the fuel connectors. Use socket J 8932-01 to tighten the connections to 12-15 lb-ft torque.

> **CAUTION: Do not bend the fuel pipes and do not exceed the specified torque. Excessive tightening will twist or fracture the flared end or the fuel line and result in leaks. Lubricating oil diluted by fuel oil can cause serious damage to the engine bearings.**

6. Perform a complete engine tune-up as outlined in Section 14. However, if only one injector has been removed and replaced and the other injectors and the governor adjustment have not been disturbed, it will only be necessary to adjust the valve clearance and time the injector for the one cylinder, and to position the injector rack control lever.

© 1972 General Motors Corp.

FUEL INJECTOR TUBE

The bore in the cylinder head for the fuel injector is directly through the cylinder head water jacket as shown in Fig. 1. To prevent cooling water from contacting the injector and still maintain maximum cooling of the Injector, a tube is pressed into the injector bore. This tube is sealed at the top with a neoprene ring and upset into a flare on the lower side of the cylinder head to create water-tight and gas-tight joints at the top and bottom.

Remove Injector Tube

When removal of an Injector tube is required, use injector tube service tool set J 22525 as follows:

1. Remove, disassemble and clean the cylinder head as outlined in Section 1.2

2. Place the Injector tube Installer J 52864 in the injector tube. Insert the pilot J 5286-5 through the small opening of the injector tube and thread the pilot into the tapped hole in the end of the installer (Fig. 1.).

3. Tap on the end of the pilot to loosen the injector tube. Then, lift the injector tube, installer and pilot from the cylinder head.

Install Injector Tube

Thoroughly clean the injector tube hole in the cylinder head to remove dirt, burrs or foreign material that may prevent the tube from seating at the lower end or



Fig. 1. - Removing Injector Tube



Fig. 2. - Installing Injector Tube

sealing at the upper end. Then install the tube as follows:

1. Place a new injector tube seal ring in the couterbore in the cylinder head.

2. Place the installer J 52864 in the injector tube. Then, insert the pilot J 5286-5 through the small opening of the injector tube and thread it into the tapped end of the installer (Fig. 2.).

3. Slip the injector tube into the injector bore and drive it in place as shown in Fig. 2. Sealing is accomplished between the head counterbore (inside diameter) and outside diameter of the injector tube. The tube flange is merely used to retain the seal ring.

4. With the injector tube properly positioned in the cylinder head, upset (flare) the lower end of the injector tube as follows:

a. Turn the cylinder head bottom side up, remove the pilot J 5286-5 and thread the upsetting die J 5286-6 into the tapped end of the installer J 52864 (Fig. 3.).
b. Then, using a socket and torque wrench, apply approximately 30 Ib-ft torque on the upsetting die.
c. Remove the installing tools and ream the injector tube as outlined below.

© 1970 General Motors Corp.



Fig. 3. - Upsetting Injector Tube

Ream Injector Tube

After an injector tube has been installed in a cylinder head, it must be finished in three operations: First, hand reamed, as shown in Fig. 4, to receive the injector body nut and spray tip; second, spot-faced to remove excess stock at the lower end of the injector tube; and third, hand reamed, as shown in Fig. 5, to provide a good seating surface for the bevel or the lower end of the injector nut. Reaming must be done carefully and without undue force or speed so as to avoid cutting through the thin wall of the injector tube.

NOTE: The reamer should be turned in a clockwise direction only, both when inserting and when withdrawing the reamer, because movement in the opposite direction will dull the cutting edges of the flutes.

1. Ream the injector tube for the injector nut and spray tip. With the cylinder head right side up and the injector tube free from dirt, proceed with the first reaming operation as follows:

a. Place a few drops of light cutting oil on the reamer flutes, then carefully position the reamer J 22525-1 in the injector tube.
b. Turn the reamer in a clockwise direction (withdrawing the retainer frequently for removal of chips) until the lower shoulder of the reamer contacts the injector tube (Fig. 4.). Clean out all of the chips.

2. Remove excess stock:

a. With the cylinder head bottom side up, insert the pilot of cutting tool J 5286-8 into the small hole of the injector tube.

b. Place a few drops of cutting oil on the tool. Then, using a socket and a speed handle, remove the excess stock so that the lower end of the injector tube is from flush to .005" below the finished surface of the cylinder head.

3. Ream the bevel seat in the injector tube:

The tapered lower end of the injector tube must provide a smooth and true seat for the lower end of the injector nut to effectively seal the cylinder pressures and properly position the injector tip in the combustion chamber. Therefore, to determine the amount of stock that must be reamed from the bevel seat of the tube, the injector assembly should be



Fig. 4. - Reaming Injector Tube for Injector Body and Spray Tip

© 1970 General Motors Corp.



Fig. 5. - Reaming Injector Tube for Injector Nut with Reamer J 5286-9

installed in the tube and the relationship between the numbered surface of the spray tip to the fire deck of the cylinder head noted (Fig. 6.).

With the first reaming operation completed and the injector tube spot-faced, wash the interior of the injector tube with trichloroethylene or clean fuel oil and dry it with compressed air. Then perform the second reaming operation as follows:

a. Place a few drops of cutting oil on the bevel seat of the tube. Carefully lower the reamer J 5286-9 into the injector tube until it contacts the bevel seat.

b. Make a trial cut by turning the reamer steadily without applying any downward force on the reamer. Remove the reamer, blow out the chips, and look at the bevel seat to see what portion of the seat has been cut.

c. Proceed carefully with the reaming operation, withdrawing the reamer occasionally to observe the reaming progress.

d. Remove the chips from the injector tube and, using an injector as a gage, continue the reaming operation until the shoulder of the spray tip is flush to .015" recessed in the cylinder head as shown in Fig. 6. Then, wash the interior of the injector tube with trichloroethylene or clean fuel oil and dry it with compressed air.



Fig. 6. - Checking Location of Injector Spray Tip Relative to Lower Surface of Cylinder Head

FUEL PUMP

The positive displacement gear type fuel pump (Fig. 1.) transfers the fuel from the supply tank to the fuel injectors. The pump circulates an excess supply of fuel through the injectors which purges the air from the system and cools the injectors. The unused portion of fuel returns to the fuel tank by means of a fuel return manifold and fuel return line.

The fuel pump is mounted on the flywheel housing and is driven by the accessory drive gear.

The fuel pump cover and body are positioned by means of two dowels. The dowels aid in maintaining gear shaft alignment. The mating surfaces of the pump body and cover are perfectly flat ground surfaces. No gasket is used between the cover and body since the pump clearances are set up on the basis of metal-to-metal contact. A very thin coating of sealant provides a seal against any minute irregularities in the mating surfaces. Cavities in the pump cover accommodate the ends of the drive and driven shafts.

The fuel pump body is recessed to provide running space for the pump gears (Fig. 2.). Recesses are also provided at the inlet and outlet positions of the gears.

The small hole "A" permits the fuel oil in the inlet side of the pump to lubricate the relief valve at its outer end and to eliminate the possibility of a hydrostatic lock which would render the relief valve inoperative. Pressurized fuel contacts the relief valve through hole "B" and provides for relief of excess discharge pressures. Fuel re-enters the inlet side of the pump through hole "C" when the discharge pressure is great enough to move the relief valve back from its seat. Part of the relief valve may be seen through hole "C" The cavity "D" provides escape for the fuel oil which is squeezed out of the gear teeth as they mesh together on the discharge side of the pump. Otherwise, fuel trapped at the root of the teeth would tend to force the gears apart, resulting in undue wear on the gears, shafts, body and cover.

Two oil seals are pressed into the bore in the flanged side of the pump body to retain the fuel oil in the pump and the lubricating oil in the blower timing gear



Fig. 1. - Typical Fuel Pump Assembly

compartment (Fig. 1.). The oil seals are installed with the lips of the seals facing toward the flanged end of the pump body. A small hole "E" (Fig. 2.) serves as a vent passageway in the body, between the inner oil seal and the suction side of the pump, which prevents building up any fuel oil pressure around the shaft ahead of the inner seal. Two tapped holes in the under side of the pump body, between the oil seals, furnish a means of attaching tubing for draining off any leakage.

The drive and driven gears are a line-to-line to a .001" press fit on their shafts. The drive gear is provided with a gear retaining ball to locate the gear on the shaft.

A spring-loaded relief valve incorporated in the pump body normally remains in the closed position, operating only when pressure on the outlet side (to the filter) reaches approximately 65 psi.

Operation

In operation, fuel enters the pump on the suction side and fills the space between the gear teeth which are exposed at that instant. The gear teeth then carry the fuel oil to the discharge side of the pump and, as the gear teeth mesh in the center of the pump, the fuel oil is forced out into the outlet cavity. Since this is a continuous cycle and fuel is continually being forced into the outlet cavity, the fuel flows from the outlet cavity into the fuel lines and through the engine fuel system under pressure.

The pressure relief valve relieves the discharge pressure by by-passing the fuel from the outlet side of

©1970 General Motors Corp.



Fig. 2. - Fuel Pump Valving and Rotation (Right Hand Pump Shown)

the pump to the inlet side when the discharge pressure reaches approximately 65 to 75 psi.

The fuel pump should maintain the fuel pressure at the fuel inlet manifold as shown in Section 13.2.

If leakage exceeds one drop per minute, the oil seals should be replaced.

Remove Fuel Pump

1. Disconnect the fuel lines from the inlet and outlet openings of the fuel pump.

2. Disconnect the drain tube, if used, from the fuel pump.

3. Remove the three pump attaching bolt and seal assemblies and withdraw the pump.

4. Check the drive coupling fork and, if broken or worn, replace it with a new coupling.

Disassemble Fuel Pump

With the fuel pump removed from the engine and mounted in holding fixture J 1508-10 as shown in Fig. 3., refer to Figs. 1. and 2. and disassemble the pump as follows:



Fig. 3. - Removing Fuel Pump Cover Using Holding Fixture J 1508-10

© 1970 General Motors Corp.

1. Remove the eight cover bolts and withdraw the pump cover from the pump body. Use care not to damage the finished faces of the pump body and cover.

2. Withdraw the drive shaft, drive gear and gear retaining ball as an assembly from the pump body.

3. Press the drive shaft just far enough to remove the steel locking ball. Then, invert the shaft and gear assembly and press the shaft from the gear. Do not misplace the steel ball. Do not press the squared end of the shaft through the gear as slight score marks will damage the oil seal contact surface.

4. Remove the driven shaft and gear as an assembly from the pump body. Do not remove the gear from the shaft. The driven gear and shaft are serviced only as an assembly.

5. Remove the relief valve plug.

6 Remove the valve spring. pin and relief valve from the valve cavity in the pump body.

7. If the oil seals need replacing, remove them with tool J 1508-7, as shown in Fig. 4., by clamping the pump body in a bench vise and screwing the threaded end of the tool shaft into the outer oil seal (seal nearest to the bolting flange). Then tap the pilot end of the shaft with a hammer to remove the seal. Repeat this operation to remove the inner oil seal.

Inspection

Clean all of the parts in clean fuel oil and dry them with compressed air.

Oil seals, once removed from the pump body, must be discarded and replaced with new seals. The lips of the oil seals must fit snug around the pump shaft and must be free of nicks or cracks.

Check the pump gear teeth for scoring, chipping or wear. Check the ball slot in the drive gear for wear. If necessary, replace with a new gear.

Inspect the drive and driven shafts for scoring or wear.

Replace with new shafts if necessary. The driven shaft is serviced as a gear and shaft assembly only. The mating faces of the pump body and cover must be flat and smooth and fit tightly together. Any scratches or slight damage may result in pressure leaks. Also check for wear at areas contacted by gears and shafts. Replace the cover or body if necessary.

The relief valve must be free from score marks and burrs and fit its seat in the/pump body. If the relief valve is scored and cannot be cleaned up with fine emery cloth or crocus cloth, it must be replaced.



Fig. 4 Removing Oil Seals

Assemble Fuel Pump

1. Lubricate the lips of the oil seals with a light coat of vegetable shortening, then install the oil seals in the pump body as follows:

a. Place the inner oil seal on the pilot of the installer handle J 1508-8 so that the lip of the seal will face toward the shoulder on the tool.

b. With the pump body supported on wood blocks, insert the oil seal and tool in the pump body and drive the seal in until it bottoms in the counterbore (Fig. 6.).

c. Place the shorter end of the adaptor J 1508-9 over the pilot and against the shoulder of the installer handle. Place the outer oil seal on the pilot of the installer handle with the lip of the seal facing the adapter. Then, insert the pilot of the installer handle into the pump body and drive the seal in (Fig. 7.) until the shoulder of the adaptor contacts the pump body. Thus the oil seals will be positioned so that the space between them will correspond with the drain holes located in the bottom of the pump body.

2. Clamp the pump body in a bench vise (equipped with soft jaws) with the valve cavity up. Lubricate the outside diameter of the valve and place it in the cavity



Fig. 5. - Fuel Pump Details and Relative Location of Parts (Right Hand Pump Shown)

with the hollow end up. Insert the spring inside of the valve and the pin inside of the spring. With a new gasket in place next to the head of the valve plug, place the plug over the spring and thread it into the pump body. Tighten the plug.

3. Install the pump drive gear over the end of the drive shaft which is not squared (so the slot in the gear will face the plain end of the shaft). This operation is very important, otherwise fine score marks caused by pressing the gear into position from the square end of the shaft may cause rapid wear of the oil seals. Press the gear beyond the gear retaining ball detent. Then, place the ball in the detent and press the gear back until the end of the slot contacts the ball.

4. Lubricate the pump shaft and insert the square end of the shaft into the opening at the gear side of the pump body and through the oil seals as shown in Fig. 8.

5. Place the driven shaft and gear assembly in the pump body.

CAUTION: The driven gear must be centered on the shaft to give proper end clearance. Also, the chamfered end of the gear teeth of the production gear must face the pump body. If a service replacement gear with a slot is used, the slot must face toward the pump cover.



Fig. 6 Installing Inner Oil Seal

© 1970 General Motors Corp.

6. Lubricate the gears and shafts with clean engine oil.

7. Apply a thin coating of quality sealant on the face of the pump cover outside of the gear pocket area.

Then, place the cover against the pump body with the two dowel pins in the cover entering the holes in the pump body. The cover can be installed in only one position over the two shafts.

> **CAUTION The coating of sealant must be extremely thin since the pump clearances have been set up on the basis of metal-to-metal contact. Too much sealant could increase the clearances and affect the efficiency of the pump.**

Use care that sealant Is not squeezed into the gear compartment. otherwise damage to the gears and shafts may result.

8. Secure the cover in place with eight bolts and lock washers. tightening the bolts alternately and evenly.



Fig. 7 . Installing Outer Oil Seal ' 1970 General Motors



Fig. 8 Inserting Fuel Pump Drive Shaft and Gear Assembly through Oil Seals

9. After assembly, rotate the pump shaft by hand to make certain that the parts rotate freely. When the shaft does not rotate freely, attempt to free it by tapping a corner of the pump.

10. If the pump is not to be used immediately, place plastic shipping plugs in the inlet and outlet openings to prevent dirt or other foreign material from entering the pump.

Install Fuel Pump

1. Affix a new gasket to the pump body and locate the pump drive coupling over the square end of the fuel pump drive shaft.

2. Install the fuel pump on the engine and secure it with three bolt and washer assemblies.

3. Connect the inlet and outlet fuel lines to the fuel pump.

©1970 General Motors Corp.

FUEL PUMP DRIVE

The fuel pump is mounted on the flywheel housing and is driven by an accessory drive gear. The fuel pump drive consists of a gear, stationary hub and drive adaptor (Fig. 1). The fuel pump drive gear rotates on the stationary hub attached to the cylinder block and is driven at approximately twice the engine speed by the camshaft gear.



Fig. 2. - Camshaft Drive for Fuel Pump (6V Engine Shown)

Lubrication

The fuel pump drive gear bearing (bushing type) is pressure lubricated. Lubricating oil from the oil gallery in the cylinder block flows through a drilled passage in the block, around the gear retaining bolt, and through another drilled hole in the gear hub to the bearing.

Remove Fuel Pump Drive Gear (V-Type Engine)

With the flywheel housing removed, the fuel pump drive gear may be removed as follows:

1. Remove the bolts and detach the fuel pump drive adapter from the gear.

2. Loosen the fuel pump drive gear retaining bolt and remove the bolt, gear, washers and hub from the engine.



Fig. 1. - Typical Fuel Pump Drive Gear Mounting and Details (V-Type Engine)

© 1970 General Motors Corp.

Inspection

Wash the drive gear and its related parts with fuel oil and dry them with compressed air. Inspect the thrust washers, hub and drive gear bearing for wear and scoring. Parts which are excessively worn or scored must be replaced. A pre-finished drive gear bearing (bushing type) is available for service. A new bushing should be pressed in flush to .010" below the gear face (both sides). Examine the gear teeth and, if they are excessively worn, scored or pitted, replace the gear and bushing assembly.

Install Fuel Pump Drive Gear (V-Type Engine)

The fuel pump drive gear and its related parts may be installed on the engine as outlined below:

1. Lubricate the drive gear bearing, thrust washers and hub with engine oil.

2. Assemble the fuel pump drive gear and thrust washers on the hub. The oil grooves in the thrust washers must face toward the gear. Note the position of the oil hole in the hub.

3. Install the hub and gear assembly on the engine with the small diameter of the hub entering the rear end plate and the counterbore in the cylinder block.

and the fuel pump drive gear teeth in mesh with the camshaft gear teeth. The oil hole in the hub should be toward bottom-of the engine.

4. Secure the gear and hub assembly in place with the gear retaining bolt and washer. Tighten the 1/2"-13 bolt to 71-75 lb-ft torque.

5. Check the clearance between the gear and the thrust washer. The specified clearance between new parts Is between .011' and .018". The maximum clearance between used parts must not exceed .022" .

6. Attach the fuel pump drive adaptor to the gear with the two bolts.

© 1970 General Motors Corp.

STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

THREAD SIZE	TORQUE (lb-ft)	THREAD SIZE	TORQUE (lb.-ft)
1/4 -20	7-9	9/16-12	90-100
1/4 -28	8-10	9/16-18	107-117
5/16-18	13-17	5/8 -11	137-147
5/16-24	15-19	5/8 -18	168-178
3/8 -16	30-35	3/4 -10	240-250
3/8 -24	35-39	3/4 -16	290-300
7/16-14	46-50	7/8 9	410-420
7/16-20	57-61	7/8 -14	475-485
1/2 -13	71-75	1-8	580-590
1/2 -20	83-93	1-14	685-695

EXCEPTIONS TO STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

APPLICATION	THREAD SIZE	TORQUE (lb-ft)
Blower drive coupling to rotor gear (6V)	1/4 "-28	10-14
Blower drive gear pilot bolt (6V)	5/16 "-24	25-30
Blower timing gear-to-rotor shaft bolts 46V)	5/16 "-24	25-30
Front end plate cover bolts E,6V-53)	3/8" -16	20-25
Air inlet housing-to blower housing bolts,	3/8" -16	16-20
Governor-to-blower front end plate bolts	3/8" -16	20-24
Blower drive support-to-blower rear end plate bolts	3/8" -16	20-24
Flywheel housing-to-blower drive support bolts	3/8" .-16	20-24
Blower drive gear cover bolt	3/8" -16	20-24
	3/8" -24	20-25
Blower thrust washer retaining bolt {6V)	3/8" -24	54-59
Blower end plate-to-block bolts 6V)	7/16 "-14	55-60

© 1972 General Motors Corp

SERVICE TOOLS

TOOL NAME	TOOL NO.
BLOWER	
Blower clearance feeler gage set	J 1698-02
Universal puller t6V-53)	J 4794-01
Blower drive cam installer	J 5209
Handle	J 7079-2
Oil seal installer	J 22576
Oil seal sleeve installer (6V)	J 23679-1
Oil seal sleeve remover (6V)	J 23679-2

© 1972 General Motors Corp.

AIR CLEANER

The air cleaner is designed to remove foreign matter from the air, pass the required volume of air for proper combustion and scavenging, and maintain efficient operation for a reasonable period of time before requiring service.

The importance of keeping dust and grit-laden air out of the engine cannot be over-emphasized, since clean air is so esseritial to satisfactory engine operation and long engine life. Should dust in the air supply enter the engine, it would be carried directly into the cylinders and, due to its abrasive properties, cause premature wear of the moving parts. Dirt, which is allowed to build-up in the air cleaner passages, will eventually restrict the air supply to the engine and result in heavy carbon deposits on the valves and pistons due to incomplete combustion. The air cleaner sump must have a capacity large enough to retain the material separated from the air to permit operation for a reasonable length of time before cleaning is required.

Air Cleaner Maintenance

Although the air cleaner is highly efficient, this efficiency depends upon proper maintenance and periodic servicing.

Damaged gaskets, loose hose connections or leaks in the duct work, which permit dust-laden air to completely by-pass the cleaner and enter the engine directly, will lower the efficiency of the air cleaner. If the air cleaner is not serviced periodically, the engine will not receive a sufficient amount of clean air.

No set rule for servicing an air cleaner can be given since it depends upon the type of air cleaner, the condition of the air supply, and the type of application. An air cleaner operating in severe dust will require more frequent service than an air cleaner operating in comparatively clean air. The most satisfactory service period should be determined b) frequently inspecting the air cleaner under normal operating conditions, then setting the service period to best suit the requirements of the particular engine application. The following maintenance procedure will assure efficient air cleaner operation.

1. Keep the air cleaner tight on the air intake pipe t(the engine.
2. Keep the air cleaner properly assembled so the joints are strictly oil and air tight.
3. Repair any damage to the air cleaner or related parts immediately.

4. Inspect and clean or replace the air cleaner element as operating conditions warrant. In certain dry type cleaners, it is possible to clean and reuse the element several times as long as the paper is not ruptured in the process. In an oil bath type cleaner, keep the oil at the level indicated on the air cleaner sump. Overfilling may result in oil being drawn through the element ant into the engine, thus carrying dirt into the cylinder! and also resulting in excessive engine speed.

5. After servicing the air cleaner, remove the air inlet housing and clean accumulated dirt deposits from the blower screen and the inlet housing. Keep all air intake passages and the air box clean.

6. Where rubber hose is employed, cement it in place. Use new hose and hose clamps, if necessary, to obtain an air tight connection.

7. Carefully inspect the entire air system periodically Enough dust-laden air will pass through an almost, invisible crack or opening to eventually cause damage to an engine.

OIL BATH TYPE AIR CLEANER

LIGHT-DUTY AIR CLEANER

The light-duty oil bath air cleaner (Fig. 1.) consists of a metal wool cleaning element supported inside a housing beneath which is contained a bath of oil. The lower portion of the housing incorporates a chamber which serves as a silencer for the incoming air to the blower.

Air drawn into the cleaner by the blower passes over the top of the oil bath, where a major portion of the dirt is trapped, then up through the metal wool where the finer particles are removed, then down the central duct to the blower.

Service

Service the light-duty oil bath air cleaner as follows:

1. Loosen the wingbolt and remove the cleaner from the air inlet housing. The cleaner may then he separated into two sections of the upper section contains the metal wool element, the lower section is made up of the oil sump, removable baffle and center tube.
2. Soak the upper shell and element in fuel oil so loosen the dirt; then flush the element with clean fuel oil and allow it to drain thoroughly.

© 1970 General Motors Corp.



Fig. 1. - Light-Duty Oil Bath-Type Air Cleaner

3. Empty the sump, remove the baffle and clean both the sump and the baffle with fuel oil to remove all sediment.

4. Push a lint-free cloth through the center tube to remove dirt or oil from the walls.

5. Clean and check all gaskets and sealing surfaces to insure air tight seals.

6. Refill the sump to the oil level mark ONLY, with the same grade of oil used in the engine.

7. Before installing the air cleaner on the engine, check the air inlet housing for dirt. If the service period has been too long, or if dust-laden air has been leaking past the air cleaner to the air inlet housing seals, the inlet will be dirty. This will serve as a good check on the servicing of the air cleaner. When installing the cleaner (and its seal) on the inlet housing, be sure the cleaner seats properly, then tighten the wingbolt securely until the cleaner is rigidly mounted.

8. Install the baffle and reassemble the air cleaner.

HEAVY-DUTY AIR CLEANER

The heavy-duty oil bath air cleaner (Fig. 2) consists of a metal wool cleaning element supported inside a housing, beneath which a removable screen and an oil cup is located. Air, drawn into the air cleaner by the blower, enters the cleaner at the air inlet hood, passes down the central duct over the oil bath and up through the removable screen and metal wool cleaning element. The air leaves the cleaner through a tube at the side and enters the blower.

The major portion of dirt is washed from the air as it passes over the oil bath, and any remaining foreign matter is removed as the air passes up through the removable screen and the metal wool cleaning element.

Service

Service the heavy-duty air cleaner as follows:

1. Remove the oil sump from the cleaner by loosening the retaining band (or wing nuts). Empty the sump and wash it with fuel oil to remove all of the sediment.

2. Remove the detachable screen by loosening the wing nuts and rotating the screen one-quarter turn.

One of the most important steps in properly cleaning the tray type oil bath air cleaner is a step that is most overlooked. Unless the filter tray is thoroughly cleaned, satisfactory performance of any engine



Fig. 2.-· Heavy-Duty Oil Bath-Type Air Cleaner

© 1970 General Motors Corp.

cannot be realized. The presence of fibrous material found in the air is often underestimated and is the main cause of the malfunctioning of heavy-duty air cleaners. This material comes from plants and trees during their budding season and later from airborne seed from the same sources. Figure 3 illustrates the severity of plugging in a tray that is 50% plugged. The solid black areas in the mesh are accumulations of this fibrous material. When a tray is plugged in this manner, washing in a solvent or similar washing solution will not clean the tray satisfactorily. It must also be blown out with high velocity compressed air or steam to remove the material that accumulates between the layers of screening. When a clean tray is held up to the light, an even pattern of light should be visible. It may be necessary, only as a last resort, to burn off the lint. Extreme care must be taken not to melt the galvanized coating in the tray screens. Some trays have equally spaced holes in the retaining baffle.

Check to make sure that they are clean and open. A thoroughly cleaned tray is illustrated in Fig. 4. The dark spots in the mesh indicate the close overlapping of the mesh and emphasize the need for using compressed air or steam. It is suggested that users of heavy-duty air cleaners have a spare tray on hand to replace the tray that requires cleaning. Having an extra tray available makes for better service and the dirty tray can be cleaned thoroughly as recommended. Spare trays are well worth their investment.

3. Remove the hood and clean it by brushing or by blowing out with compressed air. Push a lint-free cloth



Fig. 3. - Air Cleaner Tray (50%Plugged)



Fig. 4. - Air Cleaner Tray (Clean)

through the center tube to remove dirt or oil from the walls.

4. The fixed element should be serviced as operating conditions warrant. Remove the entire cleaner from the engine, soak the unit in fuel oil to loosen the dirt, then flush with clean fuel oil and allow to drain thoroughly.

5. Clean and check all gaskets and sealing surfaces to insure air tight seals.

6. Refill the oil cup to the oil level mark ONLY. Use oil of same grade as used in the engine crankcase.

7. Install the removable screen in the housing and reinstall the housing.

8. Install the oil cup and the hood.

9. Check all of the joints and tubes and make sure they are air tight.

All oil bath air cleaners should be serviced as operating conditions warrant. At no time should more than 1/2 of "sludge" be allowed to form in the oil cup or the area used for sludge deposit, nor should the oil cup be filled above the oil level mark.

©1970 General Motors Corp.

DRY TYPE AIR CLEANER



Fig. 5. - United Specialties Dry Type Air Cleaner

UNITED SPECIALTIES AIR CLEANER

The dry type United Specialties air cleaner shown in Fig. 5. consists of a body, dust unloader and element clamped to a base.

Air is drawn through the cleaner intake pipe and is automatically set into a circular motion. This positive spinning of the dirty air "throws out" the heavier particles of dust and dirt where they are collected in the dust port and then expelled through the dust unloader. The circular action continues even during low air intake at engine idle speed.

Service

Service the dry type United Specialties air cleaner as follows:

1. Loosen the clamp screw and check the dust unloader for obstruction or damage. Refer to Section 15.1 for maintenance.

2. Unlock the spring clamps that hold the cleaner body to the cleaner base which is bolted to the air inlet housing. Remove the body and then remove the element from the cleaner base.

3. Clean the paper pleated air cleaner element as follows:

a. For a temporary expedient in the field, tap the side or end of the element carefully against the palm of your hand.

CAUTION: Do not tap the element against a hard surface. This could damage the element.

b. Compressed air can be used when the major contaminant is dust. The compressed air (not to exceed 100 psi) should be blown through the element in a direction opposite to the normal air flow. Insert the nozzle inside of the element and gently tap and blow out the dust with air. When cleaning the dust from the outside of the element. hold the nozzle at least 6" from the element.

c. Wash the element if compressed air is not available, or when the contaminant is carbon, soot, oily vapor or dirt which cannot be removed with compressed air. Agitate the element in warm water containing a non-sudsing detergent.

CAUTION: Do not use water hotter than your hand can stand, solvents or oil, fuel oil or gasoline.

Preceding the washing, it helps to direct air (not exceeding 100 psi) through the element in a direction opposite to the normal air flow, to dislodge as much dust as possible. Reverse flush with a stream of water (not exceeding 40 psi) until the water runs clean to rinse all loosened foreign material from the element. Shake out excess water from the element and allow it to dry thoroughly.

CAUTION Do not attempt to remove excess water by using compressed air.

4. Inspect the cleaned element with a light bulb after each cleaning for damage or rupture. The slightest break in the element will admit sufficient airborne dirt to cause rapid failure of piston rings. If necessary, replace the element.

5. Inspect the gasket on the end of the element. If the gasket is damaged or missing, replace the element.



Fig. 6. - Farr Dry Type Air Cleaner

© 1970 General Motors Corp.

6. Install the element on the base with the gasket side of the element down against the base. Place the body over the element and the base and tighten the spring clamps by hand.

Replace the element after 10 washings or I year of service, whichever comes first, or any time damage is noted.

7. Install the dust unloader and tighten the clamp.

FARR AIR CLEANER

The Farr dry type air cleaner illustrated in Fig. 6 is designed to provide highly efficient air filtration under all operating conditions and is not affected by engine speed. The cleaner assembly consists of a cleaner panel with a replaceable impregnated paper filter element.

The cleaner panel and replaceable filter element are held together in a steel housing with fasteners.

Operation

The deflector vanes impart a swirling motion to the air entering the air cleaner and centrifuge the dust particles against the walls of the tubes. The dust particles are then carried to the dust bin at the bottom of the cleaner by approximately 10% bleed-off air and are finally discharged into the atmosphere.

The cleaner panel is fully effective at either high or low velocities.

The remainder of the air in the cleaner reverse, direction and spirals back along the discharge tubes again centrifuging the air. The filtered air then reverses direction again and enters the replaceable filter element through the center portion of the discharge tubes. The air is filtered once more as .t passes through the pleats of the impregnated paper element before leaving the outlet port of the cleaner housing.

Service

The cleaner panel tends to be self-cleaning. However, it should be inspected and any accumulated foreign material removed during the periodic replacement of the impregnated paper filter element. Overloading of the paper element will not cause dirt particles to bypass the filter and enter the engine, but will result in starving the engine for air.

Replace the filter element as follows:
1. Loosen the wing nuts on the fasteners and swing the retaining bolts away from the cleaner panel.

2. Lift the cleaner panel away from the housing and inspect it. Clean out any accumulated foreign material.

3. Withdraw the paper filter element and discard it.

4. Install a new filter element.

5. Install the cleaner panel and secure it in place with the fasteners.

© 1970 General Motors Corp.

AIR SHUT-DOWN HOUSING

The air shut-down housing on the V-type engine has the air shut-down housing mounted on the top of the blower. The housing serves as a mounting for an air cleaner mounted away from the engine. The air shut-down housing contains an air shut-off valve that shuts off the air supply and stops the engine whenever abnormal operating conditions require an emergency shut-down.

Remove Air Shut-Down Housing

1. Disconnect and remove the air ducts between the air cleaner and the air shut-down housing.

2. Disconnect the control wire from the air shut-off cam pin handle.

3. Remove the bolts and washers that retain the housing to the blower and remove the housing from the blower. Remove the air shut-down housing gasket from the blower.

NOTE: Cover the blower opening to prevent dirt or foreign material from entering the blower.

Disassemble Air Shut-Down Housing

Refer to Fig. 1. and disassemble the air shut-down housing as follows:

1. Remove the pin from the end of the shut-down shaft. Then remove the washer from the shaft and the seal ring from the housing.

2. Remove the two pins that secure the shut-off valve to the shaft.

3. Remove the bolt, lock washer and plain washer which attach the latch to the housing. Then remove the latch, latch spring and spacer.

4. Note the position of the air shut-off valve spring and the valve (Fig. 2); then withdraw the shaft from the housing to release the valve and the spring. Remove the valve and spring and the seal ring from the housing.

5. Remove the cam pin handle and withdraw the tam from the shaft.

Inspection

Clean all of the parts thoroughly, including the blower screen, with fuel oil and dry them with compressed air. Inspect the parts for wear or damage. The face of the shut-down valve must be perfectly flat to assure a tight seal when it is in the shut-down position.

© 1970 General Motors Corp.



Fig. 1. - Installing Air Shut-Off Valve Spring and Valve

Assemble Air Shut-Down Assembly

The holes for the cam pin handle and the retaining pins must be drilled, using a 1/8" diameter drill, at the time a new service shaft or air shut-off valve(s) is assembled. The valve(s) must be in the same plane within .03" when in the stop position (flush with the housing face). Refer to Fig 1. and proceed as follows:

1. Place the valve(s) and spring in position in the housing (Fig.1.) and slip the shaft in place. The shaft must extend .70" from the side of the housing where the shut-down latch is assembled.

2. Install a new seal ring at each end of the shaft. Be sure the seals are seated in the counterbores of the housing.

3. Install the cam and cam pin handle on the shaft.

4. Install a washer and retaining pin at the other end of the shaft.

5. Assemble the spacer (bushing), spring and latch to the shut-down housing with the 1/4"-20 bolt, lock washer and plain washer.

   a. Align the notch on the bushing with the notch on the latch and lock the bushing In this position.

   b. Install the pins in the valve(s) to retain it to the shaft with the cam release latch set and the valve(s) in the run position.

   c. Level the valve(s) in the shut-down position.

   d. Adjust the bushing so the valve(s) contacts the housing when the cam release latch is set.



Fig. 2. - Location of Air Shut-Down Housing Mounting Bolts (6VEngines)

©1970 General Motors Corp.

Install Air Shut-Down Housing (6V Engines)

1. Place the blower screen and gasket assembly in position with the screen side of the assembly toward the blower.

2. Refer to Fig.4and mount the air inlet housing on the blower and secure it with bolts, washers and lock washers. Tighten the bolts to 16-20 Ib-ft torque.

3. Reset the air shut-down to the run position.

4. Start and run the engine at idle speed and no load.

Trip the air shut-down. If the engine does not stop, check it for air leakage between the valves and the gasket. If necessary, reposition the valves.

© 1970 General Motors Corp.

BLOWER

The blower supplies the fresh air required for combustion and scavenging. Its operation is similar to that of a gear-type oil pump. Two hollow double-lobe rotors revolve in a housing bolted on top of the cylinder block between the cylinder banks on the 6V engine (Fig. 1.).

The revolving motion of the rotors provides a continuous and uniform displacement of air.

The blower rotors are pinned to the rotor shafts. The rotor shafts are steel and the blower end plates are aluminum, providing for a compatible bearing arrangement.

Gears located on the splined end of the rotor shafts space the rotor lobes with a close tolerance. Since the lobes of the two rotors do not touch at any time, no lubrication is required.

Lip type oil seals are used in both the front and rear end plates. The seals prevent air leakage past the blower rotor shaft bearing surfaces and also keep the oil, used for lubricating the blower rotor gears, from entering the rotor compartment.



Fig. 1.- Blower Mounting (6V-53 Engine)

Inspect Blower (Attached to Engine)

The blower may be inspected without removing it from the engine. However, the air cleaner and the air inlet housing must be removed.

CAUTION When inspecting the blower with the engine running, keep your fingers and clothing away from the moving parts of the blower and run the engine at low speeds only.



Fig. 3. - Removing/installing Blower Drive Support (6V-53 Engine)

© 1972 General Motors Corp

Dirt or chips drawn through 'the blower will make deep scratches in the rotors and housing. Burrs around such abrasions may cause interference between the rotors or between the rotors and the blower housing.

Leaky oil seals are usually indicated by the presence of oil on the blower rotors or inside surfaces of the blower housing. Run the engine at low speed and direct a light into the rotor compartment and toward the end plates and the oil seals. A thin film of oil radiating away from a seal indicates an oil leak.

A worn blower drive resulting in a loose, rattling sound within the blower may be detected by running the engine at approximately 500 rpm.

Loose rotor shafts or worn rotor shaft bearing surfaces will result in contact between the rotor lobes, the rotors and the end plates, or the rotors and the housing.

Excessive backlash between the blower rotor gears usually results in the rotor lobes rubbing throughout their entire length.

Remove Blower Before removing the blower from the engine, remove the air shut-down housing as outlined in Section 3.3.

6V-53 ENGINE BLOWER

1. Disconnect the linkage to the governor control levers.

2. Remove the screws and lock washers which attach the governor cover to the governor housing. Remove the cover and gasket.

3. Remove the two bolts and lock washers which hold



Fig. 3. - Removing/installing Blower (6V-53 Engine)

© 1972 General Motors Corp

the spring housing to the governor housing. Remove the spring housing and gasket.

4. Remove the spring assembly from the governor.

5. Loosen the hose clamps and slide the hoses back on the fuel rod covers.

6. Clean and remove the valve rocker cover from each cylinder head.

7. Disconnect the lower fuel rod from each injector control tube lever and also from each upper fuel rod.

8. Remove the threaded pins connecting the fuel rods to the control link lever. Remove the upper fuel rods.

9. Remove the blower drive cover plate. Remove the snap ring and withdraw the blower drive shaft from the housing.

10. Remove the two bolts and copper washers securing the blower drive support assembly. Then withdraw the drive assembly until the splined end of the drive shaft is free from the drive plate (Fig. 3). Turn the drive assembly slightly so the serrated end of the governor weight shaft will pass around the governor operating fork. Remove the drive support from the engine.

11. The governor is doweled to the cylinder block rear end plate. Use a suitable tool to press or drive the dowel pin from the end plate.

12. Remove the four bolts and flat washers which attach the blower to the top face of the cylinder block. Lift the blower and governor assembly from the engine (Fig. 4.).

13. Remove the six bolts and lock washers which attach the governor housing to the blower rear end plate. Remove the governor and gasket.

6V-53 ENGINE BLOWERS

1. Remove the six bolts, special washers and reinforcement plates which secure .he front end plate cover and the front end plate to :he blower housing. Then remove the end plate cover and gasket from the end plate.

© 1970 General Motors Corp.

© 1972 General Motors Corp.

©1972 General Motors Corp.



Fig. 4. - Installing Lip Type Oil Seal in End Plate

NOTE: On the 6V engine, this step is accomplished by removing the governor.

2. Wedge a clean cloth between the rotors to prevent their turning and remove the four bolts that hold the blower drive cam retainer and blower drive spring support to the gear. Separate the retainer, support and spacer from the gear.

NOTE: On the 6V engine, the governor drive plate must also be removed from the opposite gear.

3. On the 6V engine blower, a cam pilot is used on both gears.

4. For identification, mark the left-hand gear on the 6V blower.

5. Use two pullers J 4794-01 to remove the two gears simultaneously.

6. Remove the rotor shims and the gear spacers and place them with their respective gears to ensure correct re-assembly.

7 At the other end of the blower, remove the three thrust plate bolts, the thrust plate and three spacers from the front end plate. Remove the bolts and thrust washers.

8 Tap the end plate off of the dowel pins and housing with a soft (plastic) hammer, being careful not to damage the mating surfaces of the end plate and the housing.



Fig. 5. - Installing Blower Rotors in Front End Plate



Fig. 6. - Installing Blower Housing Over Rotors

©1972 General Motors Corp.



Fig. 7. - Installing Rear End Plate

9. Remove the rotors from the blower housing.

10 Remove the rear end plate as in Step 9.

11.Remove and discard the lip type oil seals from the end plates.

12 If required, disassemble the blower drive spring support by driving the cam from the support with a brass drift, permitting the springs and spring seats to fall free.



Fig. 8. - Installing Blower Rotor Gears

Inspection

Clean and dry all of the parts thoroughly.

The finished inside face of each end plate must be smooth and flat. Slight scoring may be cleaned up with a fine grit emery cloth. If the surface is badly score J replace the end plate.

Inspect the surfaces of the rotors and the blow r housing. Remove burrs or scratches with an oil stone.

Examine the rotor shaft, gear or drive coupling for burred or worn serrations.

Inspect the blower gears for excessive wear or damage.

Check the bearing and oil seal contact surfaces of the rotor shafts and end plates for scoring, wear or nicks.

If an oil seal sleeve is used on the rotor shaft, it can le replaced as follows:

a. Place sleeve remover J 23679-2 over the rot-). shaft and behind the oil seal sleeve.

b. Back out the center screw of one gear puller J 21672-7 and attach the puller to the sleeve remover with three 1/4 "-20 x 3 " bolts and flit washers.



Fig. 9. - Measuring Rotor Lobe to Housing Clearance

© 1972 General Motors Corp.

c. Turn the puller screw clockwise and pull the sleeve off of the shaft.

d. Support the rotor, gear end up, on the bed of an arbor press.

e. Start a new sleeve straight on the shaft.

f. Place sleeve installer J 23679-1 on top of the sleeve and press the sleeve on the shaft until the step in the installer contacts the shoulder on the shaft.

NOTE: The step in the sleeve installer properly positions the sleeve on the shaft.



Fig. 10. - Minimum Blower Rotor Clearance

Assemble Blower

Assemble the blower as follows:

1. Install new lip type oil seals in each end plate in as follows:

a. Place the end plate on the bed of an arbor press.

b. Lubricate the outer diameter of the seal and, using installer J 22576, press the seal (lip facing down) into the counterbored hole until the shoulder on the installer contacts the end plate (Fig. 5.).

NOTE: A step on the seal installer will position the oil seal below the finished face of the end plate within the .002 " to .008 " specified.

2. Place the front end plate on two wood blocks. Then install, the rotors, gear end up, on the end plate (Fi;* I.

3. Install the blower housing over the rotors (Fig.).

NOTE: To prevent inadequate lubrication or low oil pressure, care must be exercised in the assembly of the front and rear blower end plates to the blower housing.

The rear end plate for the 6 V-53 blower does not have tapped holes for the thrust washer plates and is the only cover that has the horizontal ell passage drilled through into the pocket on the left side of the end plate for supplying oil to the blower drive gear support bearing.

4. Pace the rear end plate over the rotor shafts (Fig. 7.)

© 1972 General Motors Corp.



Fig. 11. - Measuring Rotor Lobe to End Plate Clearance

Secure each end plate to the 6V blower with four end plate cover bolts and plain washers.

5. Attach the two thrust washers to the front end of the blower with the washer retaining bolts. Tighten them to 54-59 lb.-ft torque.

6. Attach the three spacers and the thrust plate to the front end of the blower. Tighten the three bolts to 7-9 lb.-ft torque. Then check the clearance between the thrust plate and the thrust washers. The specified clearance is .001 " to .003 ".

7. Position the rotors so that the missing serrations on the gear end of the rotor shafts are 90° apart. This is accomplished by placing the rotors in a "T" shape, with the missing serration in the upper rotor facing to the left and the missing serration in the lower rotor facing toward the bott6m (Fig. 4.). Install the shims and spacers in the counterbore in the rear face of the rotor gears. Then place the gears on the ends of the shafts with the missing serrations in alignment with the missing serrations on the shafts.

8 Tap the gears lightly with a soft hammer to seat t em on the shafts. Then rotate the gears until the punch marks on the face of the gears match. If the marks do not match, re-position the gears.

9. Wedge a clean cloth between the blower rotor;. Use the gear retaining bolts and plain washers to prep, the gears on the rotor shafts (Fig.8.) Turn the bolts uniformly until the gears are tight against the shoulders on the shafts.

10. Remove the gear retaining bolts and washers. Then proceed as follows:

> **6V Blower**-Place a pilot in the counterbore each gear and start the 12-point bolt in the right hand rotor shaft and start the hex head bolt in the left-hand rotor shaft. Tighten the bolts to 25-30 lb-ft torque.

11 Check the backlash between the blower gears, using a suitable dial indicator. The specified backlash is .0005 " to .0025 " with new gears or a maximum) .0035 " with used gears.

12. Time Blower Rotors

After the blower rotors and gears have been installed, the blower rotors must be timed. When properly positioned, the blower rotors run with a slight clearance between the rotor lobes and with a slight clearance between the lobes and the walls of the housing.

The clearances between the rotors may be establish :d by moving one of the helical gears out or in on the shaft relative to the other gear by adding or removing shims between the gear hub and the rotor spacers.

It is preferable to measure the clearances with a feels r gage comprised of two or more feelers, since a combination is more flexible than a single feeler gage. Take measurements from both the inlet and outlet sides of the blower.

a. Measure the clearance between the rotor lobes and

©1972 General Motors Corp.



Fig. 12. - Inserting Cam in Blower Drive Support

the housing as shown in Fig. 9. Take measurements across the entire length of each rotor lobe to be certain that a minimum clearance of .004 " exists at the air outlet side of all blowers and a minimum clearance of .010 " (6V engine blower) exists at the air inlet side of the blower (Fig. 15).

b. Measure the clearance between the rotor lobes, across the length of the lobes, in a similar manner. By rotating the gears, position the lobes so that they are at their closest relative position (Fig. 10.) The clearance between the lobes should be a minimum of .010 "

c. Measure the clearance between the end of the ROTOR the blower end plate as shown in Fig. 11.; Refer to the chart for the required minimum clearances.

NOTE: Push and hold the rotor toward the end plate at which the clearance is being measured.

After timing the rotors, complete assembly of the blower.

13. Remove the bolts and washers used to temporarily secure the front end plate to the housing. Then install the front end plate to the blower with six bolts and special washers and two reinforcement plates and tighten the bolts to 20-25 lb.-ft torque.

BLOWER ROTOR END CLEARANCES (Minimum)		
Engine	**Front End Plate**	**Rear End Plate**
6V-53	008”	.012"

The gasket used between the blower and the governor housing on the 6V engine is not interchangeable with the front end plate cover gasket.

14. Assemble the blower drive spring support as flows:

a. Place the drive spring support on two blocks of wood (Fig. 12)

b. Position the drive spring seats in the support.

c. Apply grease to the springs to hold the leaves together, then slide the two spring packs (15 leaves per pack) in place.

d. Place the blower drive cam over the end of tool J 5209, insert the tool between the spring packs and press the cam in place.

15. Install the drive spring support coupling on the rotor gear at the rear end of the blower.

NOTE: The coupling is placed on the left-hand gear on the 6V engine blower. A spacer is placed between the gear and the coupling on the 6V engine blower.

16. Secure the cam retainer to the coupling with four 1/4 "-28 bolts and tighten them to 14-18 lb.-ft torque.

17. On the 6V engine blower, install the governor drive plate on the right-hand rotor gear with four bolts and tighten them to 8-10 lb-ft torque.

©1972 General Motors Corp.

18. Remove the bolts and, washer used to temporarily secure the rear end plate to the 4-53 engine blower.

Then install the rear end plate cover and gasket and secure the, cover and end plate to the blower with six bolts and special washers and two reinforcement plates and tighten the bolts to 20-25 Ib-ft torque.

> **NOTE: This step is accomplished on the 6V engine blower by securing the governor to the end plate with six bolts.**

Install Blower

Examine the inside of the blower for any foreign material. Also revolve the rotors by hand to be sure that they turn freely. Then install the blower on the engine as follows:

© 1972 General Motors Corp

6V-53 ENGINE BLOWER

1. Install a new blower-to-block seal ring and two new blower-to-block gaskets. Affix the gaskets to the cylinder block and engine end plate with Scotch Grip Rubber Adhesive No. 430a, or equivalent.

2. Install the blower and governor assembly on the engine as follows:

a. To install the blower and governor on the engine without disturbing the gaskets and seal, use guide studs (Fig.;). Install the guide studs in the end blower bolt holes in the cylinder block.

b. While lowering the blower and governor assembly over the guide studs, push the blower away from the governor housing gasket attached to the rear end plate.

c. Remove the guide studs and install the blower to block bolts and flat washers. Tighten the bolts finger tight only.

d. Press or drive the governor housing dowel pin into the rear end plate with a suitable tool.

3. Tighten the blower to block bolts to 10-15 lb-ft torque.

4. Install the blower drive support as follows:

a. Affix a new gasket to the blower drive support.

b. Position the light governor weights (high speed limiting speed governor) in a horizontal position to provide clearance (Figr4). Turn the operating shaft fork away from the blower, if necessary, for additional clearance.

c. Move the blower drive assembly into the openings in the flywheel housing until the blower drive gear enters the housing. Then turn the drive assembly slightly so that the serrated end of the governor weight shaft may pass around behind the governor operating fork, permitting the fork to slip into place between the serrated end of the shaft and the riser bearing.

d. Push the drive support assembly up against the flywheel housing; the serrations in the governor weight shaft and in the governor drive plate on the blower timing gear must mesh. The blower drive gear must also mesh with the mating gear.

5. Secure the small end of the blower drive support to the flywheel housing with two 3/8 "-16 bolts and copper washers. Tighten the bolts to 20-25 lb-ft torque.

6. Insert the blower drive shaft into the blower gear shaft. If necessary, turn the crankshaft so that the serrations on the blower drive shaft register with the serrations in the blower drive cam and the blower drive gear shaft.

7. Install the snap ring in the blower drive gear shaft to secure the blower drive shaft.

8. Attach a new gasket to the blower drive support cover. Then secure the cover to the support with four 3/8 "-16 bolts and lock washers. Tighten the bolts to 20-25 lb.-ft torque.

9. Tighten the blower-to-block bolts to 55-60 lb.-ft torque.

10. Insert the upper fuel rods through the fuel rod covers and attach the rods to the governor control link lever.

11. Attach the lower fuel rods to the injector control tube levers and upper fuel rods.

12. Slide the fuel rod cover hoses in place and secure them with hose clamps.

13. Install the spring assembly in the governor.

14. Install the air shut-down housing (Section 3.3).

@ 1972 General Motors Corp.

SECTION 4

LUBRICATION SYSTEM

CONTENTS

Lubrication System 4

Lubricating Oil Pump 4.1

Lubricating Oil Pressure Regulator 4.1.1

Lubricating Oil Filter 4.2

Lubricating Oil Cooler 4.4

Oil Level Dipstick 4.6

Oil Pan..... 4.7

Ventilating System 4.8

Shop Notes - Specifications - Service Tools 4.0

LUBRICATION SYSTEM

The engine lubrication systems, illustrated in Fig. 1 include an oil intake screen and tube assembly, an oil pump, an oil pressure regulator valve, a full flow oil filter with a by-pass valve, an oil cooler and oil cooler by-pass valve.

The rotor type oil pump is bolted to the back of the engine lower front cover and is driven directly by the crankshaft.

Lubricating oil from the pump passes from the lower front engine cover through short gallery passages in the cylinder block. From the block, the oil flows to the full flow filter, then through the oil cooler and back into the front engine cover and cylinder block oil galleries for distribution to the various engine bearings. The drain from the cylinder head and other engine parts leads back to the oil pan.

Clean engine oil is assured at all times by the use of a replaceable element type full flow filter. With this type filter, which is installed between the oil pump and the oil cooler, all of the oil is filtered before entering the engine. Should the filter become plugged, the oil will flow through a by-pass valve, which opens at approximately 18-21 psi, directly to the oil coolers.

If the cooler becomes plugged, the oil flow will be to a by-pass valve in the lower engine front cover and then to the cylinder block oil galleries. The by-pass valve opens at approximately 52 psi.

©1972 General Motors Corp.

Stabilized lubricating oil pressure is maintained within the engine at all speeds, regardless of the oil temperature, by means of a regulator valve located in the lower front engine cover. The regulator valve, located in the pump outlet passage, opens at 52 psi on 6V engines and returns excess oil directly to the crankcase.

©1972 General Motors Corp.



Fig.1. Schematic Diagram for 6V-53 Engine Lubrication System

Lubricating Oil Distribution

On a 6V engine, oil from the pump enters a passage in the cylinder block and flows under pressure to the filter and oil cooler and returns through a passage in the block to the lower engine front cover. From a passage in the cover, the oil flows to the longitudinal main oil gallery in the block which distributes the oil, under pressure, to the main bearings. Oil passages branching off from the main oil gallery direct oil tc the camshaft end bearings, idler gear and accessory drive gear bearings, blower, and cylinder heads.

In addition, oil is forced through-an oil passage iii each camshaft which lubricates the camshaft intermediate bearings. All of the camshaft bearings incorporate small slots through which lubricating oil is directed at the cam follower rollers.

© 1972 General Motors Corp.

Oil for lubricating the connecting rod bearings, piston pins, and for cooling the piston head is provided through the drilled crankshaft from the adjacent forward main bearings. The gear train is lubricated by the overflow of oil from the camshaft pocket through a communicating passage into the flywheel housing. Some oil spills into the flywheel housing from the bearings of the camshafts, idler gears and accessory drive gears.

Drilled oil passages on the camshaft side of the cylinder head (Fig . 1) are supplied with oil from the bores located at each end of the cylinder block. Oil from these drilled passages enters the drilled rocker shaft brackets at the lower ends of the drilled bolts and lubricates the rocker arm bearings and push rod clevis bearings.

Excess oil from the rocker arms lubricates the lower ends of the push rods and cam followers, then drains to cam pockets in the top of the cylinder block, from which the cams are lubricated. When these pockets are filled, the oil overflows through holes at each end of the cylinder block and then through the flywheel housing and front cover to the crankcase.

The blower bearings are pressure lubricated by oil from drilled passages in the cylinder block which connect matching passages in the blower end plates which, * turn, lead to the bearings. Lubricating oil is supplied directly to the front and rear right bank camshaft end bearings and supplies oil to the blower bearings. Excess oil returns to the crankcase via drain holes in the blower end plates which lead to corresponding drain holes in governor housing (6V engine).

The blower drive gear hub in a 6V engine is pressure lubricated through a connecting passage from the rear blower end plate, through the governor housing and into the blower and governor drive support.

Four tapped oil pressure take-off holes (three at the rear and one at the front) are provided in a 6V cylinder block.

Cleaning lubrication System Thorough flushing of the lubrication system is required at times. Should the engine lubrication system become contaminated by ethylene glycol antifreeze solution or other soluble material. refer to Section 5 for the recommended cleaning procedure.

© 1972 General Motors Corp.

LUBRICATING OIL PUMP

The lubricating oil pump, assembled to the inside of the lower engine front cover as illustrated in Fig. 1, is of the rotor type in which the inner rotor is driven by a gear pressed on the front end of the crankshaft. The outer rotor is driven by the inner rotor. The bore in the pump body, in which the outer rotor revolves, is eccentric to the crankshaft and inner rotor. Since the outer rotor has nine cavities and the inner rotor has eight lobes, the outer rotor revolves at eight-ninths crankshaft speed. Only one lobe of the inner rotor is in full engagement with the cavity of the outer rotor at any given time, so the former can revolve inside the latter without interference.

Operation

As the rotors revolve, a vacuum is formed on the inlet side of the pump and oil is drawn from the crankcase, through the oil pump inlet pipe and a passage in the front cover, to the inlet port and then into the rotor compartment of the pump. Oil drawn into the cavities between the inner and outer rotors on the inlet side of the pump is then forced out under pressure through the discharge port into a passage in the front cover which leads to the lubricating oil filter and cooler, an(is then distributed throughout the engine.



Fig. 1. - Typical Right-Hand rotation Lubricating Oil Pump Mounting

If a check of the lubrication system indicates improper operation of the oil pump, remove and disassemble i; as outlined below.

Remove Oil Pump

1. Drain the oil from the engine.

2. Remove the crankshaft pulley, fan pulley, support bracket and any other accessories attached to the front cover.

3. Remove the oil pan.

4. Refer to Fig. 2 and remove the four bolts which attach the oil pump inlet pipe and screen assembly to the main bearing cap and engine front cover or oil pump inlet elbow. Slide the flange and the seal ring oil the inlet pipe and remove the pipe and screen as an assembly. Remove the oil pump inlet elbow (if used) and gasket from the engine front cover.

5. Remove the lower engine front cover.


Fig. 2. - Typical Oil Pump Inlet Pipe and Screen Mounting

© 1972 General Motors Corp. July, 1972



Fig. 3. Measuring Rotor Clearance

6. Remove the six bolts and lock washers (if used) which attach the pump assembly to the engine front cover (Fig. 1) and withdraw the pump assembly from the cover.

Disassemble Oil Pump

If the oil pump is to be disassembled for inspection or reconditioning, proceed as follows:



Fig. 4.-- Measuring Clearance from Face of Pump Body to Side of Rotor

1. Refer to Fig. 5 or 6 and remove the two drive screws holding the pump cover plate to the pump body. Withdraw the cover plate from the pump body.

2. Remove the inner and outer rotors from the pump housing.

Inspection

Wash all of the parts in clean fuel oil and dry them with compressed air.

The greatest amount of wear in the oil pump is imposed on the lobes of the inner and outer rotors.

This wear may be kept to a minimum by using clean oil. If dirt and sludge are allowed to accumulate in the lubricating system, excessive rotor wear may occur in a comparatively short period of time.

Inspect the lobes and faces of the pump rotors for scratches or burrs and the surfaces of the pump body and cover plate for scoring. Scratches or score marks may be removed with an emery stone.

Measure the clearance between the inner and outer rotors at each lobe (Fig. 3). The clearance should not be less than .004" or more than .011". Measure the clearance from the face of the pump body to the side of the inner and outer rotor with a micrometer depth gage (Fig. 4). The clearance should be not less than .001 " or more than .0035 ".

Inspect the splines of the inner rotor and the oil pump drive gear. If the splines are excessively worn, replace the parts. The rotors are serviced as matched sets, therefore, if one rotor needs replacing, replace both rotors.

Remove the oil inlet screen from the oil inlet pipe and clean both the screen and the pipe with fuel oil and dry them with compressed air. Replace the inlet pipe flange seal ring with a new seal ring if necessary.

Assemble Oil Pump

After the oil pump parts have been cleaned and inspected, refer to Fig. 5 and assemble the pump as follows:

1. Lubricate the oil pump outer rotor with engine oil and place it in the pump body.

2. Lubricate the oil pump inner rotor with engine oil and place it inside of the outer rotor.

3. Place the cover plate on the pump body and align the drive screw and bolt holes with the holes in the.

© 1972 General Motors Corp.



Fig. 5. - Lubricating Oil Pump Details and Relative Location of Parts (Current)

© 1972 General Motors Corp.



Fig. 6. - Removing Oil Pump Drive Gear

pump body. Since the holes are offset, the cover plate can be installed in only one position.

4. Install two new drive screws to hold the assembly together.

Remove Pump Drive Gear From Crankshaft

With the lower engine front cover and the lubricating oil pump removed from the engine, the oil pump drive gear may, if necessary, be removed from the end of the crankshaft as follows:

1. Thread the crankshaft pulley retaining bolt in the end of the crankshaft (Fig.6L.

2. Attach the jaws of a suitable gear puller behind the gear and locate the end of the puller screw in the center of the pulley retaining bolt.

3. Turn the puller screw clockwise to remove the gear from the crankshaft.

Install Pump Drive Gear on Crankshaft

1. Lubricate the inside diameter of a new oil pump drive gear with engine oil. Then start the gear straight on the crankshaft. Re-installation of a used gear is not recommended.

2. Position the drive gear installer J 8968-01 over the end of the crankshaft and against the drive gear and force the gear in place as shown in Fig./y When the end of the bore in the tool contacts the end of the crankshaft, the drive gear is correctly positioned.

3. It is important that the press fit of the drive gear to the crankshaft be checked to be sure that the gear does not slip on the crankshaft. It is recommended the press



Fig.2. Installing Oil Pump Drive Gear

fit (slip torque) be checked with tool J 23126. On 6V engines, the drive gear should not slip on the crankshaft at 100 lb-ft torque.

CAUTION: Do not exceed these torques. If the gear slips on the shaft, it is suggested that another oil pump drive gear be installed.

Install Oil Pump

1. The markings on the pump body indicate the installation as pertaining to left or right-hand crankshaft rotation. Be sure that the letters "UP R.H." (right-hand rotation engine) on the pump body are at the top (Fig. 1).

2. Insert the six bolts with lock washers (if used) through the pump body and thread them into the engine front cover. Tighten the bolts to 13-17 lb-ft torque.

© 1972 General Motors Corp.

3. Install the lower engine front cover and pump assembly on the engine as outlined in Section 1.3.5.

4. Attach the oil inlet' screen to the oil inlet pipe support with two lock nuts (6V engine) or two bolts and lock washers (Fig. 9).

5. Use a new gasket and attach the oil pump inlet elbow (6V engine) to the under side of the engine front cover with the two bolts and lock washers.

6. Place the oil pump inlet pipe and screen assembly in position and fasten the support to the main bearing cap with the two bolts and lock washers.

7. Slide the inlet pipe flange and seal ring against engine front cover (or oil pump inlet elbow on the 6'V engine) and secure them with the two bolts and lock washers.

8. Install the oil pan and refill the crankcase to the proper level.

9. Install the crankshaft pulley, fan pulley, support bracket and any other accessories that were attached to the front cover.

© 1972 General Motors Corp.

LUBRICATING OIL PRESSURE REGULATOR

Stabilized lubricating oil pressure is maintained within the engine at all speeds, regardless of oil temperature, by a pressure regulator valve installed in the engine lower front cover as shown in Fig. 1

The regulator assembly consists of a hollow piston type valve, a spring, gasket and plug. The valve is located in an oil gallery within the lower front cover and is held tight against a counterbored valve seat by the valve spring and plug. When the oil pressure exceeds a given value as shown in the following chart, the valve is forced from its seat and the lubricating oil is by-passed into the engine oil pan.

Engine	Front Cover	Valve Opening Pressure (psi)
6V		
	Current	52

Under normal conditions, the pressure regulator valve should require very little attention. If sludge accumulates in the lubrication system, the valve may not work freely, thereby remaining open or failing to open at the normal operating pressure.



Fig. 1. Location of Former Oil Pressure Regulator Valve -6V Engine Shown

Whenever the lubricating oil pump is removed for inspection, the regulator valve and spring should also be removed, thoroughly cleaned in fuel oil and inspected.

Remove Oil Pressure Regulator

1. Remove the plug and washer from the engine lower front cover.

2. Withdraw the spring and the valve from the cover.

Inspection

Clean all of the regulator parts in fuel oil and dry them with compressed air. Then inspect the parts for wear or damage.

The regulator valve must move freely in the valve bore. If the valve is scored and cannot be cleaned up with crocus cloth, it must be replaced.

Replace a fractured or pitted spring.

Install Oil Pressure Regulator

1. Apply clean engine oil to the outer surface of the valve and slide it into the opening in the engine lower front cover (closed end first).

2. Install a new copper gasket on the plug.

3. While compressing the spring, start the plug in the side of the cover; then tighten the plug.

© 1972 General Motors Corp.

LUBRICATING OIL FILTER

FULL-FLOW FILTER

The engine is equipped with a full-flow type lubricating oil filter. The filter is mounted vertically when attached to the cylinder block of the 6V engine.

The filter assembly consists of a replaceable element enclosed within a shell which is mounted on a base (Fig. 1). When the filter shell is in place, the element is restrained from movement by a coil spring at the bottom.

All of the oil supplied to the engine by the oil pump passes through the filter before reaching the various parts of the engine. The lubricating oil is forced by the pump through a passage in the filter base to the space surrounding the filter element. Impurities are filtered out as the oil is forced through the element to a central passage surrounding the center stud and out through another passage in the filter base and then to the oil; cooler.

Remove and Install By-pass Valve

Remove the four bolts and washers and detach the



Fig.1. Typical Full-Flow Filter Mounting (6V Engine Shown)

© 1972 General Motors Corp.



Fig. 2. Typical Full-Flow Filter Details and Relative Location of Parts

filter base or filter junction housing from the oil cooler adaptor (Fig. 2).

2. Remove the retaining screw which secures the spring retainer to the filter base and withdraw the spring and valve from the base.

3. Wash all of the parts in fuel oil and dry them with compressed air.

4. Inspect the parts for wear or damage and replace them if necessary.

5. Reassemble the by-pass valve.

6. Place a new gasket on the oil cooler adaptor. The small protrusion on the oil filter base gasket must mate with the boss on the filter base regardless of position in which the filter is assembled. If the gasket is not correctly positioned, the flow of oil may be obstructed. Secure the oil filter base or filter junction housing to the oil cooler adaptor.

7. Start the engine and check for ail leaks.

© 1972 General Motors Corp.

Remove and Install Filter Element

Periodic servicing of the lubricating oil filter is very important. Install a new element as follows:

1. Remove the drain plug at the bottom of the filter shell.

2. Unscrew the center stud and lift the shell, element and stud as an assembly off the base, Discard the filter element and the shell gasket.

3. Remove the center stud.

NOTE: Remove the snap ring or thin nut on the full-flow filter center stud and slide the stud out of the shell. Then examine the retainer seal (Fig.2.) for hardening or cracking. If necessary, replace the seal.

4. Clean the filter shell and the adaptor or base.

5. Install the center stud gasket and slide the stud through the filter shell. Install the spring (also washer, seal and retainer on the full-flow filter) on the stud.



Fig.3. By-Pass Valve Assembly Secured by Retainer and Screw

6. Install a new shell gasket in the filter adaptor or base.

NOTE: When replacing the filter shell gasket, be sure all of the old gasket material is removed from the shell and the filter adaptor. Also make sure the gasket surface of the shell and adaptor have no nicks, burrs or other damage.

7. Position the new filter element carefully over the center stud and within the shell. Then place the sheli, element and stud assembly in position on the filter adaptor or base and tighten the center stud to 50-60 Ib-ft torque.

8. Install the drain plug.

9. Start and run the engine for a short period and check for oil leaks. After any oil leaks have been corrected and the engine has been stopped long enough for the oil from various parts of the engine to drain back to the crankcase, bring the oil to the proper level on the dipstick.

© 1972 General Motors Corp.

LUBRICATING OIL COOLER

The oil cooler is mounted on the side of the cylinder block at the lower front corner (Fig. 1).

To assure engine lubrication should the oil cooler become plugged, a by-pass valve located near the top of the lower engine front cover by-passes oil from the oil pump discharge port directly to the oil galleries in the cylinder block. The by-pass valve opens at 52 psi (6V engines).

The valve components are the same as and serviced in the same manner as the oil pressure regulator valve in Section 4.1.1.

Cooling water circulated through the oil cooler completely surrounds the oil cooler core. Therefore, whenever an oil cooler is assembled, special care must be taken to have the proper gaskets in place and the retaining bolts tight to assure good sealing.



Fig. 1. Typical Oil Cooler Mounting (6V-53 Engine Shown)

The oil cooler housing on a V-type engine Is attached directly to the cylinder block.

Remove Oil Cooler Core

1. Drain the cooling system by opening the drain cock at the bottom of the oil cooler housing.

2. Remove any accessories or other equipment necessary to provide access to the cooler.

3 Loosen and slide the clamps and hose back on the water inlet elbow on the cylinder block.

4. Loosen and slide the clamps and hose back on the tube leading from the thermostat to the water pump.

5. Remove the bolts and lock washers which attach the water pump to the oil cooler housing.

6. Matchmark the end of the oil cooler housing, cooler core with a punch or file so they can be reinstalled in the same position.

7. Remove the bolts and lock washers which attach the oil cooler housing to the cylinder block and remove the housing and core as an assembly. Be careful when withdrawing the assembly not to drop or damage the cooler core.



Fig. 2. Preparing Oil Cooler Core for Pressure Test

© 1972 General Motors Corp.

8. Remove all traces of gasket material from the cylinder block and the oil cooler components.



Fig.3. Oil Cooler Details and Relative Location of Parts

© 1972 General Motors Corp.

Clean Oil Cooler Core

1. *Clean oil side of Core.* Remove the core from the oil cooler. Circulate a solution of trichloroethylene through the core passages with a force pump to remove the carbon and sludge.

CAUTION: This operation should be done in the open or in a well ventilated room when trichloroethylene or other toxic chemicals are used for cleaning.

Clean the core before the sludge hardens. If the oil passages are badly clogged, circulate an Oakite or alkaline solution through the core and flush thoroughly with clean, hot water.

2. Clean water side of Cooler After cleaning the oil side of the core, immerse it in the following solution: Add one-half pound of oxalic acid to each two and one-half gallons of solution composed of one third muriatic acid and two-thirds water. The cleaning action is evidenced by bubbling and foaming.

Watch the process carefully and, when bubbling stops (this usually takes from 30 to 60 seconds), remove the core from the cleaning solution and thoroughly flush it with clean, hot water, After cleaning, dip the core in light oil.

NOTE: Do not attempt to clean an oil cooler core when an engine failure occurs in which metal particles from worn or broken parts are released into the lubricating oil. Replace the oil cooler core.

Pressure Check Oil Cooler Core

After the oil cooler core has been cleaned, check for leaks as follows:

1. Make a suitable plate and attach it to the flanged side of the cooler core. Use a gasket made from rubber to assure a tight seal. Drill and tap the plate to permit an air hose fitting to be attached at the inlet side of the core (Fig. 2).

2. Attach an air hose, apply approximately 75-150 psi air pressure and submerge the oil cooler core and plate assembly in a container of water heated to 180 °F. Any leaks will be indicated by air bubbles in the water. If leaks are indicated, replace the core.

CAUTION: When making this pressure test be sure that personnel are adequately protected against any stream of pressurized water from a leak or rupture of a fitting, hose or the oil cooler core.

3. After the pressure check is completed, remove the plate and air hose from the cooler core, then dry the core with compressed air.

NOTE: In cases where a leaking oil cooler core has caused contamination of the engine, the engine must be immediately flushed to prevent serious damage (refer to Section 5).

Install Oil Cooler Core

1. Clean the old gasket material from both faces of the core flange and affix new gaskets to the inner aid outer faces (Fig. 3.). Insert the core into the cooler housing.

NOTE: The inlet and outlet openings in the oil cooler core are stamped "IN" and "OUT". It is very important that the core be installed in the correct position to prevent any possibility of foreign particles and sludge, which may not have been removed in cleaning the fins of the core, entering and cirulating through the engine.

2. Align the matchmarks previously placed on the core and housing and install the oil cooler core in the oil cooler housing.

3. With the matchmarks in alignment. place the oil cooler housing and core against the cylinder block.

4. Slide the hose and clamps in position between the cylinder block water inlet elbow and the oil cooler. Secure the clamps in place.

5. Place a new gasket between the fresh water pump and the cooler housing and secure the pump to - he cooler housing.

6. Position the hose and clamps in place between the water pump and the tube to the thermostat housing. Secure the clamps.

7. Install all of the accessories or equipment it was necessary to remove.

© 1972 General Motors Corp.

8. Make sure the draincock in the bottom of the cooler housing is closed. Then fill the cooling system to the proper level.

© 1972 General Motors Corp.

OIL LEVEL DIPSTICK

steel ribbon type oil level dipstick is mounted in an adaptor on the side of the engine (Fig. 1). to check the amount of oil in the engine oil pan. The dipstick has markings to indicate the Low and Full oil level.

NOTE: On 8V engines, effective with 8D-468, a new dipstick, adaptor and guide combination is employed to raise the full mark on the dipstick approximately two (2) quarts. When replacement of any part of the combination is required on an early engine, the complete new combination is necessary.



Fig. 1. Typical Oil Dipstick Mounting

The engine should not be operated if the oil level is below the Low mark and no advantage is gained by having the oil quantity above the Full mark. Start and operate the engine for ten minutes to fill the oil filter, oil passages, etc., then stop the engine. After the engine has been stopped for a minimum of ten minutes, add oil as required to bring the oil level up to the full mark on the dipstick.

© 1971 General Motors Corp.

OIL PAN

The oil pan is made of cast iron, A four-piece gasket is used with the cast oil pans.

Removing and Installing Oil Pan

I may be possible to remove the oil pan without removing the engine. It is recommended that if the engine is to be taken out of the unit, the oil pan be left in place until the engine is removed.

The procedure for removing the oil pan without taking the engine out and after taking the engine out of the unit will vary. However, the following will generally apply.

1. Remove the drain plug and drain the engine lubricating oil.

2. Detach the oil pan; take precautions to avoid damaging the oil pump inlet pipe and screen.

3. Remove the oil pan gasket completely.



Fig. 1. Typical Oil Pan

4. Clean the oil pan with a suitable solvent and dry it with compressed air.

5. Inspect a cast oil pan for porosity or cracks.

6. When replacing the pan, use a new gasket and tighten the bolts evenly to avoid damaging the gasket or springing the pan.

7. Install and tighten the oil drain plug. Tighten the plug (with nylon washer) to 25-35 lb-ft torque. Replenish the lubricating oil supply and, after the engine is started, check for leaks.

© 1971 General Motors Corp.

VENTILATING SYSTEM

Harmful vapors which may be formed within the engine are removed from the crankcase, gear train and valve compartment by a continuous, pressurized ventilating system.

A slight pressure is maintained in the engine crankcase by the seepage of a small amount of air from the airbox past the piston rings. This air sweeps up through the engine and is drawn off through) a crankcase breather.

On 6V engines, a breather assembly is mounted on the upper engine front cover (Fig.1).

Service It is recommended that the breather tube be inspected and cleaned, if necessary, to eliminate the possibility of clogging. This can best be done by removing the tube from the engine, washing it with a suitable solvent and drying it with compressed air.

The wire mesh pad (element) in the breather

© 1970 General Motors Corp.



Fig. 1. Typical Crankcase Breather Mounting and Details (6V-53 Engine)

assemblies should be cleaned if excessive crankcase pressure is observed.

If it is necessary to clean the element, remove the breather housing from the flywheel housing (In-line engines), or the upper front cover (6V engines), or the governor housing and/or valve rocker cover (8V engines).
Wash the element in fuel oil and dry it with compressed air.

Reinstall the element in the breather housing, the upper front cover or the governor housing and/or the valve rocker cover and install them by reversing the procedure for removal.

@ 1970 General Motors Corp.

©1971 General Motors Corp

SPECIFICATIONS

STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

THREAD SIZE	TORQUE (lb-ft)	THREAD SIZE	TORQUE (lb-ft)
1/4 -20	7-9	9/16-12	90-100
1/4 -28	8-10	9/16-18	107-117
5/16-18	13-17	5/8 -11	137-147
5/16-24	15-19	5/8 -18	168-178
3/8 -16	30-35	3/4 -10	240-250
3/8 -24	35-39	3/4 -16	290-300
7/16-14	46-50	7/8 - 9	410-420
7/16-20	57-61	7/8 -14	475-485
1/2 -130	71-75	1 -8	580-590
1/2 -20	83-93	1 -14	685-695

EXCEPTIONS TO STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

APPLICATION	TORQUE (lb-ft)
Oil filter center stud	40-50
Oil pan drain plug (Nylon washer) 18mm	25-35

SERVICE TOOLS

TOOL NAME	TOOL NO.
Crankshaft and oil pump gear puller	J 3051
Oil pump drive gear installer	J 8968-01
Oil pump drive gear adaptor	J 23126
Two-arm steel grip puller	J 8174

© 1971 General Motors Corp.

SECTION 5
COOLING SYSTEM
CONTENTS

Cooling System **5**

Water Pump **5.1**
Water Pump Idler Pulley Assembly **5.1.1**

Thermostat **5.2.1**

Engine Cooling Fan **5.4**

Specifications - Service Tools **5.0**

COOLI NG

A centrifugal type water pump is used to circulate the engine coolants. Each system incorporates thermostats to maintain a normal operating temperature of 160 ° 185 °F. Typical V-type engine cooling system is shown in Fig . 1.

Radiator and Fan Cooling System

The engine coolant is drawn from the lower portion of the radiator by the water pump and is forced through the oil cooler and into the cylinder block.

From the cylinder block, the coolant passes up through the cylinder head(s) and, when the engine is at normal operating temperature, through the thermostat housing(s) and into the upper portion of the radiator. Then the coolant passes down a series of tubes where the coolant temperature is lowered by the air stream created by the revolving fan.

Upon starting a cold engine or when the coolant is below operating temperature, the coolant is restricted at the thermostat housing(s) and a by-pass provides water circulation within the engine during the warm. up period.

© 1972 General Motors Corp.

ENGINE COOLING SYSTEM MAINTENANCE

Engine Coolant

The function of the engine coolant is to absorb the heat, developed as a result of the combustion process

© 1972 General Motors Corp.



Fig 1. Coolant Flow Though a 6 Engine

in the cylinders, from component parts such as exhaust valves, cylinder liners and pistons which are surrounded by water jackets. In addition, the heat absorbed by the oil is also removed by the engine coolant when oil to water oil coolers are used. Refer to Section 13.3 for coolant recommendations.

Cooling System Capacity

The capacity of the basic engine cooling system (cylinder block, head, thermostat housing and oil cooler housing) is shown in the Table.

To obtain the complete amount of coolant in the cooling system of a unit, the additional capacity of the radiator, hoses, etc. must be added to the capacity of the basic engine. The capacity of the radiator and related equipment should be obtained from the equipment supplier, or the capacity of a particular cooling system may be determined by filling the system with water, then draining and measuring the amount required.

© 1972 General Motors Corp.

COOLING SYSTEM CAPACITY CHART (BASIC ENGINE)	
ENGINE	CAPACITY (Quarts)
6V-53	14

Fill Cooling System

Before starting the engine, close all of the drain cocks and fill the cooling system with water.

The use of clean, soft water will eliminate the need for de-scaling solutions to clean the cooling system. A hard mineral-laden water should be made soft by using water softener chemicals before it is poured into the cooling system. These water softeners modify the minerals in the water and greatly reduce or eliminate the formation of scale.

Start the engine and, after normal operating temperature has been reached, allowing the coolant to expand to its maximum, check the coolant level. The coolant level should be within 2 " of the filler neck.

Excessive amounts of air in the cooling system may hinder the flow of water due to pump cavitation or result in hot spots when air collects at low velocity points in the water passages. Therefore, whenever the cooling system is filled or make-up water is added, the air must be thoroughly vented from the system.

Should a daily loss of coolant be observed, and there are no apparent leaks, there is a possibility of gases leaking past the cylinder head water seal rings into the cooling system. The presence of air or gases in the cooling system may be detected by connecting a rubber tube from the overflow pipe to a water container. Bubbles in the water in the container during engine operation will indicate this leakage. Another method for observing air in the cooling system is by inserting a transparent tube in the water outlet line.

COOLANT DRAIN VALVES		
Engine	Oil Cooler or Coolant Inlet Side of Black	Side d Block Opposite Oil Cooler or Coolant Inlet
6V-53	Bottom of oil cooler, coolant inlet, and side of block near rear end	Water hole cover between hand hold covers and side of block near rear end

Drain Cooling System

Drain the cooling system by opening the cylinder block and radiator drain cocks and removing the cooling system filler cap. Removal of the filler cap permits air to enter the cooling passages and the coolant to drain completely from the system.

Drain cocks are located as indicated the coolant drain valve chart. Radiators that do not have-a drain cock are drained through the oil cooler housing drain.

If freezing weather is anticipated and the engine is not protected by antifreeze, drain the cooling system completely when the engine is not in use. Leave all of the drain cocks open until the cooling system is refilled. Should any entrapped water in the cylinder block, radiator or other engine parts freeze, it will expand and may result in damage to the engine.

© 1972 General Motors Corp.

Flushing

The cooling system should be flushed each spring and fall. The flushing operation cleans the system of antifreeze solution in the spring and removes the summer rust inhibitor in the fall, cleaning the system for the next solution. The flushing operation should be performed as follows:

1. Drain the previous season's solution from the engine.

2. Refill with soft clean water.

CAUTION: If the engine is hot, fill slowly to prevent rapid cooling and distortion of the engine castings.

3. Start the engine and operate it for 15 minutes to thoroughly circulate the water.

4. Drain the unit completely.

5. Refill with the solution required for the coming season.

Cooling System Cleaners

If the engine overheats, and the fan belt tension and water level have been found to be satisfactory, clean and flush the entire cooling system. Remove scale formation by using a reputable and safe de-scaling solvent. Immediately after using the de-scaling solvent, neutralize the system with the neutralizer. It is important descaler that the directions printed on the container of the be thoroughly read and followed.

After the solvent and neutralizer have been used, completely drain the engine and radiator and reverse-flush before filling the system.

Reverse-Flushing

After the engine and radiator have been thoroughly cleaned, they should be reverse-flushed. The water pump should be removed and the radiator and engine reverse-flushed separately to prevent dirt and scale deposits clogging the radiator tubes or being forced through the pump. Reverse-flushing is accomplished by hot water, under air pressure, being forced through the cooling system in a direction opposite to the normal flow of coolant, loosening and forcing scale deposits out.

The radiator is reverse-flushed as follows:

1. Remove the radiator inlet and outlet hoses and replace the radiator cap.

2. Attach a hose at the top of the radiator to lead water away from the engine.

3. Attach a hose to the bottom of the radiator and insert a flushing gun in the hose.

4. Connect the water hose of the gun to the water, outlet and the air hose to the compressed air outlet.

5. Turn on the water and, when the radiator is full. turn on the air in short blasts, allowing the radiator to fill between air blasts.

CAUTION: Apply air gradually. Do not exert more than 30 psi air pressure. Too great a pressure may rupture a radiator tube.

6. Continue flushing until only clean water is expelled from the radiator.

The cylinder block and cylinder head water passages are reverse-flushed as follows:

1. Remove the thermostats and the water pump.

2. Attach a hose to the water inlet of the cylinder block to drain the water away from the engine.

3. Attach a hose to the water outlet at the top of the cylinder block and insert the flushing gun in the hose.

4. Turn on the water and, when the water jackets are filled, turn on the air in short blasts, allowing the engine to fill with water between air blasts.

5. Continue flushing until the water from the engine.: runs clean.

If scale deposits in the radiator cannot be removed by chemical cleaners or reverse-flushing as outlined above, it may be necessary to remove the upper tank and rod out the individual radiator tubes with flat steel rods. Circulate water through the radiator core from the bottom to the top during this operation.

Miscellaneous Cooling System Checks

In addition to the above cleaning procedures, the other components of the cooling system should be checked periodically to keep the engine operating at peak efficiency. The cooling system hoses, thermostats and radiator pressure cap should be checked and replaced if found to be defective.

When water connection seals and hoses are installed, be sure the connecting parts are properly aligned and

© 1972 General Motors Corp.

the seal or hose is in its proper position before tightening the clamps. All external leaks should be corrected as soon as detected.

The fan belt must be checked and adjusted, if necessary, to provide the proper tension and the fan shroud must be tight against the radiator core to prevent recirculation of air which may lower the cooling efficiency.

Contaminated Engines

When the engine cooling or lubricating system becomes contaminated, it should be flushed thoroughly to remove the contaminants before the engine is seriously damaged. One possible cause of such contamination, that is damaging to the engine if it is not corrected immediately, is a cracked oil cooler core. With a cracked oil cooler core, oil will be forced into the cooling system while the engine is operating, and when it is stopped, coolant will leak into the lubricating system.

Coolant contamination of the lubricating system is especially harmful to engines during the cold season when the cooling system is normally filled with an ethylene glycol antifreeze solution. If mixed with the oil in the crankcase, this antifreeze forms a varnish which quickly immobilizes moving engine parts.

To remove such contaminants from the engine, both the cooling system and the lubrication system must be thoroughly flushed as follows:

COOLING SYSTEM

If the engine has had a failure resulting in the contamination of the cooling system with lubricating oil, the following procedure is recommended.

1. Prepare a mixture of Calgon, or equivalent, and water at the rate of two ounces (dry measure) to one gallon of water.

2. Remove the engine thermostats to permit the Calgon and water mixture to circulate through the engine and the radiator or heat exchanger.

3. Fill the cooling system with the Calgon solution.

4. Run the engine for five minutes.

5. Drain the cooling system.

6. Repeat Steps 3 through 5.

7. Fill the cooling system with clean water.

8. Let the engine run five minutes.
9. Drain the cooling system completely.

10. Install the engine thermostats.

11. Close all of the drains and refill the engine with fresh coolant.

LUBRICATION SYSTEM

When the engine lubricating system has been contaminated by an ethylene glycol antifreeze solution or other soluble material, the following cleaning procedure, using Butyl Cellosolve, or equivalent, is recommended.

> **CAUTION: Use extreme care in the handling of these chemicals to prevent serious injury to the person or damage to finished surfaces. Wash off spilled fluid immediately with clean water.**

If the engine is still in running condition, proceed as follows:

1. Drain all of the lubricating oil.

2. Remove and discard the oil filter element. Clean and dry the filter shell and replace the element.

3. Mix two parts of Butyl Cellosolve, or equivalent, with one part SAE 10 engine oil. Fill the engine crankcase to the proper operating level with the mixture.

4. Start and run the engine at a fast idle (1,000 to 1,200 rpm) for 30 minutes to one hour. Check the oil pressure frequently.

5. After the specified time, stop the engine and immediately drain the crankcase and the filter.
Sufficient time must be allowed to drain all of the fluid.

6. Refill the crankcase with SAE 10 oil after the drain plugs are replaced, and run the engine at the same fast idle for ten or fifteen minute-sand again drain the oil thoroughly.

7. Remove and discard the oil filter element, clean the filter shell and install a new element.

8. Replace the drains and fill the crankcase to the proper level with the oil recommended for normal engine operation.

9. To test the effectiveness of the cleaning procedure, it is recommended that the engine be started and run at a fast idle (1,000 to 1,200 rpm) for approximately 30 minutes. Then stop and immediately restart the

© 1972 General Motors Corp.

engine. There is a possibility that the engine is not entirely free of contaminant deposits if the starting speed is slow.

10. If the procedures for cleaning the lubricating oil system were not successful, it will be necessary to disassemble the engine and to clean the affected parts thoroughly.

Make certain that the cause of the internal coolant leak has been corrected before returning the engine to service.

© 1972 General Motors Corp.

WATE PUMP

A centrifugal-type water pump (Fig. I) is mounted on top of the engine oil cooler housing as shown in Fig. 2. It circulates the coolant through the oil cooler, cylinder block, cylinder head(s) and radiator.

The pump is belt driven by one of the camshafts (V-type engine).

An impeller is pressed onto one end of the water pump shaft, and a water pump drive pulley-is pressed onto the opposite end. The pump shaft is supported on a sealed double-row combination radial and thrust ball bearing. Coolant is prevented from creeping along the shaft toward the bearing by a seal. The shaft and bearing constitute an assembly, and are serviced as such, since the shaft serves as the inner race of the ball bearing.

The sealed water pump shaft ball bearing is filled with lubricant when assembled. No further lubrication is required.

Remove Water Pump

1. Remove the radiator cap, open the block and radiator drain cocks, and drain the cooling system.
2. Loosen and remove, the water pump belts.



Fig. 1. - Water Pump Assembly



Fig. 2. - Typical Water Pump Mouring

NOTE: An idler pulley is used on some engines to adjust the water pump drive belt tension.

3. Loosen the hose clamps and slide the hose up on the water by-pass tube.
4. Remove the five bolts securing the water pump tc the oil cooler housing and take off the pump.

Disassemble Pump

1. Note the position of the pulley on the shaft so that the pulley can be reinstalled in the same position when the pump is reassembled. Remove the water pump pulley as shown in Fig. 3.

2. Remove the pump cover and discard the gasket.

3. Press the shaft and bearing assembly, seal, and impeller out of the pump body as an assembly, by applying pressure on the bearing outer race with remover J 1930.

CAUTION: The bearing will be damaged if the pump is disassembled by pressing on the end of the pump shaft.

4. Press the end of the shaft out of the impeller as shown in Fig. 4, using plates J 8329 and holder J 3581.

5. Remove the seal assembly from the pump shaft and discard it.

© 1970 General Motors Corp.

Inspection

Wash all of the pump parts, except the bearing and shaft assembly, in clean fuel oil and dry them with compressed air.

> **NOTE: A permanently sealed and lubricated bearing is used in the bearing and shaft assembly and should not be washed. Wipe the bearing and shaft assembly with a clean lintless cloth.**

Examine the impeller for damage and excessive wear on the impeller face which contacts the seal. Replace the impeller if it is worn or damaged.

Discard the bearing if it has a general feeling of roughness, is tight or has indications of damage.

Assemble Pump

1. Use installer J 1930 to apply pressure to the outer race of the bearing as shown in Fig. 5 and press the shaft and bearing assembly into the pump body until the outer race of the bearing is flush with the outer face of the body.

> **CAUTION: The bearing will be damaged if the bearing and shaft assembly is installed by applying pressure on the end of the shaft.**

2. Lightly coat the outside diameter of the new seal with sealing compound. Then, with the face of the



Fig. 3. - Removing Pulley



Fig. 4. - Removing Shaft form Impeller with Tools J 8329 and J 358-1

body and the bearing outer race supported, install the seal by applying pressure on the seal outer flange only, until the flange contacts the body (Fig. 1). Wipe the face of the seal with a chamois to remove all dirt and metal particles.

3. Support the pulley end of the shaft on the bed of an arbor press and press the impeller on the shaft until the impeller is flush with the large end of the body.



Fig. 5. · Pressing Shaft Assembly into Water Pump

© 1970 General Motors Corp.



Fig. 6. -· Fresh Water Pump Details and Relative Location of Parts

4. Place the pulley on the bed of an arbor press. Place a suitable rod between the ram of the press and the impeller end of the shaft, then press the shaft into the pulley until the pulley is in its original position on the shaft.

5. Install the cover and a new gasket on the pump body. Tighten the cover bolts to 6-7 lb-ft torque.

6. Run the pump dry at 1200 rpm for a minimum of 30 seconds, or as required, to assure satisfactory seating of the seal.

Install Water Pump

1 Affix a new gasket to the flange of the water pump body.

2. Secure the water pump to the oil cooler housing with the five bolts and lock washers.

3. Install the hose between the water pump and water by-pass tube and tighten the hose clamps.

4. Install and tighten the belts.

NOTE: An idler pulley is used on some engines to adjust the water pump drive belt tension.

5. Close all of the drain cocks and refill the cooling system.

6. Start the engine and check for leaks.

FRESH WATER PUMP WITH CERAMIC INSERT IN IMPELLER

The water pump assemblies used includes an impeller and ceramic insert combination (Figs. 7 and 8). Disassembly and assembly of the current water pump is the same as the former water pump except as follows:

When removing the impeller protect the ceramic insert from damage at all times during pump overhaul. Always lay the impeller on the bench with the ceramic insert up to prevent damage to the insert.

Inspect the ceramic insert for cracks, scratches and bond to the impeller. If the insert is damaged, it may be replaced in the following manner:

1. Bake the used ceramic insert and impeller assembly at 500°F. for one hour to remove the ceramic insert. The ceramic insert can be removed easily from the counterbore while the adhesive is hot. Wire brush the impeller bond area to remove the old adhesive, oxide, scale, etc.
2. Wipe the impeller bond area and the grooved side of the new ceramic insert with a cloth soaked in a

© 1970 General Motors Corp.



Fig. 7. - Comparison of Water Pumps

common solvent such as alcohol. Wipe clean with a dry cloth.

3. Place the adhesive washer in the impeller bond area with the ceramic insert on top. The polished face of the ceramic insert should be visible to the assembler. Clamp the ceramic insert and impeller together with a' 3/8" bolt and nut and two smooth 1/8" thick washers. Tighten the bolt to 10 lb-ft torque.

CAUTION: Do not mar the polished surface of the ceramic insert.

4. Place the impeller assembly in a level position, with the ceramic insert up, in an oven preheated to 350'F and bake it for one hour.

NOTE: The face of the ceramic insert must be square with the axis of the tapered bore within .004". The pump shaft may be used as a mandrel for inspection.

5. Remove the impeller from the oven and, after it has cooled to room temperature, install it in the pump. Do not loosen the clamping bolt until the assembly cools. Make sure the mating surfaces of the water seal and the ceramic insert are free of dirt, metal particles and oil film.



Fig. 8. - Details of Water Pump with Ceramic Seal

© 1970 General Motors Corp.

FRESH WATER PUMP IDLER PULLEY ASSEMBLY

The fresh water pump idler pulley assembly is mounted on the upper engine front cover (Fig. 1).

Remove Idler Pulley Assembly

Remove the two attaching bolts and lift the pulley assembly away from the front cover and drive belts.

Disassemble Idler Pulley Assembly

1. Support the pulley, then press the shaft and bearing assembly and bracket from the pulley by applying pressure to the outer race of the bearing (Fig. 2).

2. Support the bracket, then press the shaft and bearing assembly from the idler pulley bracket by applying pressure on the shaft only.

Inspection

Wash the idler pulley bracket and pulley in clean fuel oil and dry them with compressed air. The idler pulley shaft and bearing assembly must not be washed in fuel oil. If the bearing is immersed in cleaning fluid dirt may be washed in and the fluid and dirt could not be entirely removed from the bearing.

Examine the bracket and pulley for excessive wear or cracks.

Revolve the shaft slowly in the bearing by hand. If rough or tight spots are detected, the bearing and shaft assembly must be replaced.



Fig. 1. - Typical Fresh Water Pump Idler Pulley Mounting in Idler Pulley



Fig. 2. - Removing Shaft and Bearing Assembly and Bracket from Idler Pulley



Fig. 3. - Installing Shaft and Bearing Assembly

© 1971 General Motors Corp. April, 1971



Fig. 4. - Installing Shaft and Bearing Assembly and Pulley in Bracket

Assemble Idler Pulley Assembly

1. Apply a minimum of 2500 lbs pressure only on the outer race of the bearing as shown in Fig. 3 and press the bearing and shaft assembly into the idler pulley until the outer race of the bearing is flush with the inside surface of the pulley.

2. With a short rod, apply pressure on the shaft only (Fig. 4) and press the shaft and bearing assembly with the pulley into the idler pulley bracket. The distance between the outer edge of the pulley and the bracket must be .160" .

Install Idler Pulley Assembly

1. Attach the idler pulley assembly to the front cover with two bolts and lock washers.

2. Install the water pump drive belts.

3. Adjust the idler pulley assembly so that the drive belts have the proper tension and tighten the bolts.

© 1971 General Motors Corp.

THERMOSTAT

Two by-pass type thermostats are used in the V-type engine. one at each cylinder head.

The by-pass system on the V-type engine consists of a cross-over tube connecting the two thermostat housings and an outlet tube attached between one thermostat housing and the water pump (Fig. 1).

At coolant temperatures below approximately 170 F. the thermostat valve remains closed and blocks the flow of coolant through the radiators.
During this period, the coolant circulates through the cylinder block and head and then back to the suction side of the pump via the by-pass tube. As the coolant temperature rises. the thermostat valve begins to open, restricting the by-pass system and permits the coolant to circulate through the radiator, When the valve is fully open. the by-pass system of the V-type engine is completely blocked off and all of the coolant circulates through the radiator.



Fig. 1. -Thermostat Housings Mounted on a 6V Engine

A properly operating thermostat is essential for efficient operation of the engine. If the engine operating temperature deviates from the normal range of 160°F - 185°F., remove and check the thermostat(s).

Remove Thermostat

1. Drain the cooling system to the necessary level by opening the drain valves.

©1971 General Motors Corp



Fig. 2. - Thermostat Housing Details and Relative Location of Parts (V-Type Engine)

2. Remove the hose connections between the thermostat housing water outlet elbow and the radiator.

3. On the V-type engine, remove the cross-over by-pass tube which is located between the thermostat housings. Also, disconnect the by-pass tube between the water pump and the thermostat housing (Fig. 2). Remove the gaskets. Then loosen the bolts and remove the thermostat housings from their bases. Remove the thermostats and remove and discard the thermostat seals.

Inspection

If the action of the thermostat has become impaired due to accumulated rust and corrosion from the engine coolant so that it remains closed, or only partially open, thereby restricting the flow of water, overheating of the engine will result. A thermostat which is stuck in a wide open position may not permit the engine to reach its normal operating temperature. The incomplete combustion of fuel due to cold operation will result in a build-up of carbon deposits on the pistons, rings and valves.

The operation of the thermostat may be checked by immersing it in a container of hot water (Fig. 3). Place a thermometer in the container. but do not allow It to touch the bottom. Agitate the water to maintain an even temperature throughout the container. As the water is heated, the thermostat valve should begin to open when the temperature reaches 167° - 174° - 176°F. (V-engine). The opening temperature is usually stamped on the thermostat. The thermostat should be fully open at approximately 190° - 192°F.

Clean the thermostat seating surface in the thermostat housing and base or the water outlet elbow

Install Thermostat

Refer to Figs. 2 -and install the thermostat(s) as follows:



Fig 3. - Method of Checking Thermostat Operation

© 1971 General Motors Corp.

V-TYPE ENGINE:

1. Install new seals in the thermostat housings. Position the seals so the lips face away from the thermostats. Press the seals in with seal installer J 22091 and handle J 7092-2.

2. Place a new gasket on each thermostat housing base.

3. Insert a thermostat in each base.

4. Install the thermostat housings and secure the housings with bolts and lock washers.

CAUTION: Exercise care to prevent damaging the thermostat seals.

5. Place new seals on the cross-over by-pass tube; then. reinstall the tube.

6. Use new gaskets and attach the water outlet elbows to the thermostat housings; secure them with bolts and lock washers.

7. Place a new seal ring on the upper end of the bypass tube and install the tube between the thermostat housing and the water pump.

8. Install the hoses between the radiator and the water outlet elbows and secure them with the hose clamps.

After the thermostats have been. installed, close all of the drain cocks and fill the cooling system. Then start the engine and check for leaks.

1971 General Motors Corp.

ENGINE COOLING FAN

The engine cooling fan is driven by a pair of V-drive belts from the crankshaft pulley (Fig. 1)

The belt-driven fan is bolted to a combination fan hub and pulley which turns on two tapered roller bearings.



Fig. 1. - Belt-Driven Fan Mounting (V-Type Engine)

Lubrication

The tapered roller bearings, used in the fan hub on V-type engines. are pressure lubricated prior to assembly. the cavity between the bearings is packed with Chevron BRB No. 2 grease or an equivalent performance grease at the time the hub is assembled. Also the fan hub cap is packed approximately 75% full of grease. Repack the fan hub assembly as outlined in the assembly procedure. The hub cap at the front and a seal at the rear of the hub prevents leakage of the lubricant.

Remove Fan, Hub and Adjusting Bracket

The fan blades must rotate in a vertical plane parallel with and a sufficient distance from the radiator core.

© 1972 General Motors Corp.



Fig. 2. - Removing Fan Hub (Pulley)

Bent fan blades reduce the efficiency of the cooling system, may throw the fan out of balance, and are apt to damage the radiator core. Before removing the fan blades, check the blades for alignment. Do not rotate the fan by pulling on the fan blades.

1. Remove the attaching bolts and lock washers and remove the fan and spacer (if used).

2. Loosen the fan hub adjusting bracket bolts and remove the drive belts. Then withdraw the bolts and washers and remove the hub and bracket assembly from the engine.

Disassemble Hub and Adjusting Bracket

V-TYPE ENGINES:

1. Remove the fan hub cap (if a spacer and cap assembly were not used).

2. Remove the hub retaining bolt and special washer

© 1972 General Motors Corp.

(Fig. 3) Also remove the shims if the former type fan) hub assembly illustrated in Fig. 7 is used.

3. Withdraw the hub and bearing assembly from the shaft. It may be necessary to tap the end of the shaft with a soft hammer to loosen the hub assembly.

4. Remove the seal and bearings from the fan hub.

5. Remove the bearing spacer (Fig. 7) and shims (if the current type hub assembly is used).

Inspection

Wash the fan and fan hub parts thoroughly with fuel oil, dry them with compressed air and inspect them for wear or damage.

Hold the inner race (shaft of sealed ball bearing assembly) and revolve the outer race of each bearing



Fig 3. Spindle Type Fan Hub Assembly (6V Engine

© 1972 General Motors Corp.

slowly by hand. If rough or tight spots are detected, replace the bearing.

Examine the fan blades for cracks. Replace the fan if the blades are badly bent,. since straightening may weaken the blades. particularly in the hub area.

Remove any rust or rough spots in the grooves of the fan pulley and crankshaft pulley. If the grooves are damaged or severly worn. replace the pulleys.

The stindle-type fan hub assembly illustrated in Fig. 3 has also been revised. A bearing spacer has been added and a new outer bearing, which provides a closer fit on the shaft, replaces the old. A baffle has also been added to retain the grease and assure lubrication at the outer bearing. To facilitate installation of the grease baffle, a .030" by 15° chamfer has been added to the bore in the pulley.

The tapped hole in the end of the shaft has beer, counterbored and increased in depth from 1.00 " to 1.26 ". A longer hub retaining bolt and a .32' thick washer replaces the former bolt and 1/8" thick washer.

New shims, assembled between the bearing spacer and the inner race of the outer bearing, provide .001 " to .006" end play The former shims, which were assembled between the hub retaining washer and the end of the shaft, provide .002 " to .004 " end play.

Assemble Hub and Adjusting Bracket

© 1972 General Motors Corp



Fig 4. - Typical Fan Hub and Spindle Details and Relative Location of Parts (6V and 8V Engine)

©1972 General Motors Corp July, 1972

Assemble the fan hub and spindle shown in Fig. 3 and 4 as follows:

1. Apply Chevron BRB No. 2 grease or an equivalent performance grease to the rollers of both bearings before installing them in the fan hub (pulley).

2. Install the inner bearing with the protruding face of the inner race facing outward from the hub.

3. Install a new seal with the felt-side flush with the outer edge of the hub.

4. Place the hub over the spindle and install the bearing spacer.

V-TYPE ENGINE

5. Pack the cavity approximately 1/4 full with grease and install the grease baffle.

6. Place the shims against the bearing spacer. Then install the outer bearing with the protruding face of the inner race facing outward from the hub.

7. Secure the hub with the retaining washer and bolt. Tighten the 1/2 "-20 bolt to 83-93 lb-ft torque while rotating the pulley.

8. Check the end play in the assembly with the spindle (shaft) in a horizontal position. The end play must be within .001 " to .006 ". If necessary, remove the bolt, washer and outer bearing and adjust the number and thickness of shims to obtain the required end play. Shims are available in .015 " .020 " and .025 "

©1972 General Motors Corp.

thickness. Then reassemble the fan hub and check the end play.

9. Fill a new fan hub cap 3/4 full of grease and install it in the end of the fan hub (pulley).

Install Fan, Hub and Adjusting Bracket

New .500 " thick and .800 " thick fan hub spacers and a new fan hub cap replaces the former spacer and cap assemblies to provide spacers compatible with the six bolt hole mounting fan hub assemblies. The spacers (individually or in combination) also provide a means for setting the different clearances between the back of the fan blades and front groove of the crankshaft pulley.

The new spacers have a flange on one side that serves as a pilot for the fan as well as a spacer pilot for the second spacer when two or more spacers are used together.

1. Attach the fan hub and adjusting bracket assembly to the bracket support on the engine with bolts, lock washers and plain washers. Do not tighten the bolts.

2. Install the drive belts and adjust the belt tension as outlined in Section 15.1. If used, install the adjusting bracket, bolt and plain washer shown in Fig. 10.

3. Install the fan (and fan spacer and cap, if used) on the hub and secure it with the 5/16 "-18 bolts and lock washers.

©1972 General Motors Corp.

SPECIFICATIONS - SERVICE TOOLS

SPECIFICATIONS

STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

THREAD SIZE	TORQUE (lb-ft)	THREAD SIZE	TORQUE (lb-ft)
1/4 -20	7-9	9/16-12	90-100
1/4 -28	8-10	9/16-18	107-117
5/16-18	13-17	5/8 -11	137-147
5/16-24	15 19	5/8 .18	168-178
3/8 -16	30-35	3/4 -10.	240-250
3/8 *-24	35-39	34-16	290-300
7/16-14	46-50	7/8 - 9	410-42C
7/16-20	57-61	7/8 -14	475-485
1/2 -13	71-75	1 .8	580-590
1/2 -20	83-93	1 .14	685-69'

EXCEPTIONS TO STANDARD BOLT AND NUT TORQUE SPECIFICATIONS

APPLICATION	THREAD SIZE	TORQUE (lb-ft)
Water pump cover bolt	5/16-18	6-7
Fan shaft bolt (V-type engines)	1/2 -20	83-93

SERVICE TOOLS

TOOL NAME	TOOL NO.
Holder	J 358-1
Remover and installer	J 1930
Installer	J 22091
Puller	J 4794-01
Handle	J 7092-2
Plates	J 8329

© 1971 General Motors Corp. May, 1971

SECTION 6

EXHAUST SYSTEM

CONTENTS

Exhaust System 6

Exhaust Manifold (Air Cooled) 6.1

EXHAUST SYSTEM

The engines are equipped with air cooled (dry type) exhaust manifolds. The air cooled manifolds are used on engines employing fan and radiator cooling. Manifolds have a flange at one end.

Manifold is attached to the head by studs, special washers and nuts.

© 1970 General Motors Corp.

EXHAUST MANIFOLD (AIR COOLED)

Manifolds used.

has a circular outlet which is connected to the exhaust pipe with a Marmon-type clamp (Fig. 1).

Remove Exhaust Manifold

1. Disconnect the exhaust pipe or muffler from the exhaust manifold flange.

2. Loosen, but do not remove, one of the center exhaust manifold nuts. Remove the other nuts and washers.

3. Support the manifold and remove the center nut and washer.

4. Remove the manifold and gasket from the cylinder head.

Inspection

Remove any loose scale and carbon that may have accumulated on the internal walls of the exhaust manifold. Clean the manifold and check for cracks, especially in the holding lug areas.

Clean all traces of gasket material from the cylinder head.

Examine the exhaust manifold studs. Replace damaged studs. Apply sealant to the threads and drive new studs to 25-40 lb-ft torque (1.40" to 1.50" height).

Install Exhaust Manifold

1. Place a new gasket over the studs and against the cylinder head.

2. Position the exhaust manifold over the studs and hold it against the cylinder head.

3. Install the washers and nuts on the studs. If beveled (dished) washers are used, position them so that the crown side faces the nut. Crabs are used in place of washers at the end positions (Fig. 1).

© 1970 General Motors Corp.



Fig. 1. - Exhaust Manifold with Marmon Flange

Beginning with one of the center stud nuts and working alternately toward each end of the manifold, tighten the nuts to 30-35 lb-ft torque.

4. Connect the exhaust pipe or muffler to the exhaust manifold flange.

© 1970 General Motors Corp.

SECTION 7

ELECTRICAL EQUIPMENT, INSTRUMENTS AND PROTECTIVE SYSTEMS

CONTENTS

Electrical System	**7**
Battery-Charging Generator	**7.1**
Battery-Charging Generator Regulator	**7.1.1**
Starting Motor	**7.3**
Shop Notes - Trouble Shooting - specifications - Service Tools	**7.0**

ELECTRICAL SYSTEM

The engines are equipped with a 12 volt electrical system.

A typical electrical system generally consists or a starting motor, a battery charging generator (alternator), a transistor combination voltage regulator, current regulator and cutout relay to protect the electrical system, a storage battery and the necessary wiring.

Detailed information on maintenance and repair of the specific types of electrical equipment used can be found in the service manuals and bulletins issued by the equipment manufacturer. Information regarding equipment manufactured by the Delco-Remy Division of General Motors Corporation may be obtained from their electrical equipment operation and maintenance manuals. The manuals may be obtained from United Motors Service, or from the Technical Literature Section, Delco-Remy, Division of General Motors Corporation, Anderson, Indiana.

In most instances, repairs and overhaul work on electrical equipment should be referred to an authorized repair station of the manufacturer of the equipment. For electrical equipment manufactured by Delco-Remy Division, repair service and parts are available through United Motors Service branches and repair stations.

©1972 General Motors Corp.

BATTERY-CHARGING GENERATOR (~~D.C. ,and~~ A.C.)

The battery-charging circuit consists of a generator (alternator), regulator, battery and the wiring. The battery-charging generator is introduced into the electrical system to provide a source of electrical current for maintaining the storage battery in a charged condition and to supply sufficient current to carry any other electrical load requirements up to the rated capacity of the generator.

The alternating current self-rectifying generator (alternator), Figs. 2 and 3, is especially beneficial on an engine with extra electrical accessories and one that has to operate for extended periods at idle speeds. Diodes, built into the slip ring end frame, rectify the three phase A.C. voltage to provide D.C. voltage at the battery terminal of the generator, thereby eliminating the need for an external rectifier. The alternator is also available in a variety of sizes and types.

The proper selection of a generator which will meet the needs of the battery-charging circuit on the particular engine is mandatory. This. together with adherence to the recommended maintenance procedures, will reduce generator troubles to a minimum. Since most generators adhere to the same basic design. the maintenance. removal and installation procedures for all are similar.

Generator Maintenance

1. Maintain the proper drive belt tension. Replace worn or frayed belts. Belts should be replaced as a set when there is more than one belt on the generator drive.

2. Lubricate the generator bearings as outlined in the Lubrication and Preventive Maintenance Chart In Section 15.1.

Remove Generator

1. Disconnect all of the leads from the generator and tag each one to ensure correct re-installation.

2. Loosen the generator mounting bolts and nuts and the adjusting strap bolt. Then, remove the generator drive belts.

© 1971 General Motors Corp.



Fig. 1 - 30. DN Type 100 A.C. Self-Rectifying Generator (Alternator)



Fig. 2 - 10. DN Type 112 A.C. Self-Rectifying Generator (Alternator)

© 1971 General Motors Corp.

3. While supporting the generator, remove the adjusting strap bolt and washers and the mounting bolts, washers and nuts. Then remove the generator.

4. Remove the pulley assembly if the generator is to be replaced.

Install Generator

1. Install the generator drive pulley, if it was removed. Tighten the pulley retaining nut to 60 lb-ft torque.

NOTE: If the pulley was not removed, check the retaining nut for proper torque.

2. Position the generator on the mounting brackets and start the bolts, with lock washers, through the bolt holes in the generator end frames. If nuts are used, insert the bolts through the bolt holes and then install the lock washers and nuts.

3. Align the threaded hole in the extension ear of the drive end frame with the slot in the adjusting strap. Start the bolt, with the lock washer and plain washer, through the slot of the adjusting strap and into the threaded hole in the generator end frame.

4. Place the drive belts in the grooves of the pulleys.

5. Adjust the generator belt tension as outlined in Section 15.1.

6. Attach the wires and cables. Be sure that each one is correctly installed in accordance with its previous location on the generator. Keep all connections clean and tight.

Polarizing D.C Generator

After each check or adjustment of the voltage regulator or generator, particularly after the leads have been disconnected and then reconnected, it is necessary to polarize the D.C. generator before starting the engine. This is to ensure correct polarity with respect to the battery.

CAUTION: Never attempt to polarize an alternator.

Failure to polarize a D.C. generator wilt result in burned or stuck cutout relay contact points in the regulator, a rundown battery and damage to the generator.

The procedure for correctly polarizing a generator will vary with the type of electrical equipment installed and upon the generator regulator wiring circuit. If the generator field is grounded through the regulator. it Is an "A" circuit; if it is internally grounded, it is a "B" circuit.

If Delco-Remy electrical equipment is installed, reference can be made to the Delco-Remy "Electrical Equipment Manual" and "Test Specifications" (refer to Section 7) to determine the type of circuit applicable to the regulator being used. Since it is possible to have either an "A" or "B" circuit regulator with any given generator, the polarizing procedures must be carefully adhered to. Use of the wrong polarizing procedure or neglecting to polarize will result in reversed generator polarity and serious damage to electrical components.

After ascertaining the correct circuit used, polarize the generator as outlined below:

1. "A" Circuit:

   Connect a jumper lead momentarily between the "BAT' and "GEN" terminals of the regulator.

2. "B" Circuit:

   Remove the "F" lead from the regulator and momentarily connect it to the "BAT" terminal of the regulator.

A momentary surge of current to the generator correctly polarizes it with respect to the battery.

Alternator Precautions

Precautions must be taken when working on or around alternators. The diodes and transistors in the alternator circuit are very sensitive and can be easily destroyed.

Avoid grounding or shorting the output wires or the field wires between the generator and the regulator.

Grounding an A.C. generator's output wire or terminals, which are always "hot" regardless of whether or not the engine is running, or accidental reversing of the battery polarity will destroy the diodes. Grounding the field circuit will also result in the destruction of the diodes. Some voltage regulators provide protection against some of these circumstances. However, it is recommended that extreme caution be used.

© 1971 General Motors Corp.



Fig. 4 - 20. DN Type 250 A.C. Self-Rectifying Generator(Alternator)

Accidentally reversing the battery connections must be avoided.

Never disconnect the battery while an alternator is in operation. Disconnecting the battery may result in damage to the generator diodes due to the momentary high voltage and current generated by the rapid collapse of the magnetic field surrounding the field windings.

In marine applications which have two sets of batteries, switching from one set of batteries to the other while the engine is running will momentarily disconnect the batteries and result in damage to the generator diodes unless the field circuit is opened first.

If a booster battery is to he used. the batteries must be connected correctly (negative to negative and positive to positive).

Never use a fast charger with the battery connected or as a booster for battery output.

Never attempt to polarize 'the alternator.

The alternator diodes are also sensitive to heat and care must be exercised to prevent damage to them from soldering irons. etc.

If faulty operation of an alternator occurs on an engine equipped with an insulated starting motor. check to be sure that a ground strap is present and is correctly installed.

© 1971 General Motors Corp.

BATTERY-CHARGING GENERATOR REGULATOR

A.C. CHARGING CIRCUIT

The alternating current generator regulator is similar in outward appearance to the regulator used with the D.C. generator. The D.C. and A.C. regulators are NOT interchangeable.

The internal wiring circuits of all standard A.C. generator regulators are similar, but the internal connections vary somewhat according to the method used to control the circuit breaker relay.

There are two and three unit standard A.C. generator regulators: the two unit regulators have a circuit breaker relay controlled by a relay rectifier or by an oil pressure switch and the three-unit regulators have a circuit breaker relay controlled by a built-in control relay.

The generator field circuit is insulated in the generator and grounded in the regulator. This type of connection is designated as Circuit "A".

NOTE: Each type of regulator is used with a certain circuit. Do not attempt to interchange regulators.

The two unit A.C. generator regulator has a circuit breaker relay and a voltage regulator unit while the three unit regulator is also equipped with a control relay in addition to the other two units.

CIRCUIT BREAKER RELAY

The circuit breaker relay has a core with the winding made up of many turns of fine wire. This core and winding are assembled into a frame. A flat steel armature is attached to the frame by a hinge and is centered above the core. Two contact points, supported by two flat springs on the armature, are located above two stationary contact points. The upper and lower contact points are held apart by the tension of a flat spring riveted to the top side of the armature.

Operation

When the D.C. voltage reaches the value for which the circuit breaker relay is adjusted, the magnetism Induced in the core by current flow in the winding is sufficient to overcome the armature spring tension and the relay points close. Closing of the contact points connects the D.C. side of the power rectifier to the battery so that current will flow to the battery whenever the generator is driven at sufficient speed.

The relay contact points remain closed as long as the D.C. voltage is enough to hold the relay armature against the core. They open when the voltage decreases to a value at which the magnetic pull of the core can no longer overcome the armature spring tension.

VOLTAGE REGULATOR

The voltage regulator unit has a core with a single shunt winding. This winding also consists of fine wire and is connected across the D.C. side of the power rectifier. The assembly and parts are similar to the circuit breaker relay. The matching upper contact point is supported by a detachable contact support insulated from the frame.

Operation

If the voltage regulator unit is not operating, the generator field circuit is completed to ground through the contact points which are held closed by the tension of a spiral spring acting on the armature.

When the D.C. voltage of the A.C. D.C. system reaches the value for which the voltage regulator is adjusted, the magnetic field produced by the shunt winding overcomes the armature spring tension and pulls the armature down, causing the contact points to separate. When the contact points separate, resistance is introduced into the field circuit. The resistance decreases the field current causing a corresponding decrease in generator voltage and magnetic pull on the regulator armature. This allows the armature spring tension to reclose the contact points. When the voltage again reaches the value for which the voltage regulator is adjusted, this cycle repeats and continues to repeat many times a second, thus limiting the voltage to the value for which the regulator is set.

With the voltage limited in this manner, the generator supplies varying amounts of current to meet the various states of battery charge and electrical load.

Voltage regulators are compensated for variations in temperature by means of a bimetal thermostatic hinge on the armature. The effect of this hinge causes the regulator to adjust at a higher voltage when cold, which partly compensates for the fact that a high voltage is required to charge a cold battery.

© 1971 General Motors Corp.

CONTROL RELAY

In addition to a circuit breaker and a voltage regulator. the three-unit regulator has a control relay unit. This unit has a core with a single shunt winding connected from the "SW" terminal of the regulator to ground. The winding and core are assembled into a frame. A flat steel armature supporting the upper one of two relay contacts is attached to the frame by a hinge and is centered above the core. The lower contact point is supported by a detachable contact support insulated from the frame. An armature stop is assembled above the upper contact.

Operation

When the ignition switch is "OFF", the contact points are held apart by the tension of a spiral spring acting on the armature. When the ignition switch is turned "ON", battery current flows through the control relay winding to ground. The magnetic field produced by the winding overcomes the armature spring tension and pulls the armature down causing the contact points to close. This completes the circuit to ground for the circuit breaker relay winding so that it can operate when the D.C. voltage from the power rectifier reaches the value for which the circuit breaker relay is adjusted. The control relay contact points remain closed until the ignition switch is turned "OFF".

TRANSISTORIZED AND TRANSISTOR REGULATORS

In addition to the standard regulator. there are two other types of regulators being used with the self-rectifying A.C. generators in the battery-charging circuit. One Is a transistorized regulator which contains a vibrating voltage regulator unit and a field relay unit. The other is a transistor regulator which contains no moving parts and is used with a separately mounted field relay.

TRANSISTORIZED REGULATOR

The transistorized regulator (Fig. 3). for use on a negative ground circuit. contains a vibrating voltage regulator unit and a field relay unit. The regulator uses a single transistor and two diodes. The transistor works In conjunction with the conventional voltage unit having a vibrating contact point to limit the generator voltage to a preset value. A field discharge diode reduces arcing at the voltage regulator contacts by dissipating the energy created in the generator field windings when the contacts separate. A suppression diode prevents damage from transient voltages which may appear in the system.

Certain transistorized regulators are equipped with a choke coil to permit the installation of a capacitor between the regulator and the "BAT" terminal on installations experiencing radio interference. The capacitor suppresses the radio noise and the choke coil



Fig. 3. - Transistorized Regulator

© 1971 General Motors Corp.

acts to prevent oxidation of the voltage regulator contacts. Regulators incorporating the choke coil are identified by a spot of green paint on the regulator base, next to the single mounting bolt hole.

CAUTION: A capacitor must not be installed unless the transistorized regulator incorporates the choke coil.

Operation

When the engine starting switch is closed, the field relay winding is energized and causes the contacts to close. Current then flows from the battery through the relay contacts to the regulator "F2" terminal. From this point, the current flows through the generator field winding and then through the transistor and voltage contact points to ground.

As the generator speed increases, the increased voltage from the generator "BAT' terminal is impressed through the field relay contacts across the regulator shunt winding. The magnetism created in the winding causes the voltage contacts to open, thus causing the transistor to shut off the field current. The generator voltage then decreases and the voltage contacts reclose. This cycle repeats many times per second, thereby limiting the generator voltage to the value for which the regulator is set.

The magnetism produced in an accelerator winding, when the voltage contacts are closed, aids the shunt winding in opening the contacts. When the contacts are open, the absence of the magnetism i n the accelerator winding allows the spring to immediately reclose the contacts. This action speeds up the vibration of the contacts.

CAUTION: Do not short across or ground any of the terminals on the regulator or the generator and do not attempt to polarize the generator.

TRANSISTOR REGULATOR

The transistor regulator is composed principally of transistors, diodes, capacitors and resistors to form a completely static electrical unit containing no moving parts.

The transistor is an electrical device which limits the generator voltage to a preset value by controlling the generator field current. The diodes, capacitors and resistors act together to aid the transistor in performing this function, which is the only function that the regulator performs in the charging circuit.

The voltage at which the generator operates is determined by the regulator adjustment. Once adjusted, the generator voltage remains almost constant, since the regulator is unaffected by length of service, changes in temperature or changes in generator output and speed.

A separately mounted field relay connects the regulator "POS" terminal and the generator field windings to the battery when the engine starting switch is closed.



Fig. 4. · Transistor Regulator (Negative Ground Circuits Only)

© 1971 General Motors Corp



Fig. 5 - Transistor Regulator with Plug-In Connections

The voltage regulator illustrated in Fig. 4 is designed for negative ground battery-charging circuits only. It has two exposed terminals. The voltage setting may be adjusted by relocating a screw in the base of the regulator.

The voltage regulator shown in Fig. 5 has shielded plug-in connections and requires a cable and plug assembly to connect the regulator into the battery-charging circuit. This type of regulator may be used in negative ground. positive ground and insulated charging circuits. The voltage setting may be adjusted by removing a plug in the cover and turning a slotted adjusting button inside the regulator.

Operation

When the engine starting switch is closed, the field relay winding is energized, which causes the relay contacts to close.

In the **negative ground circuit** with the field relay contacts closed and the engine not running, generator field current can be traced from the battery through the relay contacts to the regulator "POS" terminal. Current then continues through the back-bias diode (Dl) and power transistor (TRI) to the regulator "FLID" terminal, and then through the generator field winding to ground, completing the circuit back to the battery.

When the generator begins to operate, A.C. voltages are induced in the stator windings. These voltages are changed, or rectified. to a D.C. voltage which appears at the output, or "BAT", terminal on the generator The generator then supplies current to charge the battery and operate vehicle accessories.

As generator speed increases, the voltage reaches the pre-set value and the components in the regulator cause transistor TR-I to alternately "turn off"' and "turn on" the generator field voltage. The regulator thus operates to limit the generator output voltage to the pre-set value.

In the **positive ground circuit**, when the switch is closed and the engine is not running, the field current can be traced from the battery positive ground to generator ground, and then to the regulator "POS" terminal. The current continues through diode Dl and transistor TRI to the regulator "FLD" terminal, and then through the field winding and field relay contacts back to the battery, thus completing the circuit. Except for this primary difference, this circuit operates in the same manner as that described for the negative ground circuit.

REGULATOR PRECAUTIONS

Never short or ground the regulator terminals; do not attempt to polarize the circuit.

Make sure all connections in the charging circuit are tight to minimize resistance.

Refer to "A.C. Generator Precautions" in Section 7 1

© 1971 General Motors Corp

STARTING MOTOR

The starting motor (Fig. 1) has a shift lever and solenoid plunger that are totally enclosed to protect them from dirt.

The starting motor is equipped with a Sprag overrunning clutch drive (Figs. 2 and 3). An important feature of the Sprag type drive is that once the solenoid has moved the starter pinion in mesh with the ring gear on the flywheel, it will not disengage during intermittent engine firing, which prevents damage to the pinion and the ring gear teeth. The pinion remains engaged until starting is assured and the solenoid circuit is interrupted.

The solenoid switch, mounted on the starting motor housing, operates the overrunning clutch drive by means of linkage and a shift lever. When the starting switch is engaged, the solenoid is energized, shifting the starting motor pinion in mesh with the engine flywheel ring gear and closing the main contacts within the solenoid. Battery current is then directed to the motor causing the armature to turn. Cranking torque is transmitted by the Sprag clutch from the starting motor armature to the engine flywheel ring gear. To protect the armature from excessive speed as the engine starts, the clutch "overruns", or turns faster than the armature, which permits the pinion to disengage.

The Sprag overrunning clutch drive type starting motor is used with an engine flywheel ring gear which has either no chamfer or a Bendix chamfer. It cannot be used with a ring gear which has a Dyer chamfer. When installing a service replacement starting motor, make sure the correct flywheel ring gear is also used.

Under normal operating conditions, no maintenance will be required on the starting motor between engine overhaul periods.

Adjustable Nose Housing

The nose housing on the Sprag clutch type starting motor can be rotated to obtain a number of different solenoid positions with respect to the mounting flange. When repositioning of the solenoid is required on a service replacement starting motor, proceed as follows:

STARTER WITH INTERMEDIATE DUTY CLUTCH

The lever housing and the commutator end frame are held to the field frame by bolts extending from the end frame to threaded holes in the lever housing. The nose housing is held to the lever housing by internal attaching bolts extending from the lever housing to



Fig. 1 · Typical Starting Motor Mounting

threaded holes in the nose housing (Fig. 2). With this arrangement, it is necessary to partially disassemble the motor to provide access to the nose housing attaching bolts. Relocate the nose housing as follows:

1. Remove the electrical connector and the screws attaching the solenoid assembly to the field frame; then, remove the bolts from the commutator end frame.

2. Separate the field frame from the remaining assembly and pull the armature away from the lever housing until the pinion stop rests against the clutch pinion; this will provide access to the nose housing attaching bolts.

3. Remove the nose housing attaching bolts with a box wrench or open end wrench.

4. Turn the nose housing to the required position.
   NOTE: The solenoid must never be located below the centerline of the starter or dust, oil, moisture and foreign material can collect and cause solenoid failures.

5. Reinstall the nose housing attaching bolts and tighten them to 11-15 lb-ft torque.

6. Reassemble the motor.

STARTER WITH HEAVY-DUTY CLUTCH

The nose housing, on starters equipped with the heavy-duty clutch, is attached to the lever housing by six bolts located around the outside of the housing (Fig. 3). Relocate the nose housing as follows:

1. Remove the six socket head screws (1short and

© 1971 General Motors Corp.



Fig. 2. - Cross-sectional View of Motor with Sprag Intermediate Duty Clutch

5 long) and six neoprene plugs from the unused holes if a 12 hole starter mounting flange is used.

2. Turn the nose housing to the required position.

NOTE: The solenoid must never be located below the centerline of the starter or dust, oil, moisture and foreign material can collect and cause solenoid failures.

3. Install the six socket head screws, with the short screw in the shallow hole nearest the solenoid. Install six neoprene plugs in the unused holes if a 12 hole starter mounting flange is used.

4. Tighten the screws to 13-17 lb-ft torque.

High-Output Starting Motor

A high-output 12volt starting motor. with a Sprag overrunning clutch type drive, is provided for certain vehicle applications which require the equivalent of 24volts for starting the engine and 12volts for lighting and operation of electrical accessories. The same total battery capacity recommended for use with a 24volt starter (two 205 ampere-hour batteries) must be retained and connected in parallel for the high-output 12volt starter.

Lubrication of Starting Motors

The starting motor bearings (bushings) are lubricated by oil saturated wicks which project through each



Fig. 3. - Cross-sectional View of Motor with Sprag Heavy Duty Clutch

© 1971 General Motors Corp.

bronze bushing (one at each end and one at the center) and contact the armature shaft. Oil can be added to each wick by removing a pipe plug which is accessible on the outside of the motor.

Remove Starting Motor

1. Remove the ground strap or cable from the battery or the cable from the starting motor solenoid. Tape the end of the cable to prevent discharging the battery from a direct short.

2. Disconnect all of the wires from the starting motor solenoid terminals. Tag the wires to insure correct reinstallation.

3. Support the motor and remove the three bolts and lock washers which secure it to the flywheel housing. Then pull the motor forward to remove it from the flywheel housing.

Check the starting motor, if required, in accordance with the Delco-Remy "Cranking Circuit" maintenance handbook.

Install Starting Motor

To install the starting motor, reverse the procedure outlined for removal. Tighten the 5/8" -11 mounting bolts to 137-147 lb-ft torque.

Keep all of the electrical connections clean and tight.

When installing wiring terminal leads to the starting motor and the solenoid switch, tighten the No. 1032 connections to 1630 lb-in torque and the 1/2" x 13 connections to 20-25 lb-ft torque.

1971 General Motors Corp.

SECTION 12

SPECIAL EQUIPMENT

CONTENTS

Air Compressor 12.4

Trouble Shooting-Specifications Service Tools 12.0

© 1970 General Motor Corp.

AIR COMPRESSOR

The air compressor

is flange-mounted to the flywheel housing and gear driven by means of an accessory drive attached to the

camshaft gear.

The air compressor runs continuously while the engine is running. While the compressor is running, actual compression of air is controlled by the compressor governor which acts in conjunction with the unloading mechanism in the compressor cylinder block. The governor starts and stops the compression of air by loading or unloading the compressor when the air pressure in the system reaches the desired minimum or maximum pressure.

During the down stroke of each piston, a partial vacuum is created above the piston which unseats the inlet valve and then allows air drawn from the air box



Fig. 1.- Typical Air Compressor With Drive Hub

in the engine cylinder block or through an intake strainer to enter the cylinder above the piston. As the piston starts the upward stroke, the air pressure on top of the inlet valves plus the inlet valve return spring force, closes the inlet valve. The air above the piston is further compressed until the pressure lifts the discharge valve and the compressed air is discharged through the discharge line into the reservoir.



Fig. 2. - Fixture For Holding Drive While Installing or Removing Slotted Nut

© 1972 General Motors Corp. **July, 1972**

As each piston starts its downstroke, the discharge valve above it returns to its seat, preventing the compressed air from returning to the cylinder and the same cycle is repeated.

When the air pressure in the reservoir reaches the maximum setting of the governor, compressed air from the reservoir passes through the governor into the cavity below the unloading pistons in the compressor cylinder block. The air pressure lifts the unloading pistons which in turn lifts the inlet valves off their seats.

With the inlet valves held off their seats, the air during each upstroke of the piston is merely passed back through the air inlet cavity and to the other cylinder where the piston is on the downstroke. When the air pressure in the reservoir drops to the minimum setting of the governor, the governor releases the air pressure beneath the unloading pistons. The unloading piston return spring then forces the piston down and the inlet valve springs return the inlet valves to their seats and compression is resumed.

Service Note

When installing the drive hub on a flange mounted air compressor (Fig.1), it is important the 3/4 "10 drive shaft slotted nut be tightened to 100 lb-ft torque minimum before installing the 3/32 "x 1 1/4 " cotter pin.

The air compressor drive shaft will turn during the torquing operation unless some provision is made to hold it. One way this can be done is to weld a modified drive coupling to a support or base which in turn can be anchored to the mounting flange of the compressor. An old flywheel housing cover that matches the flange of the compressor makes an ideal base for the modified coupling. With the exterior splines of the coupling in mesh with the internal splines of the drive hub and the entire assembly secured to the compressor housing, the hub and shaft are kept from rotating when the torque is applied. That part of the base within the inner diameter of the coupling must be removed to permit placement of the wrench socket on the nut. Two bolts will secure the base to the compressor during the torquing operation (Fig. 2).

© 1972 General Motors Corp.

SECTION 13

OPERATING INSTRUCTIONS

CONTENTS

Engine Operating Instructions 13.1

Engine Operating Conditions 13.2
Engine Run-In Instructions 13.2.1

Fuels, Lubricants and Coolants 13.3

© 1970 General Motors Corp.

ENGINE OPERATING INSTRUCTIONS

PREPARATION FOR STARTING ENGINE FIRST TIME

Before starting an engine for the first time, carefully read and follow the instructions in Sections 13 and 14 of this manual. Attempting to run the engine before studying these instructions may result in serious damage to the engine.

NOTE: When preparing to start a new or overhauled engine or an engine which has been in storage, perform all of the operations listed below. Before a routine start (at each shift), see Daily Operations in the Lubrication and Preventive Maintenance Chart, Section 15.1.

Cooling System

Install all of the drain cocks or plugs in the cooling system (drain cocks are removed for shipping).

Open the cooling system vents, if the engine is so equipped.

Remove the filler cap and fill the cooling system with clean, soft water or a protective solution consisting of high boiling point type antifreeze, if the engine will be exposed to freezing temperatures. Keep the liquid level about two inches below the filler neck to allow for fluid expansion.

Use a quality rust inhibitor if only water is used in the cooling system.

Close the vents, if used, after filling the cooling system.

Lubrication System

The lubricating oil film on the rotating parts and bearings of a new or overhauled engine, or one which has been in storage, may be insufficient for proper lubrication when the engine is started for the first time.

It is recommended that the engine lubricating system be charged with a pressure prelubricator, set to supply a minimum of 25 psi oil pressure, to ensure an immediate flow of oil to all bearings at the initial engine startup. The oil supply line should be attached to the engine so that oil under pressure is supplies to the main oil gallery.

With the oil pan dry, use the prelubricator to prime the engine with sufficient oil to reach all beating surfaces. Use heavy-duty lubricating oil as specified under Lubricating Oil Specifications in Section 13.3. Then remove the dipstick, wipe it with a clean cloth, insert and remove it again to check the oil level in the oil pan. Add sufficient oil, if necessary, to bring it to the full mark on the dipstick. Do not overfill.

If a pressure prelubricator is not available, fill ;he crankcase to the proper level with heavy-duty lubricating oil as specified under Lubricating Oil Specifications in Section 13.3. Then prelubricate the upper engine parts by removing the valve rocker covers and pouring lubricating oil, of the same grade and viscosity as used in the crankcase, over the rocker arms.

Air Cleaner

If the engine is equipped with oil bath air cleaners, fill the air cleaner oil cups to the proper level with clean engine oil. Do not overfill.

Fuel System

Fill the fuel tank with the fuel specified under Diesel Fuel Oil Specifications in Section 13.3.

© 1972 General Motors Corp.

If the unit is equipped with a fuel valve, it must be opened.

To ensure prompt starting, fill the fuel system between the pump and the fuel return manifold with fuel. If the engine has been out of service for a considerable length off time, prime the filter between the fuel pump and the injectors. The filter may be primed by removing the plug in the top of the filter cover and slowly filling the filter with fuel.

Lubrication Fittings

Fill all grease cups and lubricate at all fittings with an all purpose grease. Apply lubricating oil to the throttle linkage and other moving parts and fill the hinged cap oilers with a hand oiler.

Drive Belts

Adjust all drive belts as recommended under Lubrication and Preventive Maintenance in Section 15.1.

Storage Battery

Check the battery. The top should be clean and dry, the terminals tight and protected with a coat of petroleum jelly and the electrolyte must be at the proper level.

NOTE: When necessary, check the battery with a hydrometer; the reading should be 1.265 or higher. However, hydrometer readings should always be corrected for the temperature of the electrolyte.

Clutch

Disengage the clutch, if the unit is so equipped.

STARTING

Before starting the engine for the first time, perform the operations listed under Preparation For Starting Engine First rime.

Before a routine start, see Daily Operations in the Lubrication and Preventive Maintenance Chart, Section 15.1.

If a manual or an automatic shut-down system is incorporated in the unit, the control must be set in the open position before starting the engine.

The blower will be seriously damaged if operated with the air shut-off valve in the closed position.

Initial Engine Start (Electric)

Start an engine equipped with an electric starting motor as follows: Set the speed control lever at part throttle, then bring it back to the desired no-load speed. In addition, on mechanical governors, make sure the stop lever on the governor cover is in the run position. Then press the starting motor switch firmly. If the engine fails to start within 30 seconds, release the starting switch and allow the starting motor to cool a few minutes before trying again. If the engine fails to start after four attempts, an inspection should be made to determine the cause.

CAUTION: To prevent serious damage to the starter, if the engine does not start, do not press the starting switch again while the starting motor is running.

© 1972 General Motors Corp.

RUNNING

Oil Pressure

Observe the oil pressure gage immediately after starting the engine. If there is no pressure indicated within 10 to 15 seconds, stop the engine and check the lubricating oil system. Refer to the Trouble Shooting Charts in Section 152.

Warm-Up

Run the engine at part throttle and no-load for approximately five minutes, allowing it to warm-up before applying a load.

Ambient Temperature	Pressure Gage Reading
Above 40°F.	1500 psi
40°F. to 0°F.	2500 psi
Below 0° F.	3300 psi

Inspection

While the engine is running at operating temperature, check for coolant, fuel or lubricating oil leaks. Tighten the line connections where necessary to stop leaks.

Engine Temperature

Normal engine coolant temperature is 160 °F. To 185 °F.

Crankcase

If the engine crankcase was refilled, stop the engine after normal operating temperature has been reached, allow the oil to drain back into the crankcase and check the oil level. Add oil, if necessary, to bring it to the proper level on the dipstick.

Use only the Heavy Duty lubricating oil specified under Lubricating Oil Specifications.

Cooling System

Remove the radiator tank cap slowly after the engine has reached normal operating temperature and check the engine coolant level. The coolant level should be near the top of the opening. If necessary, add clean soft water or a high boiling point type antifreeze.

Avoid Unnecessary Engine Idling

During long engine idling periods, the engine coolant temperature will fall below the normal operating range. The incomplete combustion of fuel in a cold engine will cause crankcase dilution, formation of lacquer or gummy deposits on the valves, pistons and rings and rapid accumulation of sludge 'in the engine.

NOTE: When prolonged engine idling is necessary, maintain at least 800 rpm.

© 1972 General Motors Corp.

STOPPING

Normal Stopping

1. Release the load and decrease the engine speed. Put all shift levers in the neutral position.

2. Allow the engine to run at half speed or slower with no load for a short time, then move the stop lever to stop to shut down the engine.

Emergency Stopping

If the engine does not stop after using the normal stopping procedure, pull the "Emergency Stop" knob all the way out. This control cuts off the air to the engine. Do not try to restart again until the cause for the malfunction has been found and corrected.

> **CAUTION: The emergency shut-down system should never be used except in an emergency. Use of the emergency shut-down can cause oil to be sucked past the oil seals and into the blower housing.**

The air shut-off valve, located on the blower air inlet housing, must be reset by hand and the "Emergency Stop" knob pushed in before the engine is ready to start again.

Fuel System

If the unit is equipped with a fuel valve, close it. Fill the fuel tank; a full tank minimizes condensation.

Cooling System

Drain the cooling system if it is not protected with antifreeze and freezing temperatures are expected. Leave the drains open.

Crankcase

Check the oil level in the crankcase. Add oil, if necessary, to bring it to the proper level on the dipstick.

Clean Engine

Clean and check the engine thoroughly to make certain it will be ready for the next run.

Refer to Lubrication and Preventive Maintenance and perform all of the daily maintenance operations. Also, perform the operations required for the number of hours or miles the engine has been in operation.

Make the necessary adjustments and minor repairs to correct difficulties which became apparent to the operator during the last run.

© 1972 General Motors Corp.

ENGINE OPERATING CONDITIONS

The engine operating charts are included as an aid for engine operation and trouble shooting. Any variations from the conditions as listed may indicate an abnormal situation in need of correction. Make sure that the readings represent true values, and that instruments are accurate, before attempting to make corrections to the engine.

© 1972 General Motors Corp.

6V, 53N ENGINES
(4-Vave Cylinder Head)

	2200 rpm	2500 rpm	2800 rpm
Lubrication System			
Lubricating oil pressure (psi):			
Normal	40-60	40-60	40-60
Minimum for safe operation	30.0	32.0	32.0
*Lubricating oil temperature (degr F.) - max	200-235	200-235	200-235
Air System			
Air box pressure (inches mercury) - min ..... at full load:			
At zero exhaust back pressure	3.7	4.8	6.1
At maximum exhaust back pressure	5.4	8.0	9.3
Air inlet restriction (inches water) - full load max.:			
Dirty air cleaner - oil bath or dry type	18.8	23.0	25.0
Clean air cleaner - oil bath or dry type with precleaner	12.0	14.0	16.0
Clean air cleaner - dry type without precleaner	7.4	8.7	10.0
Crankcase pressure (inches water) - max	0.8	0.9	1.0
Exhaust back pressure (inches mercury) · max.:			
Full load	3.0	4.0	4.0
No load	2.1	2.7	2.7
Fuel System			
Fuel pressure at inlet manifold (psi):			
Normal with .070" restriction	45-70	45-70	45-70
Minimum	35	35	35
Fuel spill (gpm) - minimum at no-load:			
.070" restriction	0.6	0.6	0.6
Fuel pump suction at pump inlet (inches mercury) - max.:			
Clean system	6.0	6.0	6.0
Dirty system	12.0	12.0	12.0

© 1972 Go Motors Corp.

	2200 rpm	2500 rpm	2800 rpm
Cooling System			
Coolant temperature (degr F.) - normal	160-185	160-185	160-185
Compression			
Compression pressure (psi at sea level):			
Average - new "N" engine · at 600 rpm	590		
Minimum-"N" engine - at 600 rpm	540		

*The lubricating oil temperature range is based on the temperature measurement in the oil pan at the oil pump inlet. When measuring the oil temperature at the cylinder block oil gallery, it will be 10° lower than the oil pan temperature.

🖬Maximum when this is the full-load engine speed.

© 1972 General Motors Corp.

4-53 TURBOCHARGED ENGINES

4-53 TURBOCHARGED ENGINES	2500 rpm
Lubrication System	
Lubricating oil pressure (psi):	
Normal	40-60
Minimum for safe operation	32.0
*Lubricating oil temperature (degr F.) - max	205-240
Air System	
Air box pressure (inches mercury) - N70 injectors - full load:	
Minimum exhaust back pressure (clean ports)	31.5-38.5
Maximum exhaust back pressure	29.6-36.6
Air inlet restriction (inches water) - full load max.:	
Air silencer	20.0
Crankcase pressure (inches water) - maximum	1.0
Exhaust back pressure (inches mercury) - maximum:	
Full load	2.5
No load	1.8
Fuel System	
Fuel pressure at inlet manifold (psi):	
Normal with .070" restriction	45-70
Minimum	35.0
Fuel spill (gpm) - minimum at no-load:	
.070 " restriction	0.6
Cooling System	
Coolant temperature (degr F.) - normal	160-185
Compression	
Compression pressure (psi at sea level):	
Average - new engine - at 600 rpm	480
Minimum - at 600 rpm	430

*The lubricating oil temperature range is based on the temperature measurement in the oil pan at the oil pump inlet. When measuring the oil temperature at the cylinder block oil gallery, it will be 10° lower than the oil pan temperature.

© 1972 General Motors Corp.

ENGINE RUN-IN INSTRUCTIONS

Following a complete overhaul or any major repair job involving the installation of piston rings, pistons, cylinder liners or bearings, the engine should be "run-in" on a dynamometer prior to release for service.

The dynamometer is a device for applying specific loads to an engine. It permits the serviceman to physically and ,visually inspect and check the engine while it is operating. It is an excellent method of detecting improper tune-up, misfiring injectors, low compression and other malfunctions, and may save an engine from damage at a later date.

The operating temperature within the engine affects the operating clearances between the various moving parts of the engine and determines to a degree how the parts will wear. Normal coolant temperature (160° - 185°F.) should be maintained throughout the run-in.

The rate of water circulation through the engine on a dynamometer should be sufficient to avoid having the engine outlet water temperature more than 10°F. higher than the water inlet temperature. Though a 10° rise across an engine is recommended, it has been found that a 15° temperature rise maximum can be permitted.

Thermostats are used in the engine to control the coolant flow; therefore, be sure they are in place and fully operative or the engine will overheat during the run-in. However, if the dynamometer has a water stand-pipe with a temperature control regulator, such as a Taylor valve or equivalent, the engine should be tested without thermostats.

The Basic Run-In Horsepower Schedule is shown in the Table. The horsepower shown in the table is at SAE conditions: dry air density .0705 lb/cu. ft., air temperature of 85°F., and 500 ft. elevation.

DYNAMOMETER TEST AND RUN-IN PROCEDURES

The Basic Engine

A basic engine includes only those items actually required to run the engine. The addition of any engine driven accessories will result in a brake horsepower figure less than the values shown in the Basic Engine Run-In Schedule. The following items are includes on the basic engine: blower, fuel pump, fresh water pump and governor. The fan and battery-charging generator typify accessories not considered on the basic engine.

In situations where other than basic engine equipment is used during the test, proper record of this fact should be made on the Engine Test Report. The effects of this additional equipment on engine performance should then be considered when evaluating test results.

Dynamometer

The function of the dynamometer is to absorb and measure the engine output. Its basic components are a frame, engine mounts, the absorption unit, a heat exchanger, and a torque loading and measuring device.

The engine is connected through a universal coupling to the absorption unit. The load on the engine may be varied from zero to maximum by decreasing or increasing the resistance in the unit. The amount of

Final run-in should be for 1/2 hr. at 2800 RPM within 5% of 210 B.H.P.

© 1970 General Motors Corp.

power absorbed in a water brake type dynamometer, as an example, is governed by the volume of fluid within the working system. The fluid offers resistance to a rotating motion. By controlling the volume of water in the absorption unit, the load may be increased or decreased as required.
The power absorbed is generally measured in torque (lb-ft, on a suitable scale. This value for a given engine speed will show the brake horsepower developed in the engine by the following formula:

BHP - (T x RPM)/5250
Where:
BHP - brake horsepower
T - torque in lb-ft
RPM - revolutions per minute

Some dynamometers indicate direct brake horsepower readings. Therefore, the use of the formula is not required when using these units.

During the actual operation, all data taken should be recorded immediately on an Engine Test Report (see sample on page 4).

Instrumentation
Certain instrumentation is necessary so that data required to complete the Engine Test Report may be obtained. The following list contains both the minimum amount of instructions and the proper location of the fittings on the engine so that the readings represent a true evaluation of engine conditions.

a. Oil pressure gage installed in one of the engine main oil galleries.

b. Oil temperature gage installed in the oil pan, or thermometer installed in the dipstick hole in the oil pan.

c. Adaptor for connecting a pressure gage or mercury manometer to the engine air box.

d. Water temperature gage installed in the thermostat housing.

e. Adaptor for connecting a pressure gage or water manometer to the crankcase.

f. Adaptor for connecting a pressure gage or mercury manometer to the exhaust manifold at the flange.

g. Adaptor for connecting a vacuum gage or water manometer to the blower inlet.

h. Adaptor for connecting a fuel pressure gage to the fuel manifold inlet passage.

In some cases, gages reading in pounds per square inch are used for determining pressures while standard characteristics are given in inches of mercury or inches of water. It is extremely important that the scale of such a gage be of low range and finely divided if accuracy is desired. This is especially true of a gage reading in psi, the reading of which is to be converted to inches of water. The following conversion factors may be helpful.

Inches of water - psi x 27.7"
Inches of mercury - psi x 2.04"

NOTE: Before starting the Run-In or starting the engine for any reason following an overhaul, it is of extreme importance to observe the instructions on Preparation for Starting Engine First Time in Section 13.1.

Run-In Procedure
The procedure outlined below will follow the order of the sample Engine Test Report.

A. PRE-STARTING
1. Fill the lubrication system as outlined under Lubricating System -- Preparation for Starting Engine First Time in Section 13.1.
2. Prime the fuel system as outlined under Fuel System -- Preparation for Starting Engine First Time in Section 13.1.
3. A preliminary valve clearance adjustment must be made before the engine is started. See Valve Clearance Adjustment in Section 14.1.
4. A preliminary injector timing check must be made before starting the engine. See Timing Injector in Section 142.
5. Preliminary governor adjustments must be made as outlined in Section 14.
6. Preliminary injector rack adjustment must be made - see Section 14.

© 1970 General Motors Corp.

B. BASIC ENGINE RUN-IN

The operator should be observant at alt times, so that any malfunction which may develop will be detected. Since the engine has just been reconditioned, this run-in will be a test of the workmanship of the serviceman who performed the overhaul. Minor difficulties should be detected and corrected so that a major problem will not develop.

After performing the preliminary steps, be sure all water valves, fuel valves, etc are open. Also inspect the exhaust system, being sure that it is properly connected to the engine. Always start the engine with minimum dynamometer resistance.

After the engine starts, if using a water brake type dynamometer, allow sufficient water, by means of the control loading valves, into the dynamometer absorption unit to show a reading of approximately 5 Ib-ft on the torque gage (or 10-15 HP on a horsepower gage). This is necessary, on some units, to lubricate the absorption unit seals and to protect them from damage.

Set the engine throttle at idle speed, check the lubricating oil pressure and check all connections to be sure there are no leaks.

Refer to the Engine Test Report sample which establishes the sequence of events for the test and run-in, and to the Basic Run-In Horsepower Schedule which indicates the speed (rpm), length of time and the brake horsepower required for each phase of the test. Also, refer to the Operating Conditions in Section 13.2 which presents the engine operating characteristics. These characteristics will be a guide for tracing faulty operation or lack of power.

Engine governors in most cases must be reset at the maximum full-load speed designated for the run-in. If a governor is encountered which cannot be adjusted to this speed, a stock governor should be installed for the run-in.

After checking the engine performance at idle speed and being certain the engine and dynamometer are operating properly, increase the engine speed to half speed and apply the load indicated on the Basic Run-In Horsepower Schedule.

The engine should be run at this speed and load for 10 minutes to allow sufficient time for the coolant temperature to reach the normal operating range. Record length of time, speed, brake horsepower, coolant temperature and lubricating oil pressure on the Engine Test Report.

Run the engine at each speed and rating for the length of time indicated in the Basic Run-In Horsepower Schedule. This is the Basic Run-In. During this time engine performance will improve as new parts begin to "seat in". Record all of the required data.

C. BASIC RUN-IN INSPECTION

While the engine is undergoing the Basic Run-In, check each item indicated in Section "C" of the Engine Test Report. Check for fuel oil or water leaks in the rocker arm compartment.

During the final portion of the Basic Run-In, the engine should be inspected for fuel oil, lubricating oil and water leaks.

Upon completion of the Basic Run-In and Inspection, remove the load from the dynamometer and reduce the engine speed gradually to idle and then stop the engine.

D. INSPECTION AFTER BASIC RUN-IN

The primary purpose of this inspection is to provide a fine engine tune-up. First, tighten the cylinder head and rocker arm shaft bolts to the proper torque. Next, complete the applicable tune-up procedure. Refer to Section 14.

E. FINAL RUN-IN

After all of the tests have been made and the Engine Test Report is completed through Section "D", the engine is ready for final test. This portion of the test and run-in procedure will assure the engine owner that his engine has been rebuilt to deliver factory rated performance at the same maximum speed and load which will be experienced in the installation.

If the engine has been shut-down for one hour or longer, it will be necessary to have a warm-up period of 10 minutes at the same speed and load used for warm-up in the Basic Run-In. If piston rings, cylinder liners or bearings have been replaced as a result of findings in the Basic Run-In, the entire Basic Run-In must be repeated as though the run-in and test procedure were started anew.

All readings observed during the Final Run-In should fall within the range specified in the Operating Conditions in Section 13., and should be taken at full load unless otherwise specified. Following is a brief discussion of each condition to be observed.

The engine water temperature should be taken during the last portion of the Basic Run-In at full load. It should be recorded and should be within the specified range.

© 1970 General Motors corp.

ENGINE TEST REPORT

Date _____ Unit Number _____

Repair Order Number _____ Model Number _____

A PRE-STARTING

1. PRIME LUB. OIL SYSTEM	2. PRIME FUEL SYSTEM	3. ADJUST EXHAUST VALVES	4. TIME INJECTORS	5. ADJ. GOV.	6. ADJUST INJ. RACKS

B BASIC ENGINE RUN-IN

TIME AT SPEED	TIME		RPM	BHP	WATER TEMP.	LUB. OIL PRESS.
	START	STOP				

C BASIC RUN-IN INSPECTION

1. Check oil at rocker mechanism	
2. Inspect for lubricating oil leaks	
3. Inspect for fuel oil leaks	
4. Inspect for water leaks	
5. Check and tighten all external bolts	
6.	

D INSPECTION AFTER BASIC RUN-IN

1. Tighten Cylinder Head & Rocker Shaft Bolts		4. Adjust Governor Gap	
2. Adjust Valves (Hot)		5. Adjust Injector Racks	
3. Time Injectors		6.	

E FINAL RUN-IN

TIME		TOP RPM		BHP	AIR BOX PRESSURE FULL LOAD	EXHAUST BACK PRESSURE F/L	CRANKCASE PRESSURE F/L
START	STOP	NO-LOAD	FULL LOAD				

BLOWER INTAKE RES. - F/L	FUEL OIL PRESSURE RET. MAN. F/L	WATER TEMP. FULL LOAD	LUB. OIL TEMP. F/L	LUB. OIL PRESSURE		IDLE SPEED
				FULL LOAD	IDLE	

F INSPECTION AFTER FINAL RUN

1. Inspect Air Box, Pistons, Liners, Rings		6. Replace Lubricating Oil Filter Elements	
2. Inspect Blower		7. Tighten Flywheel Bolts	
3. Check Generator Charging Rate		8. Rust Proof Cooling System	
4. Wash Oil Pan, Check Gasket		9.	
5. Clean Oil Pump Screen, Remove Cloth		10.	

REMARKS:

Final Run OK'd _____ Dynamometer _____ Date _____

NOTE: Operator must initial each check and sign this report.

© 1970 General Motors Corp.

The lubricating oil temperature reading must be taken while the engine is operating at full load and after it has been operating long enough for the temperature to stabilize. This temperature should be recorded and should be within the specified range.

The lubricating oil pressure should be recorded in psi after being taken at engine speeds indicated in the Operating Conditions, Section 13.2.

The fuel oil pressure at the fuel manifold inlet passage should be recorded and should fall within the specified range. Fuel pressure should be recorded at maximum engine rpm during the Final Run-In.

Check the air box pressure while the engine is operating at maximum speed and load. This check may be made by attaching a suitable gage (0-15 psi) or manometer (15-0-15) to an air box drain or to a hand hole plate prepared for this purpose. If an air box drain is used as a source for this check, it must be clean. The air box pressure should be recorded in inches of mercury.

Check the crankcase pressure while the engine is operating at maximum run-in speed. Attach a manometer, calibrated to read in inches of water, to the oil level dipstick opening. Normally, crankcase pressure should decrease during the run-in indicating that new rings are beginning to "seat-in".

Check the air inlet restriction with a water manometer connected to a fitting in the air inlet ducting located 2" above the air inlet housing. When practicability prevents the insertion of a fitting at this point, the manometer may be connected to a fitting installed in the 1/4" pipe tapped hole in the engine air inlet housing. If a hole is not provided, a stock housing should be drilled, tapped and kept on hand for future use.

The restriction at this point should be checked at a specific engine speed. Then, the air cleaner and ducting should be removed from the air inlet housing and the engine again operated at the same speed while noting the manometer reading. The difference between the two readings, with and without the air cleaner and ducting, is the actual restriction caused by the air cleaner and ducting.

Check the normal air intake vacuum at various speeds (at noload) and compare the results with the Engine Operating Conditions in section 13.2. Record these readings on the Engine Test Report.

Check the exhaust back pressure at the exhaust manifold companion flange or within one inch of this location. This check should be made with a mercury manometer through a tube adaptor installed at the tapped hole. If the exhaust manifold does not provide a 1/8" pipe tapped hole, such a hole can be incorporated by reworking the exhaust manifold.

Install a fitting for a pressure gage or manometer in this hole. Care should be exercised so that the fitting does not protrude into the stack. The manometer check should produce a reading in inches that is below the Maximum Exhaust Back Pressure for the engine (refer to Section 13.2).

Refer to the Basic Run-In Horsepower Schedule and determine the maximum rated brake horsepower and the full-load speed to be used during the Final Run-In. Apply the load thus determined to the dynamometer.

When the above conditions have been met, adjust the maximum no-load speed to conform with that specified for the particular engine. This speed may be either higher or lower than the maximum speed used during the Basic Run-In. This will ordinarily require a governor adjustment.

All information required in Section "E", Final Run-In, of the Engine Test Report should be determined and filled in. After the prescribed time for the Final Run-In has elapsed, remove the load from the dynamometer and reduce the engine speed gradually to idle speed and then stop the engine. The Final Run-In is complete.

F. INSPECTION AFTER FINAL RUN-IN

After the Final Run-In and before the Engine Test Report is completed, a final inspection must be made. This inspection will provide final assurance that the engine is in proper working order. During this inspection the engine is also made ready for any brief delay in delivery or installation which may occur. This is accomplished by rust-proofing the fuel system as outlined in Section 15.3. Also, a rust inhibitor should be introduced into the cooling system (refer to Section 13.3).

© 1970 General Motors Corp.

DIESEL FUEL OIL SPECIFICATIONS

The quality of the fuel oil used for high-speed diesel engine operation is a major factor in satisfactory engine performance and life. The fuel oils selected niust be clean, completely distilled, stable, and non-corrosive. Enlist the aid of your supplier in obtaining proper fuel oil. The responsibility for clean fuel lies with the fuel supplier as well as with the operator.

DISTILLATION RANGE, CETANE NUMBER, AND SULFUR CONTENT are three of the most important properties in the selection of diesel fuels for optimum combustion and minimum wear. Engine speed, load, and atmospheric temperature influence the selection of the fuels with respect to distillation range and cetane number. THE SULFUR CONTENT OF THE FUEL MUST BE AS LOW AS POASIBLE, to avoid excessive deposit formation and premature wear.

Diesel fuels are generally marketed according to ASTM DESIGNATION D975 and only distillate fuels No. 1D and 2D are considered satisfactory for Detroit Diesel engines. Residual fuels and furnace oils, generally, are not considered satisfactory for Detroit Diesel engines. In some regions, however, fuel suppliers may distribute only one fuel that is marketed as either diesel fuel (ASTM D-975) or domestic heating fuel (ASTM D-396). In this case, the fuel should be investigated to determine whether the physical properties conform with those shown in the Fuel Oil Selection Chart.

As a guide to the selection of the proper fuel oil for various applications refer to the ASTM Classification Chart and the Fuel Oil Selection Chart.

ASTM Classification of Diesel Fuel Oils

	No. 1-D	No. 2-D
Flash Pt.; °F Min.	100	125
Carbon Residue; %	0.15	0.35
Water and Sediment; (% by Volume) Max.	Trace	0.10
Ash; % by Wt.; Max.	0.01	0.02
Distillation, °F 90% Pt.; Max.	550	640
Min.	-	540
Viscosity at 100°F; centistokes Min.	1.4	2.0
Max.	2.5	4.3
Sulfur; % Max.	0.5	0.5
Cetane No; Min.	40	40

Engine operation at altitudes above 5000 feet requires use of next lighter class of fuel oil than would normally be used.

During cold weather engine operation, the "cloud point" (the temperature at which wax crystals begin to form in the fuel oil) should be 10°F. below the lowest expected fuel temperature to prevent clogging of the fuel filters by wax crystals.

At temperatures below -20°F. consult an authorized Detroit Diesel Service Outlet, since particular attention must be given the cooling system, lubricating system, fuel system, electrical system, and cold weather starting aide for efficient engine operation.

FUEL OIL SELECTION CHART

Type of Engine Service	Typical Application	General Fuel Classification	Final Boiling Point (Max.)	Cetane Number (Min.)	Sulfur Content (Max.)
Light load and speed with considerable idling.	City Buses	No. 1-D	550°F	45	0.30%
Light load and speed.	Generator Sets, Industrial and Automotive Equipment in city and suburban operation.	Winter No. 1-D	550°F	45	0.30%
		Summer No. 1-D	600°F	40	0.50%
Medium load and speed.	Marine Pleasure Craft, Tractors, Industrial Equipment.	Winter No. 1-D	600°F	45	0.50%
		Summer No. 2-D*	675°F	40	0.50%
Heavy load and high speed with idling.	Highway Trucks	Winter No. 2-D*	675°F	45	0.50%
		Summer No. 2-D*	675°F	40	0.50%
Heavy load and high speed.	Heavy Duty Off-the-Road Equipment, Trucks, Tractors	No. 2-D*	675°F	45	0.50%

*NOTE: For most satisfactory engine life, use only those No. 2-D diesel fuel oils containing 0.50% or less sulfur. Where minimum exhaust smoke is required or where long periods of idling or cold weather conditions below 32°F. are encountered, the more volatile or light distillate fuels are recommended.

BREAK-IN OILS AND ADDITIVES MARKETED FOR FUELS AND LURICAN

The use of proprietary blends of supplementary additive or concentrates such as engine oil supplements, break-in oils, tune-up compounds and friction reducing compounds is not recommended in lubricating oils used in Detroit Diesel engines unless given official Detroit Diesel part numbers and made available for use in appropriate service applications. This also applies to the use of metal containing diesel fuel additives.

© 1970 General Motors Corp.

DIESEL LUBRICATING OIL SPECIFICATIONS

OIL QUALITY

There are hundreds of commercial crankcase oils marketed today. Lubricants marketed for heavy duty diesel service consist of refined crude oil to which has been added additives compounded to meet the desired engine performance levels. Oil additive selection is based on evaluations conducted by the oil supplier; therefore, satisfactory OIL QUALITY is the responsibility of the oil supplier. (The term oil supplier is applicable to refiners, blenders and rebranders of petroleum products, and does not include distributors of such products.) Experience has shown that oil performance in commercial heavy duty diesel service applications varies from brana to brand.

Obviously engine manufacturers or users cannot completely evaluate the hundreds of commercial oils; therefore, the selection of a suitable lubricant in consultation with a reliable oil supplier, strict observance of his oil change recommendations (used oil sample analysis can be of value), and proper filter maintenance will provide your best assurance of satisfactory oil performance.

Detroit Diesel lubricant recommendations are based on general experience with current lubricants of various types and give consideration to the commercial lubricants presently available.

RECOMMENDATION

MIL-L-2104B Lubricants

Detroit Diesel engines have given optimum performance, and experienced the longest service life with MIL-L-2104B, SAE 30 oils. However, the additive concentration of some MIL-L-2104B oils has been substantially increased in order to meet 1968-1969 MS performance requirements. Some of these 1968-1969 MS/MIL-L-2104B oils have given unsatisfactory perfornmance because of excessive exhaust valve and ring-belt ash deposits. For these reasons our primary lubricant recommendations are MIL-L-2104B and Supplement 1 oils with the following limitations:

1. Zinc, as zinc diorganodithiophosphate, between a minimum of 0.07 and a maximum of 0.10 percent by weight.
2. Sulfated ash (ASTM D-874) of 1.00 percent maximum by weight, except lubricants that contain only barium detergent dispersants where 1.50 percent by weight is allowed.

Contact a reliable oil supplier and obtain his assurance that his product has been tested and given good performance in Detroit Diesel engines. An SAE 30 oil is recommended for year-round use. The use of lower viscosity oils or multigrade products will usually result in less than normal engine life.

MIL-L-451998 (Series 3) Lubricants

The use of Low Ash Series 3 oils (sulphated ash less than 1.65 percent by weight ASTM designation D874) may be necessary if the continued use of high sulfur fuel (sulfur greater than 0.5 percent by weight ASTM D129) is unavoidable. Consult a reliable oil supplier, obtain assurance that his products have been tested in Detroit Diesel engines, and select the best performer for optimum engine life.

Low ash Series 3 oils do NOT have to meet any specific military low temperature performance requirements; therefore, they may NOT perform as well as MILL2104B lubricants in cold climates.

The older high ash Series 3 oils should NOT be used in Detroit Diesel engines as they tend to deposit heavy ash on valve faces and head inserts resulting in channelling, guttering, and short engine life.

Supplement 1 Lubricating Oils

See MIL-L-2104B limitations under Recommendation.

Multigrade Lubricating Oils

Multigrade oils are NOT recommended. The use of an SAE30 grade is desirable for year round use when cold starting can be accomplished. Multigrade oils should be considered only as the "last resort" to facilitate starting when prolonged exposure to temperatures below freezing is unavoidable and adequate starting aids are unavailable.

Experience clearly indicates that multigrade oils are NOT comparable to SAE30 lubricants for heavy duty diesel service. Cylinder liner scuffing, liner port and ring groove deposit levels are all greater using multigrade lubricants. This results in shortened engine life.

COLD WEATHER OPERATION

Cold weather starting will be facilitated when immersion type electrical coolant heaters can be used. Other practical considerations, such as the use of batteries, cables and connectors of adequate size, generators or alternators of ample capacity, proper setting of voltage regulators, ether starting aids, oil and coolant heater systems, and proper fuel selection will accomplish starting with the use of SAE30 oil. For complete cold weather starting information, consult an Authorized Detroit Diesel Service Outlet.

OIL CHANGES

It is recommended that new engines be started with 100 hour oil change periods. For highway vehicles this corresponds to approximately 3,000 miles, and for "cityservice" vehicles approximately 1,000-2,000 miles. The drain interval may then be gradually increased, or decreased with experience on a specific lubricant while also considering the recommendations of the oil supplier (analysis of the drained oil can be helpful here) until the most practical oil change period for the particular service has been established.

Solvents should not be used as flushing oils in running engines. Dilution of the fresh refill oil supply can occur which may be detrimental.

OIL FILTRATION

Heavy sludge deposits found on the oil filter elements at the time of an oil change must be taken as an indication that the detergency of the oil has been exhausted. When this occurs, the oil drain interval should be shortened Since abrasive dust, metal particles and carbon material accumulate in the lubricating oil during engine operation, the oil filter elements must be replaced each time the oil is changed.

NOTE: The manufacturer's warranty applicable to Detroit Diesel engines provides in part that the provisions of such warranty shall not apply to any engine unit which has been subject to MISUSE, negligence or accident. Accordingly, malfunctions attributable to neglect or failure to follow the manufacturer's lubricating recommendations indicated above may not be within the coverage of the warranty.

© 1970 General Motors Corp.

ENGINE COOLANT

Engine coolant is considered as any solution which is circulated through the engine to provide the means for heat transfer from the various engine components. In general, water containing various materials in solution is used for this purpose.

The function of the coolant is basic in the design and the successful operation of the engine and must be carefully selected and properly maintained.

COOLANT REQUIREMENTS

A suitable coolant solution must meet the following five basic requirements:

1. Provide for adequate heat transfer.
2. Provide a corrosion resistant environment within the cooling system.
3. Prevent formation of scale or sludge deposits in the cooling system.
4. Be compatible with the cooling system hose and seal materials.
5. Provide adequate freeze protection during cold weather operation.

Normally requirements 1 through 4 are satisfied by combining a suitable water with reliable inhibitors. When operating conditions dictate the need for freeze protection, a solution of suitable water and an ethylene glycol type antifreeze containing adequate inhibitors will provide a satisfactory coolant.

WATER

Any water, whether of drinking quality or note, will produce a corrosive environment in the cooling system. Also, scale deposits may form on the internal surfaces of the cooling system due to the mineral content of the water. Therefore, water selected as a coolant must be properly treated with inhibitors to control corrosion and scale deposition.

To determine if a particular water is suitable for use as a coolant when properly inhibited, the following characteristics must be considered. The concentration of (1) chlorides, (2) sulfates, (3) total hardness and (4) dissolved solids. These materials are objectionable for a number of reasons: chlorides and/or sulfates will accelerate corrosion, while hardness (percentage of magnesium and calciumn present) will cause deposits of scale. Total dissolved solids may cause scale deposits, sludge deposits, corrosion or a combination of these. Chlorides, sulfates, magnesium and calcium are among but not necessarily all the materials which make up dissolved solids. Water, within the limits specified on Tables I and 2, Figure A, is satisfactory as an engine coolant when proper inhibitors are added.

CORROSION INHIBITORS

A corrosion inhibitor is a water soluble chemical compound which protects the metallic surfaces of the cooling system against corrosive attack. Some of the more commonly used corrosion inhibitors are chromates, borates, nitrates, nitrites and soluble oil. Depletion of all types of inhibitors occur through normal operation and therefore strength levels must be maintained by the addition of inhibitors at prescribed intervals.

CHROMATES: Sodium chromate and potassium dichromate are two of the best and more commonly used water system corrosion inhibitors. Care should be exercised in handling these materials due to their toxic nature.

Chromate inhibitors should not be used in ethylene glycol antifreeze solutions. Chromium hydroxide, commonly called "green slime", can result from the use of chromate inhibitors with permanent type antifreeze. This material deposits on the cooling system passages, reducing the heat transfer rate and will result in engine overheating. Engines which have operated with a chromate inhibited water must be chemically cleaned before the addition of ethylene glycol type antifreeze. A commercial heavy duty descaler should be used in accordance with the manufacturer's recommendation for this purpose.

SOLUBLE OIL: Soluble oil has been used as a corrosion inhibitor for many years. It has, however, required very close attention relative to the concentration level due to adverse effects on heat transfer if the concentration exceeds 1% by volume. For example: 1 1/4% of soluble oil in the cooling system increases fire deck temperatures 6% and a 2 1/2% concentration raises fire deck temperature up to 15%. Soluble oil is not recommended as a corrosion inhibitor.

NONCHROMATES:

Nonchromate inhibitors (borates, nitrates, nitrites, etc.) provide corrosion protection in the cooling system with the basic advantage that they can be used with either water or a water and ethylene glycol solution.

© 1972 General Motors Corp.

TABLE 1

	PARTS PER MILLION	GRAINS PER GALLON
Chlorides (Maximum)	40	2.5
Sulfates (Maximum)	100	5.8
Total Dissolved Solids (Maximum)	340	20
Total Hardness (Maximum)	170	10

Refer to Table 2 for evaluation of water intended for use in a coolant solution.

TABLE 2


Determine The Concentrations Of Chlorides. Sulfates. And Total Dissolved Solids In The Water
Chlorides Under 40 ppm. And Sulfates Under 100 ppm. And Total Dissolved Solids Under 340 ppm.
Chlorides Over 40 ppm. Or Sulfates Over 100 ppm. Or Total Dissolved Solids Over 340 ppm.
Determine Total Hardness Of The Water
Distill. De-mineralize. Or De-ionize The Water
Total Hardness Under 170 ppm
Total Hardness Over 170 ppm
Water Suitable For Use in Coolant
Plus Inhibitors
Soften The Water
Water Suitable For Use In Coolant
Plus Inhibitors

Figure A

INHIBITOR SYSTEMS

An inhibitor system is considered as a combination of chemical compounds which provide corrosion protection, pH control and water softening ability. Corrosion protection has been discussed earlier under the section on Corrosion Inhibitors. The pH control is used to maintain an acid free solution. The water softening ability deters formation of mineral deposits. Inhibitor systems are available in various forms such as coolant filter elements, liquid and dry bulk inhibitor additives and as an integral part of permanent antifreeze.

COOLANT FILTER ELEMENTS: Replaceable elements are available with various chemical inhibitor systems. Care should be used in the selection of elements relative to inhibitor compatibility with coolant solutions shown in Figure B.

Problems have developed from the use of the magnesium lower support plate used by some

© 1972 General Motors Corp.

COOLANT INHIBITOR CHART

Inhibitor or Inhibitor System	Corrosion Inhibitor Type	Complete Inhibitor System	Coolant	
			Water	Ethylene Glycol Solution
Sodium Chromate	Chromate	No	Yes	No
Potassium Dichromate	Chromate	No	Yes	No
Perry Filter Element 5020 (Type O & OS)	Chromate	Yes	Yes	No
Perry Filter Element 5030 (Type O & OS)	Non-Chromate	Yes	Yes	Yes
*Perry Filter Element PAF	Non-Chromate	Yes	No	Yes
Lenroc Filter	Non-Chromate	Yes	Yes	Yes
Nalcool 2000	Non-Chromate	Yes	Yes	Yes

*Discontinued August 1968.

Figure B



Figure C

manufacturers in their coolant filters. The magnesium plate will be attached by solutions which will not be detrimental to other metals in the cooling system. The dissolved magnesium will be deposited in the hottest zones of the engine where heat transfer is most critical (Figure C). The use of aluminum or zinc in preference to magnesium is recommended to eliminate this type of deposit.

A high chloride coolant will have a detrimental effect on the water softening capabilities of systems using ion-exchange resins. Accumulations of calcium and magnesium ions removed from the coolant and held captive by the zeolite resin can be released into the coolant by a regenerative process caused by high chloride content solutions.

BULK INHIBITOR ADDITIVES: Commercially packaged inhibitor systems are available which can be added directly to the engine coolant or to bulk storage tanks containing coolant solution. Both chromate and nonchromate systems are available and care should be taken regarding inhibitor compatability with other coolant constituents (Figure B).

A nonchromate inhibitor system is recommended for use in Detroit Diesel engines. These systems can be used with either water or ethylene glycol antifreeze solutions and provide corrosion protection, pH control and water softening. One of the approved nonchromate inhibitor systems, Nalcool 2000 offers the additional advantage of a simple on site test to determine protection level and, since this product is added directly to the coolant, it requires no additional hardware or plumbing.

ANTIFREEZE

When freeze protection is required, an ethylene glyco! base permanent antifreeze should be used. An inhibitor system is included in this type of antifreeze and no additional inhibitors are required on initial fill if a minimum antifreeze concentration of 30% by volume is used. Solutions of less than 30% concentration do not provide sufficient corrosion protection. Concentrations over 67% adversely affect freeze protection and heat transfer rates (Figure D).

© 1972 General Motors Corp.

Inhibitor depletion will occur in ethylene glycol base antifreeze through normal service. The inhibitors should be replenished at approximately 500 hour or 20,000 mile intervals with a nonchromate inhibitor system. Commercially available inhibitor systems such as Nalcool 2000 may be used to reinhibit antifreeze solutions.

Several brands of permanent antifreeze are available with sealer additives. The specific type of sealers vary with the manufacturer. Antifreeze with sealer additives is not recommended for use in Detroit Diesel engines due to plugging problems throughout various areas of the cooling system.

COOLANT RECOMMENDATIONS

1. Always use a properly inhibited coolant.

2. If freeze protection is required, always use ethylene glycol antifreeze.

3. Re-inhibit antifreeze with a non-chromate inhibitor system.

4. Always follow the manufacturer's recommendations on inhibitor usage and handling.

5. Do not use soluble oil.

6. Chromate inhibitors should never be used with permanent antifreeze.

7. Scaler type antifreeze should not be used. 8. Maintain prescribed inhibitor strength.



Figure D

© 1972 General Motors Corp.

SECTION 14
ENGINE TUNE-UP
CONTENTS

Engine Tune-Up Procedures..... 14

Exhaust Valve Clearance Adjustment 14.1

Timing Fuel Injector 14.2

Variable Speed Mechanical Governor and Injector Rack Control Adjustment:

(V-Type Engine)..... 14.4.5

Supplementary Governing Device Adjustment:

Throttle Delay Mechanism 14.14

ENGINE TUNE-UP PROCEDURES

There is no scheduled interval for performing an engine tuneup. As long as the engine performance is satisfactory, no tuneup should be needed. Minor adjustments in the valve and injector operating mechanisms. governor, etc. should only be required periodically to compensate for normal wear on parts.

The following type of governor is used:

2. Variable speed mechanical.

The mechanical governors are identified by a name plate attached to the governor housing.

+

© 1972 General Motors Corp.

A single-weight variable speed governor name plate is stamped S.W.-V.S.

Normally, when performing a tuneup on an engine in service, it is only necessary to check the various adjustments for a possible change in the settings. However, if the cylinder head, governor, or injectors have been replaced or overhauled, then certain preliminary adjustments are required before the engine is started.

The preliminary adjustments consist of the first four items in the tune-up sequence. The procedures are the same except that the valve clearance is greater for a cold engine.

NOTE: If a supplementary governing device, is used, it must be disconnected prior to the tune-up. After the governor and injector rack adjustments are completed, the supplementary governing device must be re-connected and adjusted.

To tuneup an engine completely, all of the adjustments are made by following the applicable tuneup sequence given below after the engine has reached the normal operating temperature. Since the adjustments are normally made while the engine is stopped, it may be necessary to run the engine between adjustments to maintain normal operating temperature.

Tune-Up Sequence for Mechanical Governor

1. Adjust the exhaust valve clearance.
2. Time the fuel injectors.
3. Adjust the governor gap.
4. Position the injector rack control levers.
5. Adjust the maximum no-load speed.
6. Adjust the idle speed.
7. Adjust the buffer screw.
8. Adjust the throttle booster spring,

NOTE: Use new valve rocker cover gasket(s) after each tune-up.

© 1972 Gel Motors Corp.

EXHAUST VALVE CLEARANCE ADJUSTMENT

The correct exhaust valve clearance at normal engine operating temperature is important for smooth, efficient operation of the engine.

Insufficient valve clearance can result in loss of compression, misfiring cylinders and, eventually, burned valve seats and valve seat inserts. Excessive valve clearance will result in noisy operation, especially in the low speed range.

Whenever the cylinder head is overhauled, the exhaust valves are reconditioned or replaced, or the valve operating mechanism is replaced or disturbed in any way, the valve clearance must first be adjusted to the cold setting to allow for normal expansion of the engine parts during the engine warmup period. This will ensure a valve setting which is close enough to the specified clearance to prevent damage to the valves when the engine is started.

ENGINES WITH FOUR VALVE CYLINDER HEADS

All of the exhaust valves may be adjusted, in firing order sequence, during one full revolution of the crankshaft.

Refer to the General Specifications at the front of the manual for the engine firing order.

© 1972 General Motors Corp.



Fig. 1. - Adjusting Valve Clearance (Four Valve Head)

Exhaust Valve Clearance Adjustment (Cold Engine)

1. Clean the loose dirt from the exterior or the engine and remove the valve rocker cover(s).

2. Place the speed control lever in the idle speed position. If a stop lever is provided, secure it in the no-fuel position.

3. Rotate the crankshaft, manually or with the starting motor, until the injector follower is fully depressed on the cylinder to be adjusted.

CAUTION: If a wrench is used on the crankshaft bolt, do not turn the engine in a left-hand direction of rotation or the bolt will be loosened.

4. Loosen the push rod lock nut.

5. Place a .027 " feeler gage, J 9708, between the end of one valve stem and the rocker arm bridge (Fig. 1). Adjust the push rod to obtain a smooth pull on the feeler gage.

6. Remove the feeler gage. Hold the push rod with a 5/16 " wrench and tighten the lock nut with a 1/2" wrench.

7. Recheck the clearance. At this time, if the adjustment is correct, the .025 " gage will pass freely between the end of one valve stem and the rocker arm bridge and the .027" gage will not pass through. Readjust the push rod if necessary.

Exhaust Valve Clearance Adjustment (Hot Engine)

Normal engine operating temperature is particularly important when making the final valve clearance adjustment. If the engine is allowed to cool off before setting any of the valves, the clearance, when running at full load, may become insufficient.

With the engine at normal operating temperature (160 - 185 °F.), recheck the exhaust valve clearance with feeler gage J 9708. At this time, if the valve clearance is correct, the .023 " gage should pass freely between the end of one valve stem and the rocker arm bridge and the .025 " feeler gage should not. Readjust the push rod, if necessary.

Use new gaskets when installing the valve rocker cover(s).

© 1972 General Motors Corp.

TIMING FUEL INJECTOR

To properly time the injectors, the injector follower must be adjusted to a definite height in relation to the injector body.

All injectors can be timed during a full revolution of the crankshaft.

1. Clean the loose dirt from the exterior of the engine and remove the valve rocker cover(s).

2. Place the speed control lever in the idle speed position. If a stop lever is provided, secure it in the nonfuel position.

3. Rotate the crankshaft, manually or with the starting motor, until the exhaust valves are fully depressed on the particular cylinder to be timed.

> **CAUTION: If a wrench is used on the crankshaft bolt at the front of the engine, do not turn the crankshaft in a left-hand direction of rotation or the bolt will be loosened.**

4. Place the small end of the injector timing gage (refer to the chart below for the correct timing gage)

Injector	Timing Dimension	Tool Number
N50	1.460	J 1853



Fig. .1 · Timing Fuel Injector

in the hole provided in the top of the injector body, with the flat of the gage toward the injector follower as shown in Fig. 1.

5. Loosen the push rod lock nut.

6. Turn the push rod and adjust the injector rocker arm until the extended part of the gage will just pass over the top of the injector follower.

7. Hold the push rod and tighten the lock nut. Check the adjustment and readjust, if necessary.

8. Time the remaining injectors as outlined ii Steps I through 6.

9. Install the rocker cover(s) and new rocker cover gasket(s).

© 1970 General Motors Corp. **October, 1970**

VARIABLE SPEED MECHANICAL GOVERNOR AND INJECTOR RACK CONTROL ADJUSTMENT

6V ENGINE

The variable speed mechanical governor assembly is mounted at the rear of the 6V engine, between the flywheel housing and the blower (Fig. 1). The governor is driven by the right-hand blower rotor drive gear.

After adjusting the exhaust valves and timing the fuel injectors. adjust the governor and the injector rack control levers.

Adjust Governor Gap

With the engine stopped. adjust the governor gap as follows:

1. Disconnect any linkage attached to the governor levers.

2. Remove the governor cover.

3. Place the speed control lever in the maximum speed position.

4. Insert a .006" feeler gage between the spring plunger and the plunger guide as shown in Fig. 2. If required. loosen the lock nut and turn the adjusting screw in or out until a slight drag is noted on the feeler gage.

5. Hold the adjusting screw and tighten the lock nut. Check the gap and readjust if necessary.



Fig. 1. Variable Speed Governor Mounting



Fig. 2 · Adjusting Governor Gap

6. Install the governor cover.

Position Injector Rack Control Levers

The position of the injector control racks must be correctly set in relation to the governor. Their position determines the amount of fuel injected into each cylinder and ensures equal distribution of the load.

The letters R or L indicate the injector location in the right or left cylinder bank as viewed from the rear of the engine. Cylinders are numbered starting at the front of the engine on each cylinder bank. Adjust the No. 3L injector rack control lever first to establish a guide for adjusting the remaining levers.

1. Loosen the lock nut and back out the buffer screw approximately 3/4"

2. Remove the valve rocker covers.

3. Remove the clevis pin from the fuel rod and the right cylinder bank injector control tube lever.

4. Loosen all of the inner and outer injector rack control lever adjusting screws on both injector control tubes. Be sure all of the injector rack control levers are free on the injector control tubes.

ã 1971 General Motors Corp.



Fig. 3. - Positioning No. 3L Injector Rack Control Lever

5. Move the speed control lever to the maximum speed position.

6. Move the stop lever to the RUN position and hold it in that position with light finger pressure. Turn the inner adjusting screw of the No. 3L injector rack control lever down (Fig. 3) until a slight movement of the control tube is observed, or a step-up in effort to turn the screw driver is noted. This will place the No. 3L injector rack in the full-fuel position. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

> **NOTE: Overtightening of the injector rack control lever adjusting screws during installation or adjustment can result in damage to the injector control tube. The recommended torque of the adjusting screws is 24-36 in-lb.**

The above steps should result in placing the governor linkage and control tube in the respective positions that they will attain while the engine is running at full load.

7. To be sure the control lever is properly adjusted, hold the stop lever in the RUN position and press down on the injector rack with a screw driver or finger tip causing the rack to rotate. The setting is sufficiently tight if the rack returns to its original position. If the rack does not return to its original position, it is too loose. To correct this condition, back off the outer adjusting screw slightly and tighten the inner adjusting screw. The setting is too tight if, when moving the stop lever from the STOP to the RUN position. the injector rack becomes tight before the governor stop lever reaches the end of its travel. This will result in a stepup in effort required to move the stop lever to the RUN position and a deflection in the fuel rod (fuel rod deflection can be seen at the bend). If the rack is found to be too tight, back off the inner adjusting screw slightly and tighten the outer adjusting screw.

8. Remove the clevis pin from the fuel rod and the left bank injector control tube lever.

9. Insert the clevis pin in the fuel rod and the right cylinder bank injector control tube lever and position the No. 3R injector rack control lever as previously outlined in Step 6 for the No. 3L control lever.

10. Insert the clevis pin in the fuel rod and the left bank injector control tube lever. Repeat the check on the 3L and 3R injector rack control levers as outlined in Step 7. Check for and eliminate any deflection which may occur at the bend in the fuel rod where it enters the cylinder head.

11. Manually hold the No. 3L injector rack in the full fuel position, with the lever on the injector control tube, and turn the inner adjusting screw of the No. 2L injector rack control lever down until the injector rack of No. 2L injector has moved into the full-fuel position. Turn the outer adjusting screw down until it bottoms lightly on the injector control tube. Then alternately tighten both the inner and outer adjusting screws.

12. Recheck the No. 3L injector rack to be sure that it has remained snug on the ball end of the rack control lever while positioning the No. 2L injector rack. If the rack of the No. 3L injector has become loose, back off the inner adjusting screw slightly on No. 2L injector rack control lever and tighten the outer adjusting screw. When the settings are correct, the racks of both injectors must be snug on the ball end of their respective control levers.

13. Position the IL injector rack control lever as outlined in Steps 11 and 12.

14. Position the No. 2R and IR injector rack control levers as outlined above for the left cylinder bank in Steps II through 13.

15. Install the valve rocker covers.

Adjust Maximum No-Load Speed

The maximum no-load speed varies with the full-load operating speed desired.

1971 General Motors Corp.

Use an accurate hand tachometer to determine the maximum no-load speed of the engine, then make the following adjustments, if required.

1. Refer to Fig. 7 and disconnect the booster spring and the stop lever retracting spring.

2. Remove the two attaching bolts and withdraw the variable speed spring housing and the variable speed spring retainer located inside of the housing.

3. Refer to the following table and determine the stops or shims required for the desired full-load speed. A split stop can only be used with a solid stop (Fig. 4).

	Stops		
Full-Load Speed	Solid	Split	Shims*
1200-2100	1	1	As Required
2100-2500	1	0	As Required
2500-2800	0	0	As Required

*Maximum amount of shims .325"

4. Install the variable speed spring housing and recheck the maximum no-load speed.

5. If required. add shims to obtain the necessary operating speed. For each .001" in shims added. the operating speed will increase approximately 2 rpm.

IMPORTANT: If the maximum no-load speed is raised or lowered more than 50 rpm by the installation or removal of shims. recheck the governor gap. If readjustment of the governor gap is required. the position of the injector racks must be rechecked.

NOTE: Governor stops are used to limit the compression of the governor spring, which determines the maximum speed of the engine.

Adjust Idle Speed

After the maximum no-load speed has been set. adjust the idle speed as follows:



Fig. 4 - Location of Shims and Stops



Fig. 5 - Adjusting Idle Speed

1. Place the stop lever in the RUN position and the speed control lever in the IDLE position.

2. With the engine operating. loosen the lock nut and turn the idle speed adjusting screw (Fig. 5 min or out until the engine idles at the recommended idle speed The recommended idle speed is 550 rpm. hut may vary with special engine applications.

3. Hold the idle speed adjusting screw and tighten the lock nut.

Adjust Buffer Screw

With the engine idle speed properly set, adjust the buffer screw as follows:

1. With the engine running at idle speed. turn the buffer screw in (Fig. 6) so that it contacts the



Fig. 6 - Adjusting Buffer Screw



Fig. 7 - Adjusting Booster Spring

differential lever as lightly as possible and still eliminates engine roll.

NOTE: Do not raise the engine idle speed more than 15 rpm with the buffer screw.

2. Hold the buffer screw and tighten the lock nut.

Adjust Booster Spring

With the idle speed set. adjust the booster spring as follows:

1. Refer to Fig. 7 and loosen the booster spring retaining nut on the speed control lever. Loosen the lock nuts on the eye bolt at the other end of the spring.

2. Move the spring retaining bolt in the slot of the speed control lever until the center of the bolt is on an imaginary line through the center of the bolt, lever shaft and eye bolt. Hold the bolt and tighten the lock nut.

3. Start the engine and move the speed control lever to the maximum speed position and release it. The speed control lever should return to the idle position If it does not, reduce the tension on the booster spring If the lever does return to the Idle position, continue to increase the spring tension until the point is reached that it will not return to idle. Then reduce the tension until it does return to idle and tighten the lock nut on the eye bolt. This setting will result in the minimum force required to operate the speed control lever.

4. Connect the linkage to the governor levers.

1971 General Motors Corp.

THROTTLE DELAY MECHANISM

The throttle delay mechanism is used to retard full fuel injection when the engine is accelerated. This reduces exhaust smoke and also helps to improve fuel economy.

The throttle delay mechanism (Fig. 1) is installed or between the No. 1 and No. 2 cylinders on the right-bank cylinder head of V-type engines. It consists of a special rocker arm shaft bracket (which incorporates the throttle delay cylinder), a piston, throttle delay lever, connecting link, oil supply plug, ball check valve and U-bolt.

A yield lever replaces the standard operating lever in the governor of the 6V-53 engine (Fig. 2)

Operation

Oil is supplied to a reservoir above the throttle delay cylinder through a special plug in the drilled oil passage in the rocker arm shaft bracket (Fig.1). As the injector racks are moved toward the no-fuel position, free movement of the throttle delay piston is assured by air drawn into the cylinder through the ball check valve. Further movement of the piston uncovers an opening which permits oil from the reservoir to enter the cylinder and displace the air. When the engine is accelerated, movement of the injector racks toward the full-fuel position is momentarily retarded while the piston expels the oil from the cylinder through a .016 " orifice. To permit full accelerator travel, regardless of the retarded injector rack position, a spring loaded yield lever or link assembly replaces



Fig.1. Throttle Delay Cylinder



Fig. 2 - Throttle Delay Yield Lever (6V Engine)

©1972 General Motors Corp.

the standard operating lever connecting link to the governor.

Adjustment Whenever the injector rack control levers are adjusted, disconnect the throttle delay mechanism by loosening the U-bolt which clamps the lever to the injector control tube. After the injector rack control levers have been positioned, the throttle delay mechanism must be re-adjusted. With the engine stopped, proceed as follows:

1. Refer to Fig. 3 and insert gage J 23190 (.454 " setting) between the injector body and the shoulder on the injector rack. Then exert a light pressure on the injector control tube in the direction of full fuel.



Fig. 3- Adjusting Throttle Delay Cylinder

2. Align the throttle delay piston so it is flush with the edge of the throttle delay cylinder.

3. Tighten the U-bolt on the injector control tube and remove the gage.

4. Move the injector rack from the no-fuel to full-fuel to make sure it does not bind.

© 1972 General Motors Corp.

SECTION 15
PREVENTIVE MAINTENANCE - TROUBLE SHOOTING - STORAGE
CONTENTS

Lubrication and Preventive Maintenance 15.1
Trouble Shooting 15.2
Storage 15.3

© 1970 General Motors Corp.

LUBRICATION AND PREVENTIVE MAINTENANCE

To obtain the best performance and long life from a Detroit Diesel engine, the Operator must adhere to the following schedule and instructions on lubrication and preventive maintenance.

The daily instructions pertain to routine or daily starting of an engine and not to a new engine or one that has not been operated for a considerable period of time. For new or stored engines, carry out the instructions given under *Preparation for Starting Engine First Time under Operating Instructions.*

The time intervals given in the chart on the following page are actual operating hours or miles of an engine. If the lubricating oil is drained immediately after an engine has been run for some time, most of the sediment will be in suspension and, therefore, will drain readily.

© 1972 General Motors Corp.

LUBRICATION AND PREVENTIVE MAINTENANCE CHART	Time Interval								
Item Operation — Hours		8	50	100	200	300	500	1,000	2,000
Item Operation — Miles	Daily	240	1,500	3,000	6,000	9,000	15,000	30,000	60,000
1. Engine Oil	X								
2. Oil Filter*									
3. Coolant	X						X	X	
4. Hoses							X		
5. Radiator								X	
							X	X	
	X								
8. Fuel Tank	X						X		
9. Fuel Strainer and Filter	X					X			
10. Air Cleaners		X					X		
11. Air Box Drains								X	
12. Ventilating System								X	
13. Blower Screen								X	
14. Starting Motor*									
15. Battery-Charging Generator				X	X		X		X
16. Battery				X					
17. Tachometer Drive				X					
18. Throttle and Clutch Controls					X				
19. Engine Tune-Up*									
20. Drive Belts		X			X				
							X		
22. Fan Hub Bearings*									
						X			
25. Air Compressor Air Strainer					X				
				X		X			
		X	X				X		
	X		X				X		
	X				X			X	

* See items on following pages

ã 1972 General Motors Corp.

Item 1

Check the oil level daily before starling the engine.

Add oil, if necessary, to bring it to the proper level on the dipstick.

Select the proper grade of oil in accordance with the instructions in the Lubricating Oil Specifications in Section 133.3.

It is recommended that new engines be started with 100 hour oil change periods. For highway vehicles, this corresponds to approximately 3,000 miles, and for city service vehicles approximately 1,000-2.(000 miles. The drain interval may then be gradually increased, or decreased, following the recommendations of an independent oil analysis laboratory or the oil supplier (based upon the oil sample analysis) until the most practical oil change period has been established.

Item 2

Install new engine oil filter elements and gaskets each time the engine oil is changed. Check for oil leaks after starting the engine. If the engine is equipped with a governor oil filter, change the element every 1.000 hours.

Item 3

Check the coolant level daily and maintain it near the top of the radiator upper tank.

Clean the cooling system every 1,000 hours or 30,000 miles using a good radiator cleaning compound in accordance with the instructions on the container. After the cleaning operation, rinse the cooling system thoroughly with fresh water; then, fill the system with soft water, adding a good grade of rust inhibitor or a high boiling point type antifreeze (refer to Engine Coolant in Section 13.3). With the use of a proper antifreeze or rust inhibitor, this interval may be lengthened until, normally, this cleaning is done only in the spring or fall. The length of this interval will, however, depend upon an inspection for rust or other deposits on the internal walls of the cooling system. When a thorough cleaning of the cooling system is required, it should be reverse-flushed.

Item 4

Inspect all of the cooling system hoses at least once every 500 hours or 15,000 miles for signs of deterioration. Replace the hoses if necessary.



Items 1 and 2



Items 3 and 4

ã 1972 General Motors Corp

Item 5

Inspect the exterior of the radiator core. very 1,000 hours or 30,000 miles and, if necessary, clean it with a quality grease solvent such as Oleum and compressed air. Do not use fuel oil, kerosene or gasoline. It may be necessary to clean the radiator more frequently if the engine is being operated in extremely dusty or dirty areas.



Item 5



Item 6

Item 8

Keep the fuel tank filled to reduce condensation to a minimum. Select the proper grade of fuel in accordance with the Diesel Fuel Oil Specifications in Section 13.3. Open the drain at the bottom of the fuel tank every 500 hours or 15,000 miles to drain off any water or sediment.

Item 9

Drain approximately one-fourth pint of fuel to remove sediment and water from the strainer and the filter daily by opening the drain cock in the bottom of each shell. Install new elements every 300 hours or 9,000 miles or when plugging is indicated.



Item 7

© 1972 General Motors Corp

A method of determining when elements are plugged to the extent that they should be changed is based on the fuel pressure at the cylinder head fuel inlet manifold and the inlet restriction at the fuel pump. In a clean system, the maximum pump inlet restriction must not exceed 6 inches of mercury. At normal operating speeds (1800-2800 rpm), the fuel pressure is 45 to 70 psi. Change the fuel filter elements whenever the inlet restriction (suction) at the fuel pump reaches 12 inches of mercury at normal operating speeds and whenever the fuel pressure at the inlet manifold falls to 45 psi.



Item 9



Item 10

Item 10

Remove the dirty oil and sludge from the oil bath-type air cleaner cups and center tubes every 8 hours (every 6,000 miles for highway vehicle engines). or less if operating conditions warrant. Wash the cups and elements in clean fuel oil and refill the cups to the level mark with the same grade of heavy duty oil as used in the engine. The frequency of servicing may be varied to suit local dust conditions.

It is recommended that the body and fixed element in the heavy-duty oil bath type air cleaner be serviced every 500 hours, 15,000 miles or as conditions warrant.

Clean or replace the element in the dry-type air cleaner when the restriction indicator instrument indicates high restriction or when a water manometer reading at the air inlet housing indicates the maximum allowable air inlet restriction (Section 13.2).

Item 11

With the engine running, check for flow of air from the air box drain tubes every 1,000 hours or 30.000 miles. If the tubes are clogged, remove, clean and reinstall the tubes. The air box drain tubes should be cleaned periodically even though a clogged condition is not apparent. If the engine is equipped with an air box drain tank, drain the sediment periodically. If the

Item 12

Clean the externally mounted crankcase breather assemblies every 1,000 hours or 30,000 miles. This cleaning period may be reduced or lengthened according to severity of service. Clean the internally



Item 11

ã 1972 General Motors Corp. **July, 1972**

mounted breather pads at time of engine overhaul, or sooner if excessive crankcase pressure is observed.

Remove the crankcase breather from the engine and wash the steel mesh pad (element) in fuel oil and dry it with compressed air. Reinstall the breather assembly (refer to Section 4.8).

Clean the breather cap, mounted on the valve rocker cover, in clean fuel oil every time the engine oil is changed.

Item 13

Inspect the blower screen and gasket assemblies every 1.000 hours or 30,000 miles and, if necessary, clean the screens in fuel oil and dry them with compressed air.



Item 12



Item 13

Reinstall the screen and gasket assemblies with the screen side of the assemblies toward the blower.

Item 14

The electrical starting motor is lubricated at the time of original assembly. Oil can be added to the oil wicks, which project through each bushing and contact the armature shaft, by removing the pipe plugs on the outside of the motor. The wicks should be lubricated whenever the starting motor is taken off the engine or disassembled.

The Sprag overrunning clutch drive mechanism should be lubricated with a few drops of light engine oil whenever the starting motor is overhauled.

Item 15

Lubricate the generator (alternator) bearings or bushings with 5 or 6 drops of engine oil at the hinge cap oiler every 200 hours or 6,000 miles.

Some generators have a built-in supply of grease, while others use sealed bearings. In these latter two cases, additional lubrication is not necessary.

On A.C. generators (alternators), the slip rings and brushes can be inspected through the end frame



Item 14

ã 1972 General Motors Corp.



Item 15

assembly. If the slip rings are dirty, they should be cleaned with 400 grain or finer polishing cloth. Never use emery cloth to clean slip rings. Hold the polishing cloth against the slip rings with the generator in operation and blow away all dust after the cleaning operation. If the slip rings are rough or out of round, replace them.

Inspect the terminals for corrosion and loose connections and the wiring for frayed insulation.

Item 16

Check the specific gravity of the electrolyte in each cell of the battery every 100 hours or 3,000 miles. In warm weather, however, it should be checked more frequently due toga more rapid loss of water from the electrolyte. The electrolyte level should be maintained in accordance with the battery manufacturer's recommendations.

Item 17

Lubricate the tachometer drive every 100 hours or 3,000 miles with an all purpose grease at the grease fitting. At temperatures above +30 °F., use a No. 2 grade grease. Use a No. I grade grease below this temperature.

Item 18

Lubricate the throttle control mechanism every 200 hours or 6,000 miles with an all purpose grease. At temperatures above +30°F., use a No. 2 grade grease. Use a No. 1 grade grease below this temperature. Lubricate all other control mechanisms, as required, with engine oil.

Item 19

There is no scheduled interval for performing an engine tune-up. As long as the engine performance is satisfactory, no tune-up should be needed. Minor adjustments in the valve and injector operating mechanisms, governor, etc. should only be required periodically to compensate for normal wear on parts.

Item 20

New drive belts will stretch after the first few hours of operation. Run the engine for 15 seconds to seat the belts and retension. Then retighten new fan drive, pump drive and battery-charging generator drive belts



Item 17

ã 1972 General Motors Corp.

after 1/2 hour or 15 miles and again after 8 hours or 240 miles of operation. Thereafter, check the tension of the drive belts every 200 hours or 6,000 miles and adjust, if necessary. Too tight a belt is destructive to the bearings of the driven part; a loose belt will slip.

Replace all belts in a set when one is worn. Single belts of similar size should not be used as a substitute for a matched belt set; premature belt wear can result because of belt length variation. All belts in a matched set are within .032 " of their specified center distances.

NOTE: When installing or adjusting an accessory drive belt, be sure the bolt at the accessory adjusting pivot point is properly tightened, as well as the bolt in the adjusting slot.

Adjust the belt tension so that a firm push with the thumb, at a point midway between the two pulleys, will depress the belt 1/2 " to 3/4 ". If a belt tension gage such as BT-33-73F or equivalent is available, adjust the belt tension as outlined in the Table.

Model	Fan Drive		Generator Drive		
	2 or 3 belts	Single belt	Two 3/8" or 1/2" belts	One 1/2" belt	One Wide belt
6, V-53	60-80	80-100	40-50	50-70	40-50
All	For 3-point or triangular drive use a tension of 90-120.				

BELT TENSION CHART (lbs/belt)

Item 22

At a major engine overhaul, discard the bearings in the fan hub assembly used in radiator-cooled engines. Pack the hub assembly, using new bearings, with Chevron BRB No. 2 grease or an equivalent performance grease.



Item 20

Item 25

To clean either the hair or polyurethane type air compressor air strainer element, saturate and squeeze it in fuel oil, or any other cleaning agent that would not be detrimental to the element, until dirt free. Then dip it in lubricating oil and squeeze it dry before placing it back in the air strainer.

For replacement of the air strainer element, contact the nearest Bendix Westinghouse dealer; replace with the polyurethane element, if available.

© 1972 General Motors Corp.



Item 25



Item 27

© 1972 General Motors Corp.

TROUBLE SHOOTING

Certain abnormal conditions which sometimes interfere with satisfactory engine operation, together with methods of determining the cause of such conditions, are covered on the following pages.

Satisfactory engine operation depends primarily on:

1. An adequate supply of air compressed to a sufficiently high compression pressure.

2. The injection of the proper amount of fuel at the right time.

Lack of power, uneven running, excessive vibration, stalling at idle speed and hard starting may be caused by either low compression, faulty injection in one or more cylinders, or lack of sufficient air.

Since proper compression, fuel injection and the proper amount of air are important to good engine performance, detailed procedures for their investigation are given as follows:

Locating a Misfiring Cylinder

1. Start the engine and run it at part load until it reaches normal operating temperature.

2. Stop the engine and remove the valve rocker cover(s).

3. Check the valve clearance.

4. Start the engine. Then, hold an injector follower down with a screw driver, thus preventing operation of the injector. If the cylinder has been misfiring, there will be no noticeable difference in the sound and operation of the engine. If the cylinder has been firing properly, there will be a noticeable difference in the sound and operation when the injector follower is held down. This is similar to short-circuiting a spark plug in a gasoline engine.

5. If the cylinder is firing properly, repeat the procedure on the other cylinders until the faulty one has been located.

6. Provided the injector operating mechanism of the faulty cylinder is functioning satisfactorily, remove the fuel injector and install a new one.

7. If installation of a new injector does not eliminate the misfiring, the compression pressure of the cylinder in question should be checked.

Checking Compression Pressure

Compression pressure is affected by altitude as follows:



Fig. 1. - Checking Compression Pressure

Minimum Compression Pressure, psi	Altitude, Feet Above Sea Level
"N" Engine	
540	0
500	2,500
465	5,000
430	7,500
395	10,000

Check the compression pressure as follows:

1. Start the engine and run it at approximately one-half rated load until normal operating temperature is reached.

2. Stop the engine and remove the fuel pipes from the injector and fuel connectors of the No. I cylinder.

3. Remove the injector and install the adaptor J 791502 and pressure gage and hose assembly J 6992 (Fig. I).

4. Use a spare fuel pipe and fabricate a jumper connection between the fuel inlet and return manifold connectors. This will permit fuel from the inlet manifold to flow directly to the return manifold.

5. Start the engine and run it at a 600 rpm. Observe and record the compression pressure indicated on the gage.

Do not crank the engine with the starting motor to obtain the compression pressure.

6. Perform Steps 2 through 5 on each cylinder. The compression pressure in any one cylinder should be not less than (540 psi for 53N engines) at 600 rpm. In addition, the variation in compression.

© 1970 General Motors Corp.

pressures between cylinders must not exceed 25 psi at 600 rpm.

EXAMPLE: If the compression pressure readings were as shown in the following table, it would be evident that No. 3 cylinder should be examined and the cause of the low compression pressure be determined and corrected.

Cylinder	Gage Reading*
1	525 psi
2	520 psi
3	485 psi
4	515 psi

The above pressures are for an engine operating at an altitude near sea level.

Note that all of the cylinder pressures are above the low limit for satisfactory engine operation. Nevertheless, the No. 3 cylinder compression pressure indicates that something unusual has occurred and that a localized pressure leak has developed.

Low cylinder pressure may result from any one of several causes:

A. Piston rings may be stuck or broken. To determine the condition of the rings, remove the air box cover and inspect them by pressing on the rings with a blunt tool. A broken or stuck ring will not have a "springlike" action.

B. Compression pressure may be leaking past the cylinder head gasket, the valve seats, the injector tube, or a hole in the piston.

Engine Out of Fuel

The problem in restarting the engine after it has run out of fuel stems from the fact that after the fuel is exhausted from the fuel tank, fuel is then pumped from the primary fuel strainer and sometimes partially removed from the secondary fuel filter before the fuel supply becomes insufficient to sustain engine firing.

Consequently, these components must be refilled with fuel and the fuel pipes rid of air in order for the system to provide adequate fuel for the injectors.

When an engine has run out of fuel, there is a definite procedure to follow for restarting it: 1. Fill the fuel tank with the recommended grade of fuel oil. If only partial filling of the tank is possible, add a minimum of ten gallons of fuel.

2. Remove the fuel strainer shell and element from the strainer cover and fill the shell with fuel oil. Install the shell and element.

3. Remove and fill the fuel filter shell and element with fuel oil as in Step 2.

4. Start the engine. Check the filter and strainer for leaks.

NOTE: In some instances, it may be necessary to remove a valve rocker cover and loosen a fuel pipe nut in order to bleed trapped air from the fuel system. Be sure the fuel pipe is retightened securely before replacing the rocker cover.

Primer J 5956 may be used to prime the entire fuel system. Remove the filler plug in the fuel filter cover and install the primer. Prime the system. Remove the primer and install the filler plug.

Fuel Flow Test

1. Disconnect the fuel return hose and hold the open end in a suitable container.

2. Start and run the engine at approximately 1200 rpm and measure the fuel flow from the return hose for one minute. At least 0.6 gallon of fuel should flow from the return hose per minute.

3. Be sure all of the connections between the fuel supply and the pump are tight so that no air will be drawn into the fuel system; then, immerse the end of the fuel hose in the fuel in the container. Air bubbles rising to the surface of the fuel will indicate a leak on the suction side of the pump.

Crankcase Pressure

The crankcase pressure indicates the amount of air that has passed between the oil control rings and the cylinder liner into the crankcase, most of which is clean air from the air box. A slight pressure in the crankcase is desirable to prevent the entrance of dust. A loss of engine lubricating oil through the breather tube, crankcase ventilator, or dipstick hole in the cylinder block is indicative of excessive crankcase pressure.

The causes of high crankcase pressure may be traced to excessive blow-by due to worn piston rings, a hole or crack in a piston crown, loose piston pin retainers, worn blower oil seals, defective blower, cylinder, or end plate gaskets, or excessive exhaust back pressure. Also, the breather tube or crankcase ventilator should be checked for obstructions.

ã 1970 General Motor Corp

The crankcase pressure may be checked with a manometer. The manometer should be connected to the oil level dipstick opening in the cylinder block. Check the readings obtained at various engine speeds with the Engine Operating Conditions in Section 13.2.

Exhaust Back Pressure

A slight pressure in the exhaust system is normal. However, excessive exhaust back pressure seriously affects engine operation. It may cause an increase in the air box pressure with a resultant loss of efficiency of the blower. This means less air for scavenging which results in poor combustion and higher temperatures.

Causes of high exhaust back pressure are usually a result of an inadequate or improper type of muffler, an exhaust pipe which is too long or too small in diameter, an excessive number of sharp bends in the exhaust system, or obstructions such as excessive carbon formation or foreign matter in the exhaust system.

The exhaust back pressure, measured in inches of mercury, may be checked with a manometer in the engine diagnosis test kit J 9531-01. Connect the manometer to the exhaust manifold by removing the 1/8" pipe plug which is provided for that purpose. If there is no opening provided, drill an 11/32" hole in the exhaust manifold companion flange; then tap the hole to accommodate a 1/8' pipe plug.

Check the readings obtained at various speeds (at noload) with the specifications in Section 13.2.

Air Box Pressure

Proper air box pressure is required to maintain sufficient air for combustion and scavenging of the burned gases. Low air box pressure is caused by a high air inlet restriction, damaged blower rotors, an air leak from the air box, such as leaking end plate gaskets, or a clogged blower air inlet screen. Lack of power or black or grey exhaust smoke are indications of low air box pressure.

High air box pressure can be caused by partially plugged-cylinder liner ports.

To check the air box pressure, connect a manometer to an air box drain tube.

Check the readings obtained at various speeds with the Engine Operating Conditions in Section 13.2.

Air Inlet Restriction

Excessive restriction of the air inlet will affect the flow of air to the cylinders and result in poor combustion and lack of power. Consequently the restriction must be kept as low as possible considering the size and capacity of the air cleaner. An obstruction in the air inlet system or dirty or damaged air cleaners will result in a high blower inlet restriction.

The air inlet restriction may be checked with a water manometer connected to a fitting in the' air intake ducting located 2" above the air inlet housing. When practicability prevents the insertion of a fitting at this point, the manometer may be connected to the engine air inlet housing. The restriction at this point should be checked at a specific engine speed. Then, the air cleaner and ducting should be removed from the air inlet housing and the engine again operated at the same speed while noting the manometer reading.

The difference between the two readings, with and without the air cleaner and ducting, is the actual restriction caused by the air cleaner and ducting.

Check the normal air inlet vacuum at various speeds (at no-load) and compare the results with the Engine Operating Conditions in Section 13.2.

PROPER USE OF MANOMETER

The U-tube manometer is a primary measuring device indicating pressure or vacuum by the difference in the height of two columns of fluid.

Connect the manometer to the source of pressure, vacuum or differential pressure. When the pressure is imposed, add the number of inches one column of fluid travels up to the amount the other column travels down to obtain the pressure (or vacuum) reading.

The height of a column of mercury is read differently than that of a column of water. Mercury does not wet the inside surface; therefore, the top of the column has a convex meniscus (shape). Water wets the surface and therefore has a concave meniscus. A mercury column is read by sighting horizontally between the top of the convex mercury surface (Fig. 2) and the scale. A water manometer is read by sighting horizontally between the bottom of the concave water surface and the .scale.

© 1970 General Motors Corp.

Should one column of fluid travel further than the other column, due to minor variations in the inside diameter of the tube or to the pressure imposed, the accuracy of the reading obtained is not impaired.

The manometer reading may be converted into other units of measurement by use of the pressure conversion chart.

PRESSURE CONVERSION CHART

1" water	=	.0735" mercury
1" water	=	.0361 psi
1" mercury	=	.491 psi
1" mercury	=	13.6" water
1 psi	=	27.7" water
1 psi	=	2.036" mercury



Fig. 2. - Comparison of Column Height for Mercury and Water Manometers

Chart 1

EXHAUST SMOKE ANALYSIS

CHECKS SHOULD BE MADE WITH WATER OUTLET TEMPERATURE AT 160°F. MINIMUM

BLACK OR GRAY SMOKE

Probable Causes

1. INCOMPLETELY BURNED FUEL
2. EXCESSIVE FUEL OR IRREGULAR FUEL DISTRIBUTION
3. IMPROPER GRADE OF FUEL

BLUE SMOKE

Probable Causes

4. LUBRICATION OIL NOT BURNED IN CYLINDER (BLOWN THROUGH CYLINDER DURING SCAVENGING PERIOD)

WHITE SMOKE

Probable Cause

5. MISFIRING CYLINDERS

ã 1970 General Motors Corp.

Chart 1 (Cont'd.)

EXHAUST SMOKE ANALYSIS

SUGGESTED REMEDY

1. High exhaust back pressure or a restricted air inlet causes insufficient air for combustion and will result in incompletely burned fuel.

High exhaust back pressure is caused by faulty exhaust piping or muffler obstruction and is measured at the exhaust manifold outlet with a manometer. Parts causing high exhaust back pressure should be replaced.

Restricted air inlet to the engine cylinders is caused by clogged cylinder liner ports, air cleaner, or blower air inlet screen. These items should be cleaned. Check the emergency stop to make sure that it is completely open and readjust it if necessary.

2. Check for improperly timed injectors and improperly positioned injector rack control levers. Time the fuel injectors as outlined in Fuel Injector Timing and perform the appropriate governor tune-up to correct this condition.

Replace faulty injectors if this condition still persists after timing the injectors and performing the engine tune-up.

Lugging the engine will cause incomplete combustion and should be avoided. Operate the engine as outlined in the *Drivers Handbook*.

3. Check for the use of an improper grade of fuel. Consult the *Fuel Oil Specifications* for the correct fuel tot use.

4. Check for internal lubricating oil leaks, and refer to the *High Lubricating Oil Consumption chart.*

5. Check for faulty injectors and replace as necessary. Check for low compression and consult the *Hard Starting chart.*

The use of low cetane fuel will cause this condition and can be corrected by consulting and following the *Fuel Oil Specifications*.

© 1970 General Motors Corp.

Chart 2


HARD STARTING
Probable Causes
ENGINE WILL NOT ROTATE
Check For
1. LOW BATTERY, LOOSE STARTER CONNECTIONS OR FAULTY STARTER
2. DEFECTIVE STARTING MOTOR SWITCH
3. INTERNAL SEIZURE
LOW CRANKING SPEED
Check For
4. IMPROPER LUBRICATING OIL VISCOSITY
5. LOW BATTERY OUTPUT
6. LOOSE STARTER CONNECTIONS OR FAULTY STARTER
NO FUEL
Check For
7. AIR LEAKS, FLOW OBSTRUCTIONS, FAULTY FUEL PUMP, FAULTY INSTALLATION
8. INJECTOR RACKS NOT IN FULL-FUEL POSITION
LOW COMPRESSION
Check For
9. EXHAUST VALVES STICKING OR BURNED
10. COMPRESSION RINGS WORN OR BROKEN
11. CYLINDER HEAD GASKET LEAKING
12. IMPROPER VALVE CLEARANCE ADJUSTMENT
13. BLOWER NOT FUNCTIONING
INOPERATIVE STARTING AID AT LOW AMBIENT TEMP.
Check For
14. IMPROPER OPERATION OF FLUID STARTING AID

ã 1970 General Motors Corp.

Chart 2 (Cont'd.)

HARD STARTING (Cont'd.)

SUGGESTED REMEDY

1. Refer to Items 2 and 3 and perform the operations listed.

2. Replace the starting motor switch.

3. Hand crank the engine at least one complete revolution. If the engine cannot be rotated a complete revolution, internal damage is indicated and the engine must be disassembled to ascertain the extent of damage and the cause.

4. Use the proper viscosity lubricating oil grade as recommended in the Lubricating Oil Specifications.

5. Recharge the battery if a light load test indicates low or no voltage. Replace the battery if it is damaged or will not hold a charge.

Connect the leads properly after replacing the terminals that are damaged or corroded.

At low ambient temperatures, use of a starting aid will facilitate keeping the battery fully charged by reducing the cranking time.

6. Tighten the starter connections. Inspect the starter commutator and brushes for wear. Replace the brushes if badly worn and overhaul the starting motor if the commutator is damaged.

7. To check for air leaks, flow obstruction, faulty fuel pump or faulty installation, consult the No Fuel or Insufficient Fuel chart.

8. Inspect for governor-to-injector linkage binding that will prevent the governor from positioning the injector racks into the full-fuel position. Remove any bind found and readjust the governor and injector controls if necessary.

9. The cylinder head must be removed and overhauled to correct this condition.

10. Remove the air box covers and inspect the compression rings through the ports in the cylinder liners. Overhaul the cylinder assemblies if the rings are badly worn or broken.

11. To check for compression gasket leakage, remove the radiator filler cap and operate the engine. A steady flow of gases from the coolant filler indicates either a cylinder head gasket is damaged or the cylinder head is cracked. Remove the cylinder head and replace the gaskets.

12. Check the exhaust valve clearance and adjust to the correct clearance.

13. Inspect the blower drive shaft and drive coupling. Replace damaged parts.

14. Operate the starting aid according to the instructions under Cold Weather Starting Aids.

ã 1970 General Motors Corp.

Chart 3



SUGGESTED REMEDY

1. Watch the engine coolant temparature gage and if the temperature does not reach 160° to 185°F while the engine is operating, consult the Abnormal Engine Coolant Temperature chart.

2. Check engine fuel spill back and if the return is less than .6 gallon per minute consult the No Fuel or Insufficient Fuel chart.

© 1970 General Motors Corp.

Chart 3 (Cont'd.)

ABNORMAL ENGINE OPERATION (Cont'd.)

-SUGGESTED REMEDY-

3. Check the injector timing and the position of the injector racks. If the engine was not tuned correctly, perform an engine tune-up. Erratic engine operation may also be caused by leaking injector spray tips. Replace the faulty injectors.

4. Check the compression pressures within the cylinder and consult the *Hard Starting* chart if compression pressures are low.

5. Erratic engine operation may be caused by governor-to-injector operating linkage binding or by faulty adjustments when performing the engine tune-up. These items may be corrected by performing the appropriate engine tune-up procedure as outlined for the governor.

6. The engine should be tuned whenever performance is not satisfactory.

Check the engine gear train timing. An improperly timed gear train will result in a loss of power due to the valves and injectors being actuated at the wrong time in the engine's operating cycle.

7. Perform a *Fuel Flow Test* and, if less than .6 gallon per minute is returning to the fuel tank, consult the *No Fuel or Insufficient Fuel* chart.

8. Check for damaged or dirty air cleaners and clean, repair or replace damaged parts.

Remove the air box covers and inspect the cylinder liner ports. If the ports are over 50% plugged, clean them.

When it is determined that the engine is not getting an adequate supply of air into the cylinders, resulting in poor combustion, check for damaged or dirty air cleaners, inadequate air supply to the engine compartment cylinder liner ports over 50% plugged, blower air intake obstructed or high exhaust back pressure. The faulty parts should be cleaned, repaired or replaced.

Check the compression pressures; if found low, consult the *Hard Starting* chart.

9. Incorrect operation of the engine may result in excessive loads on the engine. Operate the engine according to the approved procedures outlined in the *Drivers Handbook*.

10. Refer to Item 13 on Chart 4.

11. Check the ambient air temperature. A power decrease of .15 to .5 horsepower per cylinder, depending upon injector size, for each 10°F. temperature rise above 90°F. will occur. Relocate the engine air intake to provide a cooler source of air.

12. Engines lose horsepower with increases in altitude. The percentage of power loss is governed by the altitude at which the engine is operating.

13. Check oil bath air cleaners to see that they have been filled to the proper level with the same viscosity lubricating oil that is used in the engine.

Clean the air box and drain tubes to prevent accumulations that may be picked up by the air stream and enter the engine's cylinders.

Inspect the blower oil seals by removing the air inlet housing and watching through the blower inlet, for oil radiating away from the blower rotor shaft oil seals while the engine is running. If oil is passing through the seals, overhaul the blower.

Check for a defective blower-to-cylinder block gasket. Replace the gasket if necessary. If the blower has been removed, install a new gasket.

14. Refer to Item 1 of this chart.

15. Check injector timing and the position of each injector rack. If the engine was not tuned-up correctly, perform an engine tune-up. If the engine is correctly tuned, the erratic operation may be caused by an injector check valve leaking, spray tip holes enlarged, or a broken spray tip. Replace all injectors found faulty.

© 1970 General Motors Corp. October, 1970

Chart 4


NO FUEL OR INSUFFICIENT FUEL
Probable Causes
AIR LEAKS
Check For
1. LOW FUEL SUPPLY
2. LOOSE CONNECTIONS OR CRACKED LINES BETWEEN FUEL PUMP AND TANK OR SUCTION LINE IN TANK
3. DAMAGED FUEL OIL STRAINER GASKET
4. FAULTY INJECTOR TIP ASSEMBLY
FLOW OBSTRUCTION
Check For
5. FUEL STRAINER OR LINES RESTRICTED
6. TEMPERATURE LESS THAN 10°F. ABOVE POUR POINT OF FUEL
FAULTY FUEL PUMP
Check For
7. RELIEF VALVE NOT SEATING
8. WORN GEARS OR PUMP BODY
9. FUEL PUMP NOT ROTATING
FAULTY INSTALLATION
Check For
10. DIAMETER OF FUEL SUCTION LINES TOO SMALL
11. RESTRICTED FITTING MISSING FROM RETURN LINE
12. INOPERATIVE FUEL INTAKE LINE CHECK VALVE
13. HIGH FUEL RETURN TEMPERATURE

© 1970 General Motors Corp.

Chart 4 (Cont'd.)

NO FUEL OR INSUFFICIENT FUEL (Cont'd.)

-SUGGEST REMEDY-

1. The fuel tank should be filled above the level of the fuel suction tube.

2. Perform a Fuel Flow Test and, if air is present, tighten loose connections and replace cracked lines.

3. Perform a Fuel Flow Test and, if air is present, replace the fuel strainer gasket when changing the strainer element.

4. Perform a Fuel Flow Test and, if air is present with all fuel lines and connections assembled correctly, check for and replace faulty injectors.

5. Perform a Fuel Flow Test and replace the fuel strainer and filter elements and the fuel lines, if necessary.

6. Consult the Fuel Oil Specifications and use the fuel oil recommended.

7. Perform a Fuel Flow Test and, if inadequate, clean and inspect the valve seat assembly.

8. Replace the gear and shaft assembly or the pump body.

9. Check the condition of the fuel pump drive and blower drive and replace the defective parts.

10. Replace with larger tank-to-engine fuel lines.

11. Install a restricted fitting in the return line.

12. Make sure that the check valve is installed in the line correctly; the arrow should be on top of the valve assembly or pointing upward. Reposition the valve if necessary. If the valve is inoperative, replace it with a new valve assembly.

13. Check the engine fuel spill-back temperature. The return fuel temperature must be less than 150°F. or a loss in horsepower will occur. This condition may be corrected by installing larger fuel lines or relocating the fuel tank to a cooler position.

© 1970 General Motors Corp. October, 1970

Chart 5


HIGH LUBRICATING OIL CONSUMPTION
Probable Causes
EXTERNAL LEAKS
Check For
1. OIL LINES OR CONNECTIONS LEAKING
2. GASKET OR OIL SEAL LEAKS
3. HIGH CRANKCASE PRESSURE
4. EXCESSIVE OIL IN AIR BOX
INTERNAL LEAKS
Check For
5. BLOWER OIL SEAL LEAKING
6. OIL COOLER CORE LEAKING
OIL CONTROL AT CYLINDER
Check For
7. OIL CONTROL RINGS WORN, BROKEN OR IMPROPERLY INSTALLED
8. PISTON PIN RETAINER LOOSE
9. SCORED LINERS, PISTONS, OR OIL RINGS
10. PISTON AND ROD ALIGNMENT
11. EXCESSIVE INSTALLATION ANGLE
12. EXCESSIVE OIL IN CRANKCASE

-SUGGESTED REMEDY-

1. Tighten or replace the defective parts.

2. Replace defective gaskets or oil seals.

3. Refer to the Excessive Crankcase Pressure chart.

4. Refer to the Abnormal Engine Operation chart.

5. Remove the air inlet housing and inspect the blower end plates while the engine is operating. If oil is seen on the end plate radiating away from the oil seal, overhaul the blower.

6. Inspect the engine coolant for lubricating oil contamination; if contaminated, replace the oil cooler core. Then, use a good grade of cooling system cleaner to remove the oil from the cooling system.

7. Replace the oil control rings on the piston.

8. Replace the piston pin retainer and defective parts.

9. Remove and replace the defective parts.

10. Replace all worn and defective parts.

11. Decrease the installation angle.

12. Fill the crankcase to the proper level only.

© 1970 General Motors Corp.

Chart 6



-SUGGESTED REMEDY-

1. Check the compression pressure and, if only one cylinder has low compression, remove the cylinder head and replace the head gaskets.

2. Inspect the piston and liner and replace damaged parts.

3. Install new piston rings.

4. Clean and repair or replace the breather assembly.

5. Replace the blower-to-block gasket.

6. Replace the end plate gasket.

7. Check the exhaust back pressure and repair or replace the muffler if an obstruction is found.

8. Check the exhaust back pressure and install larger piping if it is determined that the piping is too small, too long or has too many bends.

© 1970 General Motors Corp.


LOW OIL PRESSURE
CHECK SHOULD BE MADE WITH WATER OUTLET TEMPERATURE AT 160°F, MINIMUM
Probable Causes
LUBRICATING OIL
Check For
1. SUCTION LOSS
2. LUBRICATING OIL VISCOSITY
POOR CIRCULATION
Check For
3. COOLER CLOGGED
4. COOLER BY-PASS VALVE NOT FUNCTIONING PROPERLY
5. PRESSURE REGULATOR VALVE NOT FUNCTIONING PROPERLY
6. EXCESSIVE WEAR ON CRANKSHAFT BEARINGS
7. GALLERY, CRANKSHAFT OR CAMSHAFT PLUGS MISSING
PRESSURE GAGE
Check For
8. FAULTY GAGE
9. GAGE LINE OBSTRUCTED
10. GAGE ORIFICE PLUGGED
11. ELECTRICAL INSTRUMENT PANEL SENDING UNITS FAULTY
OIL PUMP
Check For
12. INTAKE SCREEN PARTIALLY CLOGGED
13. RELIEF VALVE FAULTY
14. AIR LEAK IN PUMP SUCTION
15. PUMP WORN OR DAMAGED
16. FLANGE LEAK - PRESSURE SIDE

© 1970 General Motors Corp.

Chart 7 (Cont'd.)

LOW OIL PRESSURE (Cont'd.)

-SUGGESTED REMEDY-

1. Check the oil and bring it to the proper level on the dipstick or correct the installation angle.

2. Wrong viscosity of lubricating oil being used; consult the *Lubricating Oil Specifications*.

Check for fuel leaks at the injector nut seal ring and fuel pipe connections. Leaks at these points will cause fuel oil dilution.

3. A plugged oil cooler is indicated by excessively high lubricating oil temperature. Remove and clean the oil cooler core.

4. Remove the by-pass valve and clean the valve and valve seat and inspect the valve spring. Replace defective parts.

5. Remove the pressure regulator valve and clean the valve and valve seat and inspect the valve spring. Replace defective parts.

6. Change the bearings. Consult the *Lubricating Oil Specifications* for the proper grade of oil to use and change the oil filters.

7. Replace missing plug(s).

8. Check the oil pressure with a reliable gage and replace the gage if found faulty.

9. Remove and clean the gage line; replace it if necessary.

10. Remove and clean the gage orifice.

11. Repair or replace defective electrical equipment.

12. Remove and clean the oil pan and oil intake screen; consult the *Lubricating Oil Specifications* for the proper grade of oil to use and change the oil filters.

13, Remove and inspect the valve, valve bore and spring; replace faulty parts.

14. Disassemble the piping and install new gaskets.

15. Remove the pump, clean and replace defective parts.

16. Remove the flange and replace the gasket.

© 1970 General Motors Corp.

Chart 8



-SUGGESTED REMEDY-

1. The cooling system should be cleaned with a good cooling system cleaner and thoroughly flushed to remove scale deposits.

The exterior of the radiator core should be cleaned to open plugged passages permitting normal air flow.

Loose fan belts should be adjusted to the proper tension to prevent slippage.

Check for an improper size radiator or inadequate shrouding.

Repair or replace inoperative temperature-controlled fan.

2. Check the coolant level and fill to the filler neck if the coolant level is low.

Inspect for collapsed or disintegrated hoses. Replace all faulty hoses.

Thermostat may be inoperative. Remove, inspect and test the thermostat; replace if found faulty.

Check the water pump for a loose or damaged impeller.

Check the flow of water through the radiator. A clogged radiator will cause an inadequate supply of water on the suction side of the pump. Clean the radiator core, Remove the radiator cap and operate the engine, checking for combustion gases in the cooling system.

The cylinder head must be removed and inspected for cracks and the head gaskets replaced if combustion gases are entering the cooling system.

Check for an air leak on the suction side of the water pump. Replace defective parts.

3. The thermostat may not be closing. Remove, inspect and test the thermostat. Install a new thermostat if necessary.

Check for an improperly installed heater.

4. Excessive leakage of coolant past the thermostat seal(s) is a cause of continued low coolant operating temperature. when this occurs, replace the thermostat seal(s).

© 1970 General Motors Corp.

STORAGE

PREPARING ENGINE FOR STORAGE

When an engine is to be stored or removed from operation for a period of time, special precautions should be taken to protect the interior and exterior of the engine, transmission and other parts from rust accumulation and corrosion. The parts requiring attention and the recommended preparations are given below.

It will be necessary to remove all rust or corrosion completely from any exposed part before applying a rust preventive compound. Therefore, it is recommended that the engine be processed for storage as soon as possible after removal from operation.

The engine-should be stored in a building which is dry and can be heated during the winter months. Moisture absorbing chemicals are available commercially for use when excessive dampness prevails in the storage area.

TEMPORARY STORAGE (30 days or less)

To protect an engine for a temporary period of time, proceed as follows:

1. Drain the engine crankcase.

2. Fill the crankcase to the proper level with the recommended viscosity and grade of oil.

3. Fill the fuel tank with tl'e recommended grade of fuel oil. Operate the engine for two minutes at 1200 rpm and no load.

NOTE

Do not drain the fuel system or the crankcase after this run.

4. Check the air cleaner and service it, if necessary, as outlined in Section 3.1.

5. If freezing weather is expected during the storage period, add a high boiling point type antifreeze solution in accordance with the manufacturer's recommendations.

6. Clean the entire exterior of the engine (except the electrical system) with fuel oil and dry it with air.

7. Seal all of the engine openings. The material used for this purpose must be waterproof, vaporproof and possess sufficient physical strength to resist puncture and damage from the expansion of entrapped air.

An engine prepared in this manner can he returned to service in a short time by removing the seals at the engine openings, checking the engine coolant, fuel oil, lubricating oils

EXTENDED STORAGE (30 days or more)

When an engine is to be removed from operation for an extended period of time, prepare it as follows:

1. Drain and thoroughly flush the cooling system with clean, soft water.

2. Refill the cooling system with clean, soft water.

3. Add a rust inhibitor to the cooling system (refer to Corrosion Inhibitors in Section 13.3).

4. Remove, check and recondition the injectors, if necessary, to make sure they will be ready to operate when the engine is restored to service.

5. Reinstall the injectors in the engine, time them, and adjust the valve clearance.

6. Circulate the coolant through the entire system by operating the engine until normal operating temperature is reached (160'F. to 185°F).

7. Stop the engine.

8. Remove the drain plug and completely drain the engine crankcase. Reinstall and tighten the drain plug.

Install new lubricating oil filter elements and gaskets.

9. Fill the crankcase to the proper levl with a 30weight preservative lubricating oil Mll,-L-21260, Grade 2 (PI0), or equivalent.

10. Drain the engine fuel tank.

© 1970 General Motors Corp

11. Refill the fuel tank with enough rust preventive fuel oil such as American Oil Diesel Run-In Fuel (LF4089), Mobil 4Y17, or equivalent, to enable the engine to operate 10 minutes.

12. Drain the fuel filter and strainer. Remove the retaining bolts, shells and elements. Discard the used elements and gaskets. Wash the shells in clean fuel oil and insert new elements. Fill the cavity between the element and shell about two-thirds full of the same rust preventive compound as used in the fuel tank and reinstall the shell.

13. Operate the engine for 5 minutes to circulate the rust preventive throughout the engine.

14. Refer to Section 3.1 and service the air cleaner.

© 1970 General Motors Corp

15. Apply a non-friction rust preventive compound to all exposed parts. If it is convenient, apply the rust preventive compound to the engine flywheel. If not, disengage the clutch mechanism to prevent the clutch disc from sticking to the flywheel.

CAUTION

Do not apply oil, grease or any wax base compound to the flywheel. The cast iron will absorb these substances which can "sweat" out during operation and cause the clutch to slip.

16. Drain the engine cooling system.

17. The oil may be drained from the engine crankcase if so desired. If the oil is drained, reinstall and tighten the drain plug.

18. Remove and clean the battery and battery cables with a baking soda solution and rinse them with fresh water. Do not allow the soda solution to enter the battery. Add distilled water to the electrolyte, if necessary, and fully charge the battery. Store the battery in a cool (never below 32'F.) dry place. Keep Storage 15.3 the battery fully charged and check the level and the specific gravity of the electrolyte regularly.

19. Insert heavy paper strips between the pulleys and belts to prevent sticking.

20. Seal all of the openings in the engine, including the exhaust outlet, with moisture resistant tape. Use cardboard, plywood or metal covers where practical.

21. Clean and dry the exterior painted surfaces of the engine. Spray the surfaces with a suitable liquid automobile body wax, a synthetic resin varnish or a rust preventive compound.

22. Cover the engine with a good weather-resistant tarpaulin or other cover if it must be stored outdoors. A clear plastic cover is recommended for indoor storage.

The stored engine should be inspected periodically. If there are any indications of rust or corrosion, corrective steps must be taken to prevent damage to the engine parts. Perform a complete inspection at the end of one year and apply additional treatment as required.

PROCEDURE FOR RESTORING AN ENGINE TO SERVICE WHICH HAS BEEN IN EXTENDED STORAGE

1. Remove the valve rocker cover(s) and pour at least one-half gallon of oil, of the same grade as used in the crankcase, over the rocker arms and push rods.

2. Reinstall the valve rocker cover(s).

3. Remove the covers and tape from all of the openings of the engine, fuel tank, and electrical equipment. Do not overlook the exhaust outlet.

4. Wash the exterior of the engine with fuel oil to remove the rust preventive.

5. Remove the rust preventive from the flywheel.

6. Remove the paper strips from between the pulleys and the belts.

7. Check the crankcase oil level. Fill the crankcase to the proper level with the heavy-duty lubricating oil recommended under Lubricating Oil Specifications (Section 13.3).

8. Fill the fuel tank with the fuel specified under Diesel Fuel Oil Specifications (Section 13.3).

9. Close all of the drain cocks and fill the engine cooling system with clean soft water and a rust inhibitor. If the engine is to be exposed to freezing temperatures, fill the cooling system with a high boiling point type antifreeze solution (refer to Section 13.3).

10. Install and connect the battery.

11. Service the air cleaner as outlined in Section 3.1.

© 1970 General Motors Corp.

ALPHABETICAL INDEX

Subject	Section
A	
Accessory drives	1.7.7
Air box drains	1.1.2
Air cleaner	3.1
Air compressor	12.4
Air intake system	3
Air shutdown housing	3.3
B	
Balance weights--front	1.7
Battery-charging generator	7.1
Battery-charging generator regulator	7.1.1
Bearings:	
Camshaft	1.7.2
Connecting rod	1.6.2
Connecting rod (clearance)	1.0
Crankshaft main	1.3.4
Crankshaft main (clearance)	1.0
Idler gear--engine	1.7.4
Belt adjustment--fan	15.1
Block--cylinder	I. I
Blower (6V)	3.4
Blower drive gear	1.7.6
Blower drive shaft	1.7.6
Blower end plates	3.0
Bluing injector components	2.0
Breather--crankcase	4.8
C	
Cam followers	1.2.1
Camshaft	1.7.2
Camshaft gears	1.7.3
Charts:	
Engine operating conditions	13.2
D	
Description--general	*
Diesel principle	*
Dipstick--oil level	4.6
Drains--air box	1.1.2
Dynamometer test	13.2.1
E	
Electrical system	7
End plate--cylinder block	1.1.1
End plate--blower	3.0
Engine:	
Balance	1.7
F	
Fan--engine cooling	5.4
Fan belt adjustment	15.1
Filter--fuel	2.3
Filter--lubricating oil	4.2
Firing order	*
Flywheel	1.4
Flywheel housing	1.5
Front balance weights	1.7
Fuel flow--checking	15.2
Fuel injector (needle valve)	1
Fuel injector tube	2.1.4
Fuel oil specifications	13.3
Fuel pump	2.2
Fuel pump drive	2.2.1
Fuel system	2
G	
Gear--blower drive	1.7.6
Gear--camshaft	1.7.3
Gear--crankshaft timing	1.7.5
Gear--engine idler	1.7.4
Gear--flywheel ring	1.4

* General Information Section

© 1972 General Motor Corp.

Subject	Section
H	
Head--cylinder	1.2
Housing--air shutdown	3.3
Housing--flywheel	1.5
I	
Idler gear--engine	1.7.4
Idler pulley--water pump	5.1.1
Injector--fuel (needle valve)	2.1.1
Bluing	2.0
Calibrator and Comparator	2.0
Operating mechanism	1.2.1
Spray tip	2.0
Test fixture (checking)	2.0
Timing	14.2
Timing (checking)	2.0
Trouble shooting	2.0
Tube	2.1.4
Inspection--magnetic particle method	1.3
L	
Lapping blocks--refinishing	2.0
Liner--cylinder	1.6.3
Lubricating oil cooler	4.4
Lubricating oil filters	4.2
Lubricating oil pressure regulator	4.1.1
M	
Magnetic particle inspection method	1.3
Main bearings	1.3.4
Maintenance--preventive	15.1
Manifold--air cooled exhaust	6.1
Manometer (use of)	15.2
Mechanical governor	2
Misfiring cylinder	15.2
Model description chart	*
Model number--engine	*
Motor--starting (electrical)	7.3
O	
Oil cooler--engine	4.4
Oil level dipstick	4.6
Oil pan	4.7
Oil pan	4.0
Oil pressure regulator	4.1.1
Oil pump driving gear	4.1
Oil seals--crankshaft	1.3.2
Oil specifications--fuel	1 2 '
Oil specifications--lubricating	13.3
Operating conditions	13.2
Operating instructions--engine	13.1
Operation--principles of	*
Option plate	*
P	
Pan--oil	4.7
Pan--oil	4.0
R	
Regulator--battery-charging generator	7.1.1
Regulator--oil pressure	4.1.1
Restoring engine to service	15.3
Rings--piston	1.6
Rocker arms	1.2.1
Rocker cover	1.2.4
Rod--connecting	1.6.1
Rod--push	1.2.1
Rotation--engine	*
Run-in instructions	13.2.1

*General Information Section

© 1972 General Motors Corp.

Subject	Section
S	
Seals--crankshaft oil	1.3.2
Serial number location:	
Engine	*
Shut-down housing	3.3
T	
Test--dynamometer	..
Test--report	13.2.1
Thermostat	5.2.1
throttle delay cylinder	14.14
Thrust washers--crankshaft	1.3.4
Timing--blower rotor	3.4
Timing--engine	1.7.1
Timing--injector	14.2
Timing--injector (checking)	2.0
Timing gear--crankshaft	1.7.5
V	
Valve--exhaust:	1.2.2
Clearance adjustment	14.1
Guide and insert	1.2.2
Operating mechanism	1.2.1
Trouble shooting	1.0
Ventilating system	4.8
Voltage regulator	7.1.1
W	
Washers--crankshaft thrust	1.3.4
Water pump--engine	5.1
Water pump idler pulley	5.1.1
Weights--front balance	1.7

* General Information Section

© 1972 General Motors Corp.

PART THREE

ENGINE PARTS CATALOG

PARTS CATALOG

for
DETROIT DIESEL (FSCM 24617)
6V-53 SERIES ENGINE ·

HARNISCHFEGER CORPORATION (FSCM 27315)
PART NUMBER 51Q282

DCSC CONTRACT NUMBER DSA 700-73-C-9003

This parts catalog was prepared by Harnischfeger Corporation from copyrighted information with permission of Detroit Diesel, Allison Division, General Motors Corporation.

* Includes optional equipment per Harnischfeger Corporation specifications.

Harnischfeger
P&H
milwaukee, wisconsin. 53201

2/75 - 11159

Printed in U.S.A.

TABLE OF CONTENTS

SECTION 1.0000 ENGINE (less major assemblies)

1.1000 CYLINDER BLOCK....1-11
1.1000A AIR BOX DRAINS....1-12
1.2000 CYLINDER HEAD....1-13
1.2000A ENGINE LIFTER BRACKET....1-14
1.3000 CRANKSHAFT....1-15
1.3000A CRANKSHAFT FRONT COVER....1-17
1.3000C CRANKSHAFT PULLEY....1-17
1.3000D CRANKSHAFT PULLEY BELT....1-18
1.4000A FLYWHEEL....1-18
1.5000A FLYWHEEL HOUSING....1-18
1.6000 CONNECTING ROD AND PISTON....1-20
1.7000 CAMSHAFT AND GEAR TRAIN....1-22
1.7000B ACCESSORY DRIVE....1-24
1.8000 VALVE OPERATING MECHANISM....1-25
1.8000A ROCKER COVER....1-28

SECTION 2.0000 FUEL SYSTEM

2.1000A FUEL INJECTOR....2-8
2.2000 FUEL PUMP....2-11
2.3000A FUEL FILTER....2-14
2.4000 FUEL MANIFOLD AND/OR CONNECTIONS....2-15
2.5000A FUEL LINES....2-16
2.7000A MECHANICAL GOVERNOR....2-17
2.9000 INJECTOR CONTROLS....2-24
2.9000A THROTTLE CONTROLS....2-26

SECTION 3.0000 AIR SYSTEM

3.3000A AIR INLET HOUSING....3-4
3.4000 BLOWER....3-6
3.4000A BLOWER DRIVE SHAFT....3-10

SECTION 4.0000 LUBRICATING SYSTEM

4.1000A OIL PUMP....4-7
4.1000B OIL DISTRIBUTION SYSTEM....4-7
4.1000C OIL PRESSURE REGULATOR....4-8
4.2000A OIL FILTER....4-9
4.4000A OIL COOLER....4-11
4.5000A OIL FILLER....4-11
4.7000A OIL PAN....4-12
4.8000A VENTILATING SYSTEM....4-12

SECTION 5.0000 COOLING SYSTEM

5.1000 FRESH WATER PUMP....5-4
5.2000A WATER OUTLET MANIFOLD AND/OR ELBOW....5-6
5.2000B THERMOSTAT....5-6
5.2000C WATER BY-PASS TUBE....5-7
5.3000B WATER CONNECTIONS....5-7
5.4000A FAN....5-8

SECTION 6.0000 EXHAUST MANIFOLD

6.1000A EXHAUST MANIFOLD....6-2
6.2000A EXHAUST MUFFLER AND/OR CONNECTIONS....6-2

SECTION 7.0000 ELECTRICAL SYSTEM

7.1000A BATTERY CHARGING GENERATOR....7-4
7.3000A STARTING MOTOR....7-7

SECTIONS 8.0000 THRU 10.0000 - NOT APPLICABLE

SECTION 11.0000 ENGINE MOUNTING

11.1000A ENGINE MOUNTING AND BASE....11-1

SECTION 12.0000 MISCELLANEOUS

12.4000A AIR COMPRESSOR....12-3



FIG. 1C 6V-53 CYLINDER BLOCK (Rear View)

Fig. 1C of 1.0000



FIG. 2A CYLINDER HEAD



FIG. 2B ENGINE LIFTER BRACKET

Figs. 2A & 2B of 1.0000



FIG. 3A CRANKSHAFT

Figure 3A of 1.0000



6V-53 Models
FIG. 4B



FIG. 4D LOWER FRONT COVER AND OIL PUMP



FIG. 4E CRANKSHAFT PULLEY

Fig. 4B, 4D & 4E of 1.0000



FIG. 5A FLYWHEEL AND FLYWHEEL HOUSING



FIG. 6A CONNECTING ROD, PISTON AND LINER

Figs. 5A & 6A of 1.0000



FIG. 7B CAMSHAFT (V-53)



FIG. 7D GEAR TRAIN (6V-53)



FIG. 7F IDLER GEAR

Fig. 7B, 7D & 7F of 1.0000



FIG. 8A ACCESSORY DRIVE (Two Belt)

Fig. 8A of 1.0000



FIG. 9A
VALVE MECHANISM



FIG. 9C
VALVE & ROCKER BRIDGE

Fig. 9A & 9C of 1,0000





TYPICAL 6 CYLINDER VEHICLE UNIT

Fig. 9D of 1.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.1000 CYLINDER BLOCK (Type 31)	
		1.1001 - BLOCK, Cylinder	
		For components of service cylinder block assemblies refer to Assembly Breakdown listed below.	
1C	5196821	Block Assy	1
		The following items are assembled to the cylinder block:	
-	5132479	Cap, main bearing (unfinished)(1.3110)	4
-	5197944	Bearing Set, camshaft (1.7010)	1
-	141346	Pin, 3/16" x 1/2" dowel (12.9290).	4
-	141212	Pin, 5/16" x 5/16" dowel (12.9290)	4
-	5141263	Pin, 5/16" x 5/16" dowel (12.9290)	2
-	114981	Draincock, 1/8" brass (12.9510).	2
-	5145009	Plug, 1/8" pipe (12.9550)	4
-	5150130	Plug, 5/16" cup	1
-	5115214	Plug, 1/2" pipe (12.9550)	1
-	5109157	Plug, 1 1/4" cup (5.5001) .	2
-	5196965	Spacer, main bearing bolt shipping	8
-	5141701	Bolt, main bearing cap (1.3140)	8
-	5133981	Washer, special (1.1001)	8
		The following items are "shipped loose" with the cylinder block:	
-	141245	Pin, 3/8" x 1 1/8" dowel (12.9290)	4
-	114981	Draincock, 1w" (12.9510)	1
-	5145010	Plug, 1/4" pipe (12.9550)	1
-	5115214	Plug, 1/2" pipe (12.9550)	3
-	5119218	Plug, 7/8" cup (5.1030)	1
-	134519	Draincock, 1/8" (12.9510)	2
		1.1002 - GASKET KIT, Engine Overhaul	
		Consists of necessary gaskets for one complete engine overhaul.	
-	5199793	Gasket Kit	*

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.1020 - PLATE, Cylinder Block End	
1C	5126194	Plate Assy	1
-	5121459	Nut, plug (3/8"-24)	2
-	179839	Bolt, 3/8"-16x1" (12.9001)	12
-	186725	Bolt, 1/2"-13xl 1/2" (12.9001)	2
-	5188274	Washer (6.1020)	2
-	103321	Lockwasher, 3/8" (12.9200)	12
		1.1030 - GASKET, Cylinder Block End Plate	
1C	5133397	Gasket	1
		1.1040 - COVER, Air Box	
1C	5183184	Cover.	4
1C	5130590	Clamp	4
	105451	Gasket, 3/8" copper (12.9360).	4
1C	186627	Bolt, 3/8"-24x1" (12.9001).	4
-	103341	Washer, 3/8" flat (12.9190)	4
		1.1050 - GASKET, Air Box Cover	
1C	5185416	Gasket	4
		1.1060 - COVER, Cylinder Block Water Hole	
1C	5108759	Cover (1/8" tapped hole)	1
	118536	Draincock, 3/8" (12.9510)	1
-	186618	Bolt, 5/16"-18x5/8" (12.9001)	2
1C	186625	Bolt, 5/16"-18x7/8" (12.9001)	2
	103320	Lockwasher, 5/16" (12.9200)	2
		1.1000A AIR BOX DRAINS (Type 62)	
		1.1100 - TUBE, Air Box Drain	
-	5132287	Tube Assy. (dev. L. 9.74")	2
	125859	Elbow, 1/4" fl. tube 451 (12.9390)	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
`		1.2000 CYLINDER HEAD(Type 26)	
		1.2001 - HEAD ASSY., Cylinder	
		A cylinder head assy. includes items in 1.2001, 1.2005 (4 valve), 1.2045, 1.8320, 1.8330, 1.8360 (4 valve), 2.7830 and 2.8945.	
2A	5198203	Head Assy. (4 valve)	2
2A	5145009	Plug, 1/8" pipe (12.9550)	4
2A	5125237	Plug, 1/4" pipe (12.9550).	12
2A	5121182	Plug, 1/4*' pipe hex. soc. hd. (12.9550)	4
2A	5154453	Plug, 3/8"-16 sl. hdls	8
2A	5151449	Plug, 13/16" cup (1.1001).	6
	5198655	Plug, fuse	1
		1.2002 - GASKET KIT, Cylinder Head Overhaul	
		Consists of all gaskets necessary to replace one cylinder head.	
	5199811	Gasket Kit, cylinder head.	*
		1.2005 - NOZZLE, Cylinder Head Water	
	5119293	Nozzle .	8
		1.2010 - GASKET, Cylinder Head Compression	
1C	5121254	Gasket	6
		1.2020 - GASKET SET, Cylinder Head Oil	
1C	5116292	Ring, seal	2
1C	5116290	Ring, seal (end water hole) .	8
1C	5121207	Ring, seal (center water hole)	8
1C	5116122	Ring, seal (oil hole)	4
		1.2030 - BOLT, Cylinder Head	
2A	5121263	Bolt, 5/8"-11x6 1/4" (12 pt. hd.). .	16

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.2043 - COVER, Cylinder Head Water Hole	
2A	5136610	Cover (plain) (use with 3/8"-16x1" bolt)	2
-	5123168	Cover (1/8" pipe tap, centered)	2
-	5127837	Cover (1/8" pipe tap, off center)	2
-	5129019	Cover (1/4" pipe tap)	2
-	5123352	Cover (3/8" pipe tap)	2
-	5131053	Cover (1/2" pipe tap)	2
-	5109707	Cover (1/2" pipe tap)	2
-	5145009	Plug, 1/8" pipe sq. hd. (12.9550)	2
-	5145010	Plug, 1/.4" pipe hex. soc. hd. (12.9550)	2
-	5145011	Plug, 3/8" pipe sq. hd. (12.9550)	2
-	5145012	Plug, 1/2" pipe sq. hd. (12.9550)	2
2A	179838	Bolt, 3/8"-16x7/8" (12.9001)	4
-	179839	Bolt, 3/8"-16x1" (12.9001)	4
2A	103321	Lockwasher, 3/8" (12.9200)	4
		1.2044 - GASKET, Cylinder Head Water Hole Cover	
2A	5116242	Gasket	2
		1.2045 - TUBE, Injector Hole	
2A	5199527	Tube Kit (includes seal ring in 1.2046) (2.1290)	6
		1.2046 - RING, Injector Hole Tube Seal	
2A	5160037	Ring (2.1300).	6
		1.2000A ENGINE LIFTER BRACKET (Type 44)	
		1.2070 - BRACKET, Engine Lifter - Front	
2B	5125488	Bracket (left bank)(item 3).	1
2B	5127949	Bracket (right bank)(item 2)	1
-	179839	Bolt, 3/8"-16x1" (12.9001)	4
	103321	Lockwasher, 3/8" (12.9200)	*

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.3000 CRANKSHAFT (Type 30)	
		1.3001 - CRANKSHAFT ASSY.	
		A crankshaft assy. includes plug and dowel in 1.3001. When replacing a crankshaft assy. include a 5144375 oil pump drive gear in 4.1310.	
3A	5144617	Crankshaft Assy. (splined)	1
3A	5145009	Plug, 1/8" pipe (12.9550).	3
		1.3040 - SEAL, Crankshaft Oil- Front	
-	5198503	Seal (single lip O.S., use with 5198502 sleeve)	1
3A, 4B	5116224	Seal	1
		1.3055 - SPACER, Crankshaft Front Oil Seal	
	5198502	Spacer (sleeve) (use with 5198503 seal) (1.3056)	1
		1.3060 - SEAL, Crankshaft Oil - Rear	
3A, 5A	5116229	Seal (single lip, standard)	1
		1.3066 - SLEEVE, Crankshaft Rear Oil Seal	
-	5196851	Sleeve (with O.S. oil seal) .	*
		1.3090 - SHELL, Crankshaft Main Bearing	
3A	5137595	Shell, upper (standard)	4
3A	5116401	Shell, lower (standard)	4
3A	5198415	Shell, upper (.002" U.S.)	*
3A	5196669	Shell, lower (.002" U.S.)	*
3A	5198416	Shell, upper (.010" U.S.)	*
3A	5196671	Shell, lower (.010" U.S.)	*
3A	5198417	Shell, upper (.020" U.S.)	*
3A	5196673	Shell, lower (.020" U.S.)	*
3A	5198418	Shell, upper (.030" U.S.)	*
3A	5196675	Shell, lower (.030" U.S.)	*
-	5198410	Shell Set (standard)	*

*As required

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.3090 - SHELL, Crankshaft Main Bearing (Cont'd	
-	5198411	Shell Set (.002" U.S.)	*
-	5198412	Shell Set (.010" U.S.) .*	*
-	5198413	Shell Set (.020" U.S.)	*
-	5918414	Shell Set (.030" U.S.)	*
		1.3100 - WASHER, Crankshaft Main Bearing Thrust	
3A	5159353	Washer (standard)	4
3A	5160542	Washer (.005" O.S.)	*
3A	5192111	Washer (.010" O.S.)	*
3A	141346	Pin, 3/16" x 1/2" dowel (12.9290)	4
		1.3110 - CAP, Crankshaft Main Bearing	
1C	5195936Δ	Cap	4
1C	5199506	Cap (malleable iron).	4
-	5135258	Cap (intermediate) (un-finished)	*
-	5132479	Cap (intermediate) (un-finished)	*
		1.3112 - STABILIZER, Crankshaft Main Bearing Cap	
-	5132695	Stabilizer (front on 8V)	4
-	9414523	Bolt, 7/16"-14x1" (12.9001)	8
-	5125608	Washer, 7/16" flat	8
		1.3140 - BOLT, Crankshaft Main Bearing Cap	
-	5141701	Bolt	8
1C	5125945+	Bolt	8
-	5133981	Washer (1.1001)	8
		1.3145 - GEAR, Crankshaft Timing	
3A	5116195	Gear	1
-	127559	Key, 1/4" x 3/4" woodruff (12.9350)	1

* As required. Δ Not serviced, replace with 5199506 cap and include 2-179837 bolt, 2-5138619 washer and 2-103321 lockwasher in 4.1510. + Not serviced, for replacement use 5141701 bolt and 5133981 washer.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.3000A CRANKSHAFT FRONT COVER (Type 66)	
		1.3161 - COVER, Engine Front - Upper	
		An upper cover assy. includes pins, plugs and nipple in 1.3161.	
4B	5128026	Cover Assy.	1
-	5157933	Dowel, 5/16" x 7/8"	2
-	186612	Bolt, 3/8"-16xl 3/8" (12.9001)	6
-	454906	Bolt, 3/8"-16xl 1/2" (12.9001).	5
-	179848	Bolt, 3/8"-16x2 1/4" (12.9001)	12
-	103321	Lockwasher, 3/8" (12.9200)	23
		1.3162 - COVER, Engine Front - Lower	
		A lower cover assy. includes items in 4.1690 thru 4.1720.	
4D	5136274	Cover Assy	1
-	5145014	Plug, 3/8" pipe hex. soc. hd. (12.9550)	*
-	5115214	Plug, 1/2" pipe (12.9550)	*
-	186612	Bolt, 3/8"-16xl 3/8" (12.9001).	4
-	457588	Bolt, 3/8"-16x2 1/2" (12.9001.	4
-	186283	Bolt, 3/8"-16x3 1/2" (12.9001).)	2
-	455537	Bolt, 3/8"-16x4" (12.9001)	2
-	103321	Lockwasher, 3/8" (12.9200)	12
		1.3170 - GASKET, Engine Front Cover	
4B	5124055	Gasket (upper)	1
4D	5119368	Gasket (lower)	1
		1.3000C CRANKSHAFT PULLEY (Type 316)	
		1.3280 - PULLEY, Crankshaft	
		A pulley assy. includes insulator in 1.3311.	
4E	5142222	Pulley (5.38" dia., 2 grooves) (splined)	1

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.3290 - RETAINER, Crankshaft Pulley	
-	5170513	Retainer (flange)	2
-	223761	Bolt, 3/4"-16x4 1/2" (12.9001).	1
		1.3000D CRANKSHAFT PULLEY BELT (Type 187)	
		1.3320 - BELT, Crankshaft Pulley	
		Sizes given are effective length at width shown. All belts are standard unless otherwise indicated by "P" (premium).	
-	5134212	Belt Set (2 belts) (48" L., 500"W.) (P)	1
		1.4000A FLYWHEEL (Type 609)	
		1.4001 - FLYWHEEL Includes gear in 1.4010.	
5A	5136542	Flywheel Assy. (SAE No. 2)	1
5A	5126671	Plate, scuff (bearing retainer)	1
5A	9409512	Bolt, 1/2"-20x2" lock.	6
		1.4010 - GEAR, Flywheel Ring	
5A	5116302	Gear (138 teeth, non-chamfer)	1
		1,5000A FLYWHE EL HOUSING (Type 340)	
		1.5001 - HOUSING, Flywheel	
5A	5132282	Housing (SAE No. 2)	1
-	141195	Pin, 1/4" x 5/8" dowel (12.9290)	1
5A	5145012	Plug, 1/2" pipe (12.9550).	1
-	5146646	Plug, 1 1/4" pipe (12.9550)	1
-	9409126	Bolt, 5/16"-18x2 1/2" (12.9001)	2
-	9414215	Bolt, 3/8"-16x2 1/2" (12.9001)	4
-	427588	Bolt, 3/8"-16x2 1/2" (12.9001)	6

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.5001- HOUSING, Flywheel (Cont'd)	
-	179850	Bolt, 3/8"-16x2 3/4" (12.9001)	2
-	191249	Bolt, 3/8"-16x3 3/4" (12.9001)	6
-	186309	Bolt, 3/8"-24x3 1/4" (12.9001)	2
-	186310	Bolt, 3/8"-24x3 1/2" (12.9001)	2
5A	103321	Lockwasher, 3/8" (12.9200) .	*
-	117049	Nut, 3/8"-24 hex. (12.9120)	2
		1.5002- SHIM, Flywheel Housing to End Plate	
-	5123802	Shim (2.38" dia. x .015" thick) .	1
		1.5010 - GASKET, Flywheel Housing	
-	5152904	Gasket (7/8" dia.) (4.4115)	1
5A	5137470	Gasket	1
		1.5030 - COVER, Flywheel Housing Large Hole	
5A	5122281	Cover (plain)	2
5A	179857	Bolt, 7/16"-14x7/8" (12.9001)	2
5A	122408	Bolt, 1/2"-13x1" (12.9001)	8
5A	5150568	Washer, 7/16" copper (12.4050)	*
5A	103323	Lockwasher, 1/2" (12.9200)	8
		1.5040 - GASKET, Flywheel Housing Large Hole Cover	
5A	5117061	Gasket	2
		1.5050 - COVER, Flywheel Housing Small Hole	
5A	5152716	Cover .	*
-	5130992**	Plug, cup	*
5A	186625	Bolt, 5/16"-18x7/8" (12.9001)	4
5A	103320	Lockwasher, 5/16" (12.9200) .	*
		1.5060 - GASKET, Flywheel Housing Small Hole Cover	
5A	5150193	Gasket (5.1010)	*

* As required. ** Not serviced, replace with 1-5152716 cover, 3-186625 bolts, 3-103320 lockwashers and 1-5150193 gasket.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.5075 - GASKET, Starting Motor Hole	
5A	5130995	Gasket	*
		1.6000 CONNECTING ROD AND PISTON (Type 96)	
		1.6001 - CONNECTING ROD ASSY.	
		A rod assy. includes cap which is not sold separately, plus items in 1.6001, 1.6010 and 1.6040.	
6A	5133109	Rod Assy	6
6A	5197852	Bolt (3/8"-24x2.76" L.)	12
6A	839103	Nut (3/8"-24 hex.)	12
		1.6010 - NOZZLE, Connecting Rod Spray	
6A	5150140	Nozzle	6
		1.6040 - BUSHING, Connecting Rod Piston Pin	
6A	5116181	Bushing	12
		1.6100 - SHELL, Connecting Rod Bearing	
		A shell set consists of one upper and one lower shell.	
6A	5133101	Shell, upper (standard)	6
6A	5133098	Shell, lower (standard)	6
6A	5197963	Shell, upper (.002" U.S.)	*
6A	5197964	Shell, lower (.002" U.S.)	*
6A	5197965	Shell, upper (.010" U.S.)	*
6A	5197966	Shell, lower (.010" U.S.)	*
6A	5197967	Shell, upper (.020" U.S.)	*
6A	5197968	Shell, lower (.020" U.S.)	*
6A	5197969	Shell, upper (.030" U.S.)	*
6A	5197970	Shell, lower (.030" U.S.)	*
-	5197975	Shell Set (standard)	*
-	5197976	Shell Set (.002" U.S.)	*
-	5197977	Shell Set (.010" U.S.)	*
-	5197978	Shell Set (.020" U.S.)	*
-	5197979	Shell Set (.030" U.S.)	*

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.6110 - PISTON ASSY. A piston assy. includes bushing in 1.61 45 and retainer on 1.6150.	
6A	5198877	Piston Assy. ("N" engine).	6
		1.6115 - RING SET, Piston A piston ring set consists of sufficient rings for one (1) cylinder.	
-	5198822	Ring Set .	*
		1.6120 - RING, Piston Compression	
6A	5140340	Ring (fire ring, chrome)	6
6A	5116184	Ring (chromed) (2nd, 3rd & 4th)	18
		1.6130 - RING, Piston Oil Control An oil control ring consists of two (2) scrapers and one (1) expander.	
6A	5195933	Ring	12
		1.6140 - PIN, Piston	
6A	5116189	Pin	6
		1.6145 - BUSHING, Piston Pin	
6A	5116181	Bushing (1.6040).	12
		1.6150 - RETAINER, Piston Pin	
6A	5180250	Retainer.	12
		1.6180 - LINER, Cylinder	
6A	5132803	Liner (standard)	6

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.6182 - CYLINDER KIT A cylinder kit consists of items in 1.6110, 1.6115, 1.6140, 1.6180 and 1.6190 for one (1) cyl.	
-	5198899	Cylinder Kit ("N" engines).....	*
		1.6190 - SEAL, Cylinder Liner	
6A	5121256	Seal.....	6
		1.7000 CAMSHAFT AND GEAR TRAIN (Type 35)	
		1.7001 - CAMSHAFT ASSY. A camshaft assy. includes plug in 1.7001.	
7B	5199397‡	Camshaft Assy. (R. bank R.H eng., L bank L.H. eng,) (stamped V7L).....	1
7B	5199396‡	Camshaft Assy (L bank R.H. eng., R bank L.H engg (stamped V7L).....	1
-	5151277	Plug (1/2" drive).....	4
		1.7010 - BEARING, Cam and Balancer Shaft A set includes all end and intermediate bearings which are not sold separately.	
7B	5197944	Bearing Set (std. I.D., std.O.D.)	1
7B	5198983	Bearing Set (std. I.D., .010" O.S., O.D.).....	*
7B	5197945	Bearing Set (.010" U.S. I.D., std. O.D.)	*
7B	5197946	Bearing Set (.010" U.S. I.D., std. O.D.)	*
		1.7030 - WASHER, Cam and Balancer Shaft End Bearing Thrust	
7B	5116198	Washer	2
7B	9409028	Bolt, 3/8"-16x1" (12.9001).....	4
		1.7060 - SEAL, Cam and Balancer Oil	
-	5116476	Seal, oil (front).....	2

* As required.≠Use with 5147424 spring.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.7061 - SLINGER, Cam and Balancer Shaft Oil	
7B	5134388	Slinger	2
		1.7062 - SPACER, Cam and Balancer Shaft Pulley	
7B	5121071	Spacer	2
		1.7130 - PULLEY, Front Balance	
7B	5121109	Pulley	2
7B	218217	Key, 3/16" x 5/8" woodruff (12.9350)	2
7B	5150087	Nut (1.7140)	2
		1.7200 - GEAR, Camshaft and Balancer Shaft	
7B	5133387	Gear (R. H. helix)(R. bank camshaft R. H. eng., L. bank camshaft L. H. eng.).	1
7B	5133388	Gear (L. H. helix)(L. bank camshaft R. H. eng., R. bank camshaft L. H. eng.)	1
7B	218217	Key, 3/16" x 5/8" woodruff (12.9350)	2
7B	5150087	Nut (1.7140)	2
		1.7202 - SPACER, Camshaft Gear	
7B	5121077	Spacer	2
		1.7207 - RETAINER, Cam and Balancer Shaft Gear Nut	
7B	5172734	Retainer	2
7B	181360	Bolt, 3/8"-24x3/4" (12.9001)	4
7B	103321	Lockwasher, 3/8" (12.9200	4
		1.7220 - GEAR ASSY., Idler Includes bearing in 1.7225. An 8V-53 gear assy. also includes items in 1.7222, 1.7227 and 1.7250.	
7D	5135227	Gear Assy. (L.H. helix)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.7225 - BEARING, Idler Gear	
-	5196793	Bearing	1
7D	5132504	Washer	2
		1.7250 - HUB, Idler Gear	
7D	5124458	Hub.	1
7D	5157244	Bolt (4.4190)	1
		1.7260 - SPACER, Idler Gear Hole	
-	5116220**	Spacer	1
-	5157244**	Bolt (4.4190)	1
		1.7000B ACCESSORY DRIVE (Type 266)	
		1.7622 - ADAPTOR, Accessory Drive	
-	5139376	Adapter, hyd. pump (12.5020)	1
-	179858	Bolt, 7/16"-14x1" (12.9001)	1
-	454990	Bolt, 1/2"-13xl 1/8" (12.9001)	4
		1.7623 - GASKET, Accessory Drive Adapter	
-	5117061	Gasket, adapter to f/w hsg. (12.5021)	1
-	5188755	Gasket, pump to adapter (12.5005)	1
		1.7630 - PLATE, Accessory Drive	
8A	5170450	Plate	1
-	5145092	Bolt, 3/8"-24x1.20" (12.9001)	4
		1.7635 - COUPLING, Accessory Drive	
-	5143616	Coupling	1
		1.7670 - GEAR, Accessory Drive	
-	5137473	Gear (hydraulic pump) (12.5030)	1
-	455921	Pin, 1/8" x 1 1/2" spring (12.5030)	1

** Not required in any type with flywheel housing having integral idler gear hole spacer.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.8000 VALVE OPERATING MECHANISM (Type 33)	
		1.8060 - ARM ASSY., Exhaust Valve Rocker Includes items in 1.8130, 1.8140, 1.8150 and 1.8343.	
-	5135268	Arm Assy. (right) (4 valve)	6
-	5135267	Arm Assy. (left) (4 valve)	6
		1.8080 - ARM ASSY., Injector Rocker Includes items in 1.8110 thru 1.8150.	
9A	5179954	Arm Assy	6
		1.8110 - BUSHING, Injector Rocker Arm - Large	
9A	5150318	Bushing	6
		1.8120 - BUSHING, Injector Rocker Arm - Small	
9A	5150311	Bushing	6
		1.8130 - CLEVIS, Injector & Exhaust Valve Rocker Arm	
9A	5150312	Clevis	18
		1.8140 - BUSHING, Injector & Exhaust Valve Rocker Arm Clevis	
9A,C	5123700	Bushing	30
		1.8150 - PIN, Injector & Exhaust Valve Rocker Arm Clevis	
9A	5150314	Pin (clevis end)	18
9A, C	5123711	Pin (bridge end)	12

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.8160 - SHAFT, Rocker A shaft assy. includes plug in 1.8160	
9A	5116072	Shaft Assy	6
-	5151272	Plug, 11/32" dia. x 1/4" special	6
		1.8170 - BRACKET, Rocker Shaft	
9A	5116128	Bracket	12
9A	5119198	Bolt	12
		1.8180 - ROD, Push	
9A	5128640	Rod	18
9A	5151601	Locknut	18
		1.8190 - SPRING, Push Rod	
9A	5108918	Spring (2 orange stripes) (valve and injector)	18
		1.8200 - SEAT, Push Rod Spring - Upper	
9A	5108919	Seat (valve and injector)	18
		1.8210 - SEAT, Push Rod Spring - Lower	
9A	5123250	Seat	18
		1.8250 - RETAINER, Push Rod	
9A	5150303	Retainer (snap ring)	18
		1.8260 - FOLLOWER ASSY., Cam	
9A	5115087	Follower Assy.	18

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.8265 - ROLLER SET, Cam Follower Includes roller with bushing and pin.	
-	5195220	Roller Set (standard).....	18
		1.8300 - GUIDE, Cam Follower	
9A	5116125	Guide	6
9A	443603	Bolt, 1/4"-20x3/4" (12.9001)	12
9A	103319	Lockwasher, 1/4" (12.9200)	12
		1.8310- VALVE, Exhaust	
9C	5199323	Valve (includes locks).....	24
		1.8320 - GUIDE, Exhaust Valve A valve guide kit includes 1-5131961 guide and 1-5131973 seal.	
9C	5131961	Guide.	24
-	5198529	Kit, valve guide and seal	24
-	5131973	Seal	24
		1.8330 - INSERT, Exhaust Valve	
9C	5116361	Insert (standard).....	24
9C	5196752	Insert (.010" oversize on O.D.).....	*
		1.8340 - SPRING, Exhaust Valve	
9C	5147424	Spring (blue and white stripe)	24
		1.8343 - BRIDGE, Exhaust Valve	
9C	5135262	Bridge.....	12

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		1.8350 - CAP, Exhaust Valve Spring	
9C	5123330	Cap	24
		1.8360 - SEAT, Exhaust Valve Spring	
9C	5111467	Seat (.063" thick)	24
		1.8370 - LOCK, Exhaust Valve Spring	
9C	5116341	Lock (halves)	48
		1.8000A ROCKER COVER (Type 88)	
-	5125356	Cover (plain)	1
-	5130917	Cover w/filler	1
-	5147994	Gasket	2
-	5100104	Screw assy	8



FIG. 1B FUEL INJECTOR (N ENGINES) P 299



FIG. 2A FUEL PUMP

P 1003



FIG. 2B FUEL PUMP DRIVE



FIG. 2C FUEL PUMP DRIVE

Figs. 2A, 2B & 2C of 2.0000



FIG. 3D FUEL STRAINER, FUEL FILTER (Spin-On)



FIG. 5F VARIABLE SPEED GOVERNOR SPRING AND HOUSING



FIG. 5J MECHANICAL GOVERNOR (6V engine)

Fig. 5J of 2.0000



FIG. 7A INJECTOR CONTROL TUBES

Fig. 7A d 2.0000



INJECTOR CONTROL TUBE AND THROTTLE DELAY MECHANISM

Fig. 7B of 2.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.1000A FUEL INJECTOR (Type 107)	
		2.1001 - INJECTOR ASSY. Includes items in 2.1020 thru 2.1265.	
1B	5229350	Injector Assy. (C50)	6
		2.1002 - OVERHAUL KIT, Injector Consists of one (1) seal ring, two (2) filter cap gaskets, two (2) filter elements and two (2) shipping caps.	
-	5228701	Overhaul Kit	*
		2.1010 - CONTAINER, Injector Shipping	
1B	5193171	Container (12.8050)	*
		2.1020 - BODY ASSY., Injector A body assy. includes dowel and plug in 2.1020.	
1B	5228583	Body Assy.	6
1B	5226416	Dowel	6
-	5226912	Plug, body	12
1B	5229351	Tag, number (C50)	6
		2.1030 - NUT, Injector Valve	
1B	5228601	Nut.	6
		2.1040 - RING, Injector Seal	
1B	5226564	Ring	6
		2.1050 - DEFLECTOR, Injector Spill	
1B	5228109	Deflector	6

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.1060 - FOLLOWER, Injector	
1B	5228104	Follower	6
		2.1080 - SPRING, Injector Plunger	
1B	5228739	Spring .	6
		2.1100 - PIN, Injector Stop	
1B	5228608	Pin	6
		2.1110 - ELEMENT, Injector Filter	
1B	5228587	Element	12
		2.1130 - CAP, Injector Filter	
1B	5228588	Cap.	12
		2.1140 - GASKET, Injector Filter Cap	
1B	5226186	Gasket	12
1B	5226414	2.1150 - CAP, Injector Shipping Cap	*
		2.1160 - PLUNGER AND BUSHING ASSY., Injector Plungers and bushings are not sold separately. An assy. 1 includes pin in 2.1165.	
1B	5229354	Plunger and Bushing Assy. (C50)	6
		2.1165 - PIN, Bushing Guide	
-	5226393	Pin	6
		2.1170 - RACK, Injector	
1B	5226719	Rack	6

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.1180 - GEAR, Injector	
1B	5226400	Gear	6
		2.1190 - RETAINER, Injector Gear	
1B	5228586	Retainer	6
		2.1200 - VALVE, Injector Check	
1B	5228694	Valve	6
		2.1205 - CAGE, Injector Check Valve	
1B	5228696	Cage	6
		2.1235 - TIP ASSY., Injector Spray Components of tip assy. are not sold separately.	
1B	5229034	Tip Assy. (N40, N45, N50, C50)	6
		2.1238 - VALVE KIT, Injector An injector valve kit includes items in 2.1250 and 2.1255, unless otherwise indicated.	
-	5228769	Valve Kit (short quill needle) .	*
		2.1250 - SPRING, Injector Valve	
1B	5228596	Spring	6
		2.1255 - SEAT, Injector Valve Spring	
1B	5228766	Seat . .	6
		2.1257 - CAGE, Injector Valve Spring	
1B	5228594	Cage	6

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.1270 - CLAMP, Injector	
1B	5121259	Clamp	6
1B	5150250	Washer	6
1B	179847	Bolt, 3/8"-16x2" (12.9001)	6
		2. 2000 FUEL PUMP (Type 74)	
		2.2001 - PUMP ASSY., Fuel See ASSEMBLY BREAKDOWN as indicated below. A fuel pump kit includes a 3/8" inlet pump, gasket in 2.2007 and reducing bushing in 2.2030.	
2A	5199561	Pump Kit (H. H.) (3/8" inlet)	1
-	5199560	Pump Kit (L. H.) Replaces 5146341	1
		2.2010 - BODY, Fuel Pump	
2A	5109016	Body	1
2A	141195	Pin, 1/4" x 5/8" dowel (12.9290)	2
		2.2030 - COVER, Fuel Pump	
2A	5134628	Cover	1
2A	3719219	Bolt, 1/4"-20x3/4" (with lockwasher)	8
		2.2070 - SEAL, Fuel Pump Oil	
2A	5230007	Seal	2
		2.2087 - GEAR, Fuel Pump (drive)	
-	5174975	Gear	1
-	147481	Ball, 1/8" dia. steel (12.9670) 1	
		2.2089 - SHAFT, Fuel Pump Driven A shaft assy. includes gear, which is not sold separately.	
2A	5181747	Shaft Assy	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.2093 - SHAFT, Fuel Pump A shaft assy. includes shaft in 2.2093 and items in 2.2087.	
2A	5181746	Shaft Assy. (drive)	1
-	5178700	Shaft (drive)	1
		2.2130 - VALVE, Fuel Pump	
2A	5174973	Valve	1
2A	103709	Pin, 5/32" x 1" straight (12.9300)	1
		2.2160 - SPRING, Fuel Pump Valve Retaining	
2A	5184530	Spring	1
		2.2170 - PLUG, Fuel Pump Valve	
2A	5174971	Plug	1
		2.2180 - GASKET, Fuel Pump Valve	
2A	5161003	Gasket	1
		2.2007 - GASKET, Fuel Pump to Engine	
-	5150193	Gasket	1
		2.2010 - BODY, Fuel Pump	
2A	5146337	Body	1
-	5145009	Plug, 1/8" pipe (12.9550)	1
2A	141195	Pin, i/7" x 5/8" dowel (12.9290)	2
		2.2030 - COVER, Fuel Pump	
-	5134560	Cover L. H	1
2A	5134628	Cover	1
-	5198558	Bushing, 3/8" x 1/4"	1
2A	3719219	Bolt, 1/4"-20x3/4" (with lockwasher)	8

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.2070 - SEAL, Fuel Pump Oil	
2A	5230007	Seal	2
		2.2087 - GEAR, Fuel Pump (drive)	
-	5174975	Gear	1
-	147481	Ball, 1/8" dia. steel (12.9670)	1
		2.2089 - SHAFT, Fuel Pump Driven A shaft assy. includes gear which is not sold separately.	
2A	5181747	Shaft Assy	1
		2.2093 - SHAFT, Fuel Pump A shaft assy. includes shaft in 2.2093 and items in 2.2087.	
2A	5181746	Shaft Assy. (drive)	1
-	5178700	Shaft (drive)	1
		2.2130 - VALVE, Fuel Pump	
2A	5174973	Valve	1
2A	103709	Pin, 5/32" x 1" straight (12.9300)	1
		2.2160 - SPRING, Fuel Pump Valve Retaining	
2A	5184530	Spring	1
		2.2170 - PLUG, Fuel Pump Valve	
2A	5174971	Plug	1
		2.2180 - GASKET, Fuel Pump Valve Plug	
2A	5161003	Gasket	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.2001 - PUMP ASSY., Fuel (Continued)	
-	5118219	Bolt, 5/16"-18x7/8" (w/sealwasher)	3
		2.2004 - OVERHAUL KIT, Fuel Pump	
-	5195078	Overhaul Kit	*
		2.2007 - GASKET, Fuel Pump to Engine	
2A	5150193	Gasket (5.1010)	1
		2.2220 - FORK, Fuel Pump Coupling	
2A	5150199	Fork	1
		2.2260 - ADAPTOR, Fuel Pump Drive	
2B	5125775	Adapter	1
2B	9409073	Bolt, 1/4"-20x5/8" (12.9001)	2
		2.2290 - GEAR, Fuel Pump Drive A gear assy. includes bushing.	
2B	5125768	Gear Assy. (L.H. helix)	1
2B	5196842	Bushing (finished)	1
		2.2292 - HUB, Fuel Pump Drive Gear	
2B	5125774	Hub	1
2B	9409203	Bolt, 1/2"-13x2 3/4" (12.9001)	1
2B	5125771	Washer, thrust (inner)	2
2B	5126672	Washer, retainer	1
		2.3000A FUEL FILTER (Type 319)	
		2.3001 - STRAINER ASSY., Fuel See ASSEMBLY BREAKDOWN listed below.	
3D	6438839	Strainer Cartridge (Spin on) TP815	1
3D	5148023	Cover, Strainer (Spin on)	1

*As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.3100 - PLUG, Fuel Strainer Cover	
-	5145011	Plug, 3/8" pipe (12.9550)	2
		2.3310 - FILTER ASSY., Fuel See ASSEMBLY BREAKDOWN listed below.	
3D	6438840	Filter Cartridge (Spin on) TP816	1
3D	5148171	Cover,Filter (Spin on)	1
		2.3480 - PLUG, Fuel Filter Cover	
-	5145010	Plug, 1/4" pipe (in cover) (12.9550)	2
		2.3310 - FILTER ASSY., Fuel (continued)	
-	5154453	Plug, 3/8"-16 special	1
-	186622	Bolt, 3/8"-16xl 1/4" (12.9001)	2
-	186628	Bolt, 3/8"-16x1 1/2" (12.9001)	2
-	103321	Lockwasher, 3/8" (12.9200)	2
-	117062	Nut, 3/8"-16 hex. (12.9120)	2
		2.3530 - BRACKET, Fuel Filter Mounting	
-	5129243	Bracket	1
-	186619	Bolt, 3/8"-16xl 1/8" (12.9001)	1
-	103321	Lockwasher, 3/8" (12.9200)	*
		2.3570 - GASKET, Fuel Filter Mounting Bracket	
-	5116242	Gasket (to therm. housing) (1.2044)	1
-	5152904	Gasket (to head) (4.4115)	1
		2.4000 FUEL MANIFOLD AND/OR CONNECTIONS (Type 48)	
		2.4020 - PIPE, Fuel	
-	5116204	Pipe Assy. (inlet and outlet)	12
		2.4030 - CONNECTOR, Fuel Pipe	
-	5152138	Connector	12

*As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2,400 FUEL M ANIFOLD AND/OR CONNECTIONS (Type 48) (Cont'd)	
		2.4050 - WASHER, Fuel Pipe Connector	
-	5152148	Washer, 9/16" dia. copper 12	
		2.5000A FUEL LINES (Type 524)	
		2.5100 - TUBE, Fuel Pump to Filter	
-	5108445	Tube Assy. (dev. L. 52.82")	1
-	137423	Elbow, 3/8" inv. fl. tube 90° (12.9480)	1
-	5179969	Elbow, 3/8'i sealastic 90" (12.9425)	1
-	5179938	Seal Ring, 3/8" sealastic (12.9435)	2
-	5179937	Nut, 3/8" sealastic	2
		2.5120 - CLIP, Fuel Pump to Filter Tube	
-	5151883	Clip (3/8" tube) (2.5070)	1
		2.5151 - TUBE, Filter Outlet	
-	5129240	Tube (dev. L. 13.04")	1
-	5129232	Tube (dev. L. 25.30")	1
-	5179936	Connector, 3/8" sealastic (12.9415)	2
-	5185519	Tee (3/8" sealastic) (2.5100)	1
-	5179938	Seal Ring, 3/8" sealastic (12.9435)	2
-	5179938	Seal Ring, 3/8" tube sealastic (12.9435)	4
-	5179937	Nut, 3/8" sealastic (12.9445)	4
		2.5210 - TUBE, Fuel Drain	
-	5128016	Tube Assy. (dev. L. 10.12")	1
-	5129242	Tube (dev. L. 25.88") (crossover)	1
-	5116440	Elbow, 5/16" restricted	1
-	5125447	Elbow, 3/8" tube sealastic 45° (12.9425)	1
-	5179969	Elbow, 3/8" sealastic 900 (12.9425)	1
-	5179938	Seal Ring, 3/8" tube sealastic (12.9345)	2
-	5145010	Plug, 1/4" pipe (12.9550)	1
-	5179937	Nut. 3/8" tube sealastic (12.9445)	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.5220 - CLIP, Fuel Drain Tube	
-	5110070	Clip (3/8" tube) (2.5120)	1
-	5185432	Clamp (2.5120)	4
-	180121	Bolt, 3/8"-16x7/8" (12.9001)	1
-	132908	Bolt, No. 10-32xl/2" (12.9025).	4
-	103341	Washer, 3/8" flat (12.9190)	1
-	103321	Lockwasher, 3/8" (12.9200)	1
-	120217	Lockwasher, No. 10 med. (12.9200)	4
-	120614	Nut, No. 10-32 hex. (12.9120)	4
		2.7000A MECHANICAL GOVERNOR (Type 1245)	
		2.7001 - GOVERNOR ASSY.	
		A governor assy. includes items in 2.7002, 2.7045 thru 2.7810 except 2.7165, 2.7170, 2.7520, 2.7530 & 2.7740.	
		6V-53 governors do not include items in 2.7470.	
5J	5147527	Governor Assy. (variable) .	1
-	172850	Bolt, 3/8"-16x2 3/4" (12.9001)	6
-	103321	Lockwasher, 3/8" (12.9200)	6
		2.7002 - NAME PLATE, Governor	
-	5122166	Name Plate	1
-	109371	Screw, No. 0x3/16" rd. hd. dr. (12.9067)	2
		2.7010 - GASKET, Governor to Engine	
-	5121345	Gasket (to end plate)	1
		2.7045 - COVER ASSY., Governor	
		See ASSEMBLY BREAKDOWN indicated below.	
		2.7045 - COVER ASSY., Governor (complete)	
-	5126641	Cover Assy. (variable speed)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7050- COVER ASSY., Governor (less shaft and lever)	
		Includes items in 2.7050, 2.7093 and 2.7100.	
-	5126645	Cover Assy. (variable speed) 1	1
		2.7095 - SHAFT ASSY., Governor Throttle	
		A shaft assy. includes items in 2.7095 and 2.7130.	
-	5117933	Shaft Assy	1
		2.7100 - BEARING, Governor Throttle Shaft	
-	5127591+	Bushing	1
		2.7130 - PIN, Governor Fulcrum Lever	
5J	5117927	Pin	1
		2.7140 - WASHER, Governor Throttle Shaft (Packing)	
5J	5176557	Seal Ring	1
-	5197151	Washer, seal ring back-up	*
		2.7150 - RETAINER, Governor Throttle Shaft Packing	
5J	5144177	Washer	2
5J	5174429	Ring, retaining	1
		2.7045 - COVER ASSY., Governor (continued)	
5J	5183701	Screw, 1/4"-20x5/8" fil. hd. drilled (2.7812)	1
-	271468	Screw, 1/4"-20x3/4" fil. hd. (W/LW) (12.9010)	6
-	5126792	Screw, 1/4"-20x3/4"	1
5J	120380	Lockwasher, 1/4" (12.9200)	*
		2.7051 - GASKET, Governor Cover	
5J	5121342	Gasket	1

*As required. + Not serviced, replace with 2-148402 bearing assys.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7170 - LEVER, Governor Cover Throttle Shaft	
5J	5158432	Lever	1
5J	213546	Bolt, 1/4"-20xl'- (12.9001)	1
5J	120380	Lockwasher, 1/4" (12.9200)	1
		2.7230 - HOUSING, Governor Control	
5J	5145923	Housing Assy. (includes items in 2.7230 thru 2.7300)	1
5J	116337	Plug, 1 1/16" expansion (12.9330)	1
5J	5126069	Adapter, injector control link boot	2
5J	5150942	Pin, dowel (cover aligning)	2
5J	5116071	Pin (to cylinder block end plate)	1
5J	5145823	Pin (.375" x 2.12" special)	1
		2.7250 - SHAFT ASSY., Governor Operating Includes items in 2.7255, 2.7280 and bearing in 2.7260.	
-	5121458	Shaft Assy.	1
		2.7255 - SHAFT, Governor Operating	
5J	5121339	Shaft	1
		2.7260 - BEARING, Governor Operating Shaft (upper)	
-	457187	Bearing	1
5J	113903	Screw, No. 10-24x7/16" rnd. hd. (12.9025)	1
5J	120391	Washer, No. 10 flat (12.9190)	1
-	115545	Lockwasher, No. 10 (12.9220)	1
		2.7270 - BEARING, Governor Operating Shaft (lower)	
5J	954987	Bearing	2
		2.7280 - LEVER, Governor Operating Shaft	
5J	5116011	Lever Assy.	1
5J	5132962	Screw (gap adjusting)	1
5J	122161	Nut, 1/4"-28 hex. (12.9120)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7290 - FORK, Governor Operating Shaft	
5J	5138335	Fork	1
		2.7300 - PIN, Governor Operating Shaft Lever	
5J	5150943	Pin	1
		2.7310 - LEVER, Governor Differential	
		A lever assy. includes pin in 2.7315.	
5J	5124209	Lever Assy	1
5J	142583	Retainer, 13/64" spring (12.9640)	1
5J	5150941	Washer	1
		2.7315 - PIN, Governor Differential	
5J	5150943	Pin (2.7300)	1
		2.7317 - LEVER ASSY., Governor Control Operating Link	
5J	5145820	Lever Assy. (includes bearing and spring)	1
-	447196	Bearing, needle (2.7440)	2
-	148148	Retainer, 1/4" spring (12.9460)	1
5J	5117693	Pin, 1.00" L	2
5J	5151487	Washer (2.7430)	2
		2.7350 - SHAFT AND CARRIER ASSY., Governor Weight See ASSEMBLY BREAKDOWN listed below.	
-	5122883	Shaft and Carrier Assy	1
		2.7360 - SHAFT, Governor Weight Carrier	
5J	5121337	Shaft	1
		2.7370 - CARRIER, Governor Weight	
5J	5133707	Carrier	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7380 - RISER, Governor	
5J	5125367	Riser (includes thrust bearing)	1
		2.7390 - WEIGHT, Governor	
5J	5122775	Weight	2
		2.7430 - PIN, Governor Weight	
5J	5122786	Pin	2
5J	9411504	Ring, snap	2
		2,7460 - BEARING, Governor Weight Riser Thrust	
5J	451905	Bearing	1
		2.7470 - BEARING, Governor Weight Carrier Shaft	
5J	907674	Bearing	1
-	5152462	Plug, 1 1/8" expansion (2.7230)	1
		2.7680 - HOUSING ASSY., Governor Variable Speed Spring See ASSEMBLY BREAKDOWN listed below.	
-	5139263	Housing	1
		2.7690 - HOUSING, Governor Variable Speed Spring	
5F	5126060∅	Housing (no counterbore)	1
5F	444692	Plug, 1/4" pipe sl. hd. (12.9550)	1
-	5145010	Plug, 1/4"-18 hex. skt. tef. (12.5950)	1
-	5143564	Bolt, 1/4"-20xl 1/2" hex. skt. hd. (idle speed adjust.) (12.9076).	1
5F	274856	Nut, 1/4"-20 thin hex. (12.9120)	1
		2.7712 - BEARING, Governor Variable Speed Sping Lever Shaft	
5F	148402	Bearing (2.7100)	2

∅Not serviced, use 5145444 housing and include (1) 5145446 cover, (1) 5145445 gasket and (1) 271468 screw and lockwasher assy.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7720 - SHAFT, Governor Variable Speed Spring Lever	
-	5126120	Shaft	1
5F	103904	Key, 3/32" x 1/2" woodruff (12.9350)	3
		2.7730 - LEVER, Governor Variable Speed Spring A lever assy. includes lever, not sold separately, plus items in 2.7732.	
5F	5139469	Lever Assy.....	1
5F	223065	Screw, 5/16"-24xl/4" set (12.9076)	1
5F	5143665	Washer (packing retainer).....	2
		2.7732 - BEARING, Governor Variable Speed Spring Lever (Roller Contractor)	
-	5139468	Bearing.....	1
-	9425165	Pin, 1/4" x .61".....	1
		2.7750 - PACKING, Governor Variable Speed Spring Lever Shaft	
5F	5176557	Seal Ring (2.7140).....	2
		2.7680 - HOUSING ASSY., Governor Variable Speed Spring (Continued)	
-	445520	Bolt, 5/16"-18x3 1/2" (12.9001)	2
-	103320	Lockwasher, 5/16" (12.9200)	2
		2.7700 - GASKET, Governor Variable Speed Spring Housing	
5f	5152944	Gasket (2.7650)..... .	1
		2.7760 - SPRING, Governor Variable Speed	
-	5127397	Spring (two light blue stripes)..... .	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7770 - PLUNGER, Governor Variable Speed Spring	
5F	5152929	Plunger	1
		2.7780 - GUIDE, Governor Variable Speed Spring Plunger	
-	5152939	Guide	1
		2.7790 - RETAINER, Governor Variable Speed Spring	
5F	5137276	Retainer	1
		2.7795 - STOP, Governor Variable Speed Spring Retainer	
5F	5171784	Stop (with step)	1
5F	5174430	Stop (with gap)	1
		2.7800 - SHIM, Governor Variable Speed Spring	
5F	5136590	Shim (.010")	6
5F	5136591	Shim (.078")	3
		2.7810 - SCREW ASSY., Governor Buffer	
-	5152929	Spring	1
-	5174286	Nut, 3/8"-24 hex. (12.9140)	1
		2.7819 - ROD ASSY., Governor to Injector Link	
-	5121472	Link (lower)	2
-	5121453	Link (left bank upper)	1
-	5121452	Link (right bank upper)	1
7A	103361	Pin, 1/16" x 1/2" cotter (12.9250)	2
-	114783	Pin (link to injector control tube lever) (12.9260)	2
-	454750	Nut, 1/4"-28 elastic stop (upper to lower link) (12.9120)	2
		2.7830 - ADAPTOR, Cylinder Head Governor Control Link	
-	511626	Adapter (in head) (plain end) (1.2069)	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.7834 - BOOT, Governor to Injector Link	
-	5129706	Hose, 7/8" I.D. x 1.62" L. (right bank)	1
-	5129705	Hose, 13/16" I.D. x 76" L. (left bank)	2
-	5126072	Housing, link (left bank)	1
-	111610	Clamp, 1 1/4" dia. hose (12.9660)	4
		2.7910 - SPRING, Governor Throttle Lever Return	
-	5129711	Spring	1
		2.9000 INJECTOR CONTROLS (Type 182)	
		2.9001 - TUBE & LEVER ASSY., Injector Control A tube and lever assy. includes one (1) bracket in 2.9003 and items in 2.9007 thru 2.9010 plus items listed with each number.	
7A	5196784	Tube Assy. (right bank)	1
7A	5196786	Tube Assy. (left bank)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.9003 - BRACKET, Injector Control Tube	
7A, B	5116264	Bracket	4
7A, B	186630	Bolt, 1/4"-20x5/8" (12.9001)	8
7A, B	103319	Lockwasher, 1/4" (12.9200).	8
		2.9007 - SHAFT, Injector Control Tube End	
7A, B	5150259	Shaft (1 1/16" L.)	2
-	274270	Ring, retaining .	
		2.9009 - LEVER, Injector Control Tube	
7A, B	5150263	Lever	2
7A, B	142486	Pin, 1/8" x 3/4" groove (12.9270)	2
		2.9012 - SPRING, Injector Control Tube	
7A,B	5116265	Spring (L.H. helix)	2
		2.9014 - LEVER, Injector Control Tube Rack	
7A, B	5115322	Lever	6
7A, B	5176228	Screw, 1/4"-28x11/16" special	12
		2.9030 - BRACKET, Cylinder Throttle Delay Rocker Shaft	
7B	5145826	Bracket	1
7B	5145828	Piston	1
7B	5145827	Link, throttle delay	1
7B	5110059	Valve, check (2.9862)	1
7B	5189789	Plug (oil supply) (2.9862)	1
7B	5146233	Joint, 1/4" ball	1
7B	454750	Nut, lock 1/4"-28 (joint to piston)	1
7B	454749	Nut, No. 10-32 (joint to link)	1
7B	5145829	Lever, throttle delay	1
7B	5146039	Bushing (throttle delay lever)	2
7B	5180116	Bolt, "U" (2.9867)	1
7B	9415763	Screw, No. 8-32 x 5/8" hex. (12.7066)	2
7B	132776	Screw, No. 8-32 x 1" hex. (12.9025)	1
7B	9419454	Nut. 1/4" -20 hex. (12.9120)-	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.9030 - BRACKET, Cylinder Throttle Delay Rocker Shaft (Cont'd)	
7B	192482	Nut, No. 8-32 hex. (12.9120)	1
		2.9000A THROTTLE CONTROLS (Type 865)	
		2.9344 - BRACKET, Throttle Booster Spring	
-	5134476	Bracket	1
-	189330	Bolt, 3/8"-24x3 3/4" (12.9001)	2
		2.9345 - LEVER, Throttle Booster	
-	5179112	Lever	1
-	454813	Bolt, 1/4"-20x7/8" (12.9001)	1
-	120380	Lockwasher, 1/4" (12.9200)	1
		2.9347 - SPRING, Throttle Booster	
-	5125716	Spring	1
		2.9348 - EYE, Throttle Booster Adjusting	
-	5134051	Eye, 3/8"-16x4"	1
-	123221	Nut, 3/8"-16 (12.9120)	2
		2.9349 - HANGER, Throttle Booster Spring	
		A hanger assy. includes roller assy. and retaining ring and (1) washer in 2.9349.	
-	5133026	Hanger Assy	1
-	5132389	Roller Assy. (includes bushing)	1
-	5181264	Bushing	1
-	274676	Ring, retaining (1.4650)	1
-	5133010	Bolt, 5/16"-24x1.08"	1
-	106261	Washer, 5/16" flat (12.9190)	1
-	5132934	Nut, 5/16"-24 (spring hanger)	1
		2.9355 --SOLENOID, Throttle Control	
-	1118125	Solenoid (12V.) (7.4519)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		2.9355 - SOLENOID, Throttle Control (Cont'd)	
-	1996097	Switch, push button (7.4115),	1
-	5100004	Eye, rod end	1
-	100001	Bolt, 1/4"-28x3/4" (12.9001)	4
-	181596	Bolt, 5/16"-24x7/8" (12.9001)	1
-	120392	Washer, 1/4" flat (12.9190)	4
-	120380	Lockwasher, 1/4" (12.9200)	4
-	121902	Nut, 1/4"-28 hex. (12.9120)	4
-	120613	Nut, 1/4"-28 hex. (12.9120)	1
-	122193	Nut, 5/16"-24 hex. (12.9120)	1
		2.9357 - BRACKET, Throttle Control Solenoid	
-	5142215	Bracket	1
-	5138707	Bracket	1
-	132268	Screw, 1/4"-20x7/8" fil. hd. (12.9010)	3
-	186625	Bolt, 5/16"-18x7/8" (12.9001)	2
-	103319	Lockwasher, 1/4" (12.9200)	1
-	120380	Lockwasher, 1/4" (12.9200)	4
-	103320	Lockwasher, 5/16" (12.9200)	2
-	102634	Nut, 5/16"-18 hex. (12.9120)	2
		2.9390 - LEVER, Governor Control Shaft	
-	5183802	Lever (2.7170)	1
		2.9405 - SPRING, Governor Control Retracting	
-	5108381	Clip.	1
-	186647	Bolt, 1/4"-20x1" (12.9001)	1
-	120380	Lockwasher, 1/4" (12.9200)	1
		2.9410 - LEVER, Governor Control	
-	5188432	Lever (2.7170)	1
-	454813	Bolt, 1/4"-20x7/8" (12.9001)	1
-	120380	Lockwasher, 1/4" (12.9200)	1



FIG. 3C. AIR INLET HOUSING (6V-53)

Fig. 3C of 3.0000



FIG. 4D. BLOWER ASSEMBLY (6V-53)

Fig. 4D of 3.0000



FIG. 4F. BLOWER AND GOVERNOR DRIVE (6V-53)

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.3000A AIR INLET HOUSING (Type 402)	
		3.3001 - HOUSING ASSY., Air Inlet	
		A housing assy. includes items in 3.3003 and 3.3040 thru 3.3110.	
-	5141788	Housing Assy	1
-	186612	Bolt, 3/8"-16xl 3/8" (12.9001)	1
-	179846	Bolt, 3/8"-16xl 7/8" (12.9001)	3
-	112609	Bolt, 3/8"-16x3 3/4" (12.9001)	2
-	103341	Washer, 3/8" flat (12.9190)	*
-	103321	Lockwasher, 3/8" (12.9200).	*
		3.3003 - HOUSING, Air Inlet	
3C	5137435	Housing	1
-	5145010	Plug, 1/4" pipe (12.9550)	1
-	5145013	Plug, 3/4" pipe (12.9550)	1
		3.3040 - VALVE, Air Inlet Housing Shutdown	
3C	5121353	Valve.	2
3C,D	273436	Pin, 1/4"xll/16" roll (12.9300).	*
		3.3050 - SHAFT, Air Inlet Housing Shutdown Valve	
3C	5128593	Shaft	1
-	273436	Pin, 1/8"xll/16" roll (12.9300).	1
-	103341	Washer, 3/8" flat (12.9190)	1
		3.3055 - SEAL, Air Inlet Housing Shutdown Valve Shaft	
3C	5182977	Seal Ring (1.2020).	2
		3.3070 - SPRING, Air Inlet Housing Shutdown Valve Tension	
3C,D	5111904	Spring (valve) (internal)	1

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.3090 - LEVER, Air Inlet Housing Shutdown Valve	
3D	5114727	Latch	1
3D	5113633	Spacer (17/64" I.D. x T/16" O.D. x 7/8" L.)	1
-	121926	Bolt, 1/4"-20xl 1/2" (i2.9001)	1
-	120392	Washer, 1/4" flat (12.9190).*	1
-	120380	Lockwasher, 1/4" (12.9200)	1
		3.3110 - LEVER, Air Inlet Housing Shutdown Reset	
3A, C	5114974	Handle	1
3A, C	5131361	Handle	1
3A, C	5122623	Cam	1
-	455277	Pin, 1/8" x 1 1/8" spring (12.9275)	1
		3.3250 - WIRE, Air Inlet Housing Shutdown Control	
	5146239	Wire Assy. (90" L.) (2.9422)	1
-	3796374	Guide (2.9426)	1
	140855	Screw, No. 8-32x5/16" hex. soc. (12.9027)	1
	110730	Lockwasher, 3/8" (12.9200)	1
-	122236	Nut, 3/8"-24 hex. (12.9120	1
		3.3260 - PLATE, Air Inlet Housing Shutdown Control	
-	5186687	Plate, instruction	1
		3.3270 - CLIP, Air Inlet Housing Shutdown Control Wire	
-	3290569	Clip (1 3/16" L. - 3/8" bolt) (7.8320)	1
-	181309	Bolt, 1/4"-28xl/2" (12.9001)	1
-	103319	Lockwasher, 1/4" (12.9200)	1
-	121902	Nut, 1/4"-28 hex. (12.9120)	1

π Wire Assy. length determined by installation.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.4000 BLOWER (Type 127)	
		3.4001 - BLOWER ASSY.	
		A 6 cylinder blower assy. includes items in 3.4020 and 3.4030 thru 3.4190 and 3.4370 thru 3.4420.	
-	5134916	Blower Assy. (R. H. rotation engine).	1
4D	5132923	Bolt (6.68" L.).	4
4D	5131913	Washer (7/16") (flat)	4
		3.4003 - BLOWER KIT, Installation	
		A 6 cylinder kit also includes items in 2.7010, 2.7051, 2.7650, 2.7700 and hoses and clamps in 2.7834 and gasket in 3.4190.	
-	5198043	Blower Installation Kit	*
		3.4005 - BLOWER KIT, Repair	
		Turbo and non-turbo kits consist of washers in 3.4080, pilot in 3.4082, plus items in 3.4090, 3.4100, 3.4160, 3.4320, and spacer in 3.4370.	
	5198684	Blower Repair Kit (non-turbo).....	*
		3.4010 - GASKET, Blower	
4F	5121329	Gasket (to block)	2
-	5119438	Gasket (to governor housing) (2.7010).....	1
	5127963	Ring, seal (to block).....	1
		3.4020 - HOUSING, Blower	
4D	5119393	Housing Assy. (includes pins).	1
4F	141242	Pin, 3/8"x 7/8" dowel (12.9290).....	4
		3.4025 - SCREEN, Blower	
3D	5122610	Screen.....	1

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.4030 - ROTOR, Blower	
4D	5134913	Rotor Assy	2
		3.4033 - PLATE, Blower Rotor Thrust	
4F	5134179	Plate	1
4F	5116170	Spacer	3
4F	9409062	Bolt, 1/4"-20x1" (12.9001)	3
		3.4036 - WASHER, Blower Rotor Shaft Thrust	
4F	5127077	Washer (25/64" I.D.)	2
4F	9409034	Bolt, 3/8"-24x7/8" (12.9001)	2
		3.4080 - GEAR, Blower Rotor	
4F	5128599	Gear (R.H. helix)	1
4F	5128600	Gear (L.H. helix)	1
		3.4082 - PILOT, Blower Drive Gear	
-	5126236	Pilot	2
-	9409023	Bolt, 5/16"-24x1 3/4" (left gear) (12.9001)	1
	9420604	Bolt, 5/16"-24x1 3/4" (right gear) (12 pt. hd.)	1
		3.4090 - SHIM, Blower Rotor Gear	
4F	5116164	Shim (.002")	*
4F	5116165	Shim (.003").	
4F	5116166	Shim (.004)	*
4F	5116167	Shim (.005)	*
		3.4100 - SPACER, Blower Rotor Gear	
4F	5116168	Spacer	2
		3.4115 - PLATE, Blower Rotor Governor Drive	
4F	5121336	Plate	1
4F	9409219	Bolt, 1/4"-28x3/4" (12.9001)	4

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.4140 - PLATE, Blower Housing End	
		A plate assy. includes pins, plugs and strainer in 3.4140 and seal in 3.4160.	
-	5134915	Plate, rear	1
	5143636	Plate Assy., front.	1
4F	5145009	Plug, 1/8" pipe (12.9550).	2
		3.4160 - SEAL, Blower Housing End Plate	
4D	5199367	Seal (use with spacer 5199368)	*
4D	5134924	Seal (lip type)	4
		3.4163 - SPACER, Blower Rotor Shaft Oil Seal	
	5199368	Spacer (use with seal 5199367)	*
		3.4180 - COVER, Blower Housing End Plate	
4F	5119429	Cover (front)	1
4F	5119394	Plate, reinforcement (large)	2
4F	5119395	Plate, reinforcement (small)	2
4F	427588	Bolt, 3/8"-16x2 1/2" (12.9001)	6
4F	103321	Lockwasher, 3/8" (12.9200)	6
		3.4190 - GASKET, Blower Housing End Plate Cover	
4F	5119433	Gasket	1
		3.4300 - GEAR, Blower Drive	
4F	5116377	Gear (L. H. helix) (L. H. engine)	1
4F	5116378	Gear (R.H. helix) (R.H. engine)	1
4F	124546	Key, 5/32" x 5/8" woodruff (12.9350)	1
		3.4310 - HUB, Blower Drive Gear	
4F	5116418	Hub	1

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.4320 - WASHER, Blower Drive Gear Hub Thrust	
4F	5119285	Washer	1
4F	9411765	Ring (retainer)	1
		3.4350 - SUPPORT, Blower Drive Gear Hub	
4F	5129168	Support	1
-	5121343	Cover	1
4F	186289	Bolt, 3/8"-16x5" (12.9001)	6
-	5164294	Washer (3/8" I.D. x 1/8" thick) (7.1581)	4
4F	5152148	Washer (3/8" copper) (2.4050)	2
		3.4360 - GASKET, Blower Drive Gear Hub Support	
-	5121359	Gasket (support to flywheel housing)	1
-	5121344	Gasket (cover to support)	1
		3.4370 - COUPLING, Blower Drive	
		A coupling assy. includes items in 3.4380 thru 3.4400.	
-	5119411	Coupling Assy	1
-	5126237	Spacer (3.4100)	1
4D	9409221	Bolt, 1/4"-28xl 5/8" (12.9001)	4
		3.4380 - SUPPORT, Blower Drive Coupling	
4D	5119412	Support	2
		3.4390 - CAM, Blower Drive Coupling	
4F	5180323	Cam	1
		3.4400 - SPRING, Blower Drive Coupling	
4D	5196614	Spring Pack (includes springs and seats)	1
		3.4420 - RETAINER, Blower Drive Coupling	
4F	5119466	Retainer	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		3.4000A BLOWER DRIVE SHAFT (Type 17)	
		3.4445 - SHAFT, Blower Drive	
4F	5146721*	Shaft (.500" dia. shaft).....	1
		3.4446 - RING, Blower Drive Shaft	
4F	9414044	Ring.....	1

‡ Machined for a tachometer drive.



FIG 1A. OIL PUMP AND PRESSURE REGULATOR

Fig. 1A of 4.0000



FIG. 2B. OIL DISTRIBUTION SYSTEM

Fig. 2A of 4.0000



FIG. 3 A. OIL FILTER

Fig. 3A of 4.0000



FIG. 4C. OIL COOLER

Fig. 4C of 4.0000



FIG. 7A. OIL PAN (Cast)



FIG. 8C. BREATHER
(6V-53 Models)

Figs. 7A & 8C of 4.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4. 1000A OIL PUMP (Type -51)	
		4. 1001 - PUMP ASSY., Oil	
		Includes items in 4.1040 thru 4.1220 and 4.1380.	
-	5116070	Pump Assy	1
1A	179826	Bolt, 5/16"-18x2" (12.9001)	6
1A	103320	Lockwasher, 5/16" (12.9200)	
		4. 1085 - ROTOR ASSY., Oil Pump	
1A	5195687	Rotor Set.	1
		4.1220 - COVER, Oil Pump	
1A	5195685	Cover	1
1A	145067	Screw, No. 6 x 3/8" drive (12.9067)	2
		4.1310 - GEAR, Oil Pump Drive (on crankshaft)	
1A	5144375	Gear	1
		4.1000B OIL DISTRIBUTION SYSTEM (Type 329)	
		4.1510 - PIPE, Oil Pump Inlet	
2A	5138243	Pipe Assy	1
-	179827	Bolt, 5/16"-18x2 1/4" (12.9001)	2
-	103320	Lockwasher, 5/16" (12.9200)	*
		4.1512 - SUPPORT, Oil Pump Inlet Pipe	
2A	5138254	Support	2
-	180120	Bolt, 3/8"116x3/4" (12.9001).	4
-	186627	Bolt, 3/8"-24x1" (12.9001)	2
-	103341	Washer, 3/8" (12.9200)	8
2A	5138619	Washer, 25/64" x 3/4" x .83"	4
2A	103321	Lockwasher, 3/8" (12.9200)	4
	192481	Nut, 3/8"-24 lock (12.9120)	2

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4.1520 - GASKET, Oil Pump Inlet Pipe	
2A	5126473	Gasket	1
		4.1530 - SCREEN, Oil Pump Inlet	
-	5126143	Screen Assy	1
-	9409010	Bolt, 5/16"-18x5/8" (12.9001)	2
	103340	Washer, 5/16" flat (12.9190)	2
		4. 1000C OIL PRESSURE REGULATOR (Type 12)	
		4.1690 - SPRING, Oil Pressure Regulator	
1A	5126436	Spring	2
		4.1700 - VALVE, Oil Pressure Regulator	
1A	5143021	Valve	2
		4.1710 - PLUG, Oil Pressure Regulator	
	5136227	Plug 2	2
		4.1720 - GASKET, Oil Pressure Regulator Plug	
1A	5177773	Gasket (4.4170)	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4. 2000A OIL FILTER (Type 224)	
		4.2240 - FILTER ASSY., Oil	
		See ASSEMBLY BREAKDOWN listed below.	
	5134392	Filter Assy. (9" element)	1
		4. 2250 - ELEMENT, Oil Filter	
3A	5573014	Element (9") (AC type PF-132) (includes gasket in 4. 2300).....	
		4. 2280 - SHELL, Oil Filter	
3A	5574008	Shell (includes plug)	1
		4.2290 - COVER, Oil Filter (Adaptor)	
3A	5134908	Adaptor.....	1
3A	5145010	Plug, 1/4" pipe (12. 9550)	2
		4. 2300 - GASKET, Oil Filter Cover	
3A	5571024	Gasket.....	1
		4.2310 - SPRING, Oil Filter	
3A	5187308	Spring.....	1
		4.2315 - RETAINER, Oil Filter Spring	
3A	5187309	Retainer.....	1
	122366	Nut, 5/8"-18 hex. (12. 9120).....	1
		4.2330 - GASKET, Oil Filter Cover Nut	
3A	5187310	Gasket, retainer.....	1
3A	5574130	Gasket.....	1
-	5154538	Washer (1.8182).....	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4.2410 - STUD, Oil Filter Center	
3A	5132017	Stud	1
		4.2485 - VALVE, Oil Filter By-pass	
-	5133431	Valve	1
		4.2486 - SPRING, Oil Filter By-pass Valve	
-	5134477	Spring	1
		4.2488 - PLUG, Oil Filter By-pass Valve	
-	5134456	Retainer	1
-	450865	Screw, No. 12-24x3/8" rd. hd	1
		4.2240 - FILTER ASSY., Oil (Continued)	
-	5573162	Decal (4.2280)	1
3A	186679	Bolt, 3/8"-16xl 1/4" (12.9001)	4
3A	103341	Washer, 3/8" flat (12.9190).	4
3A	103321	Lockwasher, 3/8" (12.9200)	*
		4.2291 - ADAPTOR, Oil Filter Cover	
-	5129617	Adaptor (mounting)	1
-	454906	Bolt, 3/8"-16xl 1/2" (12.9001)	4
-	103321	Lockwasher, 3/8" (12.9200)	*
		4.2293 - GASKET, Oil Filter Cover Adaptor	
-	5128486	Gasket (mounting adaptor)	1
		4.2350 - GASKET, Oil Filter Adaptor	
3A	5121205	Gasket	1

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4.4000A OIL COOLER (Type 489)	
		4.4001 - CORE ASSY., Oil Cooler	
4C	8514600	Core Assy. (12 plate)	1
		4.4030 - GASKET, Oil Cooler Core Inner	
4C	5150155	Gasket	1
		4.4040 - GASKET, Oil Cooler Core Outer	
4C	5154215	Gasket	1
		4.4050 - HOUSING, Oil Cooler	
-	5137790	Housing	1
-	186650	Bolt, 5/16"-18x4 3/4" (12.9001).	8
4C	103320	Lockwasher, 5/16" (12.9200)	*
		4.5000A OIL FILLER (Type 18)	
		4.5010 - CAP, Oil Filler Tube	
Δ	5108474	Cap Assy. (twist)	1

* As required. Δ Fig. 9D of 1.0000.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		4.7000A OIL PAN (Type 253)	
		4.7001 - PAN, Oil	
7A	5129677	Pan (cast iron)	1
7A	189700	Bolt, 5/16"-18xl 1/4" (with lockwasher) (12.9001).	22
		4.7030 - GASKET, Oil Pan to Block	
7A	5196061	Gasket Set (cast iron)	1
		4.7080 - PLUG, Oil Pan Drain	
		Plugs must be optionally selected when multiple quantities are shown in same type.	
7A	5145012	Plug, 1/2" pipe sq. hd. (12.9550)	1
7A	5178994	Plug, 3/4" pipe (magnetic)	3
		4.8000A VENTILATING SYSTEM (Type 296)	
		4.8010 - EXTENSION, Breather Pipe	
-	5162962	Pipe (dev. L. 18.50") (4.8001)	1
		4.8040 - CLIP, Breather Tube	
8C	5157702	Clip	
		4.8175 - HOSE, Breather Extension Pipe	
-	5177217	Hose (1" I.D. x 3 1/2" L.) (5.1270)	1
	111612	Clamp, 1 3/8" hose (12.9660)	2



FIG. 1B. TYPICAL COOLING SYSTEM (V-Engines)

Fig. 1B of 5.0000



FIG. 2A. FRESH WATER PUMP



FIG. 3A. THERMOSTAT
(V-Engines)

Figs. 2A & 3A of 5.0000



FIG. 4B. FAN SHAFT & PULLEY

Fig. 4B of 5.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.1000 FRESH WATER PUMP (Type 153)	
		5.1001 - PUMP ASSY., Fresh Water	
		For components of pump assy. refer to Assembly Breakdown listed below.	
2A	5144685	Pump Assy. (L. H. rotation).....	1
		5.1030 - BODY, Fresh Water Pump	
-	5144688	Body (L. H. rotation)	1
-	5145009	Plug, 1/8" pipe (12.9550).....	1
		5.1031 - COVER, Fresh Water Pump	
-	5119283	Cover.....	1
-	189691	Bolt, 5/16"-18x3/4" (with lockwasher)	7
		5.1032 - GASKET, Fresh Water Pump Body Cover	
-	5119282	Gasket	1
		5.1050 - SHAFT, Fresh Water Pump	
-	904827	Shaft Assy. (includes bearing).....	1
		5.1110 - IMPELLER, Fresh Water Pump	
-	5113800	Impeller (L. H. rotation)	1
		5.1130 - SEAL, Fresh Water Pump	
-	5130959	Seal	1
		5.1214 - PULLEY, Fresh Water Pump	
-	5144503	Pulley	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.1001 - PUMP ASSY., Fresh Water (Cont'd)	
2A	186625	Bolt, 5/16"-18x7/8" (12. 9001)	4
2A	103320	Lockwasher, 5/16" (12. 9200)	4
		5.1002 - RECONDITIONING KIT, Fresh Water Pump	
		Includes items in 5.1010, 5.1032, 5.1050, 5.1110 and 5.1130.	
	5199533	Reconditioning Kit (L. H. Rotation pump)	*
		5.1010 - GASKET, Fresh Water Pump	
2A	5133107	Gasket	1
		5.1115 - REPLACEMENT KIT, Fresh Water Pump Seal Seat	
-	5197279π	Replacement Kit, impeller insert	*
		5.1200 - PULLEY, Fresh Water Pump Idler	
		A pulley assy. includes pulley and adjusting arm, which are not serviced separately, and bearing in 5.1202.	
-	179850	Bolt, 3/8"-16x2 3/4" (12. 9001).	2
	103341	Washer, 3/8" Flat (12. 9190)	2
		5.1202 - BEARING, Fresh Water Pump Idler Pulley	
-	907394	Bearing	1

* As required. π Includes ceramic insert and adhesive.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.2000A WATER OUTLET MANIFOLD AND/OR ELBOW (Type 86)	
		5.2035 - ELBOW, Water Outlet	
3A	5128492	Elbow (300 offset to left) (L. bank)	1
3A	5128493	Elbow (300 offset to right) (R. bank)	1
3A	186679	Bolt, 3/8"-16xl 1/4" (12. 9001)	4
3A	103321	Lockwasher, 3/8" (12. 9200)	4
		5.2037 - GASKET, Water Outlet Elbow	
3A	5122437	Gasket	2
		5.2000B THERMOSTAT (Type 159)	
		5.2050 - THERMOSTAT ASSY.	
-	5143210	Thermostat Assy. (1750 opening temperature) (without vent)	2
		5.2060 - SEAL, Thermostat	
3A	5134269	Seal	2
		5.2090 - HOUSING, Thermostat	
3A	5135638	Housing (L. bank) (without vent)	1
3A	5135949	Housing (R. bank) (without vent)	1
3A	5124775	Base	2
-	5145014	Plug, 3/8" pipe (12.9550)	3
3A	5115214	Plug, 1/2" pipe (12. 9550)	5
-	186619	Bolt, 3/8"-18x1 1/8" (12. 9001)	4
3A	191249	Bolt, 3/8"-16x3 3/4" (12. 9001)	2
-	450517	Bolt, 3/8"-16x4 3/4" (12. 9001)	2
3A	103321	Lockwasher, 3/8" (12. 9200)	
		5.2110 - GASKET, Thermostat Housing	
3A	5116242	Gasket (to cylinder head) (1.2044)	2
3A	5124997	Gasket (to base)	2

* As required.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.2120 - COVER, Thermostat Housing	
3A	5125868	Cover (1/8" pipe tap)	1
3A	186618	Bolt, 5/16"-18 x 5/8" (12.9001)	2
3A	103320	Lockwasher, 5/16" (12.9200)	*
		5.2130 - GASKET, Thermostat Housing Cover	
3A	5125024	Gasket	1
		5.2000C WATER BY-PASS TUBE (Type 360)	
-	5146053	Tube	1
-	5145230	Tube	1
-	5125867	Flange	3
-	5144512	Connector	1
-	5125150	Seal Ring	3
-	5142549	Plug	1
-	186625	Bolt	6
-	103320	Lockwasher	6
		5.3000B WATER CONNECTIONS (Type 242)	
		5.3420 - ELBOW, Oil Cooler Water Outlet	
1B	5135565π	Elbow	1
--	179819	Bolt, 5/16"-18xl 1/8" (12.9001)	2
	103320	Lockwasher, 5/16" (12.9200)	2
		5.3421 - GASKET, Oil Cooler Water Outlet Elbow	
	5116357	Gasket (1.1070)	1
1B	5163824	Hose (2" I.D. x 2. L.)	1
1B	5186841	Clamp (1 9/16" x 2 1/2" dia. hose)	2

* As required. π Not serviced; for replacement use 5135679 plus (1) 103870.

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.4000A FAN (Type 627)	
		5.4015 - PULLEY AND HUB ASSY., Fan	
	5131207	Pulley Assy. (with cap)	1
		5.4025 - SUPPORT, Fan Mounting	
-	5109640	Support	1
-	450517	Bolt, 3/8"-16x 4 3/4" (12.9001)	2
-	427567	Bolt, 7/16"-14xl 3/4" (12.9001)	2
		5.4025 - SUPPORT, Fan Mounting (Cont'd)	
-	103322	Lockwasher, 7/16" (12. 9200)	2
		5.4100 SHAFT, Fan	
-	5100201	Shaft	1
-	427564	Bolt, 7/16"-14xl 3/8" (12. 9001)	4
-	5108436	Washer (15/32" flat) (7.1589)	4
-	103322	Lockwasher, 7/16" (12. 9200)	4
		5.4110 - BEARING, Fan Shaft	
-	7451080	Bearing (front)	1
-	7450630	Bearing (rear)	1
-	5131095	Retainer, grease	1
-	5131124	Shim (.015")	*
-	5131205	Shim (.020")	*
-	5131206	Shim (.025")	*
		5.4140 - RETAINER, Fan Shaft Bearing	
-	5131123	Washer (33/64"xl 1/2"x. 32")	1
-	9409060	Bolt, 1/2"-20xl 1/2" lack (12. 9001)	1
		5.4150 - SEAL, Fan Shaft	
-	5108219	Seal	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		5.4170 - SPACER, Fan Shaft Bearing	
-	5131122	Spacer.....	1
		5.4180 - CAP AND SPACER, Fan Hub	
-	5108868	Cap (pulley).....	1
		5.4235 - PULLEY, Fan	
-	5130029	Pulley (4. 90" dia. 2 grooves).....	1
		5.4290 - SCREW, Fan Bracket Adjusting	
-	5134618	Bracket.....	1
-	193221	Bolt, 7/16"-14xl 1/4" (12. 9001).....	2
-	103342	Washer, '7/16"-14xl 1/4" (12. 9001)	2
-	103322	Lockwasher, 7/16" (12. 9200).....	2



FIG. 1B. EXHAUST MANIFOLD

Fig. 1B of 6.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		6. 1000A EXHAUST MANIFOLD (Type 239)	
		6.1001 - MANIFOLD, Exhaust	
1B	5132494	Manifold (right banks	1
1B	5132495	Manifold (left bank)	1
-	5133435	Crab	4
1B	5188273	Washer (dished, 1 1/4" O.D.)	4
1B	114544	Nut, 7/16"-20 hex. br. (12.9120)	8
		6.1010 - GASKET, Exhaust Manifold	
1B	5116205	Gasket	2
		6.1020 - STUD, Exhaust Manifold to Head	
1B	5112899	Stud, 7/16"-14x2 3/32"	8
		6.2000A EXHAUST MUFFLER AND/OR CONNECTIONS (Type 219)	
		6.2085 - FLANGE, Exhaust	
1B	5137620	Clamp Assy. (Marman flange) (3.82" dia.)	2
		6.2090- PIPE, Exhaust	
	5108830ϕ	Pipe (1" L. x 3 1/4" O.D.)	2
-	5129914ϕ	Pipe (6" L. x 3 1/4" O. D.)	2

ϕ Length determined by installation.



FIG. 1B. BATTERY CHARGING GENERATOR

Fig. 1B of 7.0000



FIG. 1C. STARTING MOTOR

Illustrations are of Typical Parts only.

Fig. 1C of 7.0000



FIG. 1D. REGULATOR, VOLTAGE



FIG. 1E. GENERATOR

Illustrations are of Typical Parts only.

Figs. 1D & IE of 7.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.1000A BATTERY CHARGING GENERATOR (Type 1574)	
		NOTE: Part numbers provided for the Generator Assy. breakdown are Delco-Remy part numbers, FSCM 16764.	
		7.1001 - GENERATOR ASSY.	
1B, 1E	1117780	Generator (12V., 55 amp., neg. grd., C.W. /C. C. W.)	1
1E(1)	1970012	Frame - S. R. E .	1
1E(2)	1970016	Rotor Assembly	1
1E(3)	1958821	Stator Assembly	1
1E(4)	1961866	Frame - D. E.	1
1E(5)	1958823	Positive Heat Sink Assembly	
1E(6)	1958824	Negative Heat Sink Assembly	
1E(7)	1958825	Diode - Positive	3
1E(8)	1958826	Diode - Negative	3
1E(9)	1958827	Brush Pkg	2
1E(10)	1961890	Brush Holder	1
1E(11)	1964117	Spring - Brush	2
1E(13)	907356	Ball Bearing - D. E.	1
1E(14)	1958828	Terminal Pkg. - Battery	6
1E(15)	1956030	Terminal Screw	1
1E(16)	1961803	Adapter	1
-	1961887	Term. Blade "F-1"	1
-	1961888	Term. Blade "R	1
-	1961889	Stud - Adapter Spacing	1
1E(17)	1961867	Brg. Retainer - Assembly	1
1E(18)	1955663	Gasket	1
1E(19)	1955650	Collar - Inside	1
1E(20)	1955649	Collar - Outside	1
1E(21)	1955412	Ring - Slip	1
1E(22)	1961891	Capacitor	1
1E(23)	1956279	Bracket Capacitor .	1
1E(24)	1955667	Cover Slip Ring .	1
1E(25)	1962276	Lock Washer-Brg. Retainer Attaching Screw	3
1E(26)	456413	Lock Washer - Adapter Attaching Screw	2
-	456413	Lock Washer - Capacitor Bracket Attach. Screw	1
1E(27)	453844	Lock Washer - Capacitor Lead Attaching Screw	1
1E(28)	9421423	Lock Washer - D. E. Frame Attaching Screw	3

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.1001 - GENERATOR ASSY. (Cont'd)	
1E(30)	1914579	Lock Washer, Heat Sink Attaching Screw	3
1E(33)	9421423	Lock Washer, S. R. E. Frame Attaching Screw	3
1E(34)	1961871	Nut, D.E.I Frame Attaching Screw	3
1E(35)	1961878	Nut, Heat Sink (Grounded) Attaching Screw	3
1E(35)	9418915	Nut, Heat Sink (Insulated) Attaching Screw	
1E(37)	1961871	Nut, S. R. E. Frame Attaching Screw	3
1E(38)	453468	Screw, Brg. Retainer Attaching, D.E.	3
1E(39)	454786	Screw, Adapter Attaching .	2
	454329	Screw, Capacitor Bracket Attaching	
1E(40)	1971964	Screw (& Lockwasher), Capacitor Lead Attach.	1
1E(41)	1961965	Screw, D.E. Frame Attaching	3
1E(43)	9418913	Screw, Heat Sink Attaching	3
1E(45)	1961965	Screw, S.R.E. Frame Attaching	3
1E(49)	1961877	Bushing, Insulating, Heat Sink Attach. Screw	
1E(50)	1965145	Bushing, S.R.E. Frame Mtg. Hinge.	
1E(51)	1929959	Clamp (Rubber), Brg. Retainer, S.R.E	1
	7451641	Inner Race, S.R. E	
1E(52)	1955543	Insulator, Heat Sink	1
	1961257	Lead (Pkg.), Diode to Terminal Relay.	
	7451640	Outer Race & Roller, S.R. E ..	
1E(55)	1955520	Plug, Brg. Well, S. R. E	1
	1966554	Seal, Oil, S.R.E.	
-	179864	Bolt, 7/16"-14xl 3/4" (12.9001)	2
-	103342	Washer, 7/16" flat (12.9190)	2
-	103322	Lockwasher, 7/16" (12.9200)	2
-	117063	Nut, 7/16"-14 hex. (12.9120)	2
		7.1500 - PULLEY, Generator	
1B	5133563	Pulley (2.76" dia., 2 groove)	1
		7.1575 - BELT, Generator Drive	
		All belts are "Premium" polyester belts unless indicated "M.S." (military standard) or "Poly-Vee".	
1B	5133177	Belt Set (2 belts, 37" L. x .38" W., cogged)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.1580 - STRAP, Generator	
1B	5131768	Strap	1
-	5167319	Spacer, 5/32" x 7/8" (5.4600)	1
-	5164294	Spacer, 13/32" x 7/8" x 1/8" (7.1581)	1
-	179839	Bolt, 3/8"-16x1" (12.9001)	1
-	179848	Bolt, 3/8"-16x2 1/4" (12.9001)	1
-	103321	Lockwasher, 3/8" (12.9200)	2
		7.1595 - BRACKET, Generator Mounting	
1B	5134981	Bracket	1
-	179839	Bolt, 3/8"-16x1" (12.9001)	3
-	103321	Lockwasher, 3/8" (12.9200)	3
		7.1605 - REGULATOR, Voltage	
		NOTE: Part numbers provided for the Voltage Regulator are Delco Remy part numbers, FSCM 16764. See ASSEMBLY BREAKDOWN listed below.	
1D	1119513	Regulator (12 V.).	1
1D(1)	1958151	Cover	1
1D(4)	1958137	Spring	1
1D(5)	1941431	Resistor	1
1D(6)	1960347	Resistor	1
	9421423	Lockwasher - Terminal Screw	
1D(12)	1958148	Screw - Adjusting	1
1D(14)	1943386	Screw - Cover Attaching	2
-	1962629	Shock Bracket Package	

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.3000A STARTING MOTOR (Type 204)	
		7.3001 - MOTOR ASSY., Starting	
		NOTE: Part numbers provided for the Air Compressor Assembly breakdown are Delco Remy part numbers, FSCM 16764.	
		See ASSEMBLY BREAKDOWN listed below.	
1B,1C	1114052	Motor Assy. (12V.,C.W.,	
1C(1)	1951073	Frame, C. E	1
1C(2)	1945906	Armature .	1
1C(3)	1945496	Field Coils (4 coils)	1
1C(4)	1950561	Stud Terminal	1
1C(5)	1947262	Housing Lever	1
1C(6)	800069	Drive Assy	1
1C(7)	1949606	Housing Drive	1
1C(8)	1119879	Switch	1
1C(9)	1945484	Lever Shift	1
1C(10)	1945472	Lever Shaft	1
1C(11)	1945480	Plunger	1
1C(12)	1948515	Plate Assy., less brushes	1
1C(13)	1874847	Plate Support	1
1C(14)	1909523	Insulator, Brush Plate	1
1C(15)	1945518	Plate & Stud	1
1C(16)	1965093	Insulator, Brush Holder	2
1C(17)	1874848	Plate, Space Ins. Holder	2
1C(18)	1874851	Plate, Space Grd. Holder	2
1C(19)	1906986	Brush	8
1C(20)	1861785	Spring, Brush	8
1C(21)	1907475	Holder, Brush	4
1C(22]	1945478	Plate, Brush Cover	1
1C(23)	453435	Lock Washer, Brush Holder Screw	8
1C(24)	453844	Lock Washer, Brush Lead Attach. Screw	8
1C(25)	453844	Lock Washer, Brush Plate Assembly	3
1C(26)	9421423	Lock Washer, C. E. Frame Attach. Screw	7
1C(27)	9421427	Lock Washer, C. E. Terminal Stud.	2
1C(28)	9421427	Lock Washer, Field Terminal Stud	1
1C(29)	9421423	Lock Washer, Lever Housing Attach. Screw	5
1C(30)	120238	Nut, C. E. Terminal Stud (1/2-13 x 5/16)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.3001 - MOTOR ASSY., Starting (Cont'd)	
1C(31)	120378	Nut, C. E. Terminal Stud (1/2-13 x 7/16)	1
1C(32)	120238	Nut, Field Terminal Stud	1
1C(33)	120238	Nut, Field Terminal Stud	1
1C(34)	9412305	Nut, Plunger Rod, Guide Adjusting	1
1C(35)	9414397	Screw, Brush Cover Plate Attaching	4
1C(36)	1928500	Screw, Brush Holder, Grd. Brush, Long	
1C(37)	1904982	Screw, Brush Holder, Ins. Brush, Long	2
1C(38)	1914580	Screw, Brush Holder, Grd. Brush, Short	2
1C(39)	1968656	Screw, Brush Holder, Ins. Brush, Short 2	
1C(40)	453418	Screw, Brush Lead Attaching	8
1C(41)	1847807	Screw (& Washer), Brush Plate Assembly Attach	3
1C(42)	1914869	Screw, C.E. Frame Attaching	4
1C(43)	1948536	Screw, Drive Housing Attaching (5/16-18 x 1/2")	5
1C(44)	1948537	Screw, Drive Housing Attaching (5/16-18 x 5/64")	1
1C(45)	1914869	Screw, Lever Hou5ing Attaching	1
1C(46)	1913960	Screw, Pole Shoe	8
1C(47)	1930611	Screw, & Lock Washer, Switch Attach	4
1C(48)	1911644	Washer, Brake Between Lever Hsg. & Drive	1
1C(49)	1913080	Washer, Brush Holder Screw, Ins. (Bushing)	8
1C(51)	1922457	Washer, Field Terminal Stud, Ins	2
1C(52)	1931086	Washer, Brush Plate Assy. Attach. Screw, Plain	3
1C(53)	30205	Washer, C. E. Terminal Stud Plain (15/16)	1
1C(54)	1914647	Washer, Field Terminal Stud Plain (7/8)	1
1C(55)	807736	Washer, Shaft Lever Return Spring Retainer	1
1C(56)	1905014	Washer, Space, C. E	1
1C(57)	1936466	Washer, Space,) Between Armature & Lever Hsg	1
1C(58)	1942257	Boot, Plunger	1
1C(59)	38273	Bushing, C.E. Frame	1
1C(60)	1942258	Bushing, Drive Housing	1
1C(61)	1923484	Bushing, Lever Housing	1
1C(62)		Bushing, Ins. C. E. Terminal Stud	
1C(63)	1965472	Bushing, Ins. Field Terminal Stud (Package) . .	1
1C(64)	1945468	Connector, Terminal to Switch	1
1C(65)	1945477	Gasket, Brush Cover Plate	
1C(67)	1945476	Gasket, Between Lever & Drive Housing	1
1C(68)	1964857	Gasket, Lever Housing Plug	1
1C(70)	1945479	Insulator, Field Coil, C. E	1
1C(71)	1914873	Insulator, Field Coil Triangle	1
1C(72)		Insulator, Terminal Stud, C. E.	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		7.3001 - MOTOR ASSY., Starting (Cont'd)	
1C(73)	1953236	Lead, (& Terminals) C. E. Terminal to Switch . .	1
1C(74)		"O" Ring, C. E. Terminal Stud	1
1C(75)	1916272	"O" Ring, Field Frame Seal, C. E	1
1C(76)	1916272	"O" Ring, Field Frame Seal, D. E	1
1C(77)	1921805	"O" Ring, Shift Lever (1/2" Dia.)	1
1C(78)	1914373	"O" Ring, Shift Lever (15/64" Dia.)	1
	1955303	Plug, Felt, Oil Reservoir	
	9417501	Plug, Retaining Oil Reservoir	
1C(79)	1945356	Plug, Lever Housing Inspection	1
1C(80)	103893	Plug, Expansion, C.E	1
1C(81)	453465	Plug, Pipe, C. E	1
1C(82)	453465	Plug, Pipe, D.E. Housing (11/32" Dia.)	1
1C(83)	273913	Plug, Pipe, D.E. Housing (1/4" Dia.)	1
1C(84)	453465	Plug, Pipe, Lever Housing	1
1C(85)	1934478	Pole, Shoe (View notched end face down-longer lip on left	2
1C(86)	1948526	Retainer, Shift Lever Spring (13/32" Hole)	1
1C(87)	1948520	Retainer, Shift Lever Spring (13/64" Hole)	1
1C(88)	1918047	Seal, Oil Lever Housing	1
1C(89)	9415235	Snap, Ring, Lever Shaft Retainer	1
1C(90)	9415235	Snap, Ring, Shift Lever Return Spring	1
1C(91)	1948521	Spring, Shift Lever Return	1
1C(92)	1916439	Wick, Oil, C.E	1
1C(93)	1916439	Wick, Oil, Drive Housing	1
1C(94)	1916439	Wick, Oil, Lever Housing	1
-	9418228	Bolt, 5/8"-llxl 3/4", 12 P.T. (12.9005)	3
	103325	Lockwasher, 5/8" (12.9200).	3
		7.3004 - GASKET, Starting Motor	
-	5130995	Gasket	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		11.1000A ENGINE MOUNTING AND BASE (Type 380)	
		11.1070 - SUPPORT, Engine Front	
-	5124762	Support (11.1090)	1
-	180147	Bolt, 7/16"-14xl 1/4" (12.9Q01)	6
-	103322	Lockwasher, 7/16" (12.9200)	*
		11.1090 - SUPPORT, Engine Front Trunnion Mounting	
		A support assy. includes bolts and lockwashers.	
-	5186647	Support Assy	1
-	179867	Bolt, 7/16"-14x2 1/4" (12.9001)	2
-	103322	Lockwasher, 7/16" (12.9200)	*
		11.1094 - RING, Engine Front Trunnion Mounting Support Cushion	
	5166864	Ring (cushion)	1



FIG. 3C. AIR COMPRESSOR

Fig. 3C of 12.0000



FIG. 3D. COMPRESSOR ASSY. AIR

Fig. 3D of 12.0000

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		12. 4000A AIR-COMPRESSOR (Type 716)	
		12.4001 - COMPRESSOR ASSY., Air	
		NOTE: Components of the air compressor assemblies are not serviced by Detroit Diesel Division.	
		NOTE: Part numbers provided for the Air Compressor Assembly breakdown are Bendix-Westinghouse part number, FSCM	
		See ASSEMBLY BREAKDOWN listed below.	
3C, 3D	282389	Compressor Assy. (12CFM) (Detroit Diesel 5144302)	1
3D(1)	283615	Cylinder Head Assembly	1
3D(2)	283618	Cylinder Head Body Assy	1
3D(3)	237291	Discharge Valve Seat	2
3D(4)	247845	Cylinder Head Body	1
3D(5)	240143	Inlet Valve Spring Insert	2
3D(6)	240142	Inlet Valve Spring Seat	2
3D(7)	230935	Discharge Valve	2
3D(8)	210468	Discharge Valve Spring	2
3D(9)	236215	Discharge Valve Cap Nut.	2
3D(10)	228238	Cylinder Block Assembly	1
3D(11)	228233	Cylinder Block Body Assy	1
3D(12)	236118	Inlet Valve Seat	2
3D(13)	238586	Bushing	2
3D(14)	238629	Cylinder Block Body	1
3D(15)	238491	Unloader Spring Seat	1
3D(16)	239972	Unloader Spring	1
3D(17)	240024	Unloader Spring Saddle	1
3D(18)	240022	Unloader Plunger Guide	2
3D(19)	240023	Unloader Plunger	2
3D(20)	229875	Unloader Piston Assy.	2
3D(21)	238144	Back-Up Ring	2
	238143	Grommet. .	2
3D(22)	240018	Unloader Piston	2
3D(23)	237648	Lock Washer.	2
3D(24)	240910	Cap Screw.	2
3D(25)	236577	Gasket	1
3D(26)	210897	Cap Screw.	6

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		12.4001 - COMPRESSOR ASSY., Air (Cont'd)	
3D(27)	237686	Lock Washer	6
3D(28)	237687	Cap Screw	4
3D(29)	237648	Lock Washer	4
3D(30)	232999	Pipe Plug, 1/8"	1
	276127	Rear End Cover	1
3D(31)	241143	Rear End Cover	1
3D(32)	240745	Crankshaft Bearing	1
3D(33)	240576	Thrust Washer	1
3D(34)	239189	Grommet	1
3D(35)	235418	Crankcase Cover Gasket	1
3D(36)	241280	Crankcase Cover	1
3D(37)	202981	Lock Washer	5
3D(38)	203117	Cap Screw	5
3D(39)	228188	Connecting Rod Complete	2
3D(40)	228189	Connecting Rod & Cap Assy	2
3D(41)	238598	Bolt	4
3D(42)	239544	Wrist Pin Bushing	2
3D(43)	238596	Bearing Insert	4
3D(44)	238597	Lock Washer	4
3D(45)	210587	Machine Screw	1
3D(46)	240581	Thrust Washer	1
	276450	Crankcase Assembly	1
3D(47)	240580	Crankshaft Bearing	1
	241451	Crankcase Body	1
3D(48)	202927	Key	1
3D(49)	202926	Nut	1
3D(50)	235416	Cylinder Block Gasket	1
3D(51)	226103	Piston & Wrist Pin Set	2
3D(52)	236168	Wrist Pin	2
3D(53)	236167	Piston	2
3D(54)	236169	Wrist Pin Lock Wire	2
3D(55)	225514	Piston Ring Set	1
3D(56)	234812	Oil Scraper Ring	2
3D(57)	234811	Compression Ring	2
3D(58)	234812	Oil Scraper Ring	2
3D(59)	234811	Compression Ring	2
3D(60)	234811	Compression Ring	2
3D(61)	238634	Cylinder Head Gasket	1
3D(62)	239395	Inlet Valve Guide	2

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		12. 4001 - COMPRESSOR ASSY., Air (Cont'd)	
3D(63)	236125	Inlet Valve.	2
3D(64)	236126	Inlet Valve Spring	2
3D(65)	237696	Cap Screw	10
3D(66)	204820	Discharge Fitting Gasket	1
3D(67)	203145	Nut	2
3D(68)	236170	Strainer Gasket	1
3D(69)	237648	Lock Washer	2
3D(70)	210106	Cap Screw	2
3D(71)	230111	Pipe Plug, 1/4"	1
3D(72)	238822	Pipe Plug, 1/2". . . .	2
3D(73)	238807	Pipe Plug, 3/8"	3
-	5145014	Plug, 3/8" pipe (12.9550)	6
-	179884	Bolt, 1/2"-13x1 3/8" (12.9001)	4
		12.4037 - PLATE, Air Compressor Drive	
3C	5170450	Plate	1
-	103375	Pin, 3/32" x1 1/4" cotter (12.9250)	1
3C	5145092	Bolt, 3/8"-24xl 5/16" self-locking (12.9001)	4
		12.4040 - HUB, Air Compressor	
3C	5144866	Hub	1
		12.4050 - COUPLING, Air Compressor Drive	
	5134339	Coupling	1
		12.4065 - TUBE, Air Compressor Lube Oil Supply	
3C	2320203	Hose Assy., flex. (16 11/16" L.)	1
-	118753	Elbow, 1/4" fl. tube 1/8" P.T. 90° (12.9390)	2
-	5145009	Plug, 1/8" pipe (12.9550).	1
		12.4080 - CLIP, Air Compressor Lube Oil Tube	
-	5153473	Clip (1/2" tube x 3/8" bolt) (4.6040)	1
-	5179861	Bracket, clip (7.4255).	1
-	5114551	Tag, cable (7.4545)	1

FIG.	PART NUMBER	NAME AND DESCRIPTION	QUANTITY
		12.4085 - TUBE, Air Compressor Water Inlet	
3C	5108744	Hose Assy., flex. (23" L..)	1
	5121825	Fitting (1/2" hose x 3/8" ext. pipe) (12.4090)	1
	5120020	Fitting (1/2" hose x 1/2" fl. tube sw.)	1
	111316	Elbow, 1/2" fl. tube 90° x 3/8" P.T. (12.9390)	1
		12.4090 - TUBE, Air Compressor Water Outlet	
3C	5125902	Hose Assy., flex. (16" L.) (2.5100)	1
	5121825	Fitting (1/2" hose x 3/8" ext. pipe) (12.4090)	1
	5120020	Fitting (1/2" hose x 1/2" fl. tube sw.) (12.4085)	.1
	120702	Elbow, 3/8" street 45° (12.9590)	1
	111316	Elbow, 1/2" fl. tube 900 x 3/8" P.T. (12.9390)	1
		12.4095 - CLIP, Air Compressor Water Tube	
-	5171509	Clip, 5/8" tube	1
-	179816	Bolt, 5/16"-18x3/4" (12.9001)	1
	103320	Lockwasher, 5/16" (12.9200)	1
	123197	Nut, 5/16"-24 hex. (12.9120)	1
		BLOCK, Cylinder	
		The following parts listed in section 1.0000 are also required.	
	5123352	Cover (3/8" tapped hole) (1.2043)	1
	5115097	Cover (3/8" tapped hole) (1.1060)	1
-	118536	Draincock, 3/8" (12.9510)	1
	121207	Nipple, 3/8" x 1" pipe (12.9560)	1
	444122	Tee, 3/8"'-18 pipe (12.9616)	1
-	186625	Bolt, 5/16"-18x7/8" (12.9001)	2
	103320	Lockwasher, 5/16" (12.9200)	2

By Order of the Secretary of the Army

E. C. MEYER
General, United States Army
Chief of Staff

Official:
J. C. PENNINGTON
Major General, United States Army
The Adjutant General

Distribution:
To be distributed in accordance with DA Form 12-25B, operator maintenance requirements for cranes: truck-mounted.

* U.S. GOVERNIN PRINTING OFFICE : 1995 0 - 406-421 (53005)

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER	PUBLICATION DATE	PUBLICATION TITLE

BE EXACT. . .PIN-POINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

THE METRIC SYSTEM AND EQUIVALENTS

NEAR MEASURE

. Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
1 Kilogram = 1000 Grams = 2.2 lb.
1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

5/9(°F - 32) = °C
212° Fahrenheit is evuivalent to 100° Celsius
90° Fahrenheit is equivalent to 32.2° Celsius
32° Fahrenheit is equivalent to 0° Celsius
9/5C° + 32 =°F

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
ıts	Liters	0.473
arts	Liters	0.946
allons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
ers	Gallons	0.264
ms	Ounces	0.035
ograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
lometers per Liter	Miles per Gallon	2.354
meters per Hour	Miles per Hour	0.621



PIN: 045404-000

This fine document...

Was brought to you by me:

Liberated Manuals -- free army and government manuals

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=http://www.liberatedmanuals.com/>Free Military and Government Manuals</A>

– Sincerely
  Igor Chudov
  http://igor.chudov.com/